

Troubleshooting Packet Flow Issues

- Packet Flow Issues, on page 1

Packet Flow Issues

Packets could be dropped for the following reasons:

- Software-switched packets could be dropped because of Control Plane Policing (CoPP).
- Hardware-switched packets could be dropped by the hardware because of a bandwidth limitation.

Packets Dropped Because of Rate Limits

Use the **show hardware rate-limit** command to determine if packets are being dropped because of a rate limit.

```
switch(config)# show hardware rate-limit module 1

Units for Config: packets per second
Allowed, Dropped & Total: aggregated since last clear counters

Rate Limiter Class                      Parameters
------------------------------------------------------------
access-list-log                         Config    : 100
                                        Allowed   : 0
                                        Dropped   : 0
                                        Total     : 0
```

Packets Dropped Because of CoPP

Use the **show policy-map interface control-plane** command to determine if packets are being dropped because of CoPP.

```
switch# show policy-map interface control-plane
   class-map copp-system-p-class-exception (match-any)
      match exception ip option
      match exception ip icmp unreachable
      match exception ttl-failure
      match exception ipv6 option
      match exception ipv6 icmp unreachable
      match exception mtu-failure
```

```
set cos 1
police cir 200 pps , bc 32 packets

module 27 :
  transmitted 0 packets;
  dropped 0 packets;

module 28 :
  transmitted 0 packets;
  dropped 0 packets;
```