

Show Commands

- show aaa dead-criteria radius, on page 12
- show aaa servers, on page 14
- show aaa server brief, on page 16
- show access-list, on page 17
- show ap name icap subscription ap rf spectrum, on page 19
- show ap airtime-fairness summary, on page 20
- show ap audit-report detail, on page 21
- show ap audit-report summary, on page 22
- show ap auth-list, on page 23
- show ap auth-list ap-cert-policy, on page 24
- show ap auto-rf, on page 25
- show ap ble cmx detail ip, on page 28
- show ap ble cmx summary, on page 29
- show ap ble summary, on page 30
- show ap config, on page 31
- show ap config general, on page 32
- show ap client-trace events all, on page 33
- show ap crash-file, on page 34
- show ap dot11, on page 35
- show ap dot11, on page 41
- show ap dot11 5ghz channel , on page 42
- show ap dot11 24ghz , on page 43
- show ap dot11 24ghz SI config, on page 45
- show ap dot11 24ghz SI device type, on page 46
- show ap dot11 5ghz, on page 47
- show ap dot11 24ghz cleanair air-quality, on page 49
- show ap dot11 24ghz cleanair air-quality, on page 50
- show ap dot11 cleanair config, on page 51
- show ap dot11 cleanair summary, on page 53
- show ap dot11 dual-band summary, on page 54
- show ap environment, on page 55
- show ap file-transfer https summary, on page 56
- show ap filters active, on page 57

- show ap filters active type priming, on page 58
- show ap filters all, on page 59
- show ap filters all type priming, on page 60
- show ap fra, on page 61
- show ap fra 5-6ghz, on page 62
- show ap geolocation ranging, on page 63
- show ap geolocation uwb asset-tracking, on page 64
- show ap geolocation uwb wayfinding, on page 66
- show ap gps location, on page 68
- show ap grpc summary, on page 69
- show ap group hyperlocation, on page 70
- show history channel interface dot11Radio all, on page 72
- show ap hyperlocation, on page 73
- show ap hyperlocation cmx summary, on page 75
- show ap image, on page 76
- show ap image details, on page 77
- show ap image file summary, on page 78
- show ap image site summary, on page 80
- show ap iot-radio firmware summary, on page 81
- show ap link-encryption, on page 82
- show ap lldp neighbors detail, on page 83
- show ap lldp neighbors, on page 84
- show ap lsc-provision info, on page 85
- show ap urwb status, on page 86
- show ap name afc detail, on page 87
- show ap name afc geolocation, on page 88
- show ap name afc response, on page 89
- show ap name config dot11 6ghz, on page 90
- show ap name dot11 6ghz power-mode, on page 91
- show ap name config general, on page 92
- show ap name dot11 neighbor summary, on page 93
- show ap name geolocation detail, on page 95
- show ap name lldp neighbors detail, on page 96
- show ap name lldp neighbors, on page 97
- show ap name mesh roam history, on page 98
- show ap name ntp status, on page 99
- show ap name sensor environment accelerometer shutdown, on page 100
- show ap ntp status, on page 101
- show ap primary list, on page 102
- show ap mesh cac access, on page 103
- show ap mesh cac bwused voice, on page 104
- show ap mesh cac callpath, on page 105
- show ap mesh cac rejected, on page 106
- show ap monitor-mode summary, on page 107
- show ap multicast mom (multicast over multicast), on page 108
- show ap name *ap-name* neighbor summary, on page 109

- show ap name afc detail, on page 111
- show ap name afc geolocation, on page 112
- show ap name afc response, on page 113
- show ap name auto-rf, on page 114
- show ap name ble detail, on page 117
- show ap name cablemodem, on page 118
- show ap name config, on page 119
- show ap name config dot11 6ghz, on page 121
- show ap name config slot , on page 122
- show ap name config ethernet, on page 123
- show ap name dot11, on page 124
- show ap name dot11 5ghz slot urwb detail, on page 126
- show ap name dot11 6ghz power-mode, on page 127
- show ap name environment, on page 128
- show ap name geolocation ranging status, on page 129
- show ap name gps location, on page 130
- show ap name grpc detail, on page 131
- show ap name hyperlocation, on page 132
- show ap name mesh backhaul, on page 133
- show ap name mesh bhrate, on page 134
- show ap name mesh linktest, on page 135
- show ap name mesh neighbor detail, on page 136
- show ap name mesh neighbor detail, on page 137
- show ap name mesh path, on page 138
- show ap name mesh stats, on page 139
- show ap name tunnel eogre events, on page 140
- show ap name tunnel eogre domain detailed, on page 141
- show ap name tunnel eogre domain summary, on page 142
- show ap name tunnel eogre gateway detailed, on page 143
- show ap name tunnel eogre gateway summary, on page 144
- show ap name urwb coord-routes, on page 145
- show ap name urwb fixed-links, on page 146
- show ap name urwb info, on page 147
- show ap name urwb mobility-links, on page 148
- show ap name urwb network, on page 149
- show ap name urwb wireless-stats, on page 150
- show ap name wlan, on page 151
- show ap name wlan dot11 6ghz, on page 153
- show ap name wlan vlan, on page 154
- show ap name ble detail, on page 155
- show ap name temperature, on page 156
- show ap management-mode meraki capability summary, on page 157
- show ap management-mode meraki change summary, on page 158
- show ap management-mode meraki failure summary, on page 159
- show ap meraki monitoring summary, on page 160
- show ap neighborhood, on page 161

- show ap neighborhood details, on page 162
- show ap neighborhood mac details , on page 163
- show ap neighborhood summary, on page 164
- show ap profile, on page 165
- show ap profile name detailed, on page 166
- show ap profile name wat-ap-profile detailed, on page 167
- show ap regulatory activation , on page 168
- show ap rf-profile name, on page 169
- show ap rf-profile summary, on page 170
- show ap sensor status, on page 171
- show ap summary, on page 172
- show ap summary load-info, on page 173
- show ap summary sort name, on page 174
- show ap summary sort ascending client-count, on page 175
- show ap summary sort ascending data-usage, on page 176
- show ap summary sort ascending throughput, on page 177
- show ap summary sort descending client-count, on page 178
- show ap summary sort descending data-usage, on page 179
- show ap summary sort descending throughput, on page 180
- show ap support-bundle summary, on page 181
- show ap tag sources, on page 182
- show ap tag summary, on page 183
- show ap triradio summary, on page 184
- show ap timezone, on page 185
- show ap upgrade, on page 186
- show ap upgrade method, on page 188
- show arp, on page 189
- show arp summary , on page 190
- show ap name *ap-name* meraki connect, on page 191
- show ap tunnel eogre events, on page 194
- show ap tunnel eogre domain detailed, on page 195
- show ap name tunnel eogre domain summary, on page 196
- show ap tunnel eogre gateway detailed, on page 197
- show ap tunnel eogre gateway summary, on page 198
- show ap upgrade site, on page 199
- show ap wlan summary, on page 200
- show avc client, on page 206
- show avc wlan, on page 207
- show awips wlc-alarm, on page 208
- show awips syslog throttle, on page 209
- show capwap client configuration, on page 210
- show capwap client rcb, on page 211
- show chassis, on page 212
- show chassis rmi, on page 213
- show checkpoint, on page 214
- show cloud-services aws s3 summary, on page 221

- show cloud-services aws s3 profile, on page 222
- show cloud-services aws cloudwatch summary, on page 223
- show cloud-services aws cloudwatch profile, on page 224
- show cts environment data , on page 225
- show cts role-based sgt-map all, on page 227
- show cts role-based counters, on page 229
- show environment summary, on page 230
- show etherchannel summary, on page 233
- show fips authorization-key, on page 234
- show fips status, on page 235
- show flash wipeout-log, on page 236
- show flexconnect office-extend diagnostics, on page 237
- show flow exporter, on page 239
- show flow interface, on page 241
- show flow monitor, on page 243
- show flow record, on page 245
- show flow record wireless avc basic, on page 246
- show flow record wireless avc ipv6 basic, on page 247
- show gnxi state, on page 248
- show history channel interface dot11Radio all, on page 250
- show interfaces, on page 251
- show interfaces dot11Radio asr-info, on page 255
- show interfaces wired, on page 257
- show inventory, on page 258
- show ip, on page 260
- show ip igmp membership, on page 261
- show ip igmp snooping groups, on page 262
- show ip igmp snooping igmpv2-tracking, on page 263
- show ip igmp snooping querier, on page 264
- show ip igmp snooping wireless mcast-spi-count, on page 266
- show ip igmp snooping wireless mgid, on page 267
- show ip mroute, on page 268
- show ip mroute active, on page 270
- show ip nat statistics, on page 271
- show ip nbar protocol-discovery wlan, on page 273
- show ip ospf, on page 274
- show ip ospf database, on page 276
- show ip ospf database database-summary, on page 277
- show ip ospf database internal, on page 278
- show ip ospf database network, on page 279
- show ip ospf database router, on page 280
- show ip ospf database topology, on page 281
- show ip ospf events, on page 282
- show ip ospf interface, on page 283
- show ip ospf neighbor, on page 285
- show ip ospf neighbor summary, on page 287

- show ip ospf request-list, on page 288
- show ip ospf route-list, on page 289
- show ip ospf traffic, on page 290
- show ipv6 access-list, on page 292
- show ipv6 hop-by-hop status, on page 294
- show ipv6 mld snooping, on page 295
- show ipv6 mld snooping querier vlan, on page 297
- show ipv6 mld snooping wireless mgid, on page 298
- show ipv6 nd ra specific-route, on page 299
- show ldap attributes, on page 300
- show ldap server, on page 301
- show license air entities, on page 302
- show license all, on page 305
- show license authorization, on page 311
- show license data conversion, on page 316
- show license eventlog, on page 317
- show license history message, on page 318
- show license reservation, on page 319
- show license rum, on page 320
- show license status, on page 325
- show license summary, on page 335
- show license tech, on page 338
- show license udi, on page 353
- show license usage, on page 354
- show platform hardware chassis active qfp feature nat datapath pool, on page 357
- show platform hardware chassis active qfp feature nat datapath stats, on page 358
- show platform software nat chassis active F0 translation, on page 360
- show platform software nat chassis active r0 timeout, on page 362
- show platform software rif-mgr chassis active | standby r0 gateway-statistics, on page 363
- show platform software rif-mgr chassis active | standby r0 resource-status, on page 365
- show platform software rif-mgr chassis active R0 rmi-connection-details, on page 368
- show platform software rif-mgr chassis standby R0 rmi-connection-details, on page 369
- show platform software rif-mgr chassis active R0 rp-connection-details, on page 370
- show platform software rif-mgr chassis standby R0 rp-connection-details, on page 371
- show platform software rif-mgr chassis active R0 rif-stk-internal-stats, on page 372
- show platform software rif-mgr chassis standby R0 rif-stk-internal-stats, on page 373
- show platform software rif-mgr chassis active R0 lmp-statistics, on page 374
- show platform software rif-mgr chassis standby R0 lmp-statistics, on page 375
- show platform software selinux, on page 377
- show platform software sl-infra, on page 378
- show platform software tls client summary, on page 379
- show platform software client detail, on page 380
- show platform software tls statistics, on page 382
- show platform software tls session summary, on page 384
- show product-analytics kpi report, on page 385
- show product-analytics kpi summary, on page 386

- show product-analytics report detail, on page 387
- show product-analytics stats, on page 389
- show lisp site detail, on page 391
- show logging profile wireless end timestamp, on page 392
- show logging profile wireless filter, on page 393
- show logging profile wireless fru, on page 394
- show logging profile wireless internal, on page 395
- show logging profile wireless level, on page 396
- show logging profile wireless module, on page 397
- show logging profile wireless reverse, on page 398
- show logging profile wireless start, on page 399
- show logging profile wireless switch, on page 400
- show logging profile wireless to-file, on page 401
- show mdns-sd cache, on page 402
- show mdns-sd cache detail, on page 403
- show mdns-sd cache upn shared, on page 404
- show mdns-sd cache upn detail, on page 406
- show mdns-sd flexconnect summary , on page 407
- show mdns-sd statistics, on page 408
- show mdns-sd summary, on page 409
- show mdns-sd sp-sdg statistics, on page 410
- show meraki connect, on page 411
- show mobility, on page 413
- show monitor capture, on page 415
- show nmsp, on page 418
- show nmsp cloud-services statistics, on page 419
- show nmsp cloud-services summary, on page 420
- show nmsp subscription group detail all, on page 421
- show nmsp subscription group detail ap-list, on page 422
- show nmsp subscription group detail services, on page 423
- show nmsp subscription group summary, on page 424
- show ntp associations, on page 425
- show parameter-map type webauth name, on page 426
- show platform conditions, on page 427
- show platform hardware , on page 428
- show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf, on page 429
- show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list, on page 430
- show platform hardware chassis active qfp feature dns-snoop-agent client info, on page 431
- show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list, on page 432
- show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache, on page 433
- show platform hardware chassis active qfp feature dns-snoop-agent datapath memory, on page 434
- show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table, on page 435
- show platform hardware chassis active qfp feature dns-snoop-agent datapath stats, on page 436
- show platform hardware chassis active qfp feature et-analytics datapath runtime, on page 437
- show platform hardware chassis active qfp feature et-analytics datapath memory, on page 438
- show platform hardware chassis active qfp feature et-analytics datapath stats export, on page 439

- show platform hardware chassis active qfp feature et-analytics datapath stats flow, on page 440
- show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree, on page 441
- show platform hardware chassis active qfp feature wireless et-analytics statistics, on page 442
- show platform hardware slot R0 ha_port interface stats, on page 443
- show platform integrity, on page 446
- show platform software audit, on page 447
- show platform software arp broadcast, on page 449
- show platform software system all, on page 450
- show platform software trace filter-binary, on page 451
- show platform software trace filter-binary, on page 452
- show platform software trace level, on page 453
- show platform software utd chassis active F0 et-analytics global, on page 456
- show platform software et-analytics global, on page 457
- show platform sudi certificate, on page 458
- show platform sudi pki, on page 460
- show parameter-map type umbrella global, on page 461
- show policy-map, on page 462
- show processes cpu, on page 467
- show rate-limit client, on page 469
- show remote-lan all, on page 470
- show remote-lan id, on page 471
- show remote-lan name, on page 472
- show remote-lan policy detail, on page 473
- show remote-lan policy summary, on page 475
- show remote-lan summary, on page 476
- show rrm receive configuration, on page 477
- show sdavc ap download status, on page 478
- show sdavc status ap, on page 479
- show ssh , on page 480
- show split-tunnel client access-list, on page 481
- show tech-support diagnostic, on page 482
- show tech-support wireless, on page 489
- show tech-support wireless ap, on page 491
- show tech-support wireless client, on page 501
- **show tech-support wireless datapath**, on page 505
- show tech-support wireless fabric, on page 526
- **show tech-support wireless mobility**, on page 527
- show tech-support wireless radio, on page 539
- show telemetry connection all, on page 550
- show tunnel eogre global-configuration, on page 551
- show tunnel eogre domain detailed, on page 552
- show tunnel eogre domain summary, on page 553
- show tunnel eogre gateway summary, on page 554
- show tunnel eogre gateway detailed , on page 555
- show tunnel eogre manager stats global, on page 556

- show tunnel eogre manager stats instance, on page 558
- show umbrella config, on page 560
- show umbrella deviceid, on page 561
- show umbrella deviceid detailed, on page 562
- show umbrella dnscrypt, on page 563
- show vlan, on page 564
- show vlan access-map, on page 567
- show vlan filter, on page 568
- show vlan group, on page 569
- show vrrp events, on page 570
- show vrrp statistics, on page 571
- show vrrp status, on page 572
- show wireless active testing configuration, on page 573
- show wireless afc ap, on page 574
- show wireless afc channels , on page 575
- show wireless afc geolocation, on page 576
- show wireless afc request, on page 577
- show wireless afc response, on page 578
- show wireless afc statistics, on page 579
- show wireless stats ap history, on page 580
- show wireless stats ap join summary, on page 581
- show wireless stats ap join summary sort, on page 582
- show wireless stats ap packet, on page 583
- show wireless stat redundancy statistics client-recovery mobilityd , on page 584
- show wireless stat redundancy statistics client-recovery sisf, on page 585
- show wireless stat redundancy client-recovery wncd, on page 586
- show wireless band-select, on page 587
- show wireless certification config, on page 588
- show wireless client , on page 589
- show wireless client mac-address , on page 590
- show wireless client mac-address (Call Control), on page 592
- show wireless client mac-address (TCLAS), on page 593
- show wireless client mac-address mobility history, on page 594
- show wireless client mac-address stats latency , on page 595
- show wireless client summary, on page 596
- show wireless client timers, on page 597
- show wireless country, on page 598
- show wireless detail, on page 601
- show wireless dhcp relay statistics, on page 602
- show wireless dot11h , on page 603
- show wireless dtls connections, on page 604
- show wireless exclusionlist , on page 605
- show wireless exclusionlist client mac-address detail, on page 606
- show wireless fabric summary, on page 608
- show wireless fabric client summary , on page 610
- show wireless fabric vnid mapping, on page 611

- show wireless flow-control, on page 612
- show wireless flow-control statistics, on page 613
- show wireless load-balancing, on page 614
- show wireless mesh ap fabric summary, on page 615
- show wireless mesh rrm dca changed, on page 616
- show wireless media-stream client detail , on page 619
- show wireless media-stream group, on page 620
- show wireless media-stream message details , on page 621
- show wireless mobility controller ap, on page 622
- show wireless media-stream multicast-direct state , on page 623
- show wireless mesh ap , on page 624
- show wireless mesh ap summary , on page 625
- show wireless mesh ap tree, on page 626
- show wireless mesh cac summary, on page 627
- show wireless mesh config , on page 628
- show wireless mesh rrm dca status, on page 629
- show wireless mesh neighbor , on page 632
- show wireless profile ap priming summary, on page 634
- show wireless mobility, on page 635
- show wireless mobility peer ip , on page 636
- show wireless multicast group summary , on page 637
- show wireless mobility summary , on page 638
- show wireless multicast, on page 639
- show wireless multicast group, on page 640
- show wireless mesh ethernet daisy-chain summary, on page 641
- show wireless mesh ethernet daisy-chain bgn, on page 642
- show wireless performance, on page 643
- show wireless pmk-cache, on page 644
- show wireless probe, on page 645
- show wireless profile ap priming all, on page 646
- show wireless profile ap priming all, on page 647
- show wireless profile airtime-fairness mapping, on page 648
- show wireless profile airtime-fairness summary, on page 649
- show wireless profile ap packet-capture, on page 650
- show wireless profile calendar-profile detailed, on page 652
- show wireless profile calendar-profile summary, on page 653
- show wireless profile dot11be detailed, on page 654
- show wireless profile dot11be summary, on page 655
- show wireless profile fabric detailed, on page 656
- show wireless profile flex , on page 657
- show wireless profile policy all, on page 658
- show wireless profile policy detailed , on page 659
- show wireless profile mesh detailed, on page 660
- show wireless profile radio detailed wat-radio-profile, on page 661
- show wireless profile radio summary, on page 662
- show wireless profile tunnel summary, on page 663

- show wireless profile urwb detailed, on page 664
- show wireless redundancy statistics , on page 665
- show wireless rfid, on page 666
- show wireless stats ap name, on page 667
- show wireless stats ap image-download, on page 669
- show wireless stats ap packet, on page 670
- show wireless stats client delete reasons, on page 671
- show wireless statistics mobility , on page 677
- show wireless stats mesh packet error , on page 678
- show wireless stats pmk-propagation , on page 679
- show wireless stats mesh security and queue, on page 680
- show wireless stats client detail, on page 681
- show wireless stats redundancy config database, on page 682
- show wireless summary, on page 683
- show wireless tag policy detailed, on page 684
- show wireless tag rf, on page 687
- show wireless tag rf detailed, on page 688
- show wireless urlfilter details, on page 689
- show wireless urlfilter summary, on page 690
- show wireless vlan details , on page 691
- show wireless wgb mac-address , on page 692
- show wireless wgb summary , on page 693
- show wireless wps mfp ap summary, on page 694
- show wireless wps mfp statistics, on page 695
- show wireless wps mfp summary, on page 696
- show wireless wps rogue , on page 697
- show wireless wps rogue ap summary , on page 698
- show wireless wps rogue client detailed, on page 699
- show wireless wps rogue containment summary, on page 700
- show wireless wps rogue ap detailed, on page 701
- show wireless wps rogue client summary, on page 703
- show wireless wps rogue stats, on page 704
- show wireless wps summary, on page 705
- show wlan name client stats, on page 706
- show wlan summary sort ascending client-count, on page 707
- show wlan summary sort descending client-count, on page 708
- show wlan summary sort ascending data-usage, on page 709
- show wlan summary sort descending data-usage, on page 710
- show wps summary, on page 711
- shutdown, on page 712

show aaa dead-criteria radius

To verify the dead-server-detection information for a RADIUS server, use the **show aaa dead-criteria radius** command.

show aaa dead-criteria radius *ipaddr* **auth-port** *authport* **acct-port** *acctport*

Syntax Description

ipaddr	IP address.
authport	Authentication port.
acctport	Accounting port.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The **show aaa dead-criteria radius** *ipaddr* command displays output only if default ports are used. For non-default ports, use the **show aaa dead-criteria radius** *ipaddr* **auth-port** *authport* **acct-port** *acctport* command.

Example

The following example shows how to see the dead-server-detection information for a RADIUS server with non-default authorization and accounting ports:

```
Device# show aaa dead-criteria radius 4.4.4.4 auth-port 4444 acct-port 3333

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
============================
Server Details:
Address : 4.4.4.4
Auth Port : 4444
Acct Port : 3333
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 5
Estimated Outstanding Access Transactions: 0
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====================================================
Max Computed Outstanding Transactions: 0
Max Computed Dead Detect Time: 0s
```

```
Max Computed Retransmits : 0
```

The following example shows how to see the dead-server-detection information for a RADIUS server using default ports:

```
Device# show aaa dead-criteria radius 9.3.13.37

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
============================
Server Details:
Address : 9.3.13.37
Auth Port : 1812
Acct Port : 1813
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 30
Estimated Outstanding Access Transactions: 1
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====================================================
Max Computed Outstanding Transactions: 4
Max Computed Dead Detect Time: 48s
Max Computed Retransmits : 30
```

show aaa servers

To display the status and number of packets that are sent to and received from all public and private authentication, authorization, and accounting (AAA) RADIUS servers as interpreted by the AAA Server MIB, use the **show aaa servers** command.

show aaa servers [private | public]

Syntax Description

private	(Optional) Displays private AAA servers only, which are also displayed by the AAA Server MIB.
private	(Optional) Displays public AAA servers only, which are also displayed by the AAA Server MIB.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Only RADIUS servers are supported by the **show aaa servers** command.

Example

The following command displays information about packets sent and received for all AAA transaction types--authentication, authorization, and accounting.

```
Device# show aaa servers

RADIUS: id 2, priority 1, host 124.2.2.12, auth-port 1645, acct-port 1612, hostname rsim
     State: current UP, duration 20699s, previous duration 0s
     Dead: total time 0s, count 0
     Platform State from SMD: current UP, duration 20699s, previous duration 0s
     SMD Platform Dead: total time 0s, count 0
     Platform State from WNCD (1) : current UP
     Platform State from WNCD (2) : current UP
     Platform State from WNCD (3) : current UP
     Platform State from WNCD (4) : current UP
     Platform State from WNCD (5) : current UP
     Platform State from WNCD (6) : current UP
     Platform State from WNCD (7) : current UP
     Platform State from WNCD (8) : current UP, duration 964s, previous duration 0s
     Platform Dead: total time 0s, count 0UP
     Quarantined: No
.
.
.

     Elapsed time since counters last cleared: 5h44m
     Estimated Outstanding Access Transactions: 0
     Estimated Outstanding Accounting Transactions: 0
     Estimated Throttled Access Transactions: 0
     Estimated Throttled Accounting Transactions: 0
```

```
Maximum Throttled Transactions: access 0, accounting 0
Consecutive Response Failures: total 0
        SMD Platform : max 0, current 0 total 0
        WNCD Platform: max 0, current 0 total 0
        IOSD Platform : max 0, current 0 total 0
Consecutive Timeouts: total 0
        SMD Platform : max 0, current 0 total 0
        WNCD Platform: max 0, current 0 total 0
        IOSD Platform : max 0, current 0 total 0
Requests per minute past 24 hours:
        high - 5 hours, 44 minutes ago: 0
        low  - 5 hours, 44 minutes ago: 0
        average: 0
```

show aaa server brief

To view the summary information of Authentication, Authorization, and Accounting (AAA) servers, use the **show aaa server brief** command.

show aaa server brief

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to view the summary information of AAA servers:

```
Device# show aaa server brief

Access            Access   Access Access   Outstndg Acct.  Acct.  Acct.     Outstndg   Total
    Reqs         Total Resp  Uptime  Uptime  Uptime
                  Requests Accept Reject   timeouts Access tx Req Responses timeouts   Acct.
 tx (Auth+Acct) (Auth+Acct) (IOSD)  (SMD)    (WNCD)
-------------------------------------------------------------------------------------------
rsim              0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
R1                0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
free-radius-aut
hc-server         0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
cisco-dnac-auth
z-server          0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
r1                0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
ise               0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
Radius-2          0        0      0        0        0      0      0         0          0
      0            0           2274176 2274176 296805
```

show access-list

To display access control lists (ACLs) configured on the device, use the **show access-lists** command in privileged EXEC mode.

show access-lists[*namenumber* | **hardware counters** | **ipc**]

Syntax Description

number	(Optional) ACL number. The range is 1 to 2799.
name	(Optional) Name of the ACL.
hardware counters	(Optional) Displays the access list hardware counters.
ipc	(Optional) Display Interprocess Communication (IPC) protocol access-list configuration download information

Command Default

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Though visible in the command-line help strings, the **rate-limit** keyword is not supported

The device supports only IP standard and extended access lists. Therefore, the allowed numbers are only 1 to 199 and 1300 to 2799.

This command also displays the MAC ACLs that are configured.

This is an example of output from the **show access-lists** command:

```
Device# show access-lists

Extended IP access list 103
    10 permit ip any any dscp af11
Extended IP access list ssm-range
    10 deny ip any 232.0.0.0 0.255.255.255
    20 permit ip any any
Extended MAC access list mac1
```

This is an example of output from the **show access-lists hardware counters** command:

```
Device# show access-lists hardware counters
 L3 ACL INPUT Statistics
     All  Drop:                      frame count: 0
     All  Bridge Only:               frame count: 0
     All  Forwarding To CPU:         frame count: 294674
     All  Forwarded:                 frame count: 2577677
```

```
    All  Drop And Log:             frame count: 0
    All  Bridge Only And Log:      frame count: 0
    All  Forwarded And Log:        frame count: 0
    All  IPv6 Drop:                frame count: 0
    All  IPv6 Bridge Only:         frame count: 0
    All  IPv6 Forwarding To CPU:   frame count: 0
    All  IPv6 Forwarded:           frame count: 102
    All  IPv6 Drop And Log:        frame count: 0
    All  IPv6 Bridge Only And Log: frame count: 0
    All  IPv6 Forwarded And Log:   frame count: 0

L3 ACL OUTPUT Statistics
    All  Drop:                     frame count: 0
    All  Bridge Only:              frame count: 0
    All  Forwarding To CPU:        frame count: 0
    All  Forwarded:                frame count: 266050
    All  Drop And Log:             frame count: 0
    All  Bridge Only And Log:      frame count: 0
    All  Forwarded And Log:        frame count: 0
    All  IPv6 Drop:                frame count: 0
    All  IPv6 Bridge Only:         frame count: 0
    All  IPv6 Forwarding To CPU:   frame count: 0
    All  IPv6 Forwarded:           frame count: 0
    All  IPv6 Drop And Log:        frame count: 0
    All  IPv6 Bridge Only And Log: frame count: 0
    All  IPv6 Forwarded And Log:   frame count: 0
```

show ap name icap subscription ap rf spectrum

To display the spectrum configuration details of a corresponding AP, use the **show ap name icap subscription ap rf spectrum** command.

show ap name *ap_name***icap subscription ap rf spectrum**

Syntax Description

ap_name	AP name

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.2.1	This command was introduced.

Example

The following example shows how to display spectrum analysis on a AP:

```
Device# show ap name 4800AP icap subscription ap rf spectrum
Per-AP ICap configuration

AP RF spectrum subscription
  State                     : enabled
  Radio slots               : none
```

show ap airtime-fairness summary

To view the ATF configuration summary of all radios, use the **show ap airtime-fairness summary** command.

show ap airtime-fairness summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ATF configuration summary of all radios:

```
Device# show ap airtime-fairness summary
```

show ap audit-report detail

To display the configuration of an AP, use the **show ap** *ap-name* **audit-report detail** command.

show ap *ap-name* **audit-report detail**

Syntax Description

ap-name	AP name.
detail	Displays audit report for an AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Example

This following example shows how to display the audit report for an AP:

```
Device# show ap Cisco-AP audit-report detail
Cisco AP Name   : Cisco-AP
================================================

Radio Audit Report:

Slot   Channel   Bandwidth   Tx Power   Admin State        Operation State   Radio Role
Radio Operation
-------------------------------------------------------------------------------------------------------
0          IN_SYNC   IN_SYNC    IN_SYNC    OUT_OF_SYNC     IN_SYNC              IN_SYNC
   IN_SYNC
1          IN_SYNC   IN_SYNC    IN_SYNC    OUT_OF_SYNC     IN_SYNC              IN_SYNC
   IN_SYNC

WLAN Audit Report:

Slot-id Wlan-id Vlan           State                    SSID        Auth Type     Flags
-------------------------------------------------------------------------------------------------------
0           1            IN_SYNC    OUT_OF_SYNC IN_SYNC    IN_SYNC    IN_SYNC
0           2            IN_SYNC    OUT_OF_SYNC IN_SYNC    IN_SYNC    IN_SYNC
1           1            IN_SYNC    OUT_OF_SYNC IN_SYNC    IN_SYNC    IN_SYNC
1           2            IN_SYNC    OUT_OF_SYNC IN_SYNC    IN_SYNC    IN_SYNC
```

show ap audit-report summary

To display the audit report summary for an AP, use the **show ap audit-report summary** command.

show ap audit-report summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Example

The following example shows how to display the audit report summary of an AP:

```
Device# show ap audit-report summary
WTP Mac                    Radio                   Wlan                 IPv4 Acl
IPv6 Acl       Last Report Time
-------------------------------------------------------------------------------------------
1880.90fd.6b40   OUT_OF_SYNC    OUT_OF_SYNC    IN_SYNC        IN_SYNC        01/01/1970
05:30:00 IST
```

show ap auth-list

To see the access point authorization list, use the **show ap auth-list** command.

show ap auth-list [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the access point authorization list:

```
Device# show ap auth-list
```

show ap auth-list ap-cert-policy

To verify if the APs have been authorized by the AP certificate policy, use the **show ap auth-list ap-cert-policy**

show ap auth-list ap-cert-policy

Syntax Description

This command has no arguments.

Command Default

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to verify if the APs have been authorized by the AP certificate policy:

```
Device# show ap auth-list ap-cert-policy
```

show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

show ap auto-rf dot11 { **24ghz** | **5ghz** | **6ghz** | **dual-band** } *cisco_ap*

Syntax Description

24ghz	Specifies the 802.11b radio.
5ghz	Specifies the 802.11a radio.
6ghz	Specifies 6ghz band.
dual-band	Specifies dual bands.

Command Default

None

Usage Guidelines

The **show ap auto-rf command** output will not display neighbor AP names.

The following example shows how to display auto-RF information for an access point:

```
Device# show ap auto-rf dot11 24ghz AP1

######################################################################

Number of Slots                                 : 3
AP Name                                         : APA023.9FD8.EA22
MAC Address                                     : 40ce.24bf.8ca0
Ethernet MAC Address                            : a023.9fd8.ea22
  Slot ID                                       : 0
  Radio Type                                    : 802.11n - 2.4 GHz
  Current TX/RX Band                            : 2.4Ghz band
  Subband Type                                  : All
  Noise Information
    Noise Profile                               : Passed
    Channel   1                                 :  -91 dBm
    Channel   2                                 :  -67 dBm
    Channel   3                                 :  -54 dBm
    Channel   4                                 :  -55 dBm
    Channel   5                                 :  -71 dBm
    Channel   6                                 :  -85 dBm
    Channel   7                                 :  -50 dBm
    Channel   8                                 :  -54 dBm
    Channel   9                                 :  -77 dBm
    Channel  10                                 :  -88 dBm
    Channel  11                                 :  -65 dBm
  Interference Information
    Interference Profile                        : Failed
    Channel   1                                 :  -47 dBm @ 21% busy
    Channel   2                                 :  -45 dBm @  2% busy
    Channel   3                                 : -128 dBm @  0% busy
    Channel   4                                 : -128 dBm @  0% busy
    Channel   5                                 :  -48 dBm @  2% busy
    Channel   6                                 :  -45 dBm @  2% busy
    Channel   7                                 :  -42 dBm @  3% busy
    Channel   8                                 : -128 dBm @  0% busy
    Channel   9                                 : -128 dBm @  0% busy
    Channel  10                                 :  -39 dBm @  3% busy
```

```
  Channel  11                                  :  -46 dBm @  3% busy
  Rogue Histogram (20)
    Channel   1                                : 36
    Channel   2                                :  0
    Channel   3                                :  0
    Channel   4                                :  1
    Channel   5                                :  0
    Channel   6                                : 11
    Channel   7                                :  0
    Channel   8                                :  1
    Channel   9                                :  3
    Channel  10                                :  0
    Channel  11                                : 14
Load Information
  Load Profile                                 : Failed
  Receive Utilization                          : 0%
  Transmit Utilization                         : 0%
  Channel Utilization                          : 98%
  Attached Clients                             : 0 clients
Coverage Information
  Coverage Profile                             : Passed
  Failed Clients                               : 0 clients
Client Signal Strengths
  RSSI -100 dBm                                : 0 clients
  RSSI  -92 dBm                                : 0 clients
  RSSI  -84 dBm                                : 0 clients
  RSSI  -76 dBm                                : 0 clients
  RSSI  -68 dBm                                : 0 clients
  RSSI  -60 dBm                                : 0 clients
  RSSI  -52 dBm                                : 0 clients
Client Signal to Noise Ratios
  SNR    0 dB                                  : 0 clients
  SNR    5 dB                                  : 0 clients
  SNR   10 dB                                  : 0 clients
  SNR   15 dB                                  : 0 clients
  SNR   20 dB                                  : 0 clients
  SNR   25 dB                                  : 0 clients
  SNR   30 dB                                  : 0 clients
  SNR   35 dB                                  : 0 clients
  SNR   40 dB                                  : 0 clients
  SNR   45 dB                                  : 0 clients
Nearby APs
  AP d0ec.3572.b9a0 slot 0                     :  -23 dBm on ( 11, 20 MHz) (181.22.0.22)
  AP 0c75.bdb3.9000 slot 0                     :  -28 dBm on ( 11, 20 MHz) (181.21.0.21)
  AP a4b2.3980.3740 slot 0                     :  -28 dBm on (  1, 20 MHz) (181.21.0.21)
  AP d0ec.3576.8320 slot 0                     :  -33 dBm on ( 11, 20 MHz) (50.1.1.122)
  AP a0f8.49dc.9780 slot 0                     :  -34 dBm on (  1, 20 MHz) (9.9.57.94)
  AP a0f8.49dc.8260 slot 0                     :  -34 dBm on (  6, 20 MHz) (9.9.57.94)
  AP d0ec.3573.7c80 slot 0                     :  -36 dBm on (  6, 20 MHz) (192.185.183.44)

  AP 00b0.e192.9d20 slot 0                     :  -36 dBm on ( 11, 20 MHz) (9.9.42.47)
  AP a4b2.397f.41c0 slot 0                     :  -36 dBm on (  1, 20 MHz) (185.10.0.10)
  AP 2c5a.0fd5.b8c0 slot 0                     :  -36 dBm on (  6, 20 MHz) (9.7.97.51)
  AP a488.7351.4740 slot 0                     :  -36 dBm on ( 11, 20 MHz) (9.7.97.51)
  AP 10b3.d5e9.c8e0 slot 0                     :  -36 dBm on (  1, 20 MHz) (50.1.1.122)
  AP 0c75.bdb3.ab00 slot 0                     :  -37 dBm on (  6, 20 MHz) (185.10.0.10)
  AP 68ca.e451.5120 slot 0                     :  -37 dBm on (  1, 20 MHz) (9.4.155.15)
  AP a0f8.49dc.97a0 slot 0                     :  -37 dBm on ( 11, 20 MHz) (9.9.57.94)
  AP 188b.4501.7940 slot 0                     :  -38 dBm on ( 11, 20 MHz) (9.9.57.94)
  AP 002c.c88a.f8e0 slot 0                     :  -38 dBm on ( 11, 20 MHz) (9.9.50.55)
  AP 7069.5a78.4960 slot 0                     :  -38 dBm on ( 11, 20 MHz) (9.7.97.51)
  AP 3c41.0ea7.0880 slot 0                     :  -39 dBm on ( 11, 20 MHz) (185.10.0.10)
  AP a0f8.49dc.93a0 slot 0                     :  -39 dBm on (  6, 20 MHz) (9.9.57.94)
  AP f4db.e685.7360 slot 0                     :  -39 dBm on (  6, 20 MHz) (50.1.1.122)
```

```
  AP 7070.8bb4.4120 slot 0                    :  -40 dBm on ( 11, 20 MHz) (9.9.57.94)
  AP 707d.b93e.39e0 slot 0                    :  -40 dBm on (  1, 20 MHz) (4.4.4.1)
  AP 706d.150c.6860 slot 0                    :  -40 dBm on ( 11, 20 MHz) (50.1.1.122)
Radar Information
Channel Assignment Information via DCA
  Current Channel Average Energy               :  -50 dBm
  Previous Channel Average Energy              :  -50 dBm
  Channel Change Count                         : 9
  Last Channel Change Time                     : 02/14/2021 20:54:57
  Recommended Best Channel                     : 1
RF Parameter Recommendations
  Power Level                                  : 8
  RTS/CTS Threshold                            : 2347
  Fragmentation Threshold                      : 2346
  Antenna Pattern                              : 0
Persistent Interference Devices
Class Type                Channel  DC (%%)  RSSI (dBm)  Last Update Time
------------------------  -------  ------   ---------   ----------------
All third party trademarks are the property of their respective owners.
```

show ap ble cmx detail ip

To view the BLE management feature related global values for a specific CMX along with all the APs associated to that CMX, use the **show ap ble cmx detail ip** command.

show ap ble cmx detail ip *CMX-IP*

Syntax Description

CMX-IP	Specifies the IPv4 address.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

This example shows how to display the BLE management feature related global values for a specific CMX along with all the APs associated to that CMX:

```
Device# show ap ble cmx detail ip 10.1.2.3
BLE administrative status: Up
BLE operational status: Up
Scanning interval: 10

  AP Name                          Interface             Status
  ------------------------------------------------------------------
  AP4001.7AB2.C39A                 Integrated            Open
```

show ap ble cmx summary

To view the list of all CMXs registered for BLE Management feature and their global values for BLE, use the **show ap ble cmx summary** command.

show ap ble cmx summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

This example shows how to view the list of all CMXs registered for BLE Management feature and their global values for BLE:

```
Device# show ap ble cmx summary
CMX IP: 10.1.2.3
-----------------------
  BLE administrative status: Up
  BLE operational status: Up
  Scanning interval: 12

CMX IP: 10.1.2.4
-----------------------
  BLE administrative status: Down
  BLE operational status: Down
   Reason: BLE is administratively down
  Scanning interval: 0

CMX IP: 10.1.2.5
------------------
BLE administrative status: Up
BLE operational status: Down
 Reason: CMX is not subscribed to AP Monitor and RSSI services, or NMSP connection is down
Scanning interval: 10
```

show ap ble summary

To view the list of joined APs that support BLE Management feature along with the BLE details for each AP, use the **show ap ble summary** command.

show ap ble summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Cisco IOS XE Cupertino 17.9.1	The output of the command is modified to add new column that displays scan status.

Usage Guidelines

The BLE Management feature is enabled and APs are displayed only when the CMX is registered with the controller, and BLE is enabled on CMX.

This example shows how to view the list of joined APs that support BLE Management feature along with the BLE details for each AP:

```
Device# show ap ble summary
AP Name                          Interface             Status      CMX IP
-------------------------------------------------------------------------------
AP4001.7AB2.C39A                 Integrated            Open        10.1.2.3
AP4001.7AB2.C39B                 Integrated            Closed      10.1.2.4

Device# show ap ble summary

AP Name   AP Model     AP Ethernet MAC  BLE               BLE           BLE mode       BLE
 MAC         BLE Profile       BLE Scan
                                       Interface State   Admin State
-------------------------------------------------------------------------------------------
AP794     C9130AXI-B   04eb.409e.xxxx   Open              Up            Base (Native)
806f.b031.xxxx  Eddystone URL     Enabled/Disabled
AP50      C9130AXI-B   04eb.409e.xxxx   Close             Down          Base (Native)
Unknown         Not Configured    Enabled/Disabled
AP28      C9136I       687d.b45c.xxxx   Close             Down          Base (Native)
Unknown         Not Configured    Enabled/Disabled
```

show ap config

To display configuration settings for all access points that join the device, use the **show ap config** command.

show ap config {**general** | **global**}

Syntax Description

ethernet	Displays ethernet VLAN tagging information for all Cisco APs.
general	Displays common information for all Cisco APs.
global	Displays global settings for all Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display global syslog server settings:

```
Device# show ap config global

AP global system logging host                   : 255.255.255.255
```

show ap config general

To view the general configuration information of all the Cisco APs, use the **show ap config general** command.

show ap config general

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

This example shows how to view the general configuration information of all Cisco APs:

```
Device# show ap config general

Cisco AP Name   : APA023.9FD8.EA22
================================================

AP image integrity
Time                                    : 07/22/2023 17:10:05
Alterative image loaded                 : Yes
Backup image status
Version                                 : 17.12.0.112
Partition                               : part1
Kernel                                  : Good
Root FS                                 : Good
IOX                                     : Good
Primary image status
Version                                 : 17.13.0.39
Partition                               : part2
Kernel                                  : Good
Root FS                                 : Good
IOX                                     : Good
```

show ap client-trace events all

To view the AP client trace event information, use the **show ap client-trace events all** command.

show ap client-trace events all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Examples

This example shows how to view the AP client trace event information:

```
Device# show ap client-trace events all

[*04/29/2019 11:49:21.964964] [AP58AC.78DC.AAA0] [38:e6:0a:ea:99:d4] <apr1v0> [D:W]
DOT11_AUTHENTICATION : (.)
[*04/29/2019 11:49:21.972209] [AP58AC.78DC.AAA0] [38:e6:0a:ea:99:d4] <apr1v0> [U:W]
DOT11_ASSOC_REQUEST : (.)
[*04/29/2019 11:49:21.972227] [58:ac:78:df:6d:0f] [client] Vendor specific OUI: 00:50:f2
and Type: 02
[*04/29/2019 11:49:21.975975] [AP58AC.78DC.AAA0] [38:e6:0a:ea:99:d4] <apr1v0> [D:W]
DOT11_ASSOC_RESPONSE : (.)
```

show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

show ap crash-filechassis *chassis-number <1-2>***active standby**

Syntax Description

chassis	Displays the chassis details.
chassis-number	Specifies the chassis number, either 1 or 2.
active	Specifies an active instance.
standby	Specifies a standby instance.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the crash file generated by the access point:

```
Device# show ap crash-file
```

show ap dot11

To view 802.11a or 802.11b or 6-GHz configuration information, use the **show ap dot11** command.

show ap dot11 { **24ghz** | **5ghz** | **6ghz** } { **channel** | **coverage** | **group** | **load-info** | **logging** | **media-stream** | **monitor** | **network** | **profile** | **receiver** | **service-policy** | **summary** | **txpower** | **ccx global** }

Syntax Description

24ghz	Specifies the 2.4-GHz band.
5ghz	Specifies the 5-GHz band.
6ghz	Specifies the 6-GHz band.
channel	Displays the automatic channel assignment configuration and statistics.
coverage	Displays the configuration and statistics for coverage hole detection.
group	Displays 802.11a, 6-GHz or 802.11b Cisco radio RF grouping.
load-info	Displays channel utilization and client count information for all Cisco APs.
logging	Displays 802.11a, 6-GHz or 802.11b RF event and performance logging.
media-stream	Display 802.11a, 6-GHz or 802.11b Media Resource Reservation Control configurations.
monitor	Displays the 802.11a, 6-GHz or 802.11b default Cisco radio monitoring.
network	Displays the 802.11a, 6-GHz or 802.11b network configuration.
profile	Displays the 802.11a, 6-GHz or 802.11b lightweight access point performance profiles.
receiver	Displays the configuration and statistics of the 802.11a, 6-GHz or 802.11b receiver.
service-policy	Displays the Quality of Service (QoS) service policies for 802.11a, 6-GHz or 802.11b radio for all Cisco access points.
summary	Displays the 802.11a, 6-GHz or 802.11b Cisco lightweight access point name, channel, and transmit level summary.
txpower	Displays the 802.11a, 6-GHz or 802.11b automatic transmit power assignment.

ccx global	Displays 802.11a, 6-GHz or 802.11b Cisco Client eXtensions (CCX) information for all Cisco access points that are joined to the device.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1 Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.
	The **load-info** parameter was added.
Cisco IOS XE Cupertino 17.7.1	This command was modified to include the 6-GHz band.

This example shows how to display the automatic channel assignment configuration and statistics:

```
Device# show ap dot11 5ghz channel
Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 12 Hours
  Anchor time (Hour of the day)             : 20
  Channel Update Contribution               : SNI.
  Channel Assignment Leader                 : web (9.9.9.2)
  Last Run                                  : 13105 seconds ago
  DCA Sensitivity Level                     : MEDIUM (15 dB)
  DCA 802.11n Channel Width                 : 40 Mhz
  Channel Energy Levels
      Minimum                               : unknown
      Average                               : unknown
      Maximum                               : unknown
  Channel Dwell Times
      Minimum                               : unknown
      Average                               : unknown
      Maximum                               : unknown
  802.11a 5 GHz Auto-RF Channel List
  Allowed Channel List                      : 36,40,44,48,52,56,60,64,149,153,1
57,161
  Unused Channel List                       : 100,104,108,112,116,132,136,140,1
65
  802.11a 4.9 GHz Auto-RF Channel List
  Allowed Channel List                      :
  Unused Channel List                       : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
15,16,17,18,19,20,21,22,23,24,25,26
  DCA Outdoor AP option                     : Disabled
```

This example shows how to display the statistics for coverage hole detection:

```
Device# show ap dot11 5ghz coverage
Coverage Hole Detection
  802.11a Coverage Hole Detection Mode          : Enabled
  802.11a Coverage Voice Packet Count           : 100 packet(s)
  802.11a Coverage Voice Packet Percentage      : 50 %
  802.11a Coverage Voice RSSI Threshold         : -80dBm
  802.11a Coverage Data Packet Count            : 50 packet(s)
  802.11a Coverage Data Packet Percentage       : 50 %
  802.11a Coverage Data RSSI Threshold          : -80dBm
```

```
  802.11a Global coverage exception level       : 25
  802.11a Global client minimum exception level   : 3 clients
```

This example shows how to display Cisco radio RF group settings:

```
Device# show ap dot11 5ghz group
Radio RF Grouping

  802.11a Group Mode                 : STATIC
  802.11a Group Update Interval      : 600 seconds
  802.11a Group Leader               : web (10.10.10.1)
  802.11a Group Member               : web(10.10.10.1)
                                       nb1(172.13.21.45) (*Unreachable)
  802.11a Last Run                   : 438 seconds ago


  Mobility Agents RF membership information
  ------------------------------------------------------------
  No of 802.11a MA RF-members : 0
```

This example shows how to display 802.11a RF event and performance logging:

```
Device# show ap dot11 5ghz logging
RF Event and Performance Logging

  Channel Update Logging              : Off
  Coverage Profile Logging            : Off
  Foreign Profile Logging             : Off
  Load Profile Logging                : Off
  Noise Profile Logging               : Off
  Performance Profile Logging         : Off
  TxPower Update Logging              : Off
```

This example shows how to display the 802.11a media stream configuration:

```
Device# show ap dot11 5ghz media-stream
Multicast-direct                : Disabled
Best Effort                     : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio     : Auto
Max Allowed Streams Per Client    : Auto
Max Video Bandwidth              : 0
Max Voice Bandwidth              : 75
Max Media Bandwidth              : 85
Min PHY Rate (Kbps)              : 6000
Max Retry Percentage             : 80
```

This example shows how to display the radio monitoring for the 802.11b network:

```
Device# show ap dot11 5ghz monitor
Default 802.11a AP monitoring

  802.11a Monitor Mode                          : Enabled
  802.11a Monitor Mode for Mesh AP Backhaul     : disabled
  802.11a Monitor Channels                      : Country channels
  802.11a RRM Neighbor Discover Type            : Transparent
  802.11a AP Coverage Interval                  : 180 seconds
  802.11a AP Load Interval                      : 60 seconds
  802.11a AP Noise Interval                     : 180 seconds
  802.11a AP Signal Strength Interval           : 60 seconds
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz profile
Default 802.11a AP performance profiles
802.11a Global Interference threshold.............. 10%
802.11a Global noise threshold..................... -70 dBm
802.11a Global RF utilization threshold............ 80%
802.11a Global throughput threshold................ 1000000 bps
802.11a Global clients threshold................... 12 clients
802.11a Global coverage threshold.................. 12 dB
802.11a Global coverage exception level............ 80%
802.11a Global client minimum exception lev........ 3 clients
```

This example shows how to display the network configuration of an 802.11a profile:

```
Device# show ap dot11 5ghz network
802.11a Network : Enabled
11nSupport : Enabled
  802.11a Low Band : Enabled
  802.11a Mid Band : Enabled
  802.11a High Band : Enabled

802.11a Operational Rates
  802.11a 6M : Mandatory
  802.11a 9M : Supported
  802.11a 12M : Mandatory
  802.11a 18M : Supported
  802.11a 24M : Mandatory
  802.11a 36M : Supported
  802.11a 48M : Supported
  802.11a 54M : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported
  MCS 6 : Supported
  MCS 7 : Supported
  MCS 8 : Supported
  MCS 9 : Supported
  MCS 10 : Supported
  MCS 11 : Supported
  MCS 12 : Supported
  MCS 13 : Supported
  MCS 14 : Supported
  MCS 15 : Supported
  MCS 16 : Supported
  MCS 17 : Supported
  MCS 18 : Supported
  MCS 19 : Supported
  MCS 20 : Supported
  MCS 21 : Supported
  MCS 22 : Supported
  MCS 23 : Supported
802.11n Status:
  A-MPDU Tx:
    Priority 0 : Enabled
    Priority 1 : Disabled
    Priority 2 : Disabled
    Priority 3 : Disabled
    Priority 4 : Enabled
    Priority 5 : Enabled
```

```
    Priority 6 : Disabled
    Priority 7 : Disabled
  A-MSDU Tx:
    Priority 0 : Enabled
    Priority 1 : Enabled
    Priority 2 : Enabled
    Priority 3 : Enabled
    Priority 4 : Enabled
    Priority 5 : Enabled
    Priority 6 : Disabled
    Priority 7 : Disabled
  Guard Interval : Any
  Rifs Rx : Enabled
Beacon Interval : 100
CF Pollable mandatory : Disabled
CF Poll Request Mandatory : Disabled
CFP Period : 4
CFP Maximum Duration : 60
Default Channel : 36
Default Tx Power Level : 1
DTPC Status : Enabled
Fragmentation Threshold : 2346
Pico-Cell Status : Disabled
Pico-Cell-V2 Status : Disabled
TI Threshold : 0
Legacy Tx Beamforming setting : Disabled
Traffic Stream Metrics Status : Disabled
Expedited BW Request Status : Disabled
EDCA profile type check : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM) : Disabled
  Voice Stream-Size : 84000
  Voice Max-Streams : 2
  Voice Max RF Bandwidth : 75
  Voice Reserved Roaming Bandwidth : 6
  Voice Load-Based CAC mode : Enabled
  Voice tspec inactivity timeout : Enabled
CAC SIP-Voice configuration
  SIP based CAC : Disabled
  SIP call bandwidth : 64
  SIP call bandwith sample-size : 20
Video AC
  Video AC - Admission control (ACM) : Disabled
  Video max RF bandwidth : Infinite
  Video reserved roaming bandwidth : 0
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz receiver
Default 802.11a AP performance profiles
802.11a Global Interference threshold.............. 10%
802.11a Global noise threshold..................... -70 dBm
802.11a Global RF utilization threshold............ 80%
802.11a Global throughput threshold................ 1000000 bps
802.11a Global clients threshold................... 12 clients
802.11a Global coverage threshold.................. 12 dB
802.11a Global coverage exception level............ 80%
802.11a Global client minimum exception lev........ 3 clients
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz service-policy
```

This example shows how to display a summary of the 802.11b access point settings:

```
Device# show ap dot11 5ghz summary
AP Name MAC Address       Admin State Operation State Channel TxPower
------- ----------------- ----------- --------------- ------- -------
CJ-1240 00:21:1b:ea:36:60 ENABLED     UP              161     1( )
CJ-1130 00:1f:ca:cf:b6:60 ENABLED     UP              56*     1(*)
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz txpower
Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Transmit Power Update Contribution      : SNI.
Transmit Power Assignment Leader        : web (10.10.10.1)
Last Run                                : 437 seconds ago
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz ccx global
 802.11a Client Beacon Measurements:
     disabled
```

show ap dot11

To display 802.11 band parameters, use the **show ap dot11** command.

show ap dot11 {**24ghz** | **5ghz**} {**media-stream rrc** | **network** | **profile** | **summary**}

Syntax Description

media-stream rrc	Displays Media Stream configurations.
network	Shows network configuration.
profile	Shows profiling information for all Cisco APs.
summary	Shows configuration and statistics of 802.11b and 802.11a Cisco APs.

Command Default

None

Command Modes

User EXEC command mode or Privileged EXEC command mode

Usage Guidelines

None.

The following is a sample output of the **show ap dot11 24ghz media-stream rrc** command.

```
Device#show ap dot11 24ghz media-stream rrc

Multicast-direct                : Disabled
Best Effort                     : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio      : Auto
Max Allowed Streams Per Client     : Auto
Max Video Bandwidth              : 0
Max Voice Bandwidth              : 75
Max Media Bandwidth              : 85
Min PHY Rate (Kbps)              : 6000
Max Retry Percentage             : 80
```

show ap dot11 5ghz channel

To display the configuration and statistics of the 802.11 channel assignment, use the **show ap dot11 5ghz channel** command.

show ap dot11 5ghz channel

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Cisco IOS XE 17.17.1	This command was modified to include unii-3 low power channels.

Examples

The following example shows how to display the configuration and statistics of the 802.11 channel assignment:

```
Device# show ap dot11 5ghz channel

Leader Automatic Channel Assignment
Channel Assignment Mode                 : AUTO
Channel Update Interval                 : 600 seconds
Anchor time (Hour of the day)           : 0
Channel Update Contribution
Noise                                   : Enable
Interference                            : Enable
Load                                    : Disable
Device Aware                            : Disable
CleanAir Event-driven RRM option        : Disabled
Zero Wait DFS                           : Disabled
Channel Assignment Leader               : EWLC_RRM_DURGA (9.9.38.103) (2009:300:38::103)
Last Run                                : 300 seconds ago

DCA Sensitivity Level                   : MEDIUM : 15 dB
DCA Channel Width                       : 80 MHz
DCA Minimum Energy Limit                : -95 dBm
DCA Aggressive on startup               : Enabled
UNII-3 Low Power Channels               : Disabled
Channel Energy Levels
Minimum                                 : -86 dBm
Average                                 : -84 dBm
Maximum                                 : -81 dBm
Channel Dwell Times
Minimum                                 : 53 minutes 47 seconds
Average                                 : 19 hours 35 minutes 47 seconds
Maximum                                 : 1 day 4 hours 51 minutes 54 seconds
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List                    :
44,48,52,60,64,100,104,108,112,116,120,124,128,140,144,153,157,161
Unused Channel List                     : 36,40,56,132,136,149,165,169,173
```

show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

show ap dot11 24ghz {**ccx** | **channel** | **coverage** | **group** | **l2roam** | **logging** | **monitor** | **profile** | **receiver** | **summary** | **txpower**}

Syntax Description

ccx	Displays the 802.11b CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11b channel assignment.
coverage	Displays the configuration and statistics of the 802.11b coverage.
group	Displays the configuration and statistics of the 802.11b grouping.
l2roam	Displays 802.11b l2roam information.
logging	Displays the configuration and statistics of the 802.11b event logging.
monitor	Displays the configuration and statistics of the 802.11b monitoring.
profile	Displays 802.11b profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11b receiver.
summary	Displays the configuration and statistics of the 802.11b Cisco APs.
txpower	Displays the configuration and statistics of the 802.11b transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None.

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Device#show ap dot11 24ghz coverage

Coverage Hole Detection
  802.11b Coverage Hole Detection Mode            : Enabled
  802.11b Coverage Voice Packet Count             : 100 packet(s)
  802.11b Coverage Voice Packet Percentage        : 50%
  802.11b Coverage Voice RSSI Threshold           : -80 dBm
  802.11b Coverage Data Packet Count              : 50 packet(s)
  802.11b Coverage Data Packet Percentage         : 50%
  802.11b Coverage Data RSSI Threshold            : -80 dBm
```

```
802.11b Global coverage exception level          : 25 %
802.11b Global client minimum exception level    : 3 clients
```

show ap dot11 24ghz SI config

To see the spectrum intelligence (SI) configuration details for the 2.4-GHz band, use the **show ap dot11 24ghz SI config** command.

show ap dot11 24ghz SI config [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the SI configuration details for the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI config chassis 1 R0
```

show ap dot11 24ghz SI device type

To see the spectrum intelligence (SI) interferers of different types for the 2.4-GHz band, use the **show ap dot11 24ghz SI device type** command.

show ap dot11 24ghz SI device type {**cont_tx** | **mw_oven** | **si_fhss**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

cont_tx	SI interferers of type Continuous transmitter for the 2.4-GHz band.
mw_oven	SI interferers of type microwave oven for the 2.4-GHz band.
si_fhss	SI interferers of type Frequency Hopping Spread Spectrum for the 2.4-GHz band.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of SI interferers of type microwave oven in the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI device type mw_oven chassis 1 R0
```

show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

show ap dot11 5ghz {**ccx** | **channel** | **coverage** | **group** | **l2roam** | **logging** | **monitor** | **profile** | **receiver** | **summary** | **txpower**}

Syntax Description

ccx	Displays the 802.11a CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11a channel assignment.
coverage	Displays the configuration and statistics of the 802.11a coverage.
group	Displays the configuration and statistics of the 802.11a grouping.
l2roam	Displays 802.11a l2roam information.
logging	Displays the configuration and statistics of the 802.11a event logging.
monitor	Displays the configuration and statistics of the 802.11a monitoring.
profile	Displays 802.11a profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11a receiver.
summary	Displays the configuration and statistics of the 802.11a Cisco APs.
txpower	Displays the configuration and statistics of the 802.11a transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None.

This example shows configuration and statistics of 802.11a channel assignment.

```
Device#show ap dot11 5ghz channel

Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 12 Hours
  Anchor time (Hour of the day)             : 20
  Channel Update Contribution               : SNI..
  Channel Assignment Leader                 : web (9.9.9.2)
  Last Run                                  : 16534 seconds ago
  DCA Sensitivity Level                     : MEDIUM (15 dB)
  DCA 802.11n Channel Width                 : 40 Mhz
```

```
Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List                        : 36,40,44,48,52,56,60,64,149,153,1

               57,161
Unused Channel List                         : 100,104,108,112,116,132,136,140,1

               65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List                        :
Unused Channel List                         : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,

               15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option                       : Disabled
```

show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair** command.

show ap dot11 {**24ghz** | **5ghz** | **dual-band**} **cleanair** {**air-quality** | **config** | **device** | **summary**}

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
dual-band	Displays 802.11 dual-band radios.
cleanair	Displays cleanair configurations.
air-quality	Displays the Cleanair Air-Quality (AQ) data for 2.4GHz band.
device	Displays the CleanAir Interferers of device for 2.4GHz band.
config	Displays CleanAir Configuration for 2.4GHz band.
summary	Displays cleanair configurations for all 802.11a Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 36      95     70     0           40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 1       83     57     3           5
```

show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair air-quality** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair air-quality** {**summary** | **worst**}

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
summary	Displays a summary of 802.11 radio band air-quality information.
worst	Displays the worst air-quality information for 802.11 networks.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 36      95     70     0           40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 1       83     57     3           5
```

show ap dot11 cleanair config

To display the CleanAir configuration for the 802.11 networks, use the **show ap dot11 cleanair config** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair config**

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the CleanAir configuration for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair config
Clean Air Solution..............................: Disabled
Air Quality Settings:
    Air Quality Reporting.......................: Disabled
    Air Quality Reporting Period (min)..........: 15
    Air Quality Alarms..........................: Enabled
    Air Quality Alarm Threshold.................: 10
Interference Device Settings:
    Interference Device Reporting...............: Enabled
        Bluetooth Link..........................: Enabled
        Microwave Oven..........................: Enabled
        802.11 FH...............................: Enabled
        Bluetooth Discovery.....................: Enabled
        TDD Transmitter.........................: Enabled
        Jammer..................................: Enabled
        Continuous Transmitter..................: Enabled
        DECT-like Phone.........................: Enabled
        Video Camera............................: Enabled
        802.15.4................................: Enabled
        WiFi Inverted...........................: Enabled
        WiFi Invalid Channel....................: Enabled
        SuperAG.................................: Enabled
        Canopy..................................: Enabled
        Microsoft Device........................: Enabled
        WiMax Mobile............................: Enabled
        WiMax Fixed.............................: Enabled
    Interference Device Types Triggering Alarms:
        Bluetooth Link..........................: Disabled
        Microwave Oven..........................: Disabled
        802.11 FH...............................: Disabled
        Bluetooth Discovery.....................: Disabled
        TDD Transmitter.........................: Disabled
        Jammer..................................: Disabled
        Continuous Transmitter..................: Disabled
        DECT-like Phone.........................: Disabled
```

```
        Video Camera.............................. : Disabled
        802.15.4.................................. : Disabled
        WiFi Inverted............................. : Enabled
        WiFi Invalid Channel...................... : Enabled
        SuperAG................................... : Disabled
        Canopy.................................... : Disabled
        Microsoft Device.......................... : Disabled
        WiMax Mobile.............................. : Disabled
        WiMax Fixed............................... : Disabled
    Interference Device Alarms.................... : Enabled
Additional Clean Air Settings:
    CleanAir Event-driven RRM State............... : Disabled
    CleanAir Driven RRM Sensitivity............... : LOW
    CleanAir Persistent Devices state............. : Disabled
```

show ap dot11 cleanair summary

To view CleanAir configurations for all 802.11a Cisco APs, use the **show ap dot11 cleanair summary** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair summary**

Syntax Description

24ghz	Specifies the 2.4-GHz band
5ghz	Specifies the 5-GHz band
cleanair summary	Summary of CleanAir configurations for all 802.11a Cisco APs

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
	This command was introduced.

show ap dot11 dual-band summary

To view a brief summary of access points with dual-band radios, use the **show ap dot11 dual-band summary** command.

show ap dot11 dual-band summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to view brief summary of tag names:

```
Device# show ap dot11 dual-band summary
```

show ap environment

To see the AP environment information of all APs, use the **show ap environment** command.

show ap environment [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP environment information:

```
Device# show ap environment
```

show ap file-transfer https summary

To view the summary of AP file transfer using HTTPS, use the **show ap file-transfer https summary** command in privileged EXEC mode.

show ap file-transfer https summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to view the summary of AP file transfer using HTTPS:

```
Device# show ap file-transfer https summary

Configured port                 : 8443
Operational port                : 8443
```

show ap filters active

To see the details of active AP filters, use the **show ap filters active** command.

show ap filters active [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of the active AP filters for the active instance:

```
Device# show ap filters active chassis active R0
```

show ap filters active type priming

To display the list of all the active priming filters, use the **show ap filters active type priming** command.

show ap filters active type priming

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.2	This command was introduced.

Examples

The following example shows how to display the list of all the active priming filters:

```
Device# show ap filters active type priming

Priority   Filter Name                    regex                          Priming profile
-------------------------------------------------------------------------------------------------

 0          FLR2                           *AP-FLOOR-2*                    AP-PRIMING-2

 1          FLR1                           *AP-FLOOR-1*                    AP-PRIMING-1
```

show ap filters all

To see the details of all AP filters, use the **show ap filters all** command.

show ap filters all [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of all the AP filters for the active instance:

```
Device# show ap filters all chassis active R0
```

show ap filters all type priming

To display the list of all the priming filters, use the **show ap filters all type priming** command.

show ap filters all type priming

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.2	This command was introduced.

Examples

The following example shows how to display the list of all the priming filters:

```
Device# show ap filters all type priming

Filter Name                     regex                                  Priming profile
-------------------------------------------------------------------------------------------
FLR1                             *AP-FLOOR-1*                          AP-PRIMING-1

FLR2                             *AP-FLOOR-2*                          AP-PRIMING-2
```

show ap fra

To see the flexible radio assignment (FRA) configurations in APs, use the **show ap fra** command.

show ap fra [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the FRA configurations in APs:

```
Device# show ap fra
```

show ap fra 5-6ghz

To view the Flexible Radio Assignment (FRA) 5/6-GHz configurations, use the **show ap fra 5-6ghz** command.

show ap fra 5-6ghz

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC #

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to view the Flexible Radio Assignment (FRA) 5/6-GHz configurations:

```
Device# show ap fra 5-6ghz
```

show ap geolocation ranging

To view the AP geolocation ranging information, use the **show ap geolocation ranging** {**report** | **request** | **status**} command.

show ap geolocation ranging { **report** | **request** | **status** }

Syntax Description

report	Displays the AP geolocation ranging reports.
request	Displays the AP geolocation ranging requests.
status	Displays the AP geolocation ranging status.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.
Cisco IOS XE Dublin 17.13.1	This command was updated.

Example

This example shows how to view the AP geolocation ranging information:

```
Device# show ap geolocation ranging report
Device# show ap geolocation ranging request
```

show ap geolocation uwb asset-tracking

To view the status of geolocation UWB asset-tracking of a specified AP, use the **show ap geolocation uwb asset-tracking** command.

show ap geolocation uwb asset-tracking { **detail** | **status** }

Syntax Description

Keywords	Description
detail	Displays the AP UWB wayfinding details.
status	Displays the AP UWB asset tracking status.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

These examples shows the status of geolocation UWB asset-tracking of a specified AP in the privileged exec mode:

```
Device# show ap name <ap_name> geolocation uwb asset-tracking


AP MAC Address: f0d8.054c.12e0
Group ID: ABC1231
Status: Active
Sync slot index: 0
Primary: 1
RX Bitmap: 0X00000000FFFFFFFF
```

```
Device# show ap geolocation uwb asset-tracking status


Group-ID                        Clustered APs State        Active APs


------------------------------------------------------------------------


ABC1231                         4             Configured   4
ne2 3:Alpine1 4:Alpine4 5:Zealand2
```

```
Device# show ap geolocation uwb asset-tracking detail


AP Name                         AP MAC           Site Tag                          Group
ID                          Status


_____________________________________________________________________________________________
```

```
NAlpine2                        ecf4.0c92.b340   default-site-tag                ABC1231
                          Active

NAlpine3                        ecf4.0c92.b980   default-site-tag                ABC1231
                          Active

NAlpine1                        ecf4.0c9c.bd60   default-site-tag                ABC1231
                          Active

NZealand1                       f0d8.054c.12e0   default-site-tag                ABC1231
```

show ap geolocation uwb wayfinding

To view the status of geolocation UWB wayfinding of a specified AP, use the **show ap geolocation uwb wayfinding** command.

show ap geolocation uwb wayfinding { **detail** | **group** *group-ID* | **status** }

Syntax Description

Keywords	Description
detail	Displays the AP UWB wayfinding details.
group *group-ID*	Displays UWB wayfinding cluster grouping information.
status	Displays the AP UWB wayfinding status.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

These examples shows the status of geolocation UWB wayfinding of a specified AP in the privileged exec mode:

```
Device# show ap name <ap_name> geolocation uwb wayfinding

AP MAC Address: f0d8.054c.12e0
Group ID: new_curl_group1
Status: Active
Number of Clusters: 1
Role: Initiator
Round Index: 0
Number of Responder Anchor: 1
Responder MAC    Slot Index
--------------------------
ecf4.0c92.b340   1
```

```
Device# show ap geolocation uwb wayfinding detail
AP Name AP MAC Site Tag Group ID Status Block
Duration
NAlpine2 ecf4.0c92.b340 default-site-tag new_curl_group Active 1sec
NAlpine3 ecf4.0c92.b980 default-site-tag new_curl_group Active 1sec
NAlpine1 ecf4.0c9c.bd60 default-site-tag new_curl_group Active 1sec
NZealand1 f0d8.054c.12e0 default-site-tag new_curl_group Active 1sec
```

```
Device# show ap geolocation uwb wayfinding status
Group-ID                        Clustered APs State        Active APs

1760584021797-1                 6             Configured   6
```

```
Device# show ap geolocation uwb wayfinding group new_curl_group1
Group ID: 1760584021797-1
```

```
Max Round: 7
Cluster List
Round Initiator Anchor                Stratum Parent Anchor                   List of
Responder Anchors (Slot-Index:Responder)

0     Alpine3                         0                                       1:Zealand1
2:Alpine2 3:Alpine1 4:Alpine4 5:Zealand2
```

show ap gps location

To see the GPS location of all APs, use the **show ap gps location** command.

show ap gps location [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the GPS location of all APs:

```
Device# show ap gps location
```

show ap grpc summary

To display the status summary of GRPC channel from the AP to Cisco DNA, use the **show ap grpc summary** command.

show ap grpc summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to display the status summary of GRPC channel from the AP to Cisco DNA:

```
Device(config)# show ap grpc summary
```

show ap group hyperlocation

To view a summary or detailed information of Hyperlocation configuration for an AP group, use the **show ap group** *ap-group-name* **hyperlocation** command.

show ap group hyperlocation {**summary** | **detail**}

Syntax Description

summary	Shows the overall configuration values (AP group specific) and operational status and parameters for the AP group.
detail	Shows both overall (AP group specific) and per-AP configuration values and operational status for the AP group. The APs listed are only those that belong to the AP group.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

This example shows how to view a summary of Hyperlocation configuration for an AP group:

```
Device# show ap group my-ap-group hyperlocation summary

Site Name: my-ap-group
Site Description: This is an AP group
Hyperlocation operational status: Up
Reason: N/A
Hyperlocation NTP server: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 11
Hyperlocation reset threshold: 9
```

Note For Hyperlocation to be operational, the following conditions must be met:

- At least one Cisco CMX with Hyperlocation enabled
- Hyperlocation admin state operational
- Either AP NTP or IOS NTP configured

This example shows how to view detailed information about Hyperlocation configuration for an AP group:

```
Device# show ap group my-ap-group hyperlocation detail

Site Name: my-ap-group
Site Description: This is an AP group
Hyperlocation operational status: Up
Reason: N/A
Hyperlocation NTP server: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 11
Hyperlocation reset threshold: 9

Values for APs in all AP Groups:

AP Name                 Radio MAC        Method    Hyperlocation
-----------------------------------------------------------------
APf07f.0635.2d40        f07f.0676.3b89   WSM       Enabled
APf4cf.e272.4ed0        f4cf.e223.ba31   Local     Enabled
```

show history channel interface dot11Radio all

To check channel change or trigger reason and history, use the **show history channel interface dot11Radio all** command.

show history channel interface dot11Radio all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Examples

This example shows how to check channel change or trigger reason and history:

```
Device# show history channel interface dot11Radio all

               Timestamp Slot Client count Channel Trigger
Fri May 31 12:57:04 2019    0            0      11 RRM-DCA
Fri May 31 13:10:02 2019    0            0       1 RRM-DCA
Fri May 31 12:57:04 2019    1            0      60  Manual
Fri May 31 13:00:16 2019    1            0     149     DFS
```

show ap hyperlocation

To view a summary or detailed information about the hyperlocation configuration, use the **show ap hyperlocation** command.

show ap hyperlocation {**summary** | **detail**}

Syntax Description

summary	Shows the overall configuration and operational values.
detail	Shows the overall configuration and operation values as well as detailed information about each AP.

Command Default

None

Command History

Release	Modification
Cisco IOS XE Denali 16.2.1	This command was introduced.
Cisco IOS XE Denali 16.3.1	This command was modified. The **ble-beacon** keyword was added.

Usage Guidelines

For hyperlocation to be operational, the following conditions must be met:

- At least one Cisco Connected Mobile Experiences (CMX) must be present with hyperlocation enabled.
- The hyperlocation admin state should be operational.
- Either AP Network Time Protocol (NTP) or IOS NTP should be configured.

Example

This example shows how to view a summary of the hyperlocation configuration:

```
Device# show ap hyperlocation summary

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```

This example shows how to view detailed information about hyperlocation configuration:

```
Device# show ap hyperlocation detail

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```

```
AP Name                 Radio MAC        Method    Hyperlocation
-----------------------------------------------------------------
AP84b8.0252.b930        84b8.0216.c721   HALO      Enabled
AP84b8.0265.5540        84b8.0243.8796   WSM       Enabled
APf07f.0635.2d40        f07f.0676.3b89   WSM       Enabled
APf4cf.e272.4ed0        f4cf.e223.ba31   HALO      Enabled
```

show ap hyperlocation cmx summary

To see a summary of CMX informaiton with Hyperlocation enabled, use the **show ap hyperlocation cmx summary** command.

show ap hyperlocation cmx summary [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see a summary of CMX informaiton with Hyperlocation enabled:

```
Device# show ap hyperlocation cmx summary
```

show ap image

To display the images present on Cisco lightweight access points, use the **show ap image** command.

show ap image

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display images on the access points:

```
Device# show ap image
```

show ap image details

To view the AP image details, use the **show ap image details** command.

show ap image details

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.13.1	This command was introduced.

Example

The following example shows how to view the AP image details:

```
Device# show ap image details
AP Image Details
=============================================================================================
                                          Primary image status                    Backup
image status
Ap-Name                          Kernel       RootFs       IOX           Kernel
RootFs       IOX
Veena-AP                        Good         Good         Good          Good          Good
         Good
```

show ap image file summary

To see the summary of an access point's (AP) software install files, use the **show ap image file summary** command.

show ap image file summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was modified.

Example

The following example shows how to display the summary of an AP's software install files:

```
Device# show ap image file summary
AP Image Active List
============================
Install File Name: base_image.bin
-------------------------------
AP Image Type    Capwap Version Size (KB) Supported AP models
-------------------------------------------------------------------------------------------------------

     ap1g1       17.3.0.30       13300  NA

     ap1g2       17.3.0.30  34324       NA

     ap1g3       17.3.0.30  98549       AP803

     ap1g4       17.3.0.30        34324       AP1852E, AP1852I, AP1832I, AP1830I, AP1810W,
 OEAP1810

     ap1g5       17.3.0.30        23492       AP1815W, AP1815T, OEAP1815, AP1815I, AP1800I,
 AP1800S, AP1815M, 1542D, AP1542I, AP1100AC, AP1101AC, AP1840I

     ap1g6       17.3.0.30  93472             AP2900I, C9117AXI

    ap1g6a       17.3.0.30   247377           C9130AXI, C9130AXE, C9140AXI, C9140AXD,
C9140AXT

     ap1g7      17.3.0.30   23988           AP1900I, C9115AXI, AP1900E, C9115AXE, C9120AXE,
 C9120AXP, C9120AXI

     ap1g8       17.3.0.30   23473      C9105AXI, C9105AXW, C9110AXI, C9110AXE

     ap3g1       17.3.0.30   23422       NA

     ap3g2       17.3.0.30   23411  AP1702I
```

```
     ap3g3       17.3.0.30   23090  AP3802E, AP3802I, AP3802P, AP4800, AP2802E, AP2802I,
AP2802H, AP3800, AP1562E, AP1562I, AP1562D, AP1562PS, IW-6300H-DC, IW-6300H-AC, IW-6300H-DCW,
 ESW-6300

     c1570       17.3.0.30   13000  AP1572E, 1573E, AP1572I

     c3700       17.3.0.30   14032  AP3702E, AP3701E, AP3701I, AP3702I, AP3701P, AP3702P,
AP2702E, AP2702I, AP3702, IW3702, AP3701, AP3700C

 virtApImg       17.3.0.30               177056       APVIRTUAL


AP Image Prepare List**
============================
Install File Name: base_image.bin
------------------------------
============================
Install File Name: base_image.bin
------------------------------
AP Image Type    Capwap Version Size (KB) Supported AP models
-------------------------------------------------------------------------------------------
     ap1g1       17.3.0.30        13300  NA

     ap1g2       17.3.0.30  34324  NA

     ap1g3       17.3.0.30  98549  AP803

     ap1g4       17.3.0.30        34324  AP1852E, AP1852I, AP1832I, AP1830I, AP1810W,
OEAP1810

     ap1g5       17.3.0.30        23492  AP1815W, AP1815T, OEAP1815, AP1815I, AP1800I,
AP1800S, AP1815M, 1542D, AP1542I, AP1100AC, AP1101AC, AP1840I

     ap1g6       17.3.0.30  93472               AP2900I, C9117AXI

    ap1g6a       17.3.0.30  247377              C9130AXI, C9130AXE, C9140AXI, C9140AXD,
C9140AXT

     ap1g7       17.3.0.30  23988                AP1900I, C9115AXI, AP1900E, C9115AXE,
C9120AXE, C9120AXP, C9120AXI

     ap1g8       17.3.0.30  23473    C9105AXI, C9105AXW, C9110AXI, C9110AXE

     ap3g1       17.3.0.30  23422     NA

     ap3g2       17.3.0.30  23411     AP1702I

     ap3g3       17.3.0.30  23090     AP3802E, AP3802I, AP3802P, AP4800, AP2802E, AP2802I,
 AP2802H, AP3800, AP1562E, AP1562I, AP1562D, AP1562PS, IW-6300H-DC, IW-6300H-AC, IW-6300H-DCW,
 ESW-6300

     c1570       17.3.0.30  13000     AP1572E, 1573E, AP1572I

    c3700       17.3.0.30  14032     AP3702E, AP3701E, AP3701I, AP3702I, AP3701P, AP3702P,
 AP2702E, AP2702I, AP3702, IW3702, AP3701, AP3700C

 virtApImg       17.3.0.30              177056     APVIRTUAL

**Difference of Active and Prepare list gives images being predownloaded to Access Points.
```

show ap image site summary

To see the summary of an access point's (AP) site-filtered upgrades, use the **show ap image site summary** command.

show ap image site summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to display the summary of an AP's site-filtered upgrades:

```
Device# show ap image site summary

Image name: smu1.bin
Site Tag               Prepared              Activated             Committed
-------------------------------------------------------------------------------------------------------
BGL18                   yes                       ongoing               no
BGL17                   yes                       ongoing               no
```

show ap iot-radio firmware summary

To display the IoT radio firmware information summary of the access point, use the **show ap iot-radio firmware summary** command.

show ap iot-radio firmware summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Example

This example shows you how to display the IoT radio firmware information summary of the access point:

```
Device# show ap iot-radio firmware summary
```

show ap link-encryption

To display the link encryption status, use the **show ap link-encryption** command.

show ap link-encryption[**chassis** | {*chassis-number* | **active** | **standby**} | **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example show how to display the link-encryption status:

```
Device# show Cisco IOS XE Gibraltar 16.12.2s link-encryption
```

show ap lldp neighbors detail

To view the details of the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, when the AP is connected to the third-party switch.

show ap lldp neighbors detail

Syntax Description

This command has no arguments.

Command Default

None

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the details of AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, when the AP is connected to the third-party switch:

```
Device# show ap lldp neighbors detail
Number of neighbors: 1
AP Name               : 9130-ap1
AP Interface          : GigabitEthernet0
-------------------------------------------------------
Neighbor MAC          : c89c.1db1.1f80
Neighbor Name         : flex-ctlr-switch
System Description    : Cisco IOS Software, C3750E Software (C3750E-UNIVERSALK9-M), Version
 15.2(4)E6, RELEASE SOFTWARE (fc4)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2018 by Cisco Systems, Inc.
Compiled Thu 05-Apr-18 02:22 by prod_rel_team
Port ID               : Gi1/0/15
Port Description      : 9130-ap2
Chassis Alias         :
Management Addresses  :
  IPv4 address         : None
  IPv6 address         : None
Capabilities          :
  Bridge
  Router
Last updated time     : 12/02/2020 09:15:48
```

show ap lldp neighbors

To view the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, when the AP is connected to the third-party switch.

show ap lldp neighbors

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, when the AP is connected to the third-party switch:

```
Device# show ap lldp neighbors
Capability Codes:
     (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
     (W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other


AP Name   AP Interface      Neighbor Name Neighbor MAC    Port ID    Mgmt. Address
Capabilities  Last updated time
-------------------------------------------------------------------------------------------------------------
9130-ap1  GigabitEthernet0  switch        cxxc.1dxx.1fxx  Gi1/0/15   None          B R
     12/02/2020 09:15:48

9117-ap1  GigabitEthernet0  switch        cxxc.1dxx.1fxx  Gi1/0/19   None          B R
     12/02/2020 09:15:47
```

show ap lsc-provision info

To view the LSC provision-related configuration details for an AP, use the **show ap lsc-provision info** command.

show ap lsc-provision info

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.17.1	This command was introduced.

Examples

The following example shows you how to verify the LSC provision-related configuration details for an AP:

```
Device# show ap lsc-provision info
AP name Ethernet MAC Radio MAC LSC authentication LSC workflow Cert expiry
Last renew attempt Last renew failure
=============================================================================================================================
AP-abc 1111.2222.3333 aaaa.bbbb.ccc0 Port-802.1x PNP Onboarding <time-stamp>
<time-stamp>/NA reason-code
AP-123 1234.5678.9012 dddd.eeee.fff0 DTLS SCEP proxy <time-stamp>
<time-stamp>/NA reason-code
AP-xyz 1010.1010.1010 abcd.efab.cde0 DTLS, Port-802.1x SCEP proxy <time-stamp>
<time-stamp>/NA reason-code
0.0.0.0 372 64
AGL Enabled
```

show ap urwb status

To view the configuration status of the URWB APs, use the **show ap urwb status**.

show ap urwb status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the configuration status of the URWB APs:

```
Device# show ap urwb status
```

show ap name afc detail

To view detailed information about the Automated Frequency Coordination (AFC) system, use the **show ap name afc detail** command.

show ap name *ap-name* **afc detail**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view detailed information about the AFC system:

```
Device# show ap name AP687D.B45C.17AC afc detail

AFC event history

Timestamp                    Event                          AFC Status     Context

---------------------------- ------------------------------ --------------
----------------------------------------
08/07/2023 16:07:01.244077   AFC_EVT_REQ_RESP_RECEIVED      Active         ReqId
12195125900336565037 Response code: 0; SUCCESS
08/07/2023 16:06:55.491957   AFC_EVT_REQ_SENT               Inactive       ReqId
12195125900336565037 Sent to AFC System
08/07/2023 16:06:51.823938   AFC_EVT_REQ_QUEUED             Inactive       AFC request
queued: immediate scheduling
08/07/2023 15:28:54.608117   AFC_EVT_REQ_INACTIVE           Inactive       No location
information available; No height information available;
```

show ap name afc geolocation

To view the geolocation information about the Automated Frequency Coordination (AFC) system of a Cisco AP, use the **show ap name afc geolocation** command.

show ap name *ap-name* **afc geolocation**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the geolocation information of the AFC system of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC afc geolocation
Location type                 : Ellipse
Center ellipse - longitude    : -73.977769
Center ellipse - latitude     : 40.760168
Ellipse major-axis (meters)   : 8
Ellipse minor-axis (meters)   : 8
Ellipse orientation           : 2.5
Height (meters)               : 129
Uncertainty (meters)          : 3
```

show ap name afc response

To see the response from the Automated Frequency Coordination (AFC) system for a service request from an AP, use the **show ap name afc response** command.

show ap name *ap-name* **afc response**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to receive the response information received from the AFC system:

```
Device# show ap name AP687D.B45C.17AC afc response
AP name                 : AP687D.B45C.17AC
AP MAC Address          : 687d.b45f.1af0
Response Code           : SUCCESS
Request ID              : 2
Expire Time             : 11/14/2021 21:56:30
Last Rcvd Time          : 11/14/2021 17:56:29
Global Operating Class : 131
Channel Cfi / Max Eirp :
1       / 36.000000
5       / 33.668693
9       / 36.000000
13      / 36.000000
17      / 35.223532
21      / 36.000000
25      / 36.000000
29      / 36.000000
.
.
.
```

show ap name config dot11 6ghz

To view the 802.11 parameter configuration of a Cisco AP, use the **show ap name config dot11 6ghz** command.

show ap name *ap-name* **config dot11 6ghz**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the 802.11 parameter configuration of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC config dot11 6ghz
AP 6GHZ Power Mode                              : Low Power Indoor
Low Power Indoor Capable                        : Yes
Standard Power Capable                          : Yes
```

show ap name dot11 6ghz power-mode

To view the power-mode of a Cisco AP, use the **show ap name dot11 6ghz power-mode** command.

show ap name *ap-name* **dot11 6ghz power-mode**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the power-mode of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC dot11 6ghz power-mode
i Power mode
Standard-power mode: Allowed
```

show ap name config general

To verify whether the indoor mode is enabled for the AP, use the **show ap name config general** command.

show ap name *ap-name* **config general**

Syntax Description

ap-name	Specifies the AP name.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command verifies whether the indoor mode is enabled on the AP.

```
Device# show ap name APXXXX.31XX.83XX config general
Cisco AP Name   : APXXXX.31XX.83XX
================================================

Cisco AP Identifier                             : 4ca6.4d22.f140
Country Code                                    : Multiple Countries : CZ,US
Regulatory Domain Allowed by Country            : 802.11bg:-AE   802.11a:-ABE   802.11
6GHz:-BE
Radio Authority IDs                             : None
AP Country Code                                 : CZ  - Czech Republic
AP Regulatory Domain
  802.11bg                                      : -E
  802.11a                                       : -E
MAC Address                                     : 3c57.31c5.9478
.
.
.
AP Indoor Mode                                  : Enabled
```

show ap name dot11 neighbor summary

To view the neighbor summary of an access point (AP) in a 802.11 2.4-GHz, 5-GHz, or a 6-GHz network, use the **show ap name** *ap-name* **dot11 {24ghz | 5ghz | 6ghz} neighbor summary** command.

show ap name dot11 {24ghz | 5ghz | 6ghz} neighbor summary

Syntax Description

ap-name	Specifies the Name of the AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

This example shows how to view the neighbor summary of the 802.11 2.4-GHz parameter:

```
Device# show ap name AP687D.B45C.0554 dot11 24ghz neighbor summary

BSSID            Channel Channel-width Slot  RSSI  Last-Heard           SSID       Neighbor
-------------------------------------------------------------------------------------------
10f9.2077.6140     1      20 Mhz        0    -28   06/23/2021 01:42:51  mdns-psk   TRUE
10f9.2077.614f     1      20 Mhz        0    -28   06/23/2021 01:42:51  mdns-psk   TRUE
00b0.e192.9600    11      20 Mhz        0    -31   06/23/2021 01:42:51  mdns-psk   TRUE
00b0.e192.960f    11      20 Mhz        0    -31   06/23/2021 01:42:51  mdns-psk   TRUE
00ee.ab18.bf0f     6      20 Mhz        0    -38   06/23/2021 01:42:51  mdns-psk   TRUE
f4db.e69f.8860     1      20 Mhz        0    -75   06/23/2021 01:43:06  wlan1      FALSE
68ca.e43f.b902     1      20 Mhz        0    -77   06/23/2021 01:43:06  amaz-open  FALSE
68ca.e43f.b900     1      20 Mhz        0    -78   06/23/2021 01:43:06  amaz-web   FALSE
68ca.e43f.b903     1      20 Mhz        0    -78   06/23/2021 01:43:06  amaz-8021x FALSE
```

This example shows how to view the neighbor summary of the 802.11 5-GHz parameter:

```
Device# show ap name AP1117Q.B22U.0221 dot11 5ghz neighbor summary

BSSID          Channel  Channel-width  Slot RSSI Last-Heard          SSID     Neighbor
-----------------------------------------------------------------------------------------

7872.5dee.496f  100      80 Mhz         1    34   6/23/2021 01:43:35 mdns-psk  FALSE
```

This example shows how to view the neighbor summary of the 802.11 6-GHz parameter:

```
Device# show ap name AP1117Q.B22U.0221 dot11 6ghz neighbor summary

BSSID          Channel  Channel-width  Slot  RSSI  Last-Heard           SSID      Neighbor
-----------------------------------------------------------------------------------------
```

```
687d.b45e.4c53    1        20 Mhz        3   -37   06/23/2021 01:42:51  wpa3-6ghz  TRUE
687d.b45e.53d3    1        20 Mhz        3   -39   06/23/2021 01:42:51  wpa3-6ghz  TRUE
```

show ap name geolocation detail

To view the geolocation detail status of a specified AP, use the **show ap name geolocation detail** command.

show ap name *ap_name* **geolocation detail**

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Example

This example show the status of geolocation detail status of a specified AP in the privileged exec mode:

```
Device# show ap name <ap_name> geolocation detail

AP Name                          : Alpine1
GNSS present                     : Yes
Location type                    : Ellipse
 HDOP                            : 0.000000
 Source                          : GNSS
 Center ellipse - longitude      : -121.928826
 Center ellipse - latitude       : 37.407565
 Ellipse major-axis (meters)     : 86
 Ellipse minor-axis (meters)     : 86
 Ellipse orientation             : 0.000000
 Last update                     : 12/03/2025 22:32:15
Height                           : NA
Height above the floor (cms)     : 200
```

show ap name lldp neighbors detail

To view the details of the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, for a specific AP, when the AP is connected to the third-party switch.

show ap name *ap-name* **lldp neighbors detail**

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the details of the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, for a specific AP, when the AP is connected to the third-party switch:

```
Device# show ap name 9130-ap1 lldp neighbors detail
AP Name               : 9130-ap1
AP Interface          : GigabitEthernet0
-------------------------------------------------------
Neighbor MAC          : c89c.1db1.1f80
Neighbor Name         : flex-ctlr-switch
System Description    : Cisco IOS Software, C3750E Software (C3750E-UNIVERSALK9-M), Version
 15.2(4)E6, RELEASE SOFTWARE (fc4)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2018 by Cisco Systems, Inc.
Compiled Thu 05-Apr-18 02:22 by prod_rel_team
Port ID               : Gi1/0/15
Port Description      : 9130-ap2
Chassis Alias         :
Management Addresses  :
  IPv4 address         : None
  IPv6 address         : None
Capabilities          :
  Bridge
  Router
Last updated time     : 12/02/2020 09:15:48
```

show ap name lldp neighbors

To view the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, for a specific AP, when the AP is connected to the third-party switch.

show ap name *ap-name* **lldp neighbors**

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the AP Link Layer Discovery Protocol (LLDP) neighbor information on the controller, for a specific AP, when the AP is connected to the third-party switch:

```
Device# show ap name 9130-ap1 lldp neighbors
AP Name               : 9130-ap1
AP Interface          : GigabitEthernet0
-------------------------------------------------------
Neighbor MAC          : c89c.1db1.1f80
Neighbor Name         : flex-ctlr-switch
System Description    : Cisco IOS Software, C3750E Software (C3750E-UNIVERSALK9-M), Version
 15.2(4)E6, RELEASE SOFTWARE (fc4)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2018     by Cisco Systems, Inc.
Compiled Thu 05-Apr-18 02:22  02:22 by prod_rel_team
Port ID               : Gi1/0/15
Port Description      : 9130-ap2
Chassis Alias         :
Management Addresses  :
  IPv4 address         : None
  IPv6 address         : None
Capabilities          :
  Bridge
  Router
Last updated time     : 12/02/2020 09:15:48
```

show ap name mesh roam history

To display the roaming history of a mesh AP, use the **show ap name** *cisco-ap-name* **mesh roam history** command.

show ap name *cisco-ap-name* **mesh roam history**

Syntax Description

cisco-ap-name	Specifies the Cisco AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Example

The following example shows how to view the roaming history of a mesh AP:

```
Device# show ap name cisco-ap-name mesh roam history
```

show ap name ntp status

To display the Network Time Protocol (NTP) status of an AP, use the **show ap name ntp status** command.

show ap name *ap-name* **ntp status**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to view the NTP status of an AP:

```
Device# show ap name AP-G1-230 ntp status

ap-name       enabled v4/v6 IPAddress       Status     Stratum LastSync  SyncOffset
AP-G1-230     Y       v4    198.51.100.5    AuthFail   4       1000      100
```

show ap name sensor environment accelerometer shutdown

To display the accelerometer shutdown status of an AP, use the **show ap name sensor environment accelerometer shutdown** command.

show ap name *ap-name* **sensor environment accelerometer shutdown**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 26.1.1	This command was introduced.

Examples

The following example shows how to view the accelerometer shutdown status of an AP:

```
Device# show ap name AP-Office-01 sensor environment accelerometer shutdown
```

show ap ntp status

To display the Network Time Protocol (NTP) status for all the APs, use the **show ap name ntp status** command.

show ap ntp status

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to view the NTP status for all the APs:

```
Device# show ap ntp status

ap-name       enabled    v4/v6 IPAddress       Status   Stratum LastSync SyncOffset
AP-G1-230         Y      v4    198.51.100.5    AuthFail 2       Never
AP-G1-231         Y      v4    198.51.100.10   Synced   3       1000     100
AP-G1-232         Y      v4    198.51.100.15   Synced   16      2000     50
```

show ap primary list

To see the AP primary list, use the **show ap primary list** command.

show ap primary list [**chassis** | { *chassis-number* | **active** | **standby** } | **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP primary list:

```
Device# show ap primary list
```

show ap mesh cac access

To view the number of active calls on access radio for a given AP and its Mesh tree, use **show ap mesh cac access** command.

show ap *ap-name* **mesh cac access**

Syntax Description

ap-name	Name of the access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Example

This example shows how to display the number of active calls on access radio for a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac access

Depth   AP Name                          Slot  Radio      BW Used  Call
------  --------------------------------  ----  ---------  -------  ----
0       AALUKKAL-1562-RAP                 0     802.11b/g  0        0
                                          1     802.11a    0        0
1       AP380E.4DBF.C6B0                  0     802.11b/g  1072     2
                                          1     802.11a    0        0
```

show ap mesh cac bwused voice

To view the voice bandwidth utilization of a given AP and its Mesh tree, use the **show ap mesh cac bwused voice** command.

show ap *ap-name* **mesh cac bwused voice**

Syntax Description

ap-name	Name of the access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Example

This example shows how to display the voice bandwidth utilization of a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac bwused voice

Depth   AP Name                          Slot  Radio      BW Used
------  --------------------------------  ----  ---------  -------
1       APA023.9FA9.D920                  0     802.11b/g  1140
                                          1     802.11a    0
2       AP380E.4DBF.C80C                  0     802.11b/g  570
                                          1     802.11a    2144
2       AP380E.4DBF.C816                  0     802.11b/g  0
                                          1     802.11a    0
2       APA023.9FA9.B702                  0     802.11b/g  0
                                          1     802.11a    0
```

show ap mesh cac callpath

To view the number of active calls in access as well as backhaul for a given AP and its Mesh tree, use the **show ap mesh cac callpath** command.

show ap *ap-name* **mesh cac callpath**

Syntax Description

ap-name	Name of the access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Example

This example shows how to display the number of active calls in access as well as backhaul for a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac callpath

Depth   AP Name                          Slot  Radio      Call
------  --------------------------------  ----  ---------  ----
1       APA023.9FA9.D920                  0     802.11b/g  2
                                          1     802.11a    0
2       AP380E.4DBF.C80C                  0     802.11b/g  0
                                          1     802.11a    2
2       AP380E.4DBF.C816                  0     802.11b/g  0
                                          1     802.11a    0
2       APA023.9FA9.B702                  0     802.11b/g  0
                                          1     802.11a    0
```

show ap mesh cac rejected

To view the number of rejected calls on access as well as backhaul for a given AP and its Mesh tree, use **show ap mesh cac rejected** command.

show ap *ap-name* **mesh cac rejected**

Syntax Description

ap-name	Name of the access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Example

This example shows how to display the number of rejected calls on access as well as backhaul for a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac rejected
```

show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

show ap monitor-mode summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display current channel-optimized monitor mode settings:

```
Device# show ap monitor-mode summary

AP Name Ethernet MAC      Status   Scanning Channel List
------- -------------     -------- -------- -----------------
AP_004  xx:xx:xx:xx:xx:xx Tracking 1,6,11,  4
```

show ap multicast mom (multicast over multicast)

To confirm if the APs receive multicast to multicast (mom) traffic sent by the controller, using CAPWAP multicast group, use the **show ap multicast mom** command.

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Previleged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2	This command was introduced.

This example shows how to confirm if the APs receive multicast to multicast traffic sent by the controller using CAPWAP multicast group:

```
Device# show ap multicast mom

AP Name                     MOM-IP     TYPE MOM- STATUS
-----------------------------------------------------
SS-E-1                      IPv4             Up
SS-E-2                      IPv4             Up
9130E-r3-sw2-g1012          IPv4             Up
9115i-r3-sw2-te1-0-38       IPv4             Up
AP9120-r3-sw3-Gi1-0-46      IPv4             Up
ap3800i-r2-sw1-te2-0-2      IPv4             Up
```

Note With CSCwd12261, the MOM-STATUS has the value UNKNOWN for some Cisco Wave 1 (IOS-based) APs such as Cisco Aironet 1702i, 3702i, 3702e, and IW3702. This behaviour is because these APs do not send the MoM payload to the controller.

show ap name *ap-name* neighbor summary

To view the summary of AP neighbor information, use the **show ap name** *ap-name* **neighbor summary**

show ap name *ap-name* **neighbor summary**

Syntax Description

ap-name	Specifies the name of the AP whose neighbor summary is displayed.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to display the AP neighbor information:

```
Device#show ap name APXXXX.6DXX.59XX neighbor summary

BSSID                 Channel   Channel-width Slot        RSSI              Last-Heard
                       SSID                                        Neighbour
-------------------------------------------------------------------------------------------
0008.2f1c.8040        1         20 Mhz        0           -39               03/17/2020
18:25:14                aprusty-un-dot1x                              FALSE
0008.2f1c.8041        1         20 Mhz        0           -39               03/17/2020
18:25:14                aprusty-sim-11                                FALSE
0008.2f1c.8042        1         20 Mhz        0           -39               03/17/2020
18:25:14                one-ph                                        FALSE
0008.2f1c.8044        1         20 Mhz        0           -38               03/17/2020
18:25:14                aprusty-test                                  FALSE
0008.3296.f340        11        20 Mhz        0           -51               03/18/2020
10:39:27                ewlc-ap-dot1x                                 FALSE
0008.3296.f341        11        20 Mhz        0           -49               03/18/2020
10:39:27                vewlc_small_psk                               FALSE
002a.1022.d950        1         20 Mhz        0           -57               03/17/2020
18:25:14                ewlc-ap-dot1x                                 FALSE
002a.105c.bfd0        1         20 Mhz        0           -36               03/17/2020
18:25:14                ewlc-ap-dot1x                                 FALSE
002a.105c.bfd1        1         20 Mhz        0           -37               03/17/2020
18:25:14                vewlc_small_psk                               FALSE
002c.c864.76d0        11        20 Mhz        0           -61               03/18/2020
10:37:37                rajwlan                                       FALSE

BSSID                 Channel   Channel-width Slot        RSSI              Last-Heard
                       SSID                                        Neighbour
-------------------------------------------------------------------------------------------
002c.c8de.59e0        1         20 Mhz        0           -48               03/17/2020
18:25:14                WQ                                            FALSE
002c.c8de.5d80        11        20 Mhz        0           -54               03/18/2020
10:39:27                ewlc-ap-dot1x                                 FALSE
002c.c8de.5d81        11        20 Mhz        0           -55               03/18/2020
10:39:27                vewlc_small_psk                               FALSE
```

```
002c.c8de.7260        11        20 Mhz        0           -53               03/18/2020
10:39:27                ewlc-ap-dot1x                                 FALSE
002c.c8de.7261        11        20 Mhz        0           -54               03/18/2020
10:39:27                vewlc_small_psk                               FALSE
005d.7390.e1e0        1         20 Mhz        0           -54               03/17/2020
18:25:14                rlan                                          FALSE
006b.f114.95a0        1         20 Mhz        0           -60               03/17/2020
18:25:14                zavc                                          FALSE
006b.f114.b0e0        1         20 Mhz        0           -46               03/17/2020
18:25:14                ewlc-ap-dot1x                                 FALSE
006c.bc61.2340        1         20 Mhz        0           -63               03/17/2020
18:24:44                dnac-swim                                     FALSE
006c.bc72.5ce0        11        20 Mhz        0           -58               03/18/2020
10:39:17                dnac-swim                                     FALSE
```

show ap name afc detail

To view detailed information about the Automated Frequency Coordination (AFC) system, use the **show ap name afc detail** command.

show ap name *ap-name* **afc detail**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view detailed information about the AFC system:

```
Device# show ap name AP687D.B45C.17AC afc detail

AFC event history

Timestamp                    Event                          AFC Status     Context

---------------------------- ------------------------------ --------------
----------------------------------------
08/07/2023 16:07:01.244077   AFC_EVT_REQ_RESP_RECEIVED      Active         ReqId
12195125900336565037 Response code: 0; SUCCESS
08/07/2023 16:06:55.491957   AFC_EVT_REQ_SENT               Inactive       ReqId
12195125900336565037 Sent to AFC System
08/07/2023 16:06:51.823938   AFC_EVT_REQ_QUEUED             Inactive       AFC request
queued: immediate scheduling
08/07/2023 15:28:54.608117   AFC_EVT_REQ_INACTIVE           Inactive       No location
information available; No height information available;
```

show ap name afc geolocation

To view the geolocation information about the Automated Frequency Coordination (AFC) system of a Cisco AP, use the **show ap name afc geolocation** command.

show ap name *ap-name* **afc geolocation**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the geolocation information of the AFC system of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC afc geolocation
Location type                 : Ellipse
Center ellipse - longitude    : -73.977769
Center ellipse - latitude     : 40.760168
Ellipse major-axis (meters)   : 8
Ellipse minor-axis (meters)   : 8
Ellipse orientation           : 2.5
Height (meters)               : 129
Uncertainty (meters)          : 3
```

show ap name afc response

To see the response from the Automated Frequency Coordination (AFC) system for a service request from an AP, use the **show ap name afc response** command.

show ap name *ap-name* **afc response**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to receive the response information received from the AFC system:

```
Device# show ap name AP687D.B45C.17AC afc response
AP name                : AP687D.B45C.17AC
AP MAC Address         : 687d.b45f.1af0
Response Code          : SUCCESS
Request ID             : 2
Expire Time            : 11/14/2021 21:56:30
Last Rcvd Time         : 11/14/2021 17:56:29
Global Operating Class : 131
Channel Cfi / Max Eirp :
1       / 36.000000
5       / 33.668693
9       / 36.000000
13      / 36.000000
17      / 35.223532
21      / 36.000000
25      / 36.000000
29      / 36.000000
.
.
.
```

show ap name auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap name auto-rf** command.

show ap name *ap-name* **auto-rf dot11** {**24ghz** | **5ghz** | **dual-band**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
dual-band	Displays dual band.

Command Default

None

Command Modes

Privileged EXEC.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display auto-RF information for an access point:

```
Device# show ap name AP01 auto-rf dot11 24ghz

Number of Slots                                 : 2
AP Name                                         : TSIM_AP-1
MAC Address                                     : 0000.2000.02f0
Slot ID                                         : 0
Radio Type                                      : 802.11b/g
Subband Type                                    : All

Noise Information
  Noise Profile                                 : Failed
  Channel   1                                    :   24 dBm
  Channel   2                                    :   48 dBm
  Channel   3                                    :   72 dBm
  Channel   4                                    :   96 dBm
  Channel   5                                    :  120 dBm
  Channel   6                                    : -112 dBm
  Channel   7                                    :  -88 dBm
  Channel   8                                    :  -64 dBm
  Channel   9                                    :  -40 dBm
  Channel  10                                    :  -16 dBm
  Channel  11                                    :    8 dBm

Interference Information
  Interference Profile                          : Passed
  Channel   1                                    : -128 dBm @  0% busy
  Channel   2                                    :  -71 dBm @  1% busy
  Channel   3                                    :  -72 dBm @  1% busy
  Channel   4                                    :  -73 dBm @  2% busy
  Channel   5                                    :  -74 dBm @  3% busy
  Channel   6                                    :  -75 dBm @  4% busy
  Channel   7                                    :  -76 dBm @  5% busy
```

```
  Channel   8                                      :  -77 dBm @  5% busy
  Channel   9                                      :  -78 dBm @  6% busy
  Channel  10                                      :  -79 dBm @  7% busy
  Channel  11                                      :  -80 dBm @  8% busy

Rogue Histogram (20/40_ABOVE/40_BELOW)
    Channel  36                                    : 27/ 4/ 0
    Channel  40                                    : 13/ 0/ 0
    Channel  44                                    :  5/ 0/ 0
    Channel  48                                    :  6/ 0/ 1
    Channel  52                                    :  4/ 0/ 0
    Channel  56                                    :  5/ 0/ 0
    Channel  60                                    :  1/ 3/ 0
    Channel  64                                    :  3/ 0/ 0
    Channel 100                                    :  0/ 0/ 0
    Channel 104                                    :  0/ 0/ 0
    Channel 108                                    :  0/ 1/ 0

Load Information
  Load Profile                                   : Passed
  Receive Utilization                            : 10%
  Transmit Utilization                           : 20%
  Channel Utilization                            : 50%
  Attached Clients                               : 0 clients

Coverage Information
  Coverage Profile                               : Passed
  Failed Clients                                 : 0 clients

Client Signal Strengths
  RSSI -100 dBm                                  : 0 clients
  RSSI  -92 dBm                                  : 0 clients
  RSSI  -84 dBm                                  : 0 clients
  RSSI  -76 dBm                                  : 0 clients
  RSSI  -68 dBm                                  : 0 clients
  RSSI  -60 dBm                                  : 0 clients
  RSSI  -52 dBm                                  : 0 clients

Client Signal to Noise Ratios
  SNR    0 dB                                    : 0 clients
  SNR    5 dB                                    : 0 clients
  SNR   10 dB                                    : 0 clients
  SNR   15 dB                                    : 0 clients
  SNR   20 dB                                    : 0 clients
  SNR   25 dB                                    : 0 clients
  SNR   30 dB                                    : 0 clients
  SNR   35 dB                                    : 0 clients
  SNR   40 dB                                    : 0 clients
  SNR   45 dB                                    : 0 clients

Nearby APs
  AP 0000.2000.0300 slot 0                       : -68 dBm on  11 (10.10.10.1)
  AP 0000.2000.0400 slot 0                       : -68 dBm on  11 (10.10.10.1)
  AP 0000.2000.0600 slot 0                       : -68 dBm on  11 (10.10.10.1)

Radar Information

Channel Assignment Information
  Current Channel Average Energy                 : 0 dBm
  Previous Channel Average Energy                : 0 dBm
  Channel Change Count                           : 0
  Last Channel Change Time                       : Wed Oct 17 08:13:36 2012
  Recommended Best Channel                       : 11
```

```
RF Parameter Recommendations
  Power Level                                   : 1
  RTS/CTS Threshold                             : 2347
  Fragmentation Threshold                       : 2346
  Antenna Pattern                               : 0

Persistent Interference Devices
```

show ap name ble detail

To display BLE management details, use the **show ap name ble detail** command.

show ap name *ap-name* **ble detail**

Syntax Description

ap-name	Specifies the name of the AP.

Command Default None

Command Modes Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines None

Example

The following example shows how to display the BLE management details:

```
Device(config)# show ap name ap-name ble detail
```

show ap name cablemodem

To see cable modem information of an AP, use the **show ap name** *ap-name* **cablemodem** command.

show ap name *ap-name* **cablemodem** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see cable modem information of an AP:

```
Device# show ap name my-ap cablemodem
```

show ap name config

To display common information and Ethernet VLAN tagging information for a specific Cisco lightweight access point, use the **show ap name config** command.

show ap name *ap-name* **config** {**ethernet** | **general**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
ethernet	Displays Ethernet tagging configuration information for an access point.
general	Displays common information for an access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display Ethernet tagging information for an access point:

```
Device# show ap name AP01 config ethernet

VLAN Tagging Information for AP01
```

This example shows how to display common information for an access point:

```
Device# show ap name AP01 config general

Cisco AP Name                                  : AP01
Cisco AP Identifier                            : 5
Country Code                                   : US  - United States
Regulatory Domain Allowed by Country           : 802.11bg:-A     802.11a:-A
AP Country Code                                : US  - United States
AP Regulatory Domain                           : Unconfigured
Switch Port Number                             : Te1/0/1
MAC Address                                    : 0000.2000.02f0
IP Address Configuration                       : Static IP assigned
IP Address                                     : 10.10.10.12
IP Netmask                                     : 255.255.0.0
Gateway IP Address                             : 10.10.10.1
Fallback IP Address Being Used                 : 10.10.10.12
Domain                                         : Cisco
Name Server                                    : 0.0.0.0
CAPWAP Path MTU                                : 1485
Telnet State                                   : Enabled
SSH State                                      : Disabled
Cisco AP Location                              : sanjose
Cisco AP Group Name                            : default-group
Primary Cisco Controller Name                  : CAPWAP Controller
Primary Cisco Controller IP Address            : 10.10.10.1
Secondary Cisco Controller Name                :
Secondary Cisco Controller IP Address          : Not Configured
```

```
Tertiary Cisco Controller Name                  :
Tertiary Cisco Controller IP Address            : Not Configured
Administrative State                            : Enabled
Operation State                                 : Registered
AP Mode                                         : Local
AP Submode                                      : Not Configured
Remote AP Debug                                 : Disabled
Logging Trap Severity Level                     : informational
Software Version                                : 7.4.0.5
Boot Version                                    : 7.4.0.5
Stats Reporting Period                          : 180
LED State                                       : Enabled
PoE Pre-Standard Switch                         : Disabled
PoE Power Injector MAC Address                  : Disabled
Power Type/Mode                                 : Power Injector/Normal Mode
Number of Slots                                 : 2
AP Model                                        : 1140AG
AP Image                                        : C1140-K9W8-M
IOS Version                                     :
Reset Button                                    :
AP Serial Number                                : SIM1140K001
AP Certificate Type                             : Manufacture Installed
Management Frame Protection Validation          : Disabled
AP User Mode                                    : Customized
AP User Name                                    : cisco
AP 802.1X User Mode                             : Not Configured
AP 802.1X User Name                             : Not Configured
Cisco AP System Logging Host                    : 255.255.255.255
AP Up Time                                      : 15 days 16 hours 19 minutes 57
 seconds
AP CAPWAP Up Time                               : 4 minutes 56 seconds
Join Date and Time                              : 10/18/2012 04:48:56
Join Taken Time                                 : 15 days 16 hours 15 minutes 0
seconds
Join Priority                                   : 1
Ethernet Port Duplex                            : Auto
Ethernet Port Speed                             : Auto
AP Link Latency                                 : Disabled
Rogue Detection                                 : Disabled
AP TCP MSS Adjust                               : Disabled
AP TCP MSS Size                                 : 6146
```

show ap name config dot11 6ghz

To view the 802.11 parameter configuration of a Cisco AP, use the **show ap name config dot11 6ghz** command.

show ap name *ap-name* **config dot11 6ghz**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the 802.11 parameter configuration of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC config dot11 6ghz
AP 6GHZ Power Mode                              : Low Power Indoor
Low Power Indoor Capable                        : Yes
Standard Power Capable                          : Yes
```

show ap name config slot

To display the configuration of a Cisco AP and also display the common information for a slot, use the **show ap name config slot** command.

show ap name *Cisco-ap-name* **slot** *0-3*

Syntax Description

Cisco-ap-name	Specifies the name of the Cisco AP.
0-3	Specifies the slot ID.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to display common information for a slot in an access point:

```
Device# show ap name Cisco-ap-name config slot 3
```

show ap name config ethernet

To see Ethernet related configuration information of an AP, use the **show ap name** *ap-name* **config ethernet** command.

show ap name *ap-name* **config ethernet** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see Ethernet related configuration information of an AP:

```
Device# show ap name my-ap config ethernet
```

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

show ap name *ap-name* **dot11** { **24ghz** | **5ghz** | **6ghz** } { **ccx** | **cdp** | **profile** | **service-policy output** | **tsm** { **all** *client-mac* } }

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4-GHz band.
5ghz	Displays the 5-GHz band.
6ghz	Displays the 6-GHz band.
ccx	Displays the Cisco Client eXtensions (CCX) radio management status information.
cdp	Displays Cisco Discovery Protocol (CDP) information.
profile	Displays configuration and statistics of 802.11 profiling.
service-policy output	Displays downstream service policy information.
tsm	Displays 802.11 traffic stream metrics statistics.
all	Displays the list of all access points to which the client has associations.
client-mac	MAC address of the client.
SI	Displays the SI configurations.
airtime-fairness	Displays the stats of 24Ghz or 5Ghz or 6-GHz airtime-fairness.
call-control	Displays the call control information.
radio-reset	Displays radio-reset.
slot	Displays slot information.
voice	Displays voice information.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Cupertino 17.7.1	This command was modified to include 6-GHz band.

This example shows how to display the service policy that is associated with the access point:

```
Device# show ap name test-ap dot11 24ghz service-policy output

Policy Name  : test-ap1
Policy State : Installed
```

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Device# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz cdp

AP Name               AP CDP State
--------------------- --------------
AP03                  Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Device# show ap name AP01 dot11 24ghz profile

 802.11b Cisco AP performance profile mode             : GLOBAL
 802.11b Cisco AP Interference threshold               : 10 %
 802.11b Cisco AP noise threshold                      : -70 dBm
 802.11b Cisco AP RF utilization threshold             : 80 %
 802.11b Cisco AP throughput threshold                 : 1000000 bps
 802.11b Cisco AP clients threshold                    : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz service-policy output

Policy Name  : def-11gn
Policy State : Installed
```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Device# show ap name AP01 dot11 24ghz tsm all
```

show ap name dot11 5ghz slot urwb detail

To display the URWB details of the AP on 5-GHz band, use the **show ap name** *ap-name* **dot11 5ghz slot** *slot-id* **urwb detail**

show ap name *ap-name* **dot11 5ghz slot** *slot-id* **urwb detail**

Syntax Description

ap-name	Specifies the name of the Cisco AP.
slot-id	

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to display the URWB details of the AP on 5-GHz band:

```
Device# show ap name ap-name dot11 5ghz slot 1 urwb detail
```

show ap name dot11 6ghz power-mode

To view the power-mode of a Cisco AP, use the **show ap name dot11 6ghz power-mode** command.

show ap name *ap-name* **dot11 6ghz power-mode**

Syntax Description

ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the power-mode of a Cisco AP:

```
Device# show ap name AP687D.B45C.17AC dot11 6ghz power-mode
i Power mode
Standard-power mode: Allowed
```

show ap name environment

To see the AP environment information of an AP, use the **show ap name** *ap-name* **environment** command.

show ap name *ap-name* **environment** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP environment information of an AP:

```
Device# show ap name my-ap environment
```

show ap name geolocation ranging status

To view the status of the last ranging request of a specified AP, use the **show ap name** *Cisco-ap-name* **geolocation ranging status** command.

show ap name *Cisco-ap-name* **geolocation ranging status**

Syntax Description

Cisco-ap-name	Name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.13.1	This command was introduced.
Cisco IOS XE Dublin 17.12.2	This command was also made available in this release.

Examples

This example shows how to view the status of the last ranging request of a specified AP:

```
Device# show ap name geolocation ranging status
```

show ap name gps location

To see the GPS location of the AP, use the **show ap name gps location** command.

show ap name *ap-name* **gps location** [{*chassis-number* | **active** | **standby**}**R0**

Syntax Description

ap-name	Name of the Access Point
gps	See the GPS information of a Cisco AP
location	Shows the Mesh linktest data
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the GPS location of an AP:

```
Device# show ap name mesh-profile-name gps location
```

show ap name grpc detail

To display the detailed status of gRPC channel from AP to Cisco DNA, use the **show ap name grpc detail** command.

show ap name *ap-name* **grpc detail**

Syntax Description

ap-name	Specifies the name of the AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to display the detailed status of gRPC channel from AP to Cisco DNA:

```
Device(config)# show ap name APXXXX.BXXX.FXXX grpc detail
```

show ap name hyperlocation

To view a summary or detailed information about the hyperlocation configuration for an access point (AP), use the **show ap name hyperlocation** command.

show ap name *ap-name* **hyperlocation ble-beacon**

Syntax Description

ap-name	Access point name.
hyperlocation	Displays AP hyperlocation information.
ble-beacon	Displays BLE beacon configuration of an AP.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Example

This example shows how to view the BLE beacon configuration of an AP:

```
Device# show ap name test-ap hyperlocation ble-beacon

ID  Major  Minor  TX Power(dBm)
------------------------------
0   0      0      0
1   0      0      0
2   0      0      0
3   0      0      0
```

show ap name mesh backhaul

To see mesh backhaul statistics of an AP, use the **show ap name** *ap-name* **mesh backhaul** command.

show ap name *ap-name* **mesh backhaul** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh backhaul statistics of an AP:

```
Device# show ap name mymeshap mesh backhaul
```

show ap name mesh bhrate

To see mesh bachkhaul data rate for an AP, use the **show ap name** *ap-name* **mesh bhrate** command.

show ap name *ap-name* **mesh bhrate** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh bachkhaul data rate for an AP:

```
Device# show ap name mymeshap mesh bhrate
```

show ap name mesh linktest

To see the mesh linktest data, use the **show ap name mesh linktest data** command.

show ap name *ap-name* **mesh linktest data** *dest-mac* [**chassis** {*chassis-number* | **active** | **standby**}**R0**]

Syntax Description

ap-name	Name of the Access Point
linktest	Shows the Mesh linktest
data	Shows the Mesh linktest data
dest-mac	Enter the AP MAC address.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the mesh linktest data of an AP:

```
Device# show ap name mesh-profile-namemesh linktest data 83-88-15-0C-83-72
```

show ap name mesh neighbor detail

To see detailed information about a neighbor of a mesh AP, use the **show ap name** *ap-name* **mesh neighbor detail** command.

show ap name *ap-name* **mesh neighbor detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see detailed information about a neighbor of a mesh AP:

```
Device# show ap name mymeshap mesh neighbhor detail
```

show ap name mesh neighbor detail

To see detailed information about a neighbor of a mesh AP, use the **show ap name** *ap-name* **mesh neighbor detail** command.

show ap name *ap-name* **mesh neighbor detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see detailed information about a neighbor of a mesh AP:

```
Device# show ap name mymeshap mesh neighbhor detail
```

show ap name mesh path

To see information about the mesh AP's path, use the **show ap name** *ap-name* **mesh path** command.

show ap name *ap-name* **mesh path** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see information about the mesh AP's path:

```
Device# show ap name mymeshap mesh path
```

show ap name mesh stats

To see mesh statistics, use the **show ap name** *ap-name* **mesh stats** command.

show ap name *ap-name*[**packet error** | **queue** | **security**]

Syntax Description

ap-name	Name of the AP.
packet error	Mesh packet error statistics.
queue	Mesh queue statistics.
security	Mesh security statistics.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh statistics:

```
Device# show ap name mymeshap mesh stats
```

show ap name tunnel eogre events

To display the Ethernet over GRE (EoGRE) events on an AP, use the **show ap name tunnel eogre events** command.

show ap name *ap-name* **tunnel eogre events**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the EoGRE tunnel events on an AP:

```
Device# show ap name ap1 tunnel eogre events

AP 80e8.6fd4.9520  Event history
Timestamp               #Times   Event               RC Context
----------------------- -------- ------------------- --
----------------------------------------
02/18/2019 23:50:26.341 6        IAPP_STATS           0 GW Tunnel2 uptime:0s

02/18/2019 23:49:40.222 2       CLIENT_JOIN          0 74da.3828.88b0, (eogre_domain/2121)

02/18/2019 23:48:43.549 1       CLIENT_LEAVE         0 74da.3828.88b0, (eogre_domain/2121)

02/18/2019 23:47:33.127 1        DOMAIN_STATUS        0 eogre_domain Active GW: Tunnel1

02/18/2019 23:47:33.124 4        AP_TUNNEL_STATUS     0 Tunnel2 Dn

02/18/2019 23:47:33.124 1        MSG_CLIENT_DEL       0 GW Tunnel2 (IP: 9.51.1.12)

02/18/2019 23:47:33.124 2        TUNNEL_ADD           0 GW Tunnel2

02/18/2019 23:47:33.120 3        MSG_CLIENT_DEL_PD    0 GW Tunnel1 (IP: 9.51.1.11)

02/18/2019 23:47:31.763 2        AP_DOMAIN_PUSH       0 Delete:eogre_domain_set, 0 GWs

02/18/2019 23:47:31.753 4        AP_VAP_PUSH          0 profile:'eogre_tunnel',
wlan:pyats_eogre
```

show ap name tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain status on an AP, use the **show ap name tunnel eogre domain detailed** command.

show ap name *ap-name* **tunnel eogre domain detailed** *domain-name*

Syntax Description

ap-name	AP name.
domain-name	EoGRE domain name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel domain status on an AP:

```
Device# show ap name ap1 tunnel eogre domain detailed eogre_domain


Domain Name    : eogre_domain
 Primary GW    : Tunnel1
 Secondary GW  : Tunnel2
 Active GW     : Tunnel1
 Redundancy    : Non-Revertive
 AdminState    : Up
```

show ap name tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain on an AP, use the **show ap name tunnel eogre domain summary** command.

show ap name *ap-name* **tunnel eogre domain summary**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel domain on an AP:

```
Device# show ap name ap1 tunnel eogre domain summary

AP MAC          Domain                          Active Gateway
-----------------------------------------------------------------------------
80e8.6fd4.9520  eogre_domain
```

show ap name tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel gateway status on an AP, use the **show ap name tunnel eogre gateway detailed** command.

show ap name *ap-name* **tunnel eogre gateway detailed** *gateway-name*

Syntax Description

ap-name	AP name.
gateway-name	EoGRE gateway name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel gateway status on an AP:

```
Device# show ap name ap1 tunnel eogre gateway detailed Tunnel2

Gateway : Tunnel2
 Mode   : IPv4
 IP     : 9.51.1.12
 State  : Down
 MTU    : 0
 AP MAC : 80e8.6fd4.9520

 Clients
  Total Number of Wireless Clients      : 0
 Traffic
  Total Number of Received Packets      : 0
  Total Number of Received Bytes        : 0
  Total Number of Transmitted Packets   : 0
  Total Number of Transmitted Bytes     : 0
  Total Number of Lost Keepalive        : 151
```

show ap name tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway on an AP, use the **show ap name tunnel eogre gateway summary** command.

show ap name *ap-name* **tunnel eogre gateway summary**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel gateway on an AP:

```
Device# show ap name ap1 tunnel eogre gateway summary

AP MAC          Gateway          Type  IP                                      State  Clients
-----------------------------------------------------------------------------------------------
80e8.6fd4.9520  Tunnel1           IPv4  9.51.1.11                                 Up     1

80e8.6fd4.9520  Tunnel2           IPv4  9.51.1.12                                 Down   0
```

show ap name urwb coord-routes

To view the URWB coordinator routes, use the **show ap name** *ap-name* **urwb coord-routes**

show ap name *ap-name* **urwb coord-routes**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB coordinator routes:

```
Device# show ap name ap-name urwb coord-routes
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
Coordinator Mode                 : Enabled
URWB Coordinator routes
Index: 0
Peer: 5.23.15X.19X
Peer: 5.23.15X.12X
Index: 1
Peer: 5.23.15X.19X
Peer: 5.23.18X.80
```

show ap name urwb fixed-links

To view the URWB fixed links, use the **show ap name** *ap-name* **urwb fixed-links**

show ap name *ap-name* **urwb fixed-links**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB fixed links:

```
Device# show ap name ap-name urwb fixed-links
Mesh ID                          : 5.23.159.192
URWB Status                      : Enabled
URWB Node Links:
Link ID(src)    Link ID(dest)    Radio Role
-------------------------------------------------------------------------------------------------------
1.23.159.192    1.23.156.128     Fixed Infrastructure
1.23.159.192    1.23.183.80      Fixed Infrastructure
URWB fixed links:
Link ID(src)    Link ID(dest)    Link type
-----------------------------------------------------------
1.23.159.192    1.23.156.128     Wired
1.23.159.192    1.23.183.80      Wired
```

show ap name urwb info

To view the URWB information of the AP, use the **show ap name** *ap-name* **urwb info**

show ap name *ap-name* **urwb info**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB information of the AP:

```
Device# show ap name ap-name urwb info
```

show ap name urwb mobility-links

To view the URWB coordinator routes, use the **show ap name** *ap-name* **urwb mobility-links**

show ap name *ap-name* **urwb mobility-links**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB mobility-links:

```
Device# show ap name ap-name urwb mobility-links
```

show ap name urwb network

To view the URWB network, use the **show ap name** *ap-name* **urwb network**

show ap name *ap-name* **urwb network**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB network:

```
Device# show ap name ap-name urwb network
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
Coordinator Mode                 : Enabled
Gateway AP MAC Address           : 2cXX.8eXX.6aXX
Gateway ID                       : 5.23.15X.19X
Number of Connected Devices      : 2
Connected Devices:
  IP                : 192.71.0.1
  VLAN ID           : 1
  IP                : 192.71.0.71
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
Number of Nodes                  : 3
Number of Coordinator routes     : 2
Number of Fixed Links            : 2
Number of Mobility Links         : 0
URWB Network Nodes summary:
Node ID         Node Name                Device Model      Role             IP Address
-------------------------------------------------------------------------------------------------
5.23.15X.12X    AP8CXX.81XX.9CXX.fx       CW9166I         Backbone        192.71.0.2XX
5.23.15X.19X    AP8CXX.81XX.9FXX          CW9166I         Coordinator     192.71.0.2XX
5.23.18XA.80     AP8CXX.81XX.B7XX          CW9166I         Backbone        192.71.0.2XX
```

show ap name urwb wireless-stats

To view the URWB wireless statistics, use the **show ap name** *ap-name* **urwb wireless-stats**

show ap name *ap-name* **urwb wireless-stats**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB wireless statistics:

```
Device# show ap name ap-name urwb wireless-stats
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
URWB wireless statistics
Rx statistics
Source          Destination    Timestamp           RSSI      Received-Packets        Bytes
               BW        MCS  MCS-Index  gi
-------------------------------------------------------------------------------------------
3.23.15X.12X    3.23.15X.19X    08/11/25 22:35:46    12         12099096
2718875388           20 MHz   NO_HT 0          GI 0-8
3.23.15X.19X    3.23.15X.12X    08/11/25 22:35:45    11         12231995
2734350012           20 MHz   NO_HT 0          GI 0-8
4.23.15X.12X    4.23.18X.80     08/11/25 22:35:46    34         9667683
2184097058           20 MHz   NO_HT 0          GI 0-8
4.23.18X.80     4.23.15X.12X    08/11/25 22:35:45    32         11830571
2672218215           20 MHz   NO_HT 0          GI 0-8
Tx statistics
Source          Destination    Timestamp           Transmitted-Packets   Retries
    Bytes              BW        MCS  MCS-Index  gi
-------------------------------------------------------------------------------------------
3.23.15X.12X    3.23.15X.19X    01/01/70 05:30:00    0                     0
     0                    20 MHz   NO_HT 0      GI 0-8
3.23.15X.19X    3.23.15X.12X    01/01/70 05:30:00    0                     0
     0                    20 MHz   NO_HT 0      GI 0-8
4.23.15X.12X    4.23.18X.80     01/01/70 05:30:00    0                     0
     0                    20 MHz   NO_HT 0      GI 0-8
4.23.18X.80     4.23.15X.12X    01/01/70 05:30:00    0                     0
     0                    20 MHz   NO_HT 0      GI 0-8
```

show ap name wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point and to display WLAN statistics, use the **show ap name wlan** command.

show ap name *ap-name* **wlan** {**dot11** {**24ghz** | **5ghz**} | **statistic**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays 802.11b network settings.
5ghz	Displays 802.11a network settings.
statistic	Displays WLAN statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display BSSID information of an access point in an 802.11b network:

```
Device# show ap name AP01 wlan dot11 24ghz

Site Name                                       : default-group
Site Description                                :

WLAN ID  Interface  BSSID
-------------------------------------
1        default    00:00:20:00:02:00
12       default    00:00:20:00:02:0b
```

This example shows how to display WLAN statistics for an access point:

```
Device# show ap name AP01 wlan statistic

WLAN ID  : 1
WLAN Profile Name  : maria-open

   EAP Id Request Msg Timeouts           : 0
   EAP Id Request Msg Timeouts Failures  : 0
   EAP Request Msg Timeouts              : 0
   EAP Request Msg Timeouts Failures     : 0
   EAP Key Msg Timeouts                  : 0
   EAP Key Msg Timeouts Failures         : 0


WLAN ID  : 12
WLAN Profile Name  : 24
```

```
EAP Id Request Msg Timeouts           : 0
EAP Id Request Msg Timeouts Failures  : 0
EAP Request Msg Timeouts              : 0
EAP Request Msg Timeouts Failures     : 0
EAP Key Msg Timeouts                  : 0
EAP Key Msg Timeouts Failures         : 0
```

show ap name wlan dot11 6ghz

To display 802.11be profile parameters with MLO mapping, run the **show ap name** *row-AP-11be* **wlan dot11 6ghz** command.

show ap name *row-AP-11be* **wlandot11 6ghz**

Syntax Description

row-AP-11be	Specifies the AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to display 802.11be profile parameters with MLO mapping:

```
Device# show ap name row-AP-11be wlan dot11 6ghz
Slot id  : 2
  * Tx-VAP WLAN of MBSSID set
  WLAN ID    BSSID          MLD MAC                MBSSID SET ID
  ------------------------------------------------------------
  4          ecf4.0caf.23e7 Disabled                1*
  5          ecf4.0caf.23e6 Disabled                1
  15         ecf4.0caf.23e5 Disabled                1
  9          ecf4.0caf.23e4 Disabled                1
  13         ecf4.0caf.23e3 Disabled                2*
  14         ecf4.0caf.23e2 Disabled                2
  1          ecf4.0caf.23ef eef4.0caf.23f8          3*
  7          ecf4.0caf.23eb eef4.0caf.23fc          4*
  10         ecf4.0caf.23ea eef4.0caf.23fd          4
  12         ecf4.0caf.23e9 eef4.0caf.23fe          4
  111        ecf4.0caf.23e8 eef4.0caf.23ff          4
```

show ap name wlan vlan

To display the operational WLAN-VLAN mappings for each access point (AP), use the **show ap name wlan vlan** command.

show ap name *ap_name* **wlan vlan**

Syntax Description

ap_name	Name of the AP whose WLAN-VLAN mappings are to be displayed.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

The following example shows the operational wlan vlan mappings for an AP:

```
Device# show ap name test wlan vlan

Policy tag mapping
------------------
WLAN Profile Name Name Policy    VLAN   Flex Central Switching  IPv4 ACL    IPv6 ACL
-------------------------------------------------------------------------------------
jey_cwa            pp-local-1     46       Enabled               jey_acl1   Not Configured
swaguest           pp-local-1     46       Enabled               jey_acl1   Not Configured
```

show ap name ble detail

To view the CMX associated with an AP, use the **show ap name ble detail** command.

show ap name *ap-name* **ble detail**

Syntax Description

ap-name	Specifies the name of the AP.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

This example shows how to display the global values for BLE and BLE details for a specific AP:

```
Device# show ap name AP4001.7AB2.C39A ble detail
CMX IP: 9.9.71.100
----------------------
  BLE administrative status: Up
  BLE operational status: Up
  Scanning interval: 10

  AP Name                          Interface             Status
  ------------------------------------------------------------------
  AP4001.7AB2.C39A                 Integrated            Open
```

show ap name temperature

To view the temperature information of an AP, use the **show ap name temperature** command.

show ap name *ap-name* **temperature**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Examples

This example shows how to view the temperature information of an AP:

```
Device# show ap name ap-3702 temperature
```

show ap management-mode meraki capability summary

To display the Meraki management mode capable AP information summary, use the **show ap management-mode meraki capability summary**

show ap management-mode meraki capability summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was modified.

Example

This example show how to display the Meraki management mode capable AP information summary:

```
Device# show ap management-mode meraki capability summary
```

show ap management-mode meraki change summary

To display the summary of the AP management mode meraki changes, use the **show ap management-mode meraki change summary** command.

show ap management-mode meraki change summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was modified.

Example

This example shows how to display the summary of the AP management mode meraki changes:

```
Device# show ap management-mode meraki change summary
```

show ap management-mode meraki failure summary

To display the Meraki management mode failure summary, use the **show ap management-mode meraki failure summary** command.

show ap management-mode meraki failure summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was modified.

Example

This example shows how to display the Meraki management mode failure summary:

```
Device# show ap management-mode meraki failure summary
```

show ap meraki monitoring summary

To view the AP registration status, use the **show ap meraki monitoring summary** command.

show ap meraki monitoring summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.15.1	This command was introduced.

Example

This example shows how to view the AP registration status:

```
Device# show ap meraki monitoring summary

Meraki Monitoring          : Enabled
Number of Supported APs    : 3

AP Name           AP Model        Radio MAC      MAC Address  AP Serial Number  Cloud ID
      Status
-------------------------------------------------------------------------------------------
APM-9164-1       CW9164I-ROW   10a8.29cf.e740 6849.9259.09d0 FGL2704LXZ5      Q5AN-2RAT-SZUE
   Registered
APM-9120-1       C9120AXI-D    1cd1.e0db.28a0 1cd1.e0d2.a4f0 FGL2532LNR7      Q2ZZ-FL9D-HL8Z
   Registered
APM-9136-1       C9136I-ROW    6cd6.e35c.17a0 4891.d5ef.8118 FGL2717MEFJ      Q2ZZ-VX3L-66MT
   Registered
```

show ap neighborhood

To view the AP neighborhood information, use the **show ap neighborhood** command.

show ap neighborhood *id* **details**

Syntax Description

id	Neighborhood ID.
details	Displays the neighborhood details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to view the AP neighborhood information:

```
Device# show ap neighborhood 0 details

NH-ID = Neighborhood ID
AREA-ID = Area ID of neighborhood

Number of APs: 1

NH-ID     AREA-ID          WNCD instance     AP Name              Ethernet MAC
-------------------------------------------------------------------------------
0         0x00000000       0                 APA023.9FD8.EA22     a023.9fd8.ea22
```

show ap neighborhood details

To view the AP neighborhood details, use the **show ap neighborhood details** command.

show ap neighborhood details

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to view the AP neighborhood details:

```
Device# show ap neighborhood details

NH-ID = Neighborhood ID
AREA-ID = Area ID of neighborhood

Number of APs: 4

NH-ID   AREA-ID        WNCD instance    AP Name                 Ethernet MAC
-------------------------------------------------------------------------------
0       0x00000000     1                EDU_BR_01_00_28_3702    bc16.6509.bfcc
1       0x00000000     0                ci-glad-mdns-ap         0cd0.f894.567c
1       0x00000000     0                EDU_VW_9120_1_2         c4f7.d54c.f978
2       0x00000000     0                ewlc-hc-tsim-30-1       00b9.3000.02f0
```

show ap neighborhood mac details

To view the AP neighborhood details using MAC address, use the **show ap neighborhood mac details** command.

show ap neighborhood mac *mac-address* **details**

Syntax Description

mac-address	AP's MAC address.
details	Specifies the AP neighborhood details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Example

The following example shows how to view the AP neighborhood details using MAC address:

```
Device# show ap neighborhood mac 0aa8.89f0.0001 details

NH-ID = Neighborhood ID
AREA-ID = Area ID of neighborhood

AP Name            Ethernet MAC    Radio MAC       NH-ID  AREA-ID     WNCD instance
-------------------------------------------------------------------------------------
AP6B8B4567-0001    0aa8.89f0.0001  0aa8.8900.0100  0      0x00000000  0
```

show ap neighborhood summary

To view the AP neighborhood summary, use the **show ap neighborhood summary** command.

show ap neighborhood summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to view the AP neighborhood summary:

```
Device# show ap neighborhood summary

NH-ID = Neighborhood ID
AREA-ID = Area ID of neighborhood

Total number of neighborhood: 5
Total number of algorithm iterations: 1
Ideal AP capacity per WNCD instance: 210

Total number of neighborhood area: 14

NH-ID      AREA-ID         Process Name   Number of APs
-------------------------------------------------
0          0x00000000      WNCD_1         1
1          0x00000000      WNCD_0         2
2          0x00000000      WNCD_0         100
2          0x00000001      WNCD_0         100
2          0x00000002      WNCD_3         100
2          0x00000003      WNCD_4         50
3          0x00000000      WNCD_1         100
3          0x00000001      WNCD_1         100
3          0x00000002      WNCD_4         100
3          0x00000003      WNCD_4         50
4          0x00000000      WNCD_2         100
4          0x00000001      WNCD_2         100
4          0x00000002      WNCD_3         100
4          0x00000003      WNCD_3         50
```

show ap profile

To see overall status of Hyperlocation for an AP profile, use the **show ap profile** command.

show ap profile *profile-name* {**detailed** | **hyperlocation** {**ble-beacon** | **detail** | **summary**}} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

profile-name	AP profile name.
detailed	Shows the detailed parameters of the AP join profile.
hyperlocation	Shows Hyperlocation information for the AP profile.
ble-beacon	Show the list of configured BLE beacons for the AP profile.
detail	Shows detailed status of Hyperlocation for the AP profile.
summary	Shows overall status of Hyperlocation for the AP profile
chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the overall status of Hyperlocation for an AP profile:

```
Device# show ap profile my-ap-profile detailed
```

show ap profile name detailed

To verify the status of the CAPWAP message aggregation feature, use the **show ap profile name detailed** command.

show ap profile name *profile-name* **detailed**

Syntax Description

profile-name	Specifies the AP profile name.
detailed	Shows the detailed parameters of the AP join profile.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.14.1	This command was introduced.

Examples

The following command displays the status of the CAPWAP message aggregation feature.

```
Device# show ap profile name default-ap-profile detailed

AP Profile Name               : default-ap-profile
Description                   : default custom profile
Country code                  : Not configured
Stats Timer                   : 180
Link Latency                  : ENABLED
Data Encryption               : DISABLED
LED State                     : ENABLED
NTP server                    : 0.0.0.0
NTP Authentication            : DISABLED
Jumbo MTU                     : ENABLED
24ghz Report Interval         : 90
5ghz Report Interval          : 90
bssid stats status            : ENABLED
bssid stats frqncy interval   : 120
bssid neighbor stats status   : ENABLED
bssid neighbor stats interval : 120
CAPWAP Control Aggregation    : ENABLED
```

show ap profile name wat-ap-profile detailed

To view the status of AP join profile detailed parameters, use the **show ap profile name wat-ap-profile detailed** command.

show ap profile name wat-ap-profile detailed

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

This example shows the status of AP join profile detailed parameters in the privileged EXEC mode:

```
Device# show ap profile name wat-ap-profile detailed
…
Proxy :
  Hostname                    : http://173.36.224.109
  Port                        : 80
  NO_PROXY list               : Not Configured
  Username                    : Not Configured
…
```

show ap regulatory activation

To verify the AP regulatory domain activation details, use the **show ap regulatory activation** command.

show ap regulatory activation { **all** | **mac** *mac-address* }

Syntax Description

all	Specifies all the regulatory domain details for all APs.
mac *mac-address*	Specifes the regulatory domain details of a specific AP.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE 17.15.1	This command was introduced.

Examples

The following example shows you how to verify the AP regulatory domain activation details:

```
Device# show ap regulatory activation all
```

show ap rf-profile name

To display the selected AP RF profile details, use the **show ap rf-profile name** command.

show ap rf-profile name *profile-name* **detail**

Syntax Description

profile-name	Specifies the name of the RF profile
detail	Displays the details of the selected RF profile

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Cisco IOS XE 17.17.1	This command output was modified.

Examples

This example shows how to display the details of the selected RF profile:

```
Device# show ap rf-profile name test detail

A-MPDU Window                     : 255
Zero Wait DFS                     : Disabled
UNII-3 Low Power Channels         : Disabled
Preamble Puncturing               : Disabled
Packets Retries Settings:
Management Retries                : -1
Aggregate Retries                 : -1
Non_Aggregate Retries             : -1
```

show ap rf-profile summary

To display the ap RF-Profile summary, use the **show ap rf-profile summary** command.

show ap rf-profile summary

Syntax Description

summary	Show summary of RF Profiles

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to display the ap RF-Profile summary .

```
Device#show ap rf-profile summary
Number of RF Profiles : 1

RF Profile Name                  Band      Description           Applied   State
------------------------------------------------------------------------------
doctest                          2.4 GHz                         No        Down
```

show ap sensor status

To display the details of the AP sensors and their status, use the **show ap sensor status** command.

show ap sensor status

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.8.1	This command was introduced.

Example

The following example displays the details of the AP sensors and their status:

```
Device# show ap sensor status
```

show ap summary

To display the status summary of all Cisco lightweight access points attached to the device, use the **show ap summary** command.

show ap summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Use this command to display a list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the device port number.

This example shows how to display a summary of all connected access points:

```
Controller# show ap summary

Number of APs: 1

Global AP User Name: Cisco
Global AP Dot1x User Name: Not configured

AP Name                          AP Model  Ethernet MAC    Radio MAC       State
-----------------------------------------------------------------------------------
3602a                            3502I     003a.99eb.3fa8  d0c2.8267.8b00  Registered
```

show ap summary load-info

To view the AP per radio channel utilization and the total number of clients and slots per AP, use the **show ap summary load-info** command.

show ap summary load-info

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Example

This example shows how to view the AP per radio channel utilization and the total number of clients and slots per AP:

```
Device# show ap summary load-info

WTP-Mac         AP-Name          Tot-Slots Tot-Clients  Slot0                  Slot1
            Slot2
                                                       Clients Utilisation(%) Clients
Utilisation(%)  Clients Utilisation(%)
-------------------------------------------------------------------------------------------------

04eb.409e.a5c0  AP04EB.409E.07EC 3         0            0       99             0       63
            0       0
1880.90fd.6b40  paxxxxi-AP       2         0            0       0              0       0
            NA      NA
```

show ap summary sort name

To view the access point (AP) summary sorted by name, use the **show ap summary sort name** command.

show ap summary sort name

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

This example shows how to view the AP summary sorted by name:

```
Device# show ap summary sort name
Number of APs: 05
AP Name          Slots  AP Model          Ethernet MAC    Radio MAC       Location
Country  IP Address  State
-------------------------------------------------------------------------------------------------
ABC              2    AIR-AP1832I-D-K9   2c0b.e9b6.3618  2c0b.e9b7.3ec0  Real-AP-Testbed
IN      1.2.22.222  Registered
AP-Farm-1832I-4  2    AIR-AP1832I-D-K9   2c0b.e9b6.3e58  2c0b.e9b7.5fc0  Real-AP-Testbed
IN      1.2.22.22   Registered
AP-Farm-1832I-5  2    AIR-AP1832I-D-K9   2c0b.e9b6.3f60  2c0b.e9b7.63e0  Real-AP-Testbed
IN      1.2.22.22   Registered
AP-Farm-1832I-6  2    AIR-AP1832I-D-K9   2c0b.e9b6.3fe8  2c0b.e9b7.6600  Real-AP-Testbed
IN      1.2.22.22   Registered
AP-Farm-1832I-7  2    AIR-AP1832I-D-K9   2c0b.e9b6.4010  2c0b.e9b7.66a0  Real-AP-Testbed
IN      1.2.22.222
```

show ap summary sort ascending client-count

To view the AP summary sorted ascendingly based on the client count, use the **show ap summary sort ascending client-count** command.

show ap summary sort ascending client-count

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted ascendingly based on the client count:

```
Device# show ap summary sort ascending client-count
------------------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
------------------------------------------------------------------------------------------------------------
L2_3802I_1                       7872.5d27.b8c0       1                    622358
      11            Enabled
L2_1815w_1                       707d.b99e.c2e0       2                    5871836
      1422          Enabled
```

show ap summary sort ascending data-usage

To view the AP summary sorted ascendingly based on the data usage, use the **show ap summary sort ascending data-usage** command.

show ap summary sort ascending data-usage

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted ascendingly based on the data usage:

```
Device# show ap summary sort ascending data-usage
-------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
-------------------------------------------------------------------------------------------------
L2_3802I_1                       7872.5d27.b8c0       1                     622600
      4             Enabled
L2_1815w_1                       707d.b99e.c2e0       2                     6102216
      281           Enabled
```

show ap summary sort ascending throughput

To view the AP summary sorted ascendingly based on the throughput, use the **show ap summary sort ascending throughput** command.

show ap summary sort ascending throughput

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted ascendingly based on the throughput:

```
Device# show ap summary sort ascending throughput
-------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
-------------------------------------------------------------------------------------------------
L2_3802I_1                       7872.5d27.b8c0       1                    6749385
      6             Enabled
L2_1815w_1                       707d.b99e.c2e0       2                    94748042
      35            Enabled
```

show ap summary sort descending client-count

To view the AP summary sorted descendingly based on the client count, use the **show ap summary sort descending client-count** command.

show ap summary sort descending client-count

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the client count:

```
Device# show ap summary sort descending client-count
------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
------------------------------------------------------------------------------------------------
L2_1815w_1                       707d.b99e.c2e0       2                     94753989
      46            Enabled
L2_3802I_1                       7872.5d27.b8c0       1                     6750526
      6             Enabled
```

show ap summary sort descending data-usage

To view the AP summary sorted descendingly based on the data usage, use the **show ap summary sort descending data-usage** command.

show ap summary sort descending data-usage

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the data usage:

```
Device# show ap summary sort descending data-usage
------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
------------------------------------------------------------------------------------------------
L2_1815w_1                       707d.b99e.c2e0       2                    94756618
      47            Enabled
L2_3802I_1                       7872.5d27.b8c0       0                    6750526
      6             Enabled
```

show ap summary sort descending throughput

To view the AP summary sorted descendingly based on the throughput, use the **show ap summary sort descending throughput** command.

show ap summary sort descending throughput

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the throughput:

```
Device# show ap summary sort descending throughput
------------------------------------------------------------------------------------------------
AP-name                          AP-mac           Client count          Data Usage
  Through-Put     Admin-State
------------------------------------------------------------------------------------------------
L2_1815w_1                       707d.b99e.c2e0       2                     94758750
      23            Enabled
L2_3802I_1                       7872.5d27.b8c0       0                     6750526
      6             Enabled
```

show ap support-bundle summary

To display the summary of the AP support-bundle, use the **show ap support-bundle summary** command.

show ap support-bundle summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privilege EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Example

This examples displays the summary of the AP support-bundle:

```
Device# show ap support-bundle summary
```

show ap tag sources

To see AP tag sources with priorities, use the **show ap tag sources** command.

show ap tag sources [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP tag sources with priorities for the active instance:

```
Device# show ap tag sources chassis active R0
```

show ap tag summary

To view brief summary of tag names, use the **show ap tag summary** command.

show ap tag summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to view brief summary of tag names:

```
Device# show ap tag summary
```

show ap triradio summary

To view the tri-radio summary, and to verify if the slots are enabled and up, use the **show ap triradio summary** command.

show ap triradio summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privilege EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example displays the tri-radio summary, and to verify if the slots are enabled:

```
Device# show ap triradio summary
```

show ap timezone

To check the AP timezone information, use the **show ap timezone** command.

show ap timezone

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to check the AP timezone information:

```
Device# show ap timezone

AP Name   Status     Offsets(h/m)
--------------------------------
AP1       Disabled    0:0
AP2       Enabled     1:0
```

show ap upgrade

To see AP upgrade information, use the **show ap upgrade** command.

show ap upgrade [**name** *ap-upgrade-report-name* | **summary** | **chassis** {*chassis-number* | **active** | **standby**}]

Syntax Description

name *ap-upgrade-report-name*	Enter the name of the AP upgrade report.
summary	Shows a summary of AP upgrade information.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	Support was added for **serial** and **1%** percent batch sizes.
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The example displays output from a staggered upgrade in which the batch size is set to one percent of APs per iteration.

```
Device# show ap upgrade

Status: Complete
From version: 17.19.0.9
To version: 17.19.0.9

Started at: 12/19/2025 18:01:38 IST
Configured percentage: One AP at a time
Percentage complete: 100
End time: 12/19/2025 18:01:38 IST

Client steering: Enabled
Client de-authentication: Enabled
Accounting percentage: 90%
Iteration expiry time: 9 minutes

Progress Report
---------------
Iterations
----------
```

```
Iteration              Start time                          End time                    AP
count
-------------------------------------------------------------------------------------------
0                      12/19/2025 18:01:38 IST             12/19/2025 18:01:38 IST     1

Upgraded
-------
--------
Number of APs: 3
AP Name                          Radio MAC               Iteration       Status
    Site
-------------------------------------------------------------------------------------------------------
AP00F2.8B27.BB2C                 0896.ad9b.f9e0          0               Joined
    default-site-tag
AP4C77.6D92.C654                 00be.7570.06a0          1               Joined
    default-site-tag
APA0F8.49DC.0F78                 a0f8.49dc.9780          2               Joined
    default-site-tag

Failed
------
Number of APs: 0
AP Name                          Radio MAC               Iteration
-----------------------------------------------------------------

In Progress
-----------
Number of APs: 0
AP Name                          Radio MAC
-------------------------------------------------
```

Note

- The **Configured Percentage** field is not available for the destination controller during an N+1 upgrade.
- The **Iterations** section does not appear for serial upgrades because serial upgrades do not include iterations.

show ap upgrade method

To verify the status of the configuration of the image download over HTTPS method, use the **show ap upgrade method** command.

show ap upgrade method

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to verify the status of HTTPS image download configuration:

```
Device# show ap upgrade method

AP upgrade method https : Enabled
```

show arp

To view the ARP table, use the **show arp** command.

show arp

Syntax Description

arp	Shows ARP table

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

The following example shows a sample output of the command:

```
Device# show arp

Address Age (min)     Hardware Addr
   9.11.8.1         0 84:80:2D:A0:D2:E6
9.11.32.111         0 3C:77:E6:02:33:3F
```

show arp summary

To see the ARP table summary, use the **show arp summary** command.

show arp summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the ARP table summary:

```
Device# show arp summary
```

show ap name *ap-name* meraki connect

To view the Meraki connect information of a Cisco AP, use the **show ap name** *ap-name* **meraki connect** command.

show ap name *ap-name* **meraki connect**

Syntax Description

Keywords and Variables	Description
ap-name	Access point name

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.17.1	This command was introduced in a release earlier than Cisco IOS XE 17.17.1.

Usage Guidelines

You can see the corresponding AP-side information by using the **show cloud monitor connections** command on the AP.

The following is the output of the **show ap name** *ap-name* **meraki connect** command.

```
Device# show ap name APC414.A2D2.7600 meraki connect

Meraki Tunnel Config
------------------------------------------------
Fetch State      : Fetch Succeeded
Fetch Fail       :
Last Fetch       : 06/10/2025 20:19:32 UTC
Next Fetch       : 06/10/2025 21:47:52 UTC
Config Server    : test.io
Primary          : test.io
Secondary        : test.io
Client IPv6 Addr : FE80:9b09:1f7:1:c614:a2ff:fed2:7600

    Meraki Tunnel State
    ---------------------------------------------------
    Primary                    : Up
    Secondary                  : Up
    Primary Last Change        : 06/10/2025 16:31:03 UTC
    Secondary Last Change      : 06/10/2025 16:31:03 UTC
    Client Last Restart        : 06/10/2025 16:30:57 UTC

Meraki Tunnel Interface
-------------------------------------------------
Status                      : ENABLED

Meraki Device Registration
-------------------------------------------------
```

```
AP Model                    : CW9176I
Serial Number               : ABCDEFGHIJ
Cloud ID                    : XYZZ-BBBB-DDDD
Mac Address                 : aaaa.bbbb.cccc
Status                      : Registered
```

Detailed description of the output fields are in the tables:

Table 1: Meraki AP Connection & Status Fields

Field	Description
Fetch State	Status of the most recent configuration fetch attempt by the AP from the Meraki server.
Fetch Fail	Indicates the reason for the last fetch failure, if any. This field is blank when the last fetch succeeded.
Last Fetch	Date and time when the last configuration fetch was performed.
Next Fetch	Date and time when the next scheduled configuration fetch is expected.
Config Server	Hostname of the Meraki configuration server the AP communicates with.
Primary	Hostname of the primary Meraki tunnel server.
Secondary	Hostname of the secondary Meraki tunnel server.
Client IPv6 Addr	IPv6 address assigned to the AP's Meraki tunnel client interface.

Table 2: Meraki Tunnel State

Field	Description
Primary	Current state of the primary Meraki tunnel server. Possible values are **Up** or **Down**.
Secondary	Current state of the secondary Meraki tunnel server. Possible values are **Up** or **Down**.
Primary Last Change	Timestamp of the last status change (**Up** or **Down**) for the primary tunnel.
Secondary Last Change	Timestamp of the last status change (**Up** or **Down**) for the secondary tunnel.
Client Last Restart	Timestamp when the tunnel client process last restarted.

Table 3: Meraki Tunnel Interface

Field	Description
Status	Indicates whether the Meraki tunnel interface is **ENABLED** or **DISABLED** on the AP.

Table 4: Meraki Device Registration

Field	Description
AP Model	Model number of the access point.
Serial Number	Hardware serial number of the AP.
Cloud ID	Unique Meraki cloud identifier for the AP.
Mac Address	MAC address of the AP shown in hexadecimal notation.
Status (Registration)	Indicates the Meraki cloud registration status of the AP.

show ap tunnel eogre events

To display the Ethernet over GRE (EoGRE) tunnel events, use the **show ap tunnel eogre events** command.

show ap tunnel eogre events

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the EoGRE tunnel events:

```
Device# show ap tunnel eogre events

AP 80e8.6fd4.9520  Event history
Timestamp               #Times   Event               RC Context
----------------------- -------- ------------------- --
----------------------------------------
02/18/2019 23:50:26.341 6        IAPP_STATS           0 GW Tunnel2 uptime:0s

02/18/2019 23:49:40.222 2        CLIENT_JOIN         0 74da.3828.88b0, (eogre_domain/2121)

02/18/2019 23:48:43.549 1        CLIENT_LEAVE        0 74da.3828.88b0, (eogre_domain/2121)

02/18/2019 23:47:33.127 1        DOMAIN_STATUS        0 eogre_domain Active GW: Tunnel1

02/18/2019 23:47:33.124 4        AP_TUNNEL_STATUS     0 Tunnel2 Dn

02/18/2019 23:47:33.124 1        MSG_CLIENT_DEL       0 GW Tunnel2 (IP: 9.51.1.12)

02/18/2019 23:47:33.124 2        TUNNEL_ADD           0 GW Tunnel2

02/18/2019 23:47:33.120 3        MSG_CLIENT_DEL_PD    0 GW Tunnel1 (IP: 9.51.1.11)

02/18/2019 23:47:31.763 2        AP_DOMAIN_PUSH       0 Delete:eogre_domain_set, 0 GWs

02/18/2019 23:47:31.753 4        AP_VAP_PUSH          0 profile:'eogre_tunnel',
wlan:pyats_eogre
```

show ap tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain status on an AP, use the **show ap tunnel eogre domain detailed** command.

show ap tunnel eogre domain detailed *domain-name*

Syntax Description

domain-name	EoGRE domain name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel domain status:

```
Device# show ap tunnel eogre domain detailed Tunnel1


Gateway : Tunnel1
 Mode   : IPv4
 IP     : 9.51.1.11
 State  : Up
 MTU    : 1476
 Up Time: 14 hours 25 minutes 2 seconds
 AP MAC : 80e8.6fd4.9520

 Clients
  Total Number of Wireless Clients      : 1
 Traffic
  Total Number of Received Packets      : 6
  Total Number of Received Bytes        : 2643
  Total Number of Transmitted Packets   : 94
  Total Number of Transmitted Bytes     : 20629
  Total Number of Lost Keepalive        : 3
```

show ap name tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain on an AP, use the **show ap nametunnel eogre domain summary** command.

show ap name *ap-name* **tunnel eogre domain summary**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel domain on an AP:

```
Device# show ap name ap1 tunnel eogre domain summary

AP MAC          Domain                          Active Gateway
-----------------------------------------------------------------------------
80e8.6fd4.9520  eogre_domain                    Tunnel1
```

show ap tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel gateway status on an AP, use the **show ap name tunnel eogre gateway detailed** command.

show ap name *ap-name* **tunnel eogre gateway detailed** *gateway-name*

Syntax Description

ap-name	AP name.
gateway-name	EoGRE domain name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel gateway status on an AP:

```
Device# show ap name ap1 tunnel eogre gateway detailed Tunnel1

Gateway : Tunnel1
 Mode   : IPv4
 IP     : 9.51.1.11
 State  : Up
 MTU    : 1476
 Up Time: 14 hours 25 minutes 2 seconds
 AP MAC : 80e8.6fd4.9520

 Clients
  Total Number of Wireless Clients      : 1
 Traffic
  Total Number of Received Packets      : 6
  Total Number of Received Bytes        : 2643
  Total Number of Transmitted Packets   : 94
  Total Number of Transmitted Bytes     : 20629
  Total Number of Lost Keepalive        : 3
```

show ap tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway, use the **show ap tunnel eogre gateway summary** command.

show ap tunnel eogre gateway summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel gateway:

```
Device# show ap tunnel eogre gateway summary

AP MAC          Gateway          Type  IP                                        State  Clients
-----------------------------------------------------------------------------------------------
80e8.6fd4.9520  Tunnel1           IPv4  9.51.1.11                                   Up     1

80e8.6fd4.9520  Tunnel2           IPv4  9.51.1.12                                   Down   0
```

show ap upgrade site

To view the upgrade site-related infromation, use the **show ap upgrade site** command.

show ap upgrade site [**summary**]

Syntax Description

summary	(Optional) Displays a summary of access point (AP) upgrade on individual sites.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Examples

The following example shows how to view the upgrade site-related infromation:

```
Device# show ap upgrade site

Site-filtered AP upgrade report data
====================================
Source controller: Controller1
Destination controller: Controller2
Site-filters present: Yes

AP image upgrade site summary
-----------------------------
Operation: N+1 move

Site Tag                                    Status
------------------------------------------------------------
site1                                       In Progress

AP upgrade reports linked to these site-filters
-----------------------------------------------

Start time               Operation type             Report name
-------------------------------------------------------------------------------
01/30/2022 10:34:36 IST  AP image upgrade/move CLI  AP_upgrade_to_Controller2_3002022103435
```

show ap wlan summary

To display WLAN downgrade summary from 802.11be to 802.11ax mode, run the **show ap wlan summary** command.

show ap wlan summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to display WLAN downgrade summary from 802.11be to 802.11ax mode:

```
Device# show ap wlan summary
ecf4.0caf.23e1  wpa3owe                              wpa3owe
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                              24ghz-EHT
               Local            1485            23:31:01          *2/7
(11 dBm)    (1)*                                    7 days 22 hours 55
minutes 49 seconds                 23 hours 31 minutes 4 seconds
                 HE                                  Cipher Not Met

ecf4.0caf.23e5  mbssid-10                            mbssid-10
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                              24ghz-EHT
               Local            1485            23:31:01          *2/7
(11 dBm)    (1)*                                    7 days 22 hours 55
minutes 49 seconds                 23 hours 31 minutes 4 seconds
                 HE                                   AKM Not Met

ecf4.0caf.23e7  mdns-psk                             PSKWLAN
            Enabled        00:19:56          0             row-AP-11be
                      8.31.237.183                              24ghz-EHT
               Local            1485            23:31:01          *2/7
(11 dBm)    (1)*                                    7 days 22 hours 55
minutes 49 seconds                 23 hours 31 minutes 4 seconds
                 HE                                   PMF Required

ecf4.0caf.23e9  mbssid-4                             mbssid-4
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                              24ghz-EHT
```

```
               Local            1485             23:31:01          *2/7
(11 dBm)   (1)*                                      7 days 22 hours 55
minutes 49 seconds                 23 hours 31 minutes 4 seconds
                HE                                    PMF Required

ecf4.0caf.23ea  mixed-mode-1                         mixed-mode
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             24ghz-EHT
               Local            1485             23:31:01          *2/7
(11 dBm)   (1)*                                      7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                    AKM Not Met

ecf4.0caf.23ed  mbssid-6                             mbssid-6
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             24ghz-EHT
               Local            1485             23:31:01          *2/7
(11 dBm)   (1)*                                      7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                   NA

ecf4.0caf.23ee  mbssid-8                             mbssid-8
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             24ghz-EHT
               Local            1485             23:31:01          *2/7
(11 dBm)   (1)*                                      7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                   NA

ecf4.0caf.23ef  wpa3sae                              wpa3sae
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             5ghz-EHT
              Local            1485            23:31:01          *2/8
(16 dBm)   (64)*                                     7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                    AKM Not Met

ecf4.0caf.23ed  mbssid-1                             mbssid-1
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             5ghz-EHT
              Local            1485            23:31:01          *2/8
(16 dBm)   (64)*                                     7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                    Cipher Not Met

ecf4.0caf.23ec  mbssid-5                             mbssid-5
            Enabled        00:20:52          0             row-AP-11be
                      8.31.237.183                             5ghz-EHT
              Local            1485            23:31:01          *2/8
(16 dBm)   (64)*                                     7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
```

```
                HE                                  AKM Not Met

ecf4.0caf.23eb  mbssid-9                            mbssid-9
            Enabled        00:20:52          0              row-AP-11be
                      8.31.237.183                              5ghz-EHT
              Local            1485             23:31:01          *2/8
(16 dBm)    (64)*                                    7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                  AKM Not Met

ecf4.0caf.23ea  mbssid-10                           mbssid-10
            Enabled        00:20:52          0              row-AP-11be
                      8.31.237.183                              5ghz-EHT
              Local            1485             23:31:01          *2/8
(16 dBm)    (64)*                                    7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                  AKM Not Met

ecf4.0caf.23e9  mbssid-b                            mbssid-b
            Enabled        00:20:52          0              row-AP-11be
                      8.31.237.183                              5ghz-EHT
              Local            1485             23:31:01          *2/8
(16 dBm)    (64)*                                    7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                 NA

ecf4.0caf.23e8  mdns-psk                            PSKWLAN
            Enabled        00:19:56          0              row-AP-11be
                      8.31.237.183                              5ghz-EHT
              Local            1485             23:31:01          *2/8
(16 dBm)    (64)*                                    7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                  PMF Required

ecf4.0caf.23e7       -open                          -open
        Enabled        00:20:53          0             row-AP-11be
                  8.31.237.183                              5ghz-EHT
          Local            1485            23:31:02          *2/8 (16
dBm)   (64)*                                   7 days 22 hours 55 minutes
 50 seconds                 23 hours 31 minutes 5 seconds
          EHT                                NA

ecf4.0caf.23e6  mbssid-4                            mbssid-4
            Enabled        00:20:53          0              row-AP-11be
                      8.31.237.183                              5ghz-EHT
              Local            1485             23:31:02          *2/8
(16 dBm)    (64)*                                    7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                  PMF Required

ecf4.0caf.23e5  mixed-mode-1                        mixed-mode
```

```
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               5ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (64)*                                 7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 HE                                AKM Not Met

ecf4.0caf.23e3  mbssid-3                          mbssid-3
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               5ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (64)*                                 7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 EHT                               NA

ecf4.0caf.23e2  mbssid-6                          mbssid-6
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               5ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (64)*                                 7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 EHT                               NA

ecf4.0caf.23e7  wpa3sae                           wpa3sae
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               6ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (69,65,73,77)*                        7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 HE                                AKM Not Met

ecf4.0caf.23e6  wpa3owe                           wpa3owe
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               6ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (69,65,73,77)*                        7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 HE                                Cipher Not Met

ecf4.0caf.23e5  mbssid-1                          mbssid-1
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               6ghz-EHT
              Local            1485            23:31:02          *2/8
(16 dBm)    (69,65,73,77)*                        7 days 22 hours 55
minutes 50 seconds                23 hours 31 minutes 5 seconds
                 HE                                Cipher Not Met

ecf4.0caf.23e4  mbssid-5                          mbssid-5
            Enabled        00:20:53          0             row-AP-11be
                     8.31.237.183                               6ghz-EHT
              Local            1485            23:31:02          *2/8
```

```
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                      AKM Not Met

ecf4.0caf.23e3  mbssid-9                               mbssid-9
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                  6ghz-EHT
              Local             1485             23:31:02          *2/8
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                      AKM Not Met

ecf4.0caf.23e2  mbssid-10                              mbssid-10
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                  6ghz-EHT
              Local             1485             23:31:02          *2/8
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                HE                                      AKM Not Met

ecf4.0caf.23ef      -open                                -open
          Enabled        00:20:53          0              row-AP-11be
                   8.31.237.183                                  6ghz-EHT
            Local             1485             23:31:02          *2/8 (16
 dBm)   (69,65,73,77)*                                  7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                     NA

ecf4.0caf.23eb  mbssid-3                               mbssid-3
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                  6ghz-EHT
              Local             1485             23:31:02          *2/8
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                     NA

ecf4.0caf.23ea  mbssid-6                               mbssid-6
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                  6ghz-EHT
              Local             1485             23:31:02          *2/8
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                     NA

ecf4.0caf.23e9  mbssid-8                               mbssid-8
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                  6ghz-EHT
              Local             1485             23:31:02          *2/8
(16 dBm)   (69,65,73,77)*                              7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                EHT                                     NA
```

```
ecf4.0caf.23e8  mbssid-a                              mbssid-a
            Enabled        00:20:53          0              row-AP-11be
                     8.31.237.183                                 6ghz-EHT
              Local            1485              23:31:02           *2/8
(16 dBm)    (69,65,73,77)*                            7 days 22 hours 55
minutes 50 seconds                 23 hours 31 minutes 5 seconds
                 EHT                                  NA
```

show avc client

To display information about top number of applications, use the **show avc client** command in privileged EXEC mode.

show avc client *client-mac* **top** *n* **application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

client *client-mac*	Specifies the client MAC address.
top *n* **application**	Specifies the number of top "N" applications for the given client.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show avc client** command:

```
Device# sh avc client 0040.96ae.65ec top 10 application aggregate

Cumulative Stats:

No.  AppName      Packet-Count    Byte-Count       AvgPkt-Size     usage%
---------------------------------------------------------------------------
1    skinny          7343           449860           61              94
2    unknown         99             13631            137             3
3    dhcp            18             8752             486             2
4    http            18             3264             181             1
5    tftp            9              534              59              0
6    dns             2              224              112             0

Last Interval(90 seconds) Stats:

No.  AppName     Packet-Count     Byte-Count       AvgPkt-Size      usage%
---------------------------------------------------------------------------
1    skinny          9              540              60               100
```

show avc wlan

To display information about top applications and users using the applications, use the **show avc wlan** command in privileged EXEC mode.

show avc wlan *ssid* **top** *n* **application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

wlan *ssid*	Specifies the Service Set IDentifier (SSID) for WLAN.
top *n* **application**	Specifies the number of top "N" applications.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show avc wlan** command:

```
Device# show avc wlan Lobby_WLAN top 10 application aggregate

Cumulative Stats:

No.  AppName           Packet-Count          Byte-Count          AvgPkt-Size  usage%
-------------------------------------------------------------------------------------
1    ssl                10598677              1979525706           997          42
2    vnc                5550900               3764612847           678          14
3    http               3043131               2691327197           884          10
4    unknown            1856297               1140264956           614          4
5    video-over-http    1625019               2063335150           1269         8
6    binary-over-http   1329115               1744190344           1312         6
7    webex-meeting      1146872               540713787            471          2
8    rtp                923900                635650544            688          2
9    unknown            752341                911000213            1210         3
10   youtube            631085                706636186            1119         3

Last Interval(90 seconds) Stats:

No.  AppName          Packet-Count          Byte-Count            AvgPkt-Size  usage%
-------------------------------------------------------------------------------------
1    vnc                687093                602731844            877          68
2    video-over-http    213272                279831588            1312         31
3    ssl                6515                  5029365              771          1
4    webex-meeting      3649                  1722663              472          0
5    http               2634                  1334355              506          0
6    unknown            1436                  99412                69           0
7    google-services    722                   378121               523          0
8    linkedin           655                   393263               600          0
9    exchange           432                   167390               387          0
10   gtalk-chat         330                   17330                52           0
```

show awips wlc-alarm

To view the contents of the AWIPS WLC Alarm table, use the **show awips wlc-alarm** command.

show awips wlc-alarm

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced

Examples

The following example shows how to view the contents of the AWIPS WLC Alarm table:

```
Device# show awips wlc-alarm

Time                 BSSID           Client MAC      Alarm description
------------------------------------------------------------
04/02/2020 16:03:18  e4aa.5d53.b921  74da.3864.2a94  WPA2 Key Reinstal KRACK
04/02/2020 16:03:19  e4aa.5d53.b921  74da.3864.2a94  WPA2 Key Reinstal KRACK
04/02/2020 16:03:20  e4aa.5d53.b921  74da.3864.2a94  WPA2 Key Reinstal KRACK
04/02/2020 16:03:21  e4aa.5d53.b921  74da.3864.2a94  WPA2 Key Reinstal KRACK
```

show awips syslog throttle

To verify the syslog configuration for Cisco Advanced Wireless Intrusion Prevention System (aWIPS), use the **show awips syslog throttle** command.

show awips syslog throttle

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

The following example shows how to verify the syslog configuration for aWIPS:

```
Device# show awips syslog throttle
Syslog Throttle Interval (seconds)
------------------------------------------------------------
60
```

show capwap client configuration

To view the indoor deployment mode in AP console, use the **show capwap client configuration** command.

show capwap client configuration

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Usage Guidelines

This command needs to be run on the AP console.

Examples

The following command verifies the indoor deployment mode in AP console.

```
cisco-ap# show capwap client configuration
AdminState                          : ADMIN_ENABLED(1)
Name                                : AP3C57.31C5.9478
Location                            : default location
Primary controller name             : Rack10_katar
Primary controller IP               : 9.4.100.5
.
.
.
Indoor Deployment                   : 2
!Indoor Deployment: 2 signifies that the AP is in Indoor mode.
!Indoor Deployment: 0 signifies that the AP is in Outdoor mode.
```

show capwap client rcb

To view the CAPWAP status and modes, use the **show capwap client rcb** command on the access point.

show capwap client rcb

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Example

This example shows how to view the CAPWAP status and modes on the access point:

```
AP# show capwap client rcb

OperationState                     : UP
Name                               : AP4001.7A39.2D5A
MwarHwVer                          : 0.0.0.0
Location                           : default location
ApMode                             : Remote Bridge
ApSubMode                          : Not Configured
CAPWAP Path MTU                    : 1485
Software Initiated Reload Reason   : Reload command
CAPWAP Sliding Window
Active Window Size                 : 10
Last Request Send To Application   : 184
Expected Seq Num                   : 185
Received Seq Num                   : 184
Request Packet Count               : 42424
Out Of Range Packets Count         : 0
Window Moved  Packets Count        : 0
In Range Packets Count             : 960
Expected Packets Count             : 41464
```

show chassis

To see the chassis information, use the **show chassis** command.

show chassis [*1 2* | **detail** | **mode** | **neighbors** | **ha-status** {**active** | **local** | **standby**}]

Syntax Description

{*1* | *2*}	Chassis number as 1 or 2 to see the information about the relevant chassis.
detail	Shows detailed information about the chassis.
mode	Shows information about the chassis mode.
neighbors	Shows information about the chassis neighbors.
ha-status	Option to see information about the High Availability (HA) status.
active	Shows HA status on the chassis that is in active state.
local	Shows HA status on the local chassis.
standby	Shows HA status on the chassis that is in standby state.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the HA status on the active chassis:

```
Device# show chassis ha-status active
```

show chassis rmi

To verify the chassis Redundancy Management Interface (RMI) configuration for an active controller, use the **show chassis rmi** command.

show chassis rmi

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1	This command was introduced.

This example shows how to verify the chassis Redundancy Management Interface (RMI) configuration for an active controller:

```
Device# show chassis rmi
Chassis/Stack Mac Address : 000c.2964.1eb6 - Local Mac Address
Mac persistency wait time: Indefinite
H/W Current
Chassis# Role Mac Address Priority Version State IP RMI-IP
---------------------------------------------------------------------------------------------
*1 Active 000c.2964.1eb6 1 V02 Ready 169.254.90.147 9.10.90.147
2 Standby 000c.2975.3aa6 1 V02 Ready 169.254.90.149 9.10.90.149
```

show checkpoint

To display information about the Checkpoint Facility (CF) subsystem, use the **show checkpoint** command.

show checkpoint { **clients** *client-ID <0-381>* | **entities***entity-ID <1-7>* | **statisticsbuffer-usage** }

Syntax Description

clients	Displays detailed information about checkpoint clients.
entities	Displays detailed information about checkpoint entities.
statistics	Displays detailed information about checkpoint statistics.
buffer-usage	Displays the checkpoint statistics of clients using large number of buffers.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display all the CF clients.

```
   Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_MOBILITY
    Client ID                  : 24105
    Total DB inserts           : 0
    Total DB updates           : 0
    Total DB deletes           : 0
    Total DB reads             : 0
    Number of tables           : 6
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_DOT1X
    Client ID                  : 24106
    Total DB inserts           : 2
    Total DB updates           : 1312
    Total DB deletes           : 2
    Total DB reads             : 0
    Number of tables           : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_APFROGUE
    Client ID                  : 24107
    Total DB inserts           : 0
    Total DB updates           : 0
    Total DB deletes           : 0
    Total DB reads             : 0
    Number of tables           : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_CIDS
    Client ID                  : 24110
    Total DB inserts           : 0
```

```
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 0
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_NETFLOW
    Client ID                   : 24111
    Total DB inserts            : 7
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_MCAST
    Client ID                   : 24112
    Total DB inserts            : 0
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: wcm_comet
    Client ID                   : 24150
    Total DB inserts            : 0
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 0
    Client residing in process  : 8135
------------------------------------------------------------------------------

All iosd checkpoint clients

------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
Network RF Client           3         --       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                0
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
```

```
                            ID         ID       Mode
-------------------------------------------------------------------------------
SNMP CF Client              12         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
  Buffers Held:                                   0
  Buffers Held Peak:                              0
  Huge Buffers Requested:                         0
  Transport Frag Count:                           0
  Transport Frag Peak:                            0
  Transport Sends w/Flow Off:                     0
  Send Errs:                                      0
  Send Peer Errs:                                 0
  Rcv Xform Errs:                                 0
  Xmit Xform Errs:                                0
  Incompatible Messages:                          0
  Client Unbundles to Process Memory:             T
-------------------------------------------------------------------------------
Client Name             Client     Entity     Bundle
                            ID         ID       Mode
-------------------------------------------------------------------------------
Online Diags HA             14         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
  Buffers Held:                                   0
  Buffers Held Peak:                              0
  Huge Buffers Requested:                         0
  Transport Frag Count:                           0
  Transport Frag Peak:                            0
  Transport Sends w/Flow Off:                     0
  Send Errs:                                      0
  Send Peer Errs:                                 0
  Rcv Xform Errs:                                 0
  Xmit Xform Errs:                                0
  Incompatible Messages:                          0
  Client Unbundles to Process Memory:             T
-------------------------------------------------------------------------------
Client Name             Client     Entity     Bundle
                            ID         ID       Mode
-------------------------------------------------------------------------------
ARP                         22         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
```

```
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
-------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
-------------------------------------------------------------------------------
Tableid CF                 27         --       Off

  Total API Messages Sent:                     0
  Total Transport Messages Sent:               0
  Length of Sent Messages:                     0
  Total Blocked Messages Sent:                 0
  Length of Sent Blocked Messages:             0
  Total Non-blocked Messages Sent:             0
  Length of Sent Non-blocked Messages:         0
  Total Bytes Allocated:                       0
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
-------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
-------------------------------------------------------------------------------
Event Manager              33          0       Off

  Total API Messages Sent:                     0
  Total Transport Messages Sent:               --
  Length of Sent Messages:                     0
  Total Blocked Messages Sent:                 0
  Length of Sent Blocked Messages:             0
  Total Non-blocked Messages Sent:             0
  Length of Sent Non-blocked Messages:         0
  Total Bytes Allocated:                       0
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
```

```
--------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
--------------------------------------------------------------------------------
LAN-Switch Port Mana       35          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
--------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
--------------------------------------------------------------------------------
LAN-Switch PAgP/LACP       36          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
--------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
--------------------------------------------------------------------------------
LAN-Switch VLANs           39          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
```

```
  Length of Sent Non-blocked Messages:           0
  Total Bytes Allocated:                         0
  Buffers Held:                                  0
  Buffers Held Peak:                             0
  Huge Buffers Requested:                        0
  Transport Frag Count:                          0
  Transport Frag Peak:                           0
  Transport Sends w/Flow Off:                    0
  Send Errs:                                     0
  Send Peer Errs:                                0
  Rcv Xform Errs:                                0
```

This example shows how to display all the CF entities.

```
KATANA_DOC#show checkpoint entities
                        Check Point List of Entities

 CHKPT on ACTIVE server.

------------------------------------------------------------------------------
Entity ID         Entity Name
------------------------------------------------------------------------------
        0         CHKPT_DEFAULT_ENTITY

  Total API Messages Sent:             0
  Total Messages Sent:                 0
  Total Sent Message Len:              0
  Total Bytes Allocated:               0
  Total Number of Members:            10

  Member(s) of entity 0 are:
    Client ID          Client Name
-----------------------------------------
          168          DHCP Snooping
          167          IGMP Snooping
           41          Spanning-tree
           40          AUTH MGR CHKPT CLIEN
           39          LAN-Switch VLANs
           33          Event Manager
           35          LAN-Switch Port Mana
           36          LAN-Switch PAgP/LACP
          158          Inline Power Checkpoint
```

This example shows how to display the CF statistics.

```
KATANA_DOC#show checkpoint statistics
        IOSd Check Point Status
 CHKPT on ACTIVE server.

Number Of Msgs In Hold Q:              0
CHKPT MAX Message Size:                0
TP MAX Message Size:               65503
CHKPT Pending Msg Timer:             100 ms

  FLOW_ON  total:                      0
  FLOW_OFF total:                      0
  Current FLOW status is:             ON
  Total API Messages Sent:             0
  Total Messages Sent:                 0
  Total Sent Message Len:              0
  Total Bytes Allocated:               0
  Rcv  Msg Q Peak:                     0
  Hold Msg Q Peak:                     0
```

```
Buffers Held Peak:                  0
Current Buffers Held:               0
Huge Buffers Requested:             0
```

show cloud-services aws s3 summary

To view a summary of Amazon S3 profiles, use the **show cloud-services aws s3 summary** command.

show cloud-services aws s3 summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays a summary of Amazon S3 profiles.

```
Device# show cloud-services aws s3 summary

Profile Name                      Profile Status  Service Status
-------------------------------------------------------------------
test                              Started         Active

test2                             Started         Active
```

show cloud-services aws s3 profile

To view the operational information of an Amazon S3 profile, use the **show cloud-services aws s3 profile** command.

show cloud-services aws s3 profile *profile*

Syntax Description

profile	Amazon S3 profile name.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the operational information of an Amazon S3 profile.

```
Device# show cloud-services aws s3 profile s1

Profile Details

Profile Name          : s1
Bucket Name           : pb-s3-test1
Mount Point           : test
Bucket Permission     : Read-Only
Region                : us-west-1
VRF                   : Global

S3 Service Details

Service Status        : Active
Service PID           : 31934
Mount Time            : 09/28/23 17:06:25
Service Log Level     : Notice
```

show cloud-services aws cloudwatch summary

To view a summary of AWS CloudWatch profiles, use the **show cloud-services aws cloudwatch summary** command.

show cloud-services aws cloudwatch summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays a summary of AWS CloudWatch profiles.

```
Device# show cloud-services aws cloudwatch summary

Profile Name                      Profile Status  Service Status
-------------------------------------------------------------------
demo3                             Started         Active

demo4                             Started         Active
```

show cloud-services aws cloudwatch profile

To view the details of a particular AWS CloudWatch profile, use the **show cloud-services aws cloudwatch profile** command.

show cloud-services aws cloudwatch profile *profile*

Syntax Description

profile	AWS CloudWatch profile name.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Usage Guidelines

The command output shows only the status of the agent running on the device. It doesn't reflect the AWS CloudWatch connection status.

Examples

The following command displays the details of a particular AWS CloudWatch profile.

```
Device# show cloud-services aws cloudwatch profile demo3

Profile Details

Profile Name          : demo3
VRF                   : Global
Region                : ap-northeast-1

CloudWatch Service Details

Service Status        : Active
Service PID           : 31785
Service Log Level     : Notice

Log Details

Log Group Name                          Log Stream Name                          Log
File
-------------------------------------------------------------------------------------------------------
test                                    katar2
```

show cts environment data

To display the TrustSec environment data on the AP, use the **show cts environment data** command:

show cts environment data

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the TrustSec environment data on the AP:

```
Device# show cts environment

CTS Environment Data
====================
Current state = COMPLETE
Last status   = Successful
Local Device SGT:
SGT tag = 0-07:Unknown
Server List Info:
Installed list: CTSServerList1-0001, 1 server(s):
Server: 8.109.0.85, port 1812, A-ID 9818EE1ECA02B7BFE359C28B30EA7E2A
Status = ALIVE
auto-test = FALSE, keywrap-enable = FALSE, idle-time = 60 mins, deadtime = 20 secs
Security Group Name Table:
0-07:Unknown
2-00:TrustSec_Devices
3-00:Network_Services
4-00:Employees
5-00:Contractors
6-00:Guests
7-00:Production_Users
8-00:Developers
9-00:Auditors
10-00:Point_of_Sale_Systems
11-02:Production_Servers
12-00:Development_Servers
13-00:Test_Servers
14-00:PCI_Servers
15-00:BYOD
16-06:BGL15
17-00:BGL12
255-00:Quarantined_Systems
Environment Data Lifetime = 86400 secs
Last update time = 11:50:49 UTC Sun Jan 9 2022
Env-data expires in   0:00:28:54 (dd:hr:mm:sec)
Env-data refreshes in 0:00:28:54 (dd:hr:mm:sec)
```

```
Cache data applied = NONE
State Machine is running
```

show cts role-based sgt-map all

To display the bindings of IP address and SGT source names on the AP, use the **show cts role-based sgt-map all** command:

show cts role-based sgt-map all

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the bindings of IP address and SGT source names on the AP:

```
Device# show cts role-based stg-map all

Active IPv4-SGT Bindings Information
IP Address                                      SGT       Source
============================================================================
8.73.1.101                                       16      LOCAL
8.73.1.102                                       16      LOCAL
8.73.1.103                                       16      LOCAL
8.73.1.104                                       16      LOCAL
8.73.1.105                                       16      LOCAL
8.73.1.106                                       16      LOCAL
8.73.1.107                                       16      LOCAL
8.73.1.108                                       16      LOCAL
8.73.1.109                                       16      LOCAL
8.73.1.110                                       16      LOCAL
8.73.1.111                                       16      LOCAL
8.73.1.112                                       16      LOCAL
8.73.1.113                                       16      LOCAL
8.73.1.114                                       16      LOCAL
8.73.1.115                                       16      LOCAL
8.73.1.116                                       16      LOCAL
8.73.1.117                                       16      LOCAL
8.73.1.118                                       16      LOCAL
8.73.1.119                                       16      LOCAL
8.73.1.120                                       16      LOCAL
8.73.1.121                                       16      LOCAL
8.73.1.122                                       16      LOCAL
8.73.1.123                                       16      LOCAL
8.73.1.124                                       16      LOCAL
8.73.1.125                                       16      LOCAL
8.73.1.126                                       16      LOCAL
8.73.1.127                                       16      LOCAL
8.73.1.128                                       16      LOCAL
8.73.1.129                                       16      LOCAL
8.73.1.130                                       16      LOCAL
8.73.1.131                                       16      LOCAL
```

```
8.73.1.132                                16      LOCAL
8.73.1.133                                16      LOCAL
8.73.1.134                                16      LOCAL
8.73.1.135                                16      LOCAL
8.73.1.136                                16      LOCAL
8.73.1.137                                16      LOCAL
8.73.1.138                                16      LOCAL
8.73.1.139                                16      LOCAL
8.73.1.140                                16      LOCAL
8.73.1.141                                16      LOCAL
8.73.1.142                                16      LOCAL
FD09:8::                                  16      LOCAL
FD09:8:73:0:4051:EB27:B4A2:F6DB           16      LOCAL
FD09:8:73:0:4C3C:1D75:81E0:DB94           16      LOCAL
FD09:8:73:0:5136:9045:9D11:E191           16      LOCAL
FD09:8:73:0:6903:B84E:5BDF:9D54           16      LOCAL
FD09:8:73:0:A9F8:7825:B07:75A8            16      LOCAL
FD09:8:73:0:B505:626B:51D7:6DB6           16      LOCAL
FD09:8:73:0:D0B4:3316:7CE9:8AE8           16      LOCAL
FD09:8:73:0:ECA8:F5E:CCF5:FFD7            16      LOCAL

IP-SGT Active Bindings Summary
============================================
Total number of LOCAL    bindings = 9
Total number of active   bindings = 9
```

show cts role-based counters

To clear all role-based counters on the AP, use the **show cts role-based counters** command:

show cts role-based counters

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the clear all role-based counters on the AP:

```
Device# show cts role-based counters

From  To   SW-Denied HW-Denied SW-Permitt HW-Permitt  SW-Monitor HW-Monitor
==============================================================================
*     *     0          0          0          178837189  0          0
16    0     0          0          0          39250482   0          0
16    16    0          52835      0          0          0          0
17    16    0          0          0          0          0          0
```

show environment summary

To view a summary of all the environment-monitoring sensors, use the **show environment summary** command.

show environment summary

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.
Cisco IOS XE Bengaluru 17.5.1	This command output was modified.

Example

The following is a sample output of the **show environment summary** command:

Example

```
Device# show environment summary


Number of Critical alarms:  0
Number of Major alarms:     0
Number of Minor alarms:     0

 Slot        Sensor          Current State   Reading
Threshold(Minor,Major,Critical,Shutdown)
 ----------  --------------  --------------- ------------
---------------------------------------
 P0          Vin             Normal          231  V AC    na
 P0          Iin             Normal          2    A       na
 P0          Vout            Normal          12   V DC    na
 P0          Iout            Normal          30   A       na
 P0          Temp1           Normal          25   Celsius (na ,na ,na ,na )(Celsius)
 P0          Temp2           Normal          31   Celsius (na ,na ,na ,na )(Celsius)
 P0          Temp3           Normal          37   Celsius (na ,na ,na ,na )(Celsius)
 R0          VDMB1: VX1      Normal          1226 mV      na
 R0          VDMB1: VX2      Normal          6944 mV      na
 R0          VDMB1: VX3      Normal          1226 mV      na
 R0          VDMB1: VX4      Normal          1000 mV      na
 R0          VDMB1: VP1      Normal          1789 mV      na
 R0          VDMB1: VP2      Normal          2555 mV      na
 R0          VDMB1: VP3      Normal          2556 mV      na
 R0          VDMB1: VP4      Normal          1049 mV      na
 R0          VDMB1: VH       Normal          11993mV      na
 R0          VDMB2: VX2      Normal          4975 mV      na
 R0          VDMB2: VX3      Normal          853  mV      na
 R0          VDMB2: VX4      Normal          907  mV      na
```

```
R0          VDMB2: VX5      Normal          1008 mV      na
R0          VDMB2: VP1      Normal          1787 mV      na
R0          VDMB2: VP2      Normal          3323 mV      na
R0          VDMB2: VH       Normal          12003mV      na
R0          VDMB3: VX1      Normal          968  mV      na
R0          VDMB3: VX2      Normal          1002 mV      na
R0          VDMB3: VX5      Normal          5090 mV      na
R0          VDMB3: VP1      Normal          2492 mV      na
R0          VDMB3: VP2      Normal          1196 mV      na
R0          VDMB3: VP3      Normal          1512 mV      na
R0          VDMB3: VP4      Normal          1509 mV      na
R0          VDMB3: VH       Normal          11998mV      na
R0          Temp: DMB IN    Normal          26   Celsius (45 ,55 ,65 ,70 )(Celsius)
R0          Temp: DMB OUT   Normal          40   Celsius (70 ,75 ,80 ,85 )(Celsius)
R0          Temp: Yoda 0    Normal          54   Celsius (95 ,105,110,115)(Celsius)
R0          Temp: Yoda 1    Normal          62   Celsius (95 ,105,110,115)(Celsius)
R0          Temp: CPU Die   Normal          43   Celsius (100,110,120,125)(Celsius)
R0          Temp: FC FANS   Fan Speed 70%   26   Celsius (29 ,39 ,0  )(Celsius)
R0          VDDC1: VX1      Normal          1005 mV      na
R0          VDDC1: VX2      Normal          7084 mV      na
R0          VDDC1: VX3      Normal          950  mV      na
R0          VDDC1: VP1      Normal          1800 mV      na
R0          VDDC1: VP2      Normal          2493 mV      na
R0          VDDC1: VP3      Normal          3325 mV      na
R0          VDDC1: VH       Normal          12019mV      na
R0          VDDC2: VX2      Normal          751  mV      na
R0          VDDC2: VX3      Normal          749  mV      na
R0          VDDC2: VX5      Normal          5076 mV      na
R0          VDDC2: VP1      Normal          1009 mV      na
R0          VDDC2: VP2      Normal          1008 mV      na
R0          VDDC2: VP3      Normal          1197 mV      na
R0          VDDC2: VP4      Normal          1514 mV      na
R0          VDDC2: VH       Normal          12003mV      na
R0          Temp: DDC IN    Normal          25   Celsius (55 ,65 ,75 ,80 )(Celsius)
R0          Temp: DDC OUT   Normal          35   Celsius (75 ,85 ,95 ,100)(Celsius)
P0          Stby Vin        Normal          230  V AC    na
P0          Stby Iin        Normal          2    A       na
P0          Stby Vout       Normal          12   V DC    na
P0          Stby Iout       Normal          32   A       na
P0          Stby Temp1      Normal          24   Celsius (na ,na ,na ,na )(Celsius)
P0          Stby Temp2      Normal          29   Celsius (na ,na ,na ,na )(Celsius)
P0          Stby Temp3      Normal          35   Celsius (na ,na ,na ,na )(Celsius)
R0          Stby VDMB1: VX1 Normal          1225 mV      na
R0          Stby VDMB1: VX2 Normal          6979 mV      na
R0          Stby VDMB1: VX3 Normal          1226 mV      na
R0          Stby VDMB1: VX4 Normal          999  mV      na
R0          Stby VDMB1: VP1 Normal          1791 mV      na
R0          Stby VDMB1: VP2 Normal          2560 mV      na
R0          Stby VDMB1: VP3 Normal          2558 mV      na
R0          Stby VDMB1: VP4 Normal          1050 mV      na
R0          Stby VDMB1: VH  Normal          11977mV      na
R0          Stby VDMB2: VX2 Normal          5005 mV      na
R0          Stby VDMB2: VX3 Normal          854  mV      na
R0          Stby VDMB2: VX4 Normal          878  mV      na
R0          Stby VDMB2: VX5 Normal          1008 mV      na
R0          Stby VDMB2: VP1 Normal          1789 mV      na
R0          Stby VDMB2: VP2 Normal          3312 mV      na
R0          Stby VDMB2: VH  Normal          11977mV      na
R0          Stby VDMB3: VX1 Normal          972  mV      na
R0          Stby VDMB3: VX2 Normal          1001 mV      na
R0          Stby VDMB3: VX5 Normal          5060 mV      na
R0          Stby VDMB3: VP1 Normal          2497 mV      na
R0          Stby VDMB3: VP2 Normal          1199 mV      na
R0          Stby VDMB3: VP3 Normal          1510 mV      na
```

```
R0          Stby VDMB3: VP4 Normal          1511 mV      na
R0          Stby VDMB3: VH  Normal          11982mV      na
R0          Stby Temp: DMB INormal          22   Celsius (45 ,55 ,65 ,70 )(Celsius)
R0          Stby Temp: DMB ONormal          32   Celsius (70 ,75 ,80 ,85 )(Celsius)
R0          Stby Temp: Yoda Normal          43   Celsius (95 ,105,110,115)(Celsius)
R0          Stby Temp: Yoda Normal          45   Celsius (95 ,105,110,115)(Celsius)
R0          Stby Temp: CPU DNormal          33   Celsius (100,110,120,125)(Celsius)
R0          Stby Temp: FC FAFan Speed 70%   22   Celsius (29 ,39 ,0  )(Celsius)
R0          Stby VDDC1: VX1 Normal          1005 mV      na
R0          Stby VDDC1: VX2 Normal          7070 mV      na
R0          Stby VDDC1: VX3 Normal          949  mV      na
R0          Stby VDDC1: VP1 Normal          1814 mV      na
R0          Stby VDDC1: VP2 Normal          2501 mV      na
R0          Stby VDDC1: VP3 Normal          3331 mV      na
R0          Stby VDDC1: VH  Normal          11993mV      na
R0          Stby VDDC2: VX2 Normal          752  mV      na
R0          Stby VDDC2: VX3 Normal          750  mV      na
R0          Stby VDDC2: VX5 Normal          5052 mV      na
R0          Stby VDDC2: VP1 Normal          1009 mV      na
R0          Stby VDDC2: VP2 Normal          994  mV      na
R0          Stby VDDC2: VP3 Normal          1195 mV      na
R0          Stby VDDC2: VP4 Normal          1514 mV      na
R0          Stby VDDC2: VH  Normal          11993mV      na
R0          Stby Temp: DDC INormal          22   Celsius (55 ,65 ,75 ,80 )(Celsius)
R0          Stby Temp: DDC ONormal          28   Celsius (75 ,85 ,95 ,100)(Celsius)
```

show etherchannel summary

To show details on the ports, port-channel, and protocols in the controller, use the **show etherchannel summary** command.

show ethernet summary

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged Mode.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows the details on the ports, port-channel, and protocols in the controller.

```
controller#show etherchannel summary
Flags:  D - down        P - bundled in port-channel
        I - stand-alone s - suspended
        H - Hot-standby (LACP only)
        R - Layer3      S - Layer2
        U - in use      f - failed to allocate aggregator

        M - not in use, minimum links not met
        u - unsuitable for bundling
        w - waiting to be aggregated
        d - default port


Number of channel-groups in use: 2
Number of aggregators:           2

Group  Port-channel  Protocol    Ports
------+-------------+-----------+-----------------------------------------------
2      Po2(SD)          -
23     Po23(SD)         -
```

show fips authorization-key

To view the installed authorization key, use the **show fips authorization-key** command.

show fips authorization-key

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to view the installed authorization key:

```
Device# show fips authorization-key
FIPS: Stored key (16) : 12345678901234567890123456789012
```

show fips status

To view the status of FIPS on the device, use the **show fips status** command.

show fips status

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to view the status of FIPS on the device:

```
Device# show fips status
Chassis is running in fips mode
```

show flash wipeout-log

To view the number of files, bytes deleted, free space and PID of the Access Point, use the **show flash wipeout-log** command.

show flash wipeout-log

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Usage Guidelines

This command needs to be run on the AP console.

Examples

The following example shows how to view the number of files, bytes deleted, free space and PID of the Access Point:

```
Device# show flash wipeout-log
```

show flexconnect office-extend diagnostics

To display the results of the network diagnostics for all flexconnect OfficeExtend AP, use the **show flexconnect office-extend diagnostics** command.

show flexconnect office-extend diagnostics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

To get periodic details for latency (current, minimum, or maximum) ensure that you enable link-latency under the ap profile, as given in the following example:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# link-latency
```

If the above configuration is not in place, you will only see the following output:

```
Summary of OfficeExtend AP Link Latency

CAPWAP Latency Heartbeat

Current: current latency (ms)
Min: minimum latency (ms)
Max: maximum latency (ms)

Link Test

Upload: DTLS Upload (Mbps)
Latency: DTLS Link Latency (ms)
Jitter: DTLS Link Jitter (ms)

AP Name Last Latency Heartbeat from AP Current Max Min Last Link Test Run Upload Latency
Jitter
-------------------------------------------------------------------------------------------
ap-18   Disabled                        -       -   -  12/04/20 11:08:58   16     3
0
```

Examples

This following example shows how to display the network diagnostics information for OfficeExtend AP.

```
Device# show flexconnect office-extend diagnostics

Summary of OfficeExtend AP Link Latency

CAPWAP Latency Heartbeat

Current: current latency (ms)
```

```
Min: minimum latency (ms)
Max: maximum latency (ms)

Link Test

Upload: DTLS Upload (Mbps)
Latency: DTLS Link Latency (ms)
Jitter: DTLS Link Jitter (ms)

AP Name Last Latency Heartbeat from AP Current Max Min Last Link Test Run Upload Latency
Jitter
-----------------------------------------------------------------------------------------------
ap-18    1 minute 1 second             0        0   0  12/04/20 09:19:48  8       2
0
```

show flow exporter

To display flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

show flow exporter [**export-ids netflow-v9** | [**name**] *exporter-name* [**statistics** | **templates**] | **statistics** | **templates**]

Syntax Description

export-ids netflow-v9	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
name	(Optional) Specifies the name of a flow exporter.
exporter-name	(Optional) Name of a flow exporter that was previously configured.
statistics	(Optional) Displays statistics for all flow exporters or for the specified flow exporter.
templates	(Optional) Displays template information for all flow exporters or for the specified flow exporter.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter
Flow Exporter FLOW-EXPORTER-1:
  Description:              Exports to the datacenter
  Export protocol:          NetFlow Version 9
  Transport Configuration:
    Destination IP address: 192.168.0.1
    Source IP address:      192.168.0.2
    Transport Protocol:     UDP
    Destination Port:       9995
    Source Port:            55864
    DSCP:                   0x0
    TTL:                    255
    Output Features:        Used
```

This table describes the significant fields shown in the display:

Table 5: show flow exporter Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.

Field	Description
Description	The description that you configured for the exporter, or the default description User defined.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.
Output Features	Specifies whether the **output-features** command, which causes the output features to be run on Flexible NetFlow export packets, has been used or not.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter name FLOW-EXPORTER-1 statistics
Flow Exporter FLOW-EXPORTER-1:
  Packet send statistics (last cleared 2w6d ago):
    Successfully sent:         0                     (0 bytes)
```

show flow interface

To display the configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

show flow interface [*type number*]

Syntax Description

type	(Optional) The type of interface on which you want to display accounting configuration information.
number	(Optional) The number of the interface on which you want to display accounting configuration information.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example displays the accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Device# show flow interface gigabitethernet1/0/1

Interface Ethernet1/0
        monitor:         FLOW-MONITOR-1
        direction:       Output
        traffic(ip):     on
Device# show flow interface gigabitethernet1/0/2
Interface Ethernet0/0
        monitor:         FLOW-MONITOR-1
        direction:       Input
        traffic(ip):     sampler SAMPLER-2#
```

The table below describes the significant fields shown in the display.

Table 6: show flow interface Field Descriptions

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.
direction:	The direction of traffic that is being monitored by the flow monitor. The possible values are: • Input—Traffic is being received by the interface. • Output—Traffic is being transmitted by the interface.

Field	Description
traffic(ip)	Indicates if the flow monitor is in normal mode or sampler mode. The possible values are: • on—The flow monitor is in normal mode. • sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
monitor-name	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Displays the contents of the cache for the flow monitor.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	(Optional) Displays the flow monitor cache contents in record format.
table	(Optional) Displays the flow monitor cache contents in table format.
statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor** *monitor-name* **cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor** *monitor-name* **cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Device# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:       Used for basic traffic analysis
  Flow Record:       flow-record-1
  Flow Exporter:     flow-exporter-1
                     flow-exporter-2
  Cache:
    Type:              normal
    Status:            allocated
    Size:              4096 entries / 311316 bytes
    Inactive Timeout:  15 secs
    Active Timeout:    1800 secs
```

This table describes the significant fields shown in the display.

Table 7: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show flow record

To display the status and statistics for a flow record, use the **show flow record** command in privileged EXEC mode.

show flow record [[**name**] *record-name*]

Syntax Description

name	(Optional) Specifies the name of a flow record.
record-name	(Optional) Name of a user-defined flow record that was previously configured.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following example displays the status and statistics for FLOW-RECORD-1:

```
Device# show flow record FLOW-RECORD-1
flow record FLOW-RECORD-1:
  Description:        User defined
  No. of users:       0
  Total field space:  24 bytes
  Fields:
    match ipv6 destination address
    match transport source-port
    collect interface input
```

show flow record wireless avc basic

To view information about the flow records for wireless avc basic, use the **show flow record wireless avc basic** command.

show flow record wireless avc basic

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to see information about the flow records for wireless avc basic:

```
Device# show flow record wireless avc basic

flow record wireless avc basic:
  Description:        Basic Wireless AVC template
  No. of users:       1
  Total field space:  78 bytes
  Fields:
    match ipv4 protocol
    match ipv4 source address
    match ipv4 destination address
    match transport source-port
    match transport destination-port
    match flow direction
    match application name
    match wireless ssid
    collect counter bytes long
    collect counter packets long
    collect wireless ap mac address
    collect wireless client mac address
```

show flow record wireless avc ipv6 basic

To view information about the flow records for wireless avc ipv6 basic, use the **show flow record wireless avc ipv6 basic** command.

show flow record wireless avc ipv6 basic

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to see information about the flow records for wireless avc ipv6 basic:

```
Device# show flow record wireless avc ipv6 basic

flow record wireless avc ipv6 basic:
  Description:        Ipv6 Wireless AVC flow template
  No. of users:       1
  Total field space:  102 bytes
  Fields:
    match ipv6 protocol
    match ipv6 source address
    match ipv6 destination address
    match transport source-port
    match transport destination-port
    match flow direction
    match wireless ssid
    collect counter bytes long
    collect counter packets long
    collect application name
    collect wireless ap mac address
    collect wireless client mac address
```

show gnxi state

To verify the gnxi details, use the **show gnxi state** command.

show gnxi state

Syntax Description

detail	Displays the gnxi detailed state.
stats	Displays the gnxi operational statistics.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

The following example shows how to verify the gnxi details:

```
Device# show gnxi state detail
Settings
========
Server: Enabled
Server port: 50052
Secure server: Disabled
Secure server port: 5000
Secure client authentication: Enabled
Secure trustpoint: test
Secure client trustpoint:
Secure password authentication: Disabled

GNMI
====
Admin state: Enabled
Oper status: Up
State: Provisioned

gRPC Server
-----------
Admin state: Enabled
Oper status: Up

Configuration service
---------------------
Admin state: Enabled
Oper status: Up

Telemetry service
-----------------
Admin state: Enabled
Oper status: Up

GNOI
```

```
====

Cert Management service
-----------------
Admin state: Enabled
Oper status: Up

OS Image service
----------------
Admin state: Disabled
Oper status: Up
Supported: Not supported on this platform
```

show history channel interface dot11Radio all

To check channel change or trigger reason and history, use the **show history channel interface dot11Radio all** command.

show history channel interface dot11Radio all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Examples

This example shows how to check channel change or trigger reason and history:

```
Device# show history channel interface dot11Radio all

               Timestamp Slot Client count Channel Trigger
Fri May 31 12:57:04 2019    0            0      11 RRM-DCA
Fri May 31 13:10:02 2019    0            0       1 RRM-DCA
Fri May 31 12:57:04 2019    1            0      60  Manual
Fri May 31 13:00:16 2019    1            0     149     DFS
```

show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in privileged EXEC mode.

show interfaces [*interface-id* | **vlan** *vlan-id*] [**accounting** | **capabilities** [**module** *number*] | **debounce** | **description** | **etherchannel** | **flowcontrol** | **private-vlan mapping** | **pruning** | **stats** | **status** [**err-disabled**] | **trunk**]

Syntax Description

interface-id	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member , module, and port number) and port channels. The port channel range is 1 to 48.
vlan *vlan-id*	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets. **Note** The display shows only packets processed in software; hardware-switched packets do not appear.
capabilities	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module *number*	(Optional) Displays capabilities of all interfaces on the switch or specified stack member. This option is not available if you entered a specific interface ID.
description	(Optional) Displays the administrative status and description set for an interface.
etherchannel	(Optional) Displays interface EtherChannel information.
flowcontrol	(Optional) Displays interface flow control information.
private-vlan mapping	(Optional) Displays private-VLAN mapping information for the VLAN switch virtual interfaces (SVIs). This keyword is not available if the switch is running the LAN base feature set.
pruning	(Optional) Displays trunk VTP pruning information for the interface.
stats	(Optional) Displays the input and output packets by switching the path for the interface.
status	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.

err-disabled	(Optional) Displays interfaces in an error-disabled state.
trunk	(Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.

Note Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, **rate-limit**, and **shape** keywords are not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module** *number* command to display the capabilities of all interfaces on that chassis in the stack. If there is no chassis with that module number in the stack, there is no output.
- Use the **show interfaces** *interface-id* **capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.

This is an example of output from the **show interfaces** command for an interface on stack member 3:

```
Device# show interfaces gigabitethernet3/0/2
GigabitEthernet3/0/2 is down, line protocol is down (notconnect)
  Hardware is Gigabit Ethernet, address is 2037.064d.4381 (bia 2037.064d.4381)
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
     reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Auto-duplex, Auto-speed, media type is 10/100/1000BaseTX
  input flow-control is off, output flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/2000/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
     0 packets input, 0 bytes, 0 no buffer
     Received 0 broadcasts (0 multicasts)
     0 runts, 0 giants, 0 throttles
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
     0 watchdog, 0 multicast, 0 pause input
     0 input packets with dribble condition detected
```

```
     0 packets output, 0 bytes, 0 underruns
     0 output errors, 0 collisions, 1 interface resets
     0 unknown protocol drops
     0 babbles, 0 late collision, 0 deferred
     0 lost carrier, 0 no carrier, 0 pause output
     0 output buffer failures, 0 output buffers swapped out
```

This is an example of output from the **show interfaces** *interface* **description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```
Device# show interfaces gigabitethernet1/0/2 description
Interface                      Status         Protocol Description
Gi1/0/2                        up             down     Connects to Marketing
```

This is an example of output from the **show interfaces** *interface-id* **pruning** command when pruning is enabled in the VTP domain:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port      Vlans pruned for lack of request by neighbor
Gi1/0/2   3,4

Port      Vlans traffic requested of neighbor
Gi1/0/2   1-3
```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```
Device# show interfaces vlan 1 stats
Switching path    Pkts In    Chars In    Pkts Out    Chars Out
     Processor    1165354   136205310      570800     91731594
   Route cache          0           0           0            0
         Total    1165354   136205310      570800     91731594
```

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25:

```
Device# show interfaces gigabitethernet1/0/22 status
Port       Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/22             connected   20,25     a-full      a-100      10/100BaseTX
```

In this example, port 20 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20:

```
Device# show interfaces gigabitethernet1/0/20 status
Port       Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/20             connected   20        a-full      a-100      10/100BaseTX
```

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```
Device# show interfaces status err-disabled
Port      Name       Status         Reason
Gi1/0/2              err-disabled   gbic-invalid
Gi2/0/3              err-disabled   dtp-flap
```

This is an example of output from the **show interfaces** *interface-id* **pruning** command:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port Vlans pruned for lack of request by neighbor


Device# show interfaces gigabitethernet1/0/1 trunk
Port        Mode             Encapsulation  Status        Native vlan
Gi1/0/1     on               802.1q         other         10

Port        Vlans allowed on trunk
Gi1/0/1     none

Port        Vlans allowed and active in management domain
Gi1/0/1     none

Port        Vlans in spanning tree forwarding state and not pruned
Gi1/0/1     none
```

show interfaces dot11Radio asr-info

To view advanced scheduling request statistics along with advanced scheduling request capability and uplink latency statistics for advanced scheduling request clients on a WLAN, use the **show interfaces dot11Radio asr-info** command.

show interfaces dot11Radio asr-info *radio-interface-number* { **all** | *mac-address* }

Syntax Description

radio-interface-number	Interface number for 802.11 radio.
all	Displays advanced scheduling request statistics along with advanced scheduling request capability and uplink latency statistics for all the advanced scheduling request clients on a WLAN.
mac-address	MAC address of the AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced

Examples

The following example shows how to view advanced scheduling request statistics along with advanced scheduling request capability and uplink latency statistics for all the advanced scheduling request clients on a WLAN:

```
Device# show interfaces dot11Radio 1 asr-info all

[*10/12/2020 18:45:21.0149]
[*10/12/2020 18:45:21.0150]  Client-MAC:[26:52:CF:C8:D0:1C] AID:[3] ASR-Capability:[0x1]
[*10/12/2020 18:45:21.0150]  BE- LAT[0-20]:[267] LAT[20-40]:[57] LAT[40-100]:[32]
LAT[>100]:[26]
[*10/12/2020 18:45:21.0150]  BK- LAT[0-20]:[0] LAT[20-40]:[0] LAT[40-100]:[0] LAT[>100]:[0]
[*10/12/2020 18:45:21.0150]  VI- LAT[0-20]:[0] LAT[20-40]:[0] LAT[40-100]:[0] LAT[>100]:[0]
[*10/12/2020 18:45:21.0150]  VO- LAT[0-20]:[2222] LAT[20-40]:[409] LAT[40-100]:[224]
LAT[>100]:[163]
[*10/12/2020 18:45:21.0150]
[*10/12/2020 18:45:21.0206] HTT_PEER_DETAILS_TLV:
[*10/12/2020 18:45:21.0206] peer_type = 0
[*10/12/2020 18:45:21.0206] sw_peer_id = 98
[*10/12/2020 18:45:21.0206] vdev_id = 25
[*10/12/2020 18:45:21.0206] pdev_id = 0
[*10/12/2020 18:45:21.0206] ast_idx = 1187
[*10/12/2020 18:45:21.0206] mac_addr = 26:52:cf:c8:d0:1c
[*10/12/2020 18:45:21.0206] peer_flags = 0x200006f9
[*10/12/2020 18:45:21.0206] qpeer_flags = 0x8
[*10/12/2020 18:45:21.0206]
[*10/12/2020 18:45:21.0206] HTT_STATS_PEER_ASR_STATS_TLV
[*10/12/2020 18:45:21.0206] asr_bmap: 0x8
[*10/12/2020 18:45:21.0206] asr_muedca_update_cnt: 1
[*10/12/2020 18:45:21.0206] asr_muedca_reset_cnt: 1
```

```
[*10/12/2020 18:45:21.0206] asr_ul_mu_bsr_trigger: 2376
[*10/12/2020 18:45:21.0206] asr_min_trig_intv- BE:0         BK:0 VI:0 VO:19
[*10/12/2020 18:45:21.0206] asr_max_trig_intv- BE:0         BK:0 VI:0 VO:20
[*10/12/2020 18:45:21.0207] asr_min_alloc_rate- BE:0         BK:0 VI:0 VO:12
[*10/12/2020 18:45:21.0207] asr_ul_su_data_ppdu_cnt- BE:0         BK:0 VI:0 VO:2149
[*10/12/2020 18:45:21.0207] asr_ul_su_data_ppdu_bytes- BE:0         BK:0 VI:0 VO:757546
[*10/12/2020 18:45:21.0207] asr_ul_mu_trig_ppdu_cnt- BE:0         BK:0 VI:0 VO:5002
[*10/12/2020 18:45:21.0207] asr_ul_mu_trig_ppdu_bytes- BE:0         BK:0 VI:0 VO:2400960
[*10/12/2020 18:45:21.0207] asr_ul_mu_data_ppdu_cnt- BE:0         BK:0 VI:0 VO:2134
[*10/12/2020 18:45:21.0207] asr_ul_mu_data_ppdu_bytes- BE:0         BK:0 VI:0 VO:736578
[*10/12/2020 18:45:21.0207] asr_ul_mu_data_padding_bytes- BE:0         BK:0 VI:0 VO:2953488
```

show interfaces wired

To view the wired interface details, use the **show interfaces wired** command.

show interfaces wired *wired-interface-number*

Syntax Description

wired-interface-number	Wired interface number.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Examples

This example shows how to view the wired interface details:

```
Device# show interfaces wired 0

wired0    Link encap:Ethernet  HWaddr C8:8B:5E:BA:D0 eMac Status: UP
          inet addr:20.200.51.14  Bcast:20.255.255.255  Mask:255.255.255.255
          UP BROADCAST RUNNING PROMISC MULTICAST  MTU:2400  Metric:1
          full Duplex, 1000 Mb/s

Wired0 Port Statistics:
ID         :              2             TYPE       :              0
RX PKTS    :          35109/431         TX PKTS    :           1307/11
RX OCTETS  :       2899435/34925        TX OCTETS  :         377424/1575
RX ERR     :            287/0           TX ERR     :              0/0
```

show inventory

To display the product inventory listing of all Cisco products installed in the networking device, use the **show inventory** command.

show inventory [*entity-name* | [**fru** | **oid** | **raw**] *entity-name*]

Syntax Description

entity-name	(Optional) Name of a Cisco entity (for example, chassis, backplane, module, or slot). A quoted string may be used to display very specific UDI information; for example "sfslot 1" shows the UDI information for slot 1 of an entity named sfslot.
fru	(Optional) To display the component details of the **fru** entities within the container hierarchy in Cisco products.
oid	(Optional) To display the vendor specific hardware registration number for each part of the device.
raw	(Optional) To view the information about all Cisco products—referred to as entities—installed in the Cisco networking device, even if the entities do not have a product ID (PID) value, a unique device identifier (UDI), or other physical identification.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The **show inventory** command retrieves and displays inventory information about each Cisco product in the form of a UDI. The UDI is a combination of three separate data elements: a product identifier (PID), a version identifier (VID), and the serial number (SN).

The PID is the name by which the product can be ordered; it has been historically called the "Product Name" or "Part Number." This is the identifier that one would use to order an exact replacement part.

The VID is the version of the product. Whenever a product has been revised, the VID will be incremented. The VID is incremented according to a rigorous process derived from Telcordia GR-209-CORE, an industry guideline that governs product change notices.

The SN is the vendor-unique serialization of the product. Each manufactured product will carry a unique serial number assigned at the factory, which cannot be changed in the field. This is the means by which to identify an individual, specific instance of a product.

The UDI refers to each product as an entity. Some entities, such as a chassis, will have subentities like slots. Each entity will display on a separate line in a logically ordered presentation that is arranged hierarchically by Cisco entities.

Use the **show inventory** command without options to display a list of Cisco entities installed in the networking device that are assigned a PID.

Examples

This example shows how to display the product inventory listing of a Cisco product installed in the networking device:

```
Device# show inventory

NAME: "module R0", DESCR: "Cisco C9800-CL Route Processor"
PID: C9800-CL-K9       , VID: V00  , SN: Jxx1xxxxx1x
```

show ip

To view the IP information, use the **show ip** command.

Syntax Description

access-lists	Lists the IP access lists
interface	Displays the IP interface status and configuration
brief	Displays the brief summary of IP status and configuration
route	Displays the IP routing table
tunnel	Displays the IP tunnel information
eogre	Displays the EoGRE tunnel information
domain	Displays the EoGRE tunnel domain information
forwarding-table	Displays the EoGRE tunnel encapsulation and decapsulation information
gateway	Displays the EoGRE tunnel gateway information
fabric	Displays the IP fabric tunnel information
summary	Displays the information for all tunnels

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
8.1.111.0	This command was introduced.

The following example shows how to view information about the lists the IP access lists:

```
cisco-wave2-ap# show ip access-lists
```

show ip igmp membership

To verify the IGMP membership details, use the **show ip igmp membership** command.

show ip igmp membership

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the IGMP membership details.

```
Device# show ip igmp membership
Flags: A - aggregate, T - tracked
L - Local, S - static, V - virtual, R - Reported through v3
I - v3lite, U - Urd, M - SSM (S,G) channel
1,2,3 - The version of IGMP, the group is in
Channel/Group-Flags:
/ - Filtering entry (Exclude mode (S,G), Include mode (G))
Reporter:
<mac-or-ip-address> - last reporter if group is not explicitly tracked
<n>/<m> - <n> reporter in include mode, <m> reporter in exclude
Channel/Group          Reporter    Uptime     Exp.      Flags      Interface
*,239.255.255.250      11.1.1.4    00:01:38  02:57       2A          Vl12
*,239.0.0.158          11.1.1.3    00:00:05  02:54       2A          Vl12
*,231.1.1.1            12.1.0.8    00:00:07  02:52       2A          Vl12
*,224.0.1.40           13.1.1.1    02:34:15  02:45       2LA         Gi3
```

show ip igmp snooping groups

To verify the IGMP snooping groups, use the **show ip igmp snooping groups** command.

show ip igmp snooping groups

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the IGMP snooping groups.

```
Device# show ip igmp snooping groups
Vlan     Group           Type     Version      Port List
------------------------------------------------------------------------
12     239.0.0.158       igmp      v2          Ca2
12     239.255.255.250   igmp      v2          Ca2
```

show ip igmp snooping igmpv2-tracking

To display group and IP address entries, use the **show ip igmp snooping igmpv2-tracking** command in privileged EXEC mode.

Note The command displays group and IP address entries only for wireless multicast IGMP joins and not for wired joins. This command also displays output only if wireless multicast is enabled.

show ip igmp snooping igmpv2-tracking

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

show ip igmp snooping querier

To display the configuration and operation information for the IGMP querier that is configured on a device, use the **show ip igmp snooping querier**command in user EXEC mode.

show ip igmp snooping querier [**vlan** *vlan-id*] [**detail**]

Syntax Description

vlan *vlan-id*	(Optional) Specifies a VLAN; Ranges are from 1—1001 and 1006—4094.
detail	(Optional) Displays detailed IGMP querier information.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Use the **show ip igmp snooping querier** command to display the IGMP version and the IP address of a detected device, also called a querier, that sends IGMP query messages. A subnet can have multiple multicast routers but only one IGMP querier. In a subnet running IGMPv2, one of the multicast routers is elected as the querier. The querier can be a Layer 3 device.

The **show ip igmp snooping querier** command output also shows the VLAN and the interface on which the querier was detected. If the querier is the device, the output shows the Port field as Router. If the querier is a router, the output shows the port number on which the querier was detected in the Port field.

The **show ip igmp snooping querier detail** user EXEC command is similar to the **show ip igmp snooping querier** command. However, the **show ip igmp snooping querier** command displays only the device IP address most recently detected by the device querier.

The **show ip igmp snooping querier detail** command displays the device IP address most recently detected by the device querier and this additional information:

- The elected IGMP querier in the VLAN
- The configuration and operational information pertaining to the device querier (if any) that is configured in the VLAN

Expressions are case sensitive, for example, if you enter | **exclude output**, the lines that contain "output" do not appear, but the lines that contain "Output" appear.

Examples

The following is a sample output from the **show ip igmp snooping querier** command:

```
Device> show ip igmp snooping querier
Vlan      IP Address     IGMP Version        Port
---------------------------------------------------
1         172.20.50.11   v3                  Gi1/0/1
2         172.20.40.20   v2                  Router
```

The following is a sample output from the **show ip igmp snooping querier detail** command:

```
Device> show ip igmp snooping querier detail

Vlan      IP Address     IGMP Version   Port
-----------------------------------------------------------
1         10.0.0.10      v2             Fa8/0/1
Global IGMP device querier status

-------------------------------------------------------
admin state                    : Enabled
admin version                  : 2
source IP address              : 0.0.0.0
query-interval (sec)           : 60
max-response-time (sec)        : 10
querier-timeout (sec)          : 120
tcn query count                : 2
tcn query interval (sec)       : 10
Vlan 1:   IGMP device querier status
-------------------------------------------------------
elected querier is 10.0.0.10         on port Fa8/0/1
-------------------------------------------------------
admin state                    : Enabled
admin version                  : 2
source IP address              : 10.1.1.65
query-interval (sec)           : 60
max-response-time (sec)        : 10
querier-timeout (sec)          : 120
tcn query count                : 2
tcn query interval (sec)       : 10
operational state              : Non-Querier
operational version            : 2
tcn query pending count        : 0
```

show ip igmp snooping wireless mcast-spi-count

To display the statistics of the number of multicast stateful packet inspections (SPIs) per multicast group ID (MGID) sent to the device, use the **show ip igmp snooping wireless mcast-spi-count** command in privileged EXEC mode.

show ip igmp snooping wireless mcast-spi-count

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None

Examples

This is an example of output from the **show ip igmp snooping wireless mcast-spi-count** command:

```
Device# show ip igmp snooping wireless mcast-spi-count

Stats for Mcast Client Add/Delete SPI Messages Sent to WCM

MGID    ADD MSGs        Del MSGs
--------------------------------
4160    1323            667
```

show ip igmp snooping wireless mgid

To display multicast group ID (MGID) mappings, use the **show ip igmp snooping wireless mgid** command in privileged EXEC mode.

show ip igmp snooping wireless mgid

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines None

Examples

This is an example of output from the **show ip igmp snooping wireless mgid** command:

```
Device# show ip igmp snooping wireless mgid

Total number of L2-MGIDs    = 0

Total number of MCAST MGIDs = 0

 Wireless multicast is Enabled in the system
 Vlan     bcast   nonip-mcast   mcast    mgid    Stdby Flags
 1     Disabled   Disabled   Enabled    Disabled  0:0:1:0
 25    Disabled   Disabled   Enabled    Disabled  0:0:1:0
 34    Disabled   Disabled   Enabled    Disabled  0:0:1:0
 200   Disabled   Disabled   Enabled    Disabled  0:0:1:0
 1002  Enabled    Enabled    Enabled    Disabled  0:0:1:0
 1003  Enabled    Enabled    Enabled    Disabled  0:0:1:0
 1004  Enabled    Enabled    Enabled    Disabled  0:0:1:0
 1005  Enabled    Enabled    Enabled    Disabled  0:0:1:0

Index  MGID                  (S, G, V)
-----------------------------------------------------------
```

show ip mroute

To verify if a multicast group supports SSM or not, use the **show ip mroute** command.

show ip mroute

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the multicast group.

```
Device# show ip mroute
IP Multicast Routing Table
Flags: D - Dense, S - Sparse, B - Bidir Group, s - SSM Group, C - Connected,
L - Local, P - Pruned, R - RP-bit set, F - Register flag,
T - SPT-bit set, J - Join SPT, M - MSDP created entry, E - Extranet,
X - Proxy Join Timer Running, A - Candidate for MSDP Advertisement,
U - URD, I - Received Source Specific Host Report,
Z - Multicast Tunnel, z - MDT-data group sender,
Y - Joined MDT-data group, y - Sending to MDT-data group,
G - Received BGP C-Mroute, g - Sent BGP C-Mroute,
N - Received BGP Shared-Tree Prune, n - BGP C-Mroute suppressed,
Q - Received BGP S-A Route, q - Sent BGP S-A Route,
V - RD & Vector, v - Vector, p - PIM Joins on route,
x - VxLAN group, c - PFP-SA cache created entry,
* - determined by Assert, # - iif-starg configured on rpf intf,
e - encap-helper tunnel flag, l - LISP decap ref count contributor
Outgoing interface flags: H - Hardware switched, A - Assert winner, p - PIM Join
t - LISP transit group
Timers: Uptime/Expires
Interface state: Interface, Next-Hop or VCD, State/Mode
(*, 239.0.0.158), 00:00:07/stopped, RP 15.1.1.2, flags: SJC
Incoming interface: GigabitEthernet3, RPF nbr 13.1.1.2
Outgoing interface list:
Vlan12, Forward/Sparse, 00:00:07/00:02:52, flags:
(17.1.1.1, 239.0.0.158), 00:00:06/00:02:53, flags: JT
Incoming interface: GigabitEthernet3, RPF nbr 13.1.1.2
Outgoing interface list:
Vlan12, Forward/Sparse, 00:00:06/00:02:53, flags:
(*, 231.1.1.1), 02:32:08/stopped, RP 15.1.1.2, flags: SJCF
Incoming interface: GigabitEthernet3, RPF nbr 13.1.1.2
Outgoing interface list:
Vlan12, Forward/Sparse, 00:01:31/00:01:28, flags:
(12.1.0.198, 231.1.1.1), 02:32:08/00:02:53, flags: PFT
Incoming interface: Vlan12, RPF nbr 0.0.0.0
Outgoing interface list: Null
(*, 224.0.1.40), 02:32:14/00:02:47, RP 15.1.1.2, flags: SJPL
```

```
Incoming interface: GigabitEthernet3, RPF nbr 13.1.1.2
Outgoing interface list: Null
```

show ip mroute active

To verify the active streams from any sources, use the **show ip mroute active** command.

show ip mroute active

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the active streams from any sources.

```
Device# show ip mroute active
Active IP Multicast Sources - sending >= 4 kbps
Group: 239.255.0.1, (?)
Source: 192.168.33.32 (?)
Rate: 10 pps/115 kbps(1sec), 235 kbps(last 23 secs), 87 kbps(life avg)
```

show ip nat statistics

To verify the IP NAT statistics, use the **show ip nat statistics** command.

show ip nat statistics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the static IP NAT statistics without VRF.

```
Device# show ip nat statistics
Total active translations: 1 (1 static, 0 dynamic; 0 extended)
Outside interfaces:
Vlan62
Inside interfaces:
Vlan55
Hits: 1474 Misses: 0
Reserved port setting disabled provisioned no
Expired translations: 1
Dynamic mappings:
nat-limit statistics:
max entry: max allowed 0, used 0, missed 0
In-to-out drops: 0 Out-to-in drops: 0
Pool stats drop: 0 Mapping stats drop: 0
Port block alloc fail: 0
IP alias add fail: 0
Limit entry add fail: 0
```

The following command displays the static IP NAT statistics with VRF.

```
Device# show ip nat statistics
Total active translations: 1 (1 static, 0 dynamic; 0 extended)
Outside interfaces:
Vlan62
Inside interfaces:
Vlan55
Hits: 1474 Misses: 0
Reserved port setting disabled provisioned no
Expired translations: 1
Dynamic mappings:
nat-limit statistics:
max entry: max allowed 0, used 0, missed 0
In-to-out drops: 0 Out-to-in drops: 0
Pool stats drop: 0 Mapping stats drop: 0
Port block alloc fail: 0
```

```
IP alias add fail: 0
Limit entry add fail: 0
```

The following command displays the dynamic IP NAT statistics without VRF.

```
Device# show ip nat statistics
Total active translations: 1 (0 static, 1 dynamic; 1 extended)
Outside interfaces:
Vlan62
Inside interfaces:
Vlan155
Hits: 3 Misses: 1
Reserved port setting disabled provisioned no
Expired translations: 0
Dynamic mappings:
-- Inside Source
[Id: 2] access-list dest_nat_acl pool test_nat_pool refcount 1
pool test_nat_pool: id 1, netmask 255.255.255.252
start 62.1.1.101 end 62.1.1.101
type generic, total addresses 1, allocated 1 (100%), misses 0
longest chain in pool: test_nat_pool's addr-hash: 0, average len 0,chains 0/256
nat-limit statistics:
max entry: max allowed 0, used 0, missed 0
In-to-out drops: 0 Out-to-in drops: 0
Pool stats drop: 0 Mapping stats drop: 0
Port block alloc fail: 0
IP alias add fail: 0
Limit entry add fail: 0
```

The following command displays the dynamic IP NAT statistics with VRF.

```
Device# show ip nat statistics
Total active translations: 1 (0 static, 1 dynamic; 1 extended)
Outside interfaces:
Vlan62
Inside interfaces:
Vlan155
Hits: 3 Misses: 1
Reserved port setting disabled provisioned no
Expired translations: 0
Dynamic mappings:
-- Inside Source
[Id: 2] access-list dest_nat_acl pool test_nat_pool refcount 1
pool test_nat_pool: id 1, netmask 255.255.255.252
start 62.1.1.101 end 62.1.1.101
type generic, total addresses 1, allocated 1 (100%), misses 0
longest chain in pool: test_nat_pool's addr-hash: 0, average len 0,chains 0/256
nat-limit statistics:
max entry: max allowed 0, used 0, missed 0
In-to-out drops: 0 Out-to-in drops: 0
Pool stats drop: 0 Mapping stats drop: 0
Port block alloc fail: 0
IP alias add fail: 0
Limit entry add fail: 0
```

show ip nbar protocol-discovery wlan

To see NBAR protocol discovery statistics for a WLAN, use the **show ip nbar protocol-discovery wlan** command.

show ip nbar protocol-discovery wlan *wlan-name*

Syntax Description

wlan-name	Name of the WLAN.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the NBAR protocol discovery statistics for a WLAN named *mywlan*:

```
Device# show ip nbar protocol-discovery wlan mywlan
```

show ip ospf

To display general information about Open Shortest Path First (OSPF) routing processes, use the **show ip ospf** command.

show ip ospf *[process-id]*

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the information about OSPF with a specific OSPF process ID.

```
Device# show ip ospf 1
Routing Process "ospf 1" with ID 31.31.31.1
Start time: 00:01:46.103, Time elapsed: 03:12:34.745
Supports only single TOS(TOS0) routes
Supports opaque LSA
Supports Link-local Signaling (LLS)
Supports area transit capability
Supports NSSA (compatible with RFC 3101)
Supports Database Exchange Summary List Optimization (RFC 5243)
Event-log enabled, Maximum number of events: 1000, Mode: cyclic
Router is not originating router-LSAs with maximum metric
Initial SPF schedule delay 50 msecs
Minimum hold time between two consecutive SPFs 200 msecs
Maximum wait time between two consecutive SPFs 5000 msecs
Incremental-SPF disabled
Initial LSA throttle delay 50 msecs
Minimum hold time for LSA throttle 200 msecs
Maximum wait time for LSA throttle 5000 msecs
Minimum LSA arrival 100 msecs
LSA group pacing timer 240 secs
Interface flood pacing timer 33 msecs
Retransmission pacing timer 66 msecs
EXCHANGE/LOADING adjacency limit: initial 300, process maximum 300
Number of external LSA 0. Checksum Sum 0x000000
Number of opaque AS LSA 0. Checksum Sum 0x000000
Number of DCbitless external and opaque AS LSA 0
Number of DoNotAge external and opaque AS LSA 0
Number of areas in this router is 1. 1 normal 0 stub 0 nssa
Number of areas transit capable is 0
External flood list length 0
IETF NSF helper support enabled
Cisco NSF helper support enabled
Reference bandwidth unit is 100 mbps
```

```
Area 1
Number of interfaces in this area is 3
Area has no authentication
SPF algorithm last executed 03:11:47.277 ago
SPF algorithm executed 9 times
Area ranges are
Number of LSA 5. Checksum Sum 0x0212EE
Number of opaque link LSA 0. Checksum Sum 0x000000
Number of DCbitless LSA 0
Number of indication LSA 0
Number of DoNotAge LSA 0
Flood list length 0
```

show ip ospf database

To view the OSPF database details for a specific OSPF process ID, use the **show ip ospf database** command.

show ip ospf *[process-id]* **database**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF database details for a specific OSPF process ID.

```
Device# show ip ospf 1 database
OSPF Router with ID (31.31.31.1) (Process ID 1)
Router Link States (Area 1)
Link ID ADV Router Age Seq# Checksum Link count
31.31.31.1 31.31.31.1 1470 0x8000000C 0x00289A 3
50.50.50.1 50.50.50.1 1745 0x8000000A 0x001018 3
51.51.51.1 51.51.51.1 1500 0x8000000A 0x008EFB 2
Net Link States (Area 1)
Link ID ADV Router Age Seq# Checksum
30.30.30.2 50.50.50.1 1745 0x80000006 0x00B793
31.31.31.2 51.51.51.1 1500 0x80000006 0x0093AE
```

show ip ospf database database-summary

To view the OSPF details in the database summary, use the **show ip ospf database database-summary** command.

show ip ospf *[process-id]* **database database-summary**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF details in the database summary.

```
Device# show ip ospf 1 database database-summary
OSPF Router with ID (31.31.31.1) (Process ID 1)
Area 1 database summary
LSA Type Count Delete Maxage
Router 3 0 0
Network 2 0 0
Summary Net 0 0 0
Summary ASBR 0 0 0
Type-7 Ext 0 0 0
Prefixes redistributed in Type-7 0
Opaque Link 0 0 0
Opaque Area 0 0 0
Subtotal 5 0 0
Process 1 database summary
LSA Type Count Delete Maxage
Router 3 0 0
Network 2 0 0
Summary Net 0 0 0
Summary ASBR 0 0 0
Type-7 Ext 0 0 0
Opaque Link 0 0 0
Opaque Area 0 0 0
Type-5 Ext 0 0 0
Prefixes redistributed in Type-5 0
Opaque AS 0 0 0
Total 5 0 0
Non-self 4
```

show ip ospf database internal

To view the OSPF details in the internal database, use the **show ip ospf database internal** command.

show ip ospf *[process-id]* **database internal**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF details in the internal database.

```
Device# show ip ospf 1 database internal
OSPF Router with ID (31.31.31.1) (Process ID 1)
Stub Link States (Area 1)
Link ID ADV Router Age Seq# Checksum Mask
6.6.6.255 31.31.31.1 11545 0x0 0x006611 /24
30.30.30.255 31.31.31.1 11546 0x0 0x00032C /24
31.31.31.255 31.31.31.1 11548 0x0 0x00DE4D /24
32.32.32.255 50.50.50.1 11545 0x0 0x00F0FE /24
50.50.50.1 50.50.50.1 11545 0x0 0x005C5C /32
51.51.51.1 51.51.51.1 11547 0x0 0x002092 /32
Router Link States (Area 1)
Link ID ADV Router Age Seq# Checksum Link count
31.31.31.1 31.31.31.1 1498 0x8000000C 0x00289A 3
50.50.50.1 50.50.50.1 1772 0x8000000A 0x001018 3
51.51.51.1 51.51.51.1 1527 0x8000000A 0x008EFB 2
Net Link States (Area 1)
Link ID ADV Router Age Seq# Checksum
30.30.30.2 50.50.50.1 1772 0x80000006 0x00B793
31.31.31.2 51.51.51.1 1527 0x80000006 0x0093AE
```

show ip ospf database network

To view the OSPF details in the database network, use the **show ip ospf database network** command.

show ip ospf *[process-id]* **database network**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF details in the database network.

```
Device# show ip ospf 1 database network
OSPF Router with ID (31.31.31.1) (Process ID 1)
Net Link States (Area 1)
LS age: 1772
Options: (No TOS-capability, DC)
LS Type: Network Links
Link State ID: 30.30.30.2 (address of Designated Router)
Advertising Router: 50.50.50.1
LS Seq Number: 80000006
Checksum: 0xB793
Length: 32
Network Mask: /24
Attached Router: 50.50.50.1
Attached Router: 31.31.31.1
LS age: 1527
Options: (No TOS-capability, DC)
LS Type: Network Links
Link State ID: 31.31.31.2 (address of Designated Router)
Advertising Router: 51.51.51.1
LS Seq Number: 80000006
Checksum: 0x93AE
Length: 32
Network Mask: /24
Attached Router: 51.51.51.1
Attached Router: 31.31.31.1
```

show ip ospf database router

To view the OSPF details in the database router, use the **show ip ospf database router** command.

show ip ospf *[process-id]* **database router**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF details in the database router.

```
Device# show ip ospf 1 database router
OSPF Router with ID (31.31.31.1) (Process ID 1)
Router Link States (Area 1)
LS age: 1498
Options: (No TOS-capability, DC)
LS Type: Router Links
Link State ID: 31.31.31.1
Advertising Router: 31.31.31.1
LS Seq Number: 8000000C
Checksum: 0x289A
Length: 60
Number of Links: 3
Link connected to: a Transit Network
(Link ID) Designated Router address: 31.31.31.2
(Link Data) Router Interface address: 31.31.31.1
Number of MTID metrics: 0
TOS 0 Metrics: 1
Link connected to: a Transit Network
(Link ID) Designated Router address: 30.30.30.2
(Link Data) Router Interface address: 30.30.30.1
Number of MTID metrics: 0
TOS 0 Metrics: 1
Link connected to: a Stub Network
(Link ID) Network/subnet number: 6.6.6.0
(Link Data) Network Mask: 255.255.255.0
Number of MTID metrics: 0
TOS 0 Metrics: 1
.
.
.
```

show ip ospf database topology

To view the OSPF details in the database topology, use the **show ip ospf database topology** command.

show ip ospf *[process-id]* **database topology**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF details in the database topology.

```
Device# show ip ospf 1 database topology
OSPF Router with ID (31.31.31.1) (Process ID 1)
Base Topology (MTID 0)
Router Link States (Area 1)
Link ID ADV Router Age Seq# Checksum Link count
31.31.31.1 31.31.31.1 1498 0x8000000C 0x00289A 3
50.50.50.1 50.50.50.1 1772 0x8000000A 0x001018 3
51.51.51.1 51.51.51.1 1527 0x8000000A 0x008EFB 2
Net Link States (Area 1)
Link ID ADV Router Age Seq# Checksum
30.30.30.2 50.50.50.1 1772 0x80000006 0x00B793
31.31.31.2 51.51.51.1 1527 0x80000006 0x0093AE
```

show ip ospf events

To view the OSPF event details, use the **show ip ospf events** command.

show ip ospf *[process-id]* **events**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF event details.

```
Device# show ip ospf 1 events
OSPF Router with ID (31.31.31.1) (Process ID 1)
1 Sep 21 21:49:12.406: Generate Changed Type-1 LSA, LSID 31.31.31.1, Seq# 8000000C, Age
0, Area 1
2 Sep 21 21:48:44.064: Rcv Unchanged Type-2 LSA, LSID 31.31.31.2, Adv-Rtr 51.51.51.1,
Seq# 80000006, Age 1, Area 1
3 Sep 21 21:48:44.064: Rcv Unchanged Type-1 LSA, LSID 51.51.51.1, Adv-Rtr 51.51.51.1,
Seq# 8000000A, Age 1, Area 1
4 Sep 21 21:44:38.726: Rcv Unchanged Type-2 LSA, LSID 30.30.30.2, Adv-Rtr 50.50.50.1,
Seq# 80000006, Age 1, Area 1
5 Sep 21 21:44:38.726: Rcv Unchanged Type-1 LSA, LSID 50.50.50.1, Adv-Rtr 50.50.50.1,
Seq# 8000000A, Age 1, Area 1
.
.
.
30 Sep 21 19:01:45.594: End of SPF, Topo Base, SPF time 1ms, next wait-interval 800ms
.
.
.
74 Sep 21 19:01:44.676: Generic: ospf_external_route_sync 0x1
75 Sep 21 19:01:44.676: Generic: ospf_external_route_sync 0x1
76 Sep 21 19:01:44.676: Generic: ospf_external_route_sync 0x0
77 Sep 21 19:01:44.676: Generic: ospf_external_route_sync 0x0
78 Sep 21 19:01:44.676: Starting External processing, Topo Base in area 1
79 Sep 21 19:01:44.676: Starting External processing, Topo Base
80 Sep 21 19:01:44.676: Generic: ospf_inter_route_sync 0x1
81 Sep 21 19:01:44.676: Generic: ospf_inter_route_sync 0x1
82 Sep 21 19:01:44.676: Starting summary processing, Topo Base, Area 1
83 Sep 21 19:01:44.676: Generic: post_spf_intra 0x0
84 Sep 21 19:01:44.676: Generic: ospf_intra_route_sync 0x1
.
.
.
```

show ip ospf interface

To view the OSPF interface details, use the **show ip ospf interface** command.

show ip ospf interface

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF interface details.

```
Device# show ip ospf interface
GigabitEthernet4 is up, line protocol is up
Internet Address 31.31.31.1/24, Interface ID 10, Area 1
Attached via Network Statement
Process ID 1, Router ID 31.31.31.1, Network Type BROADCAST, Cost: 1
Topology-MTID Cost Disabled Shutdown Topology Name
0 1 no no Base
Transmit Delay is 1 sec, State BDR, Priority 1
Designated Router (ID) 51.51.51.1, Interface address 31.31.31.2
Backup Designated router (ID) 31.31.31.1, Interface address 31.31.31.1
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
oob-resync timeout 40
Hello due in 00:00:03
Supports Link-local Signaling (LLS)
Cisco NSF helper support enabled
IETF NSF helper support enabled
Can be protected by per-prefix Loop-Free FastReroute
Can be used for per-prefix Loop-Free FastReroute repair paths
Not Protected by per-prefix TI-LFA
Index 1/3/3, flood queue length 0
Next 0x0(0)/0x0(0)/0x0(0)
Last flood scan length is 1, maximum is 2
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 1, Adjacent neighbor count is 1
Adjacent with neighbor 51.51.51.1 (Designated Router)
Suppress hello for 0 neighbor(s)
Cryptographic authentication enabled
Youngest key id is 1
GigabitEthernet3 is up, line protocol is up
Internet Address 30.30.30.1/24, Interface ID 9, Area 1
Attached via Network Statement
Process ID 1, Router ID 31.31.31.1, Network Type BROADCAST, Cost: 1
Topology-MTID Cost Disabled Shutdown Topology Name
0 1 no no Base
Transmit Delay is 1 sec, State BDR, Priority 1
Designated Router (ID) 50.50.50.1, Interface address 30.30.30.2
```

```
Backup Designated router (ID) 31.31.31.1, Interface address 30.30.30.1
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
oob-resync timeout 40
Hello due in 00:00:06
Supports Link-local Signaling (LLS)
Cisco NSF helper support enabled
IETF NSF helper support enabled
Can be protected by per-prefix Loop-Free FastReroute
Can be used for per-prefix Loop-Free FastReroute repair paths
Not Protected by per-prefix TI-LFA
Index 1/2/2, flood queue length 0
Next 0x0(0)/0x0(0)/0x0(0)
Last flood scan length is 1, maximum is 2
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 1, Adjacent neighbor count is 1
Adjacent with neighbor 50.50.50.1 (Designated Router)
Suppress hello for 0 neighbor(s)
Cryptographic authentication enabled
Youngest key id is 1
Vlan6 is up, line protocol is up
Internet Address 6.6.6.2/24, Interface ID 16, Area 1
Attached via Interface Enable
Process ID 1, Router ID 31.31.31.1, Network Type BROADCAST, Cost: 1
Topology-MTID Cost Disabled Shutdown Topology Name
0 1 no no Base
Enabled by interface config, including secondary ip addresses
Transmit Delay is 1 sec, State DR, Priority 1
Designated Router (ID) 31.31.31.1, Interface address 6.6.6.2
No backup designated router on this network
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
oob-resync timeout 40
Hello due in 00:00:01
Supports Link-local Signaling (LLS)
Cisco NSF helper support enabled
IETF NSF helper support enabled
Can be protected by per-prefix Loop-Free FastReroute
Can be used for per-prefix Loop-Free FastReroute repair paths
Not Protected by per-prefix TI-LFA
Index 1/1/1, flood queue length 0
Next 0x0(0)/0x0(0)/0x0(0)
Last flood scan length is 0, maximum is 0
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 0, Adjacent neighbor count is 0
Suppress hello for 0 neighbor(s)
Cryptographic authentication enabled
Youngest key id is 1
```

show ip ospf neighbor

To view the OSPF neighbor details, use the **show ip ospf neighbor** command.

show ip ospf *[process-id]* **neighbor**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF neighbor details.

```
Device# show ip ospf 1 neighbor
OSPF Router with ID (31.31.31.1) (Process ID 1)
OSPF queue statistics for process ID 1:
InputQ UpdateQ OutputQ
Limit 0 200 0
Drops 0 0 0
Max delay [msec] 1 1 1
Max size 2 2 2
Invalid 0 0 0
Hello 0 0 0
DB des 0 0 1
LS req 1 1 1
LS upd 1 1 0
LS ack 0 0 0
Current size 0 0 0
Invalid 0 0 0
Hello 0 0 0
DB des 0 0 0
LS req 0 0 0
LS upd 0 0 0
LS ack 0 0 0
Interface statistics:
.
.
.
Summary traffic statistics for process ID 1:
OSPF packets received/sent
Type Packets Bytes
RX Invalid 0 0
RX Hello 2435 116880
RX DB des 17 584
RX LS req 2 96
RX LS upd 24 2360
RX LS ack 24 1436
RX Total 2502 121356
```

```
TX Failed 0 0
TX Hello 3653 506540
TX DB des 6 704
TX LS req 2 144
TX LS upd 31 4204
TX LS ack 14 1560
TX Total 3706 513152
OSPF header errors
Length 0, Instance ID 0, Checksum 0, Auth Type 0,
Version 0, Bad Source 0, No Virtual Link 0,
Area Mismatch 0, No Sham Link 0, Self Originated 0,
Duplicate ID 0, Hello 0, MTU Mismatch 0,
Nbr Ignored 0, LLS 0, Unknown Neighbor 0,
Authentication 0, TTL Check Fail 0, Adjacency Throttle 0,
BFD 0, Test discard 0
OSPF LSA errors
Type 0, Length 0, Data 0, Checksum 0
```

show ip ospf neighbor summary

To view the OSPF neighbor summary, use the **show ip ospf neighbor summary** command.

show ip ospf *[process-id]* **neighbor summary**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF neighbor summary.

```
Device# show ip ospf neighbor summary
        OSPF Router with ID (31.31.31.1) (Process ID 1)
DOWN 0
ATTEMPT 0
INIT 0
2WAY 0
EXSTART 0
EXCHANGE 0
LOADING 0
FULL 2
Total count 2 (Undergoing NSF 0)
```

show ip ospf request-list

To view the OSPF request details for a specific neighbor, use the **show ip ospf request-list** command.

show ip ospf request-list *neighbor-ip-address*

Syntax Description

neighbor-ip-address	Neighbor IP address.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF request details for a specific neighbor.

```
Device# show ip ospf request-list Gi3 50.50.50.1
OSPF Router with ID (31.31.31.1) (Process ID 1)
Neighbor 50.50.50.1, interface GigabitEthernet3 address 30.30.30.2
Request list size 0, maximum list size 1
```

show ip ospf route-list

To view the IP OSPF route list details, use the **show ip ospf route-list** command.

show ip ospf *[process-id]* **route-list**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the IP OSPF route list details.

```
Device# show ip ospf 1 route-list
OSPF Router with ID (31.31.31.1) (Process ID 1)
Base Topology (MTID 0)
Area 1
Intra-area Route List
* 31.31.31.0/24, Intra, cost 1, area 1, Connected
via 31.31.31.1, GigabitEthernet4
* 30.30.30.0/24, Intra, cost 1, area 1, Connected
via 30.30.30.1, GigabitEthernet3
* 6.6.6.0/24, Intra, cost 1, area 1, Connected
via 6.6.6.2, Vlan6
*> 32.32.32.0/24, Intra, cost 2, area 1
via 30.30.30.2, GigabitEthernet3
*> 50.50.50.1/32, Intra, cost 2, area 1
via 30.30.30.2, GigabitEthernet3
*> 51.51.51.1/32, Intra, cost 2, area 1
via 31.31.31.2, GigabitEthernet4
First Hop Forwarding Gateway Tree
31.31.31.1 on GigabitEthernet4, count 1
31.31.31.2 on GigabitEthernet4, count 1
30.30.30.1 on GigabitEthernet3, count 1
30.30.30.2 on GigabitEthernet3, count 2
6.6.6.2 on Vlan6, count 1
```

show ip ospf traffic

To view the OSPF traffic details, use the **show ip ospf traffic** command.

show ip ospf *[process-id]* **traffic**

Syntax Description

process-id	(Optional) Process ID. If this argument is included, only information for the specified routing process is included.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the OSPF traffic details.

```
Device# show ip ospf 1 traffic
OSPF Router with ID (31.31.31.1) (Process ID 1)
OSPF queue statistics for process ID 1:
InputQ UpdateQ OutputQ
Limit 0 200 0
Drops 0 0 0
Max delay [msec] 1 1 1
Max size 2 2 2
Invalid 0 0 0
Hello 0 0 0
DB des 0 0 1
LS req 1 1 1
LS upd 1 1 0
LS ack 0 0 0
Current size 0 0 0
Invalid 0 0 0
Hello 0 0 0
DB des 0 0 0
LS req 0 0 0
LS upd 0 0 0
LS ack 0 0 0
Interface statistics:
.
.
.
Summary traffic statistics for process ID 1:
OSPF packets received/sent
Type Packets Bytes
RX Invalid 0 0
RX Hello 2435 116880
RX DB des 17 584
RX LS req 2 96
RX LS upd 24 2360
RX LS ack 24 1436
RX Total 2502 121356
```

```
TX Failed 0 0
TX Hello 3653 506540
TX DB des 6 704
TX LS req 2 144
TX LS upd 31 4204
TX LS ack 14 1560
TX Total 3706 513152
OSPF header errors
Length 0, Instance ID 0, Checksum 0, Auth Type 0,
Version 0, Bad Source 0, No Virtual Link 0,
Area Mismatch 0, No Sham Link 0, Self Originated 0,
Duplicate ID 0, Hello 0, MTU Mismatch 0,
Nbr Ignored 0, LLS 0, Unknown Neighbor 0,
Authentication 0, TTL Check Fail 0, Adjacency Throttle 0,
BFD 0, Test discard 0
OSPF LSA errors
Type 0, Length 0, Data 0, Checksum 0
```

show ipv6 access-list

To display the contents of all current IPv6 access lists, use the **show ipv6 access-list** command in user EXEC or privileged EXEC mode.

show ipv6 access-list [*access-list-name*]

Syntax Description

access-list-name	(Optional) Name of access list.

Command Default

All IPv6 access lists are displayed.

Command Modes

User EXEC

Privileged EXEC

Command History

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The **show ipv6 access-list** command provides output similar to the **show ip access-list** command, except that it is IPv6-specific.

Examples

The following output from the **show ipv6 access-list** command shows IPv6 access lists named inbound, tcptraffic, and outbound:

```
Device# show ipv6 access-list
IPv6 access list inbound
    permit tcp any any eq bgp reflect tcptraffic (8 matches) sequence 10
    permit tcp any any eq telnet reflect tcptraffic (15 matches) sequence 20
    permit udp any any reflect udptraffic sequence 30
IPv6 access list tcptraffic (reflexive) (per-user)
    permit tcp host 2001:0DB8:1::1 eq bgp host 2001:0DB8:1::2 eq 11000 timeout 300 (time
       left 243) sequence 1
    permit tcp host 2001:0DB8:1::1 eq telnet host 2001:0DB8:1::2 eq 11001 timeout 300
    (time left 296) sequence 2
IPv6 access list outbound
    evaluate udptraffic
    evaluate tcptraffic
```

The following sample output shows IPv6 access list information for use with IPSec:

```
Device#  show ipv6 access-list
IPv6 access list Tunnel0-head-0-ACL (crypto)
     permit ipv6 any any (34 matches) sequence 1
IPv6 access list Ethernet2/0-ipsecv6-ACL (crypto)
     permit 89 FE80::/10 any (85 matches) sequence 1
```

The table below describes the significant fields shown in the display.

Table 8: show ipv6 access-list Field Descriptions

Field	Description
ipv6 access list inbound	Name of the IPv6 access list, for example, inbound.
permit	Permits any packet that matches the specified protocol type.
tcp	Transmission Control Protocol. The higher-level (Layer 4) protocol type that the packet must match.
any	Equal to ::/0.
eq	An equal operand that compares the source or destination ports of TCP or UDP packets.
bgp	Border Gateway Protocol. The lower-level (Layer 3) protocol type that the packet must be equal to.
reflect	Indicates a reflexive IPv6 access list.
tcptraffic (8 matches)	The name of the reflexive IPv6 access list and the number of matches for the access list. The **clear ipv6 access-list** privileged EXEC command resets the IPv6 access list match counters.
sequence 10	Sequence in which an incoming packet is compared to lines in an access list. Lines in an access list are ordered from first priority (lowest number, for example, 10) to last priority (highest number, for example, 80).
host 2001:0DB8:1::1	The source IPv6 host address that the source address of the packet must match.
host 2001:0DB8:1::2	The destination IPv6 host address that the destination address of the packet must match.
11000	The ephemeral source port number for the outgoing connection.
timeout 300	The total interval of idle time (in seconds) after which the temporary IPv6 reflexive access list named tcptraffic will time out for the indicated session.
(time left 243)	The amount of idle time (in seconds) remaining before the temporary IPv6 reflexive access list named tcptraffic is deleted for the indicated session. Additional received traffic that matches the indicated session resets this value to 300 seconds.
evaluate udptraffic	Indicates the IPv6 reflexive access list named udptraffic is nested in the IPv6 access list named outbound.

show ipv6 hop-by-hop status

To display information about IPv6 hop-by-hop header processing, use the **show ipv6 hop-by-hop status** command.

show ipv6 hop-by-hop status

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example displays information about IPv6 hop-by-hop header processing:

```
Device# show ipv6 hop-by-hop status
```

show ipv6 mld snooping

Use the **show ipv6 mld snooping** command in EXEC mode to display IP version 6 (IPv6) Multicast Listener Discovery (MLD) snooping configuration of the switch or the VLAN.

show ipv6 mld snooping [**vlan** *vlan-id*]

Syntax Description

vlan *vlan-id*	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.

Command Modes

User EXEC

Privileged EXEC

Command History

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Use this command to display MLD snooping configuration for the switch or for a specific VLAN.

VLAN numbers 1002 through 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in MLD snooping.

To configure the dual IPv4 and IPv6 template, enter the **sdm prefer dual-ipv4-and-ipv6** global configuration command and reload the switch.

Examples

This is an example of output from the show ipv6 mld snooping vlan command. It shows snooping characteristics for a specific VLAN.

```
Device# show ipv6 mld snooping vlan 100
Global MLD Snooping configuration:
-------------------------------------------
MLD snooping : Enabled
MLDv2 snooping (minimal) : Enabled
Listener message suppression : Enabled
TCN solicit query : Disabled
TCN flood query count : 2
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
Vlan 100:
--------
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
```

This is an example of output from the **show ipv6 mld snooping** command. It displays snooping characteristics for all VLANs on the switch.

```
Device# show ipv6 mld snooping
Global MLD Snooping configuration:
-------------------------------------------
MLD snooping : Enabled
MLDv2 snooping (minimal) : Enabled
Listener message suppression : Enabled
TCN solicit query : Disabled
TCN flood query count : 2
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000

Vlan 1:
--------
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 1
Last listener query count : 2
Last listener query interval : 1000

<output truncated>

Vlan 951:
--------
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
```

show ipv6 mld snooping querier vlan

To see IPv6 MLD querier information in a VLAN, use the **show ipv6 mld snooping querier vlan** command.

show ipv6 mld snooping querier vlan *vlan-id*

Syntax Description

vlan-id	VLAN ID. Valid range is 1 to 1001 and 1006 to 4094.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the IPv6 MLD querier information in a VLAN whose ID is 3:

```
Device# show ipv6 mld snooping querier vlan 3
```

show ipv6 mld snooping wireless mgid

To see multicast group identifer (MGID) mapping information in the IPv6 MLD wireless related snooping events, use the **show ipv6 mld snooping wireless mgid** command.

show ipv6 mld snooping wireless mgid

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see multicast group identifer (MGID) mapping information in the IPv6 MLD wireless related snooping events:

```
Device# show ipv6 mld snooping wireless mgid
```

show ipv6 nd ra specific-route

To display information about IPv6 neighbor discovery router advertisement messages, use the **show ipv6 nd ra specific-route** command.

show ipv6 nd ra specific-route *interface*

Syntax Description

interface	Interface information.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

If you do not specify the interface, routes configured under all the interfaces are displayed.

Examples

The following example displays information about IPv6 neighbor discovery router advertisement messages:

```
Device# show ipv6 nd ra specific-route
```

show ldap attributes

To view information about the default LDAP attribute mapping, use the **show ldap attributes** command.

show ldap attributes

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view information about the default LDAP attribute mapping:

```
Device# show ldap attributes
LDAP Attribute                      Format     AAA Attribute
==============                      ======     =============
airespaceBwDataBurstContract        Ulong      bsn-data-bandwidth-burst-contr
userPassword                        String     password
airespaceBwRealBurstContract        Ulong      bsn-realtime-bandwidth-burst-c
employeeType                        String     employee-type
airespaceServiceType                Ulong      service-type
airespaceACLName                    String     bsn-acl-name
priv-lvl                            Ulong      priv-lvl
memberOf                            String DN  supplicant-group
cn                                  String     username
airespaceDSCP                       Ulong      bsn-dscp
policyTag                           String     tag-name
airespaceQOSLevel                   Ulong      bsn-qos-level
airespace8021PType                  Ulong      bsn-8021p-type
airespaceBwRealAveContract          Ulong      bsn-realtime-bandwidth-average
airespaceVlanInterfaceName          String     bsn-vlan-interface-name
airespaceVapId                      Ulong      bsn-wlan-id
airespaceBwDataAveContract          Ulong      bsn-data-bandwidth-average-con
sAMAccountName                      String     sam-account-name
meetingContactInfo                  String     contact-info
telephoneNumber                     String     telephone-number
Map: att_map_1
department                          String DN  element-req-qos
```

show ldap server

To view the LDAP server information, use the **show ldap server** command.

show ldap server { *server-name* | **all** }

Syntax Description

server-name	Name of the server.
all	Information of all the servers.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the LDAP server information:

```
Device# show ldap server all
```

show license air entities

To display information about active APs, new APs, and deleted APs in connection with a Cisco Catalyst Wireless Controller, enter the **show license air entities** command in privileged EXEC mode.

show license air entities { **added** | **bulk** | **deleted** | **no-change** | **summary** }

Syntax Description

`added`	Displays the list of newly reported APs. A newly added AP is one that was not listed in the last RUM report that the product instance generated.
bulk	Displays the list of all currently active APs for the product instance
deleted	Displays the list of deleted APs. A delete AP is one that was listed as active APs in the last RUM report that the product instance generated but is now disconnected.
no-change	Displays the list of APs where there has been no change in the status since the last report.
summary	Displays the RUM report generation particulars and information about active APs, new APs, and deleted APs, and indicates by when an acknowledgement (ACK) must be installed on the product instance.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to display information relating to Smart Licensing Using Policy.
Cisco IOS XE Cupertino 17.7.1	The output of the **show license air entities summary** command was enhanced to display the following new field only on a Cisco Catalyst 9800-CL Wireless Controller: `License Ack expected within`

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Examples

For information about fields shown in the display for the **show license air entities summary** command, see Table 9: show license air entities summary Field Descriptions, on page 303 .

For sample output, see

- show license air entities summary on a Cisco Catalyst 9800-CL Wireless Controller, on page 303
- show license air entities summary on a Cisco Catalyst 9800-L Wireless Controller, on page 304

Table 9: show license air entities summary Field Descriptions

Field	Description
Last license report time	When the last RUM report was generated, in the local time zone.
Upcoming license report time	When the next RUM report will be generated, in the local time zone.
No. of APs active at last report	Total number of APs listed as active APs in the last RUM report that was generated.
No. of APs newly added with last report	Number of new APs in the last RUM report that was generated. For example, if the number displayed here is 2, this means the *last but one* RUM report did not list these 2 APs, and are therefore newly added in the last RUM report that the product instance generated.
No. of APs deleted with last report	Total number of APs deleted as of the last RUM report that was generated. For example, if the number displayed here is 2, this means 2 APs were in the *last but one* RUM report, but were deleted in the *last* RUM report was generated.
License Ack expected within	**Note** This field is displayed only on a Cisco Catalyst 9800-CL Wireless Controller running Cisco IOS XE Cupertino 17.7.1 or a later release. If the field is displayed, it means you must complete RUM reporting and ensure that the ACK is made available on the product instance - at least once.

show license air entities summary on a Cisco Catalyst 9800-CL Wireless Controller

This example shows how to identify when an ACK is required on a Cisco Catalyst 9800-CL Wireless Controller

Beginning with Cisco IOS XE Cupertino 17.7.1, if you are using a Cisco Catalyst 9800-CL Wireless Controller, you must complete RUM reporting and ensure that the ACK is made available on the product instance - at least once. This is to ensure that correct and up-to-date usage information is reflected in CSSM.

Prior to 17.7.1, reporting and ACK installation was not *mandatory* for a Cisco Catalyst 9800-CL Wireless Controller.

The following is sample output on a Cisco Catalyst 9800-CL Wireless Controller, where an ACK must be made available on the product instance within 179 days. If this deadline is not met, currently active APs are not disconnected, but no new AP joins are allowed after the ACK deadline is passed. System messages are also displayed daily, until the first ACK is installed.

```
Device# show license air entities summary
Upcoming license report time.....: 21:05:16.092 UTC Mon Oct 25 2021
No. of APs active at last report.....: 57
No. of APs newly added with last report.....: 57
No. of APs deleted with last report.....: 0
License Ack expected within.....: 179 days
```

Detailed information about this requirement is available in the configuration guide. In the Cisco Catalyst 9800 Series Wireless Controller Software Configuration Guide, version Cisco IOS XE Cupertino 17.7.1 onwards, see the *System Configuration → Smart Licensing Using Policy → RUM Reporting and Acknowledgment Requirement for Cisco Catalyst 9800-CL Wireless Controller*.

show license air entities summary on a Cisco Catalyst 9800-L Wireless Controller

The following is sample output on a Cisco Catalyst 9800-L Wireless Controller. Note how the output on this device does not display the `License Ack expected within` field. Reporting requirements on all Cisco Catalyst Wireless Controllers (except Cisco Catalyst 9800-CL Wireless Controller) are as per the standard guidelines in the Smart Licensing Using Policy environment: Reporting is required if the policy (**show license status**) or system messages indicate that it is.

```
Device# show license air entities summary
Upcoming license report time.....: 15:13:27.403 IST Tue Oct 26 2021
No. of APs active at last report.....: 1
No. of APs newly added with last report.....: 1
No. of APs deleted with last report.....: 0
```

show license all

To display all licensing information enter the **show license all** command in Privileged EXEC mode. This command displays status, authorization, UDI, and usage information, all combined.

show license all

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to display information relating to Smart Licensing Using Policy. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	The output of the command was enhanced to display the following information: • RUM report statistics, in section `Usage Report Summary`. • Smart Account and Virtual Account information, in section `Account Information`.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

This command concatenates the output of other **show license** commands, enabling you to display different kinds of licensing information together. For field descriptions, refer to the corresponding commands in the links provided below.

The `Smart Licensing Status` and `Account Information` sections of the **show license all** command corresponds with the output of the show license status, on page 325 command.

The `License Usage` section of the **show license all** command corresponds with the output of the show license usage, on page 354 command.

The `Product Information` section of the **show license all** command corresponds with the output of the show license udi, on page 353 command.

The `Agent Version` section of the **show license all** command displays the Smart Agent version and is available only in this command.

The `License Authorizations` section of the **show license all** command corresponds with the output of the show license authorization, on page 311 command.

The `Usage Report Summary` section of the **show license all** command corresponds with the output in the show license tech, on page 338 command.

Examples

For sample output, see:

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers, 17.7.1), on page 306

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers), on page 307

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers, 17.7.1)

The following is sample output of the **show license all** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1. Note the addition of the two new sections in this release: `Account Information` and `Usage Report Summary`:

```
Device# show license all

Smart Licensing Status
======================

Smart Licensing is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured
  VRF:
    Not Configured

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
```

```
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>

License Usage
=============

No licenses in use

Product Information
===================
UDI: PID:C9800-CL-K9,SN:9KGIXIDOXFE

HA UDI List:
    Active:PID:C9800-CL-K9,SN:9KGIXIDOXFE
    Standby:PID:C9800-CL-K9,SN:9UBKZU955E4

Agent Version
=============
Smart Agent for Licensing: 5.3.14_rel/47

License Authorizations
======================
Overall status:
  Active: PID:C9800-CL-K9,SN:9KGIXIDOXFE
      Status: NOT INSTALLED
  Standby: PID:C9800-CL-K9,SN:9UBKZU955E4
      Status: NOT INSTALLED

Purchased Licenses:
  No Purchase Information Available

Usage Report Summary:
=====================
Total: 0,  Purged: 0
Total Acknowledged Received: 0,  Waiting for Ack: 0
Available to Report: 0  Collecting Data: 0
```

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers)

The following is sample output of the **show license all** command on a Cisco Catalyst 9800-CL Wireless Controller. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license all

Smart Licensing Status
======================

Smart Licensing is ENABLED
License Reservation is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Transport Off

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: Nov 01 20:31:46 2020 IST
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>

License Usage
=============
```

```
air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

Product Information
===================
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN

Agent Version
=============
Smart Agent for Licensing: 5.0.6_rel/47

License Authorizations
======================
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
      Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      Last Confirmation code: ad4382fe

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
```

```
            Start Date: 2020-JUN-18 UTC
            End Date: 2020-DEC-15 UTC
            Term Count: 5
        Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
          Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
          License type: TERM
            Start Date: 2020-OCT-14 UTC
            End Date: 2021-APR-12 UTC
            Term Count: 10
    AP Perpetual Networkstack Advantage (DNA_NWStack):
      Description: AP Perpetual Network Stack entitled with DNA-A
      Total reserved count: 20
      Enforcement type: NOT ENFORCED
      Term information:
        Active: PID:C9800-CL-K9,SN:93BBAH93MGS
          Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
          License type: TERM
            Start Date: 2020-OCT-14 UTC
            End Date: 2021-APR-12 UTC
            Term Count: 5
          Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
          License type: TERM
            Start Date: 2020-JUN-18 UTC
            End Date: 2020-DEC-15 UTC
            Term Count: 5
        Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
          Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
          License type: TERM
            Start Date: 2020-OCT-14 UTC
            End Date: 2021-APR-12 UTC
            Term Count: 10

Purchased Licenses:
  No Purchase Information Available
```

show license authorization

To display authorization-related information for (export-controlled and enforced) licenses, enter the **show license authorization** command in privileged EXEC mode.

show license authorization

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

Only export-controlled or enforced licenses require authorization before use.

While there are no export-controlled or enforced licenses on Cisco Catalyst Wireless Controllers, you can use this command to display migrated SLR authorization codes.

Examples

See Table 10: show license authorization Field Descriptions, on page 312 for information about fields shown in the display.

See show license authorization Displaying Migrated Authorization Code, on page 314 for sample output.

Table 10: show license authorization Field Descriptions

Field		Description
Overall Status	Header for UDI information for all product instances in the set-up, the type of authorization that is installed, and configuration errors, if any. In a High Availability set-up, all UDIs in the set-up are listed.	
	Active: Status:	The active product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	Standby: Status:	The standby product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	Member: Status:	The member product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	ERROR:	Configuration errors or discrepancies in the High Availability set-up, if any.

Field		Description
Authorizations	Header for detailed license authorization information. All licenses, their enforcement types, and validity durations are displayed. Errors are displayed for each product instance if its authorization or mode does not match what is installed on the active. This section is displayed only if the product instance is using a license with an authorization code.	
	():	License name and a shortened form of the license name.
	Description	License description.
	Total available count:	Total count of licenses that are available to consume. This includes licenses of all durations (perpetual and subscription), including expired subscription licenses, for all the product instances in a High Availability setup.
	Enforcement type	Enforcement type for the license. This may be one of the following: • Enforced • Not enforced • Export-Controlled
	Term information:	

Field		Description
		Header providing license duration information. The following fields maybe included under this header: • Active: The active product instance UDI, followed by the status of the authorization code installation for this UDI. • Authorization type: Type of authorization code installed and date of installation. The type can be: SLAC, UNIVERSAL, SPECIFIED, PAK, RTU. • Start Date: Displays validity start date if the license is for a specific term or time period. • Start Date: Displays validity end date if the license is for a specific term or time period. • Term Count: License count. • Subscription ID: Displays ID if the license is for a specific term or time period. • License type: License duration. This can be: SUBSCRIPTION or PERPETUAL. • Standby: The standby product instance UDI, followed by the status of the authorization code installation for this UDI. • Member: The member product instance UDI, followed by the status of the authorization code installation for this UDI. For more information about the duration or term of a license's validity, see <link tbd>.
Purchased Licenses	Header for license purchase information.	
	Active:	The active product instance and its the UDI.
	Count:	License count.
	Description:	License description.
	License type:	License duration. This can be: SUBSCRIPTION or PERPETUAL.
	Standby:	The standby product instance UDI.
	Member:	The member product instance UDI.

show license authorization Displaying Migrated Authorization Code

The following is sample output of the **show license authorization** command on a Cisco Catalyst 9800-CL Wireless Controller. The `Last Confirmation code:` shows that SLR authorization code is available after migration. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license authorization
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
      Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      Last Confirmation code: ad4382fe

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10

Purchased Licenses:
  No Purchase Information Available
```

show license data conversion

To display license data conversion information, enter the **show license data** command in privileged EXEC mode.

show license data conversion

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

Although visible on the CLI, this command is not applicable to Cisco Catalyst Wireless Controllers.

show license eventlog

To display event logs relating to Smart Licensing Using Policy, enter the **show license eventlog** command in privileged EXEC mode.

show license eventlog [*days*]

Syntax Description

days	Enter the number of days for which you want to display event logs. The valid value range is from 0 to 2147483647.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Additional events were added with the introduction of Smart Licensing Using Policy: • Installation and removal of a policy • Request, installation and removal of an authorization code. • Installation and removal of a trust code. • Addition of authorization source information for license usage.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

show license history message

To display communication history between the product instance and CSSM or CSLU (as the case may be), enter the **show license history message** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting.

show license history message

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra** privileged EXEC commands.

show license reservation

To display license reservation information, enter the **show license reservation** command in privileged EXEC mode.

show license reservation

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

The command continues to be available on the CLI and corresponding output is displayed, but with the introduction of Smart Licensing Using Policy, the notion of reservation is not longer applicable. Use the **show license all** command in privileged EXEC mode, to display *migrated* SLR licenses instead (the SLR authorization code is migrated to Smart Licensing Using Policy).

show license rum

To display information about Resource Utilization Measurement reports (RUM report) available on the product instance, including report IDs, the current processing state of a report, error information (if any), and to save the detailed or summarized view that is displayed, enter the **show license rum** command in privileged EXEC mode.

show license rum { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*]

Syntax Description

feature { *license_name* | **all** }	Displays RUM report information based on the license name. Specify a particular license name to display all RUM reports for that license, or use the **all** keyword to display all RUM reports available on the product instance.
id { *rum_id* | **all** }	Displays RUM report information based on the RUM report ID. Specify a report ID to display information for a single report, or use the **all** keyword to display all RUM reports available on the product instance.
detail	Displays detailed RUM report information. You can use this to display detailed information by license name and detailed information by RUM report ID.
save *path*	Saves the information that is displayed. This can be the simplified or detailed version and depends on the preceeding keywords you have entered. Information about 200 RUM reports can be displayed. If there are more 200 RUM reports on the product instance, you can view information about all the RUM reports by saving it to a text (.txt) file. **Note** This option saves the information *about* RUM reports and is not for reporting purposes. It does not save the RUM report, which is an XML file containing usage information.

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Usage Guidelines

A RUM report is a license usage report, which the product instance generates, to fulfil reporting requirements as specified by the policy. An acknowledgement (ACK) is a response from CSSM and provides information about the status of a RUM report. Once the ACK for a report is available on the product instance, it indicates

that the corresponding RUM report is no longer required and can be deleted. You can use the **show license rum** command to:

- Display information about the available RUM reports on the product instance - filtered by ID or license name.
- Display a short summary of the information or display a detailed view of the information.
- Track a RUM report throughout its lifecycle (from the time it is first generated until its acknowledgement from CSSM). By displaying the current processing state and condition of a report you can ascertain if and when there is a problem in the reporting workflow.
- Save the displayed information. The CLI displays information about up to 200 reports. If there are more than 200 reports on the product instance and you want to view information about all of them, save the displayed info in a .txt file and export to the desired location to view.

To display a statistical view of RUM report information (the total number of reports on the product instance, the number of reports that have a corresponding ACK, the number of reports waiting for an ACK etc.) refer to the `Usage Report Summary:` section of the **show license all** and **show license tech** privileged EXEC commands.

The **show license tech** command also provides RUM report related information that the Cisco technical support team can use to troubleshoot, if there are problems with RUM reporting.

Examples

Table 11: show license rum (simplified view) Field Descriptions

Field Name	Description
Report Id	A numeric field that identifies a RUM report. The product instance automatically assigns an ID to every RUM report it generates. An ID may be up to 20 characters long.
State	This field displays the current processing state of a RUM report, and can be only one of the following: • OPEN: This means new measurements are been added into this report. • CLOSED: This means no new measurements can be added to this report, and the report is ready for communication to CSSM. • PENDING: This is a transitional status that you may see if you display a report while it is being transmitted. • UNACK: This means the report was transmitted and is waiting for confirmation from CSSM, that it is processed. • ACK: This means the report was processed or acknowledged by CSSM and is eligible for deletion.

Field Name	Description

Flag	Indicates the condition of the RUM report, and is displayed in the form of a character. Each character represents a specific condition, and can be only one of the following values:
	• N: Normal; This means no errors have been detected and the report is going through normal operation.
	• P: Purged; This means the report was removed due to system resource limitation, and can refer to a shortage of disk space or insufficient memory. If this flag is displayed, refer to the `State Change Reason` field in the detailed view for more information.
	• E: Error; This means an error was detected in the RUM report. If this flag is displayed, refer to the detailed view for more information. Possible workflow issues include and are not limited to the following:
	  • RUM report was dropped by CSSM. If this is the issue, the `State` field displays value `ACK`, but the `State Change Reason` does not change to `ACKED`.
	  • RUM Report data is missing. If this is the issue, the `Storage State` field displays value `MISSING` .
	  • Tracking information is missing. If this is the case the `State` field displays value `UNACK` and the `Transaction ID` field has no information.
	Note
	Occasional errors in RUM reports do not require any action from you and are not an indication of a problem. It is only if you see a large number of reports (greater than 10) with errors that you must contact the Cisco technical support team.

Feature Name	The name of the license that the RUM report applies to.

Table 12: show license rum (detailed view) Field Descriptions

Field Name	Description
Report Id	A numeric field that identifies a RUM report. The product instance automatically assigns an ID to every RUM report it generates. An ID may be up to 20 characters long.
Metric Name:	Shows the type of data that is recorded. For a RUM report, the only possible value is ENTITLEMENT, and refers to measurement of license usage.
Feature Name:	The name of the license that the RUM report applies to.
Metric Value	A unique identifier for the data that is recorded. This is the same as the “Entitlement Tag” in the output of the **show license tech** commad and it displays information about the license being tracked.

Field Name	Description
UDI	Composed of the Product ID (PID) and serial number of the product instance.
Previous Report Id:	ID of the previous RUM report that the product instance generated for a license.
Next Report Id:	The ID that the product instance will use for the next RUM report it generates for a llicense.
State:	Displays the current processing state of a RUM report. The value displayed here is always the same as the value displayed in the simplified view.
State Change Reason:	Displays the reason for a RUM report state change. Not all state changes provide a reason. • NONE: This means the RUM report is going through its normal lifecycle (for instance, from OPEN → CLOSED → ACK). This state change reason is usually accompanied by an `N` flag (meaning Normal) in the simplified view and requires no action from you. • ACKED: RUM report was processed normally by CSSM. • REMOVED: RUM report was received and requested to be removed by CSSM. • RELOAD: RUM report state was changed due to some type of device reload.
Start Time: End Time:	Timestamps for measurement start and measurement end for a RUM report. Together, the start time and end time provide the time duration that the measurements cover.
Storage State:	Displays current storage state of the RUM report and can be one of the following values: • EXIST: This means the data for the RUM report is located in storage. • DELETED: This means the data was intentionally deleted. Refer to the `Storage State Change Reason` in the output of the **show license tech** command for more information about this storage state. • PURGED: This means the data was deleted due to a system resource limitation. Refer to the `Storage State Change Reason` in the output of the **show license tech** command for more information about this storage state. • MISSING: This means data is missing from storage. If reports are identified as missing, there is no recovery process.
Transaction ID: Transaction Message:	Contains tracking information for the RUM report. This information can be either polling information or ACK import information. The Transaction Message contains the error message, if the product instance receives one when importing an ACK. The information in these fields is used by the Cisco technical support team when troubleshooting problems with RUM reports.

Example: show license rum feature: Simplified and Detailed View

The following is sample output of the **show license rum feature***license-name* and **show license rum feature***license-name***detail** commands on a Cisco Catalyst 9500 Series Switch. Similar output is displayed on all other Catalyst switches.

The output is filtered to display all RUM reports for the DNA Advantage license, followed by a detailed view of all RUM reports for the DNA Advantage license.

```
Device# show license rum feature air-dna-advantage

Smart Licensing Usage Report:

===================================

Report Id,          State,    Flag, Feature Name

1638055644          CLOSED    N     air-dna-advantage

1638055646          OPEN      N     air-dna-advantage


Device# show license rum feature air-dna-advantage detail
Smart Licensing Usage Report Detail:
===================================
Report Id: 1638055644
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 0,    Next Report Id: 1638055646
  State: CLOSED,      State Change Reason: RELOAD
  Start Time: Nov 28 12:02:09 2021 UTC,      End Time: Nov 30 22:02:13 2021 UTC
  Storage State: EXIST
  Transaction ID: 0
  Transaction Message: <none>

Report Id: 1638055646
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 1638055644,    Next Report Id: 0
  State: OPEN,      State Change Reason: None
  Start Time: Nov 30 23:12:56 2021 UTC,      End Time: Dec 01 02:12:56 2021 UTC
  Storage State: EXIST
  Transaction ID: 0
  Transaction Message: <none>
```

Saving a RUM Report View

The following example shows you how to save the information that is displayed.

By using the **feature** and **all** keywords, the output is filtered to display all RUM reports for all licenses being used on the product instance. It is then transferred it to a TFTP location, from where it can opened, to view the information.

```
Device# show license rum feature all save bootflash:all-rum-stats.txt
Device# copy tftp://10.8.0.6/bootflash:all-rum-stats.txt
```

show license status

To display information about licensing settings such as data privacy, policy, transport, usage reporting and trust codes, enter the **show license status** command in privileged EXEC mode.

show license status

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes `Trust code installed:`, `Policy in use`, `Policy name:` , reporting requirements as in the policy (`Attributes:`), and fields related to usage reporting. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	Command output was updated to display Smart Account and Virtual account information.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Account Information in the output

Starting with Cisco IOS XE Cupertino 17.7.1, every ACK includes the Smart Account and Virtual Account that was reported to, in CSSM. When it receives the ACK, the product instance securely stores only the latest version of this information - as determined by the timestamp in the ACK. The Smart Account and Virtual Account information that is displayed in the `Account Information` section of this command's output is therefore always as per the latest available ACK on the product instance.

If a product instance is moved from one Smart Account and Virtual Account to another, the next ACK after the move will have this updated information. The output of this command is updated once this ACK is available on the product instance.

The ACK may be received directly (where the product instance is connected to CSSM), or indirectly (where the product instance is connect to CSSM through CSLU, Cisco DNA Center, or SSM On-Prem), or by manually importing the ACK (where a product instance is in an air-gapped network).

Examples

For information about the fields shown in the display, see Table 13: show license status Field Descriptions for Smart Licensing Using Policy, on page 326 .

For sample output, see:

- show license status with Account Information (Smart Licensing Using Policy), on page 331
- show license status with Cisco Default Policy (Smart Licensing Using Policy), on page 332
- show license status with Custom Policy (Smart Licensing Using Policy), on page 333

Table 13: show license status Field Descriptions for Smart Licensing Using Policy

Field		Description
Utility	Header for utility settings that are configured on the product instance.	
	Status:	Status
	Utility report:	Last attempt:
	Customer Information:	The following fields are displayed: • Id: • Name: • Street • City: • State: • Country: • Postal Code:
Smart Licensing Using Policy:	Header for policy settings on the product instance.	
	Status:	Indicates if Smart Licensing Using Policy is enabled. Smart Licensing Using Policy is supported starting from Cisco IOS XE Amsterdam 17.3.2 and is always enabled on supported software images.

Field		Description
Account Information:	Header for account information that the product instance belongs to, in CSSM. This section is displayed only if the software version on the product instance is Cisco IOS XE Cupertino 17.7.1 or a later release.	
	Smart Account:	The Smart Account that the product instance is part of. This information is always as per the latest available ACK on the product instance.
	Virtual Account:	The Virtual Account that the product instance is part of. This information is always as per the latest available ACK on the product instance.
Data Privacy:	Header for privacy settings that are configured on the product instance.	
	Sending Hostname:	A *yes* or *no* value which shows if the hostname is sent in usage reports.
	Callhome hostname privacy:	Indicates if the Call Home feature is configured as the mode of transport for reporting. If configured, one of these values is displayed: • ENABLED • DISABLED
	Smart Licensing hostname privacy:	One of these values is displayed: • ENABLED • DISABLED
	Version privacy:	One of these values is displayed: • ENABLED • DISABLED
Transport:	Header for transport settings that are configured on the product instance.	
	Type:	Mode of transport that is in use. Additional fields are displayed for certain transport modes. For example, if transport type is set to CSLU, the CSLU address is also displayed.

Field		Description
Policy:	Header for policy information that is applicable to the product instance.	
	Policy in use:	Policy that is applied This can be one of the following: Cisco default, Product default, Permanent License Reservation, Specific License Reservation, PAK license, Installed on <date>, Controller.
	Policy name:	Name of the policy
	Reporting ACK required:	A *yes* or *no* value which specifies if the report for this product instance requires CSSM acknowledgement (ACK) or not. The default policy is always set to "yes".
	Unenforced/Non-Export Perpetual Attributes	Displays policy values for perpetual licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Unenforced/Non-Export Subscription Attributes	Displays policy values for subscription licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Enforced (Perpetual/Subscription) License Attributes	

Field		Description
		Displays policy values for enforced licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Export (Perpetual/Subscription) License Attributes	Displays policy values for export-controlled licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name
Miscellaneous	Header for custom ID.	
	Custom Id:	ID

Field		Description
Usage Reporting:	Header for usage reporting (RUM reports) information.	
	Last ACK received:	Date and time of last ACK received, in the local time zone.
	Next ACK deadline:	Date and time for next ACK. If the policy states that an ACK is not requires then this field displays `none`. **Note** If an ACK is required and is not received by this deadline, a syslog is displayed.
	Reporting Interval:	Reporting interval in days The value displayed here depends on what you configure in the **license smart usage interval***interval_in_days* and the policy value. For more information, see the corresponding Syntax Description: license smart (global config).
	Next ACK push check:	Date and time when the product instance will submit the next polling request for an ACK. Date and time are in the local time zone. This applies only to product instance- initiated communication to CSSM or CSLU. If the reporting interval is zero, or if no ACK polling is pending, then this field displays `none`.
	Next report push:	Date and time when the product instance will send the next RUM report. Date and time are in the local time zone. If the reporting interval is zero, or if there are no pending RUM reports, then this field displays `none`.
	Last report push:	Date and time for when the product instance sent the last RUM report. Date and time are in the local time zone.
	Last report file write:	Date and time for when the product instance last saved an offline RUM report. Date and time are in the local time zone.
	Last report pull:	Date and time for when usage reporting information was retrieved using data models. Date and time are in the local time zone.

Field		Description
Trust Code Installed:	Header for trust code-related information. Displays date and time if trust code is installed. Date and time are in the local time zone. If a trust code is not installed, then this field displays `none`.	
	Active:	Active product instance. In a High Availability set-up, the the UDIs of all product instances in the set-up, along with corresponding trust code installation dates and times are displayed.
	Standby:	Standby product instance.
	Member:	Member product instance

show license status with Account Information (Smart Licensing Using Policy)

The following is sample output of the **show license status** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1:

```
Device# show license status
Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured
  VRF:
    Not Configured

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
```

```
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Miscellaneous:
  Custom Id: <empty>

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>
```

show license status with Cisco Default Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a default is policy applied here.

```
Device# show license status

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
```

```
    Report on change (days): 0 (CISCO default)

Miscellaneous:
  Custom Id: <empty>

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>
```

show license status with Custom Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a custom policy applied here.

```
Device# show license status
Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured

Policy:
  Policy in use: Installed On Nov 02 05:09:31 2020 IST
  Policy name: SLE Policy
  Reporting ACK required: yes (Customer Policy)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 60 (Customer Policy)
    Reporting frequency (days): 60 (Customer Policy)
    Report on change (days): 60 (Customer Policy)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 30 (Customer Policy)
    Reporting frequency (days): 30 (Customer Policy)
    Report on change (days): 30 (Customer Policy)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 90 (Customer Policy)
    Report on change (days): 90 (Customer Policy)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 90 (Customer Policy)
    Report on change (days): 90 (Customer Policy)

Miscellaneous:
  Custom Id: <empty>
```

```
Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
    INSTALLED on Nov 02 05:09:31 2020 IST
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
    INSTALLED on Nov 02 05:09:31 2020 IST
```

show license summary

To display a brief summary of license usage, which includes information about licenses being used, the count, and status, enter the **show license summary** command in privileged EXEC mode.

show license summary

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect valid license status for Smart Licensing Using Policy. Valid license statuses include: `IN USE`, `NOT IN USE`, `NOT AUTHORIZED`. Command output was also updated to remove registration and authorization information. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	Command output was updated to display Smart Account and Virtual account information.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

The licenses on Cisco Catalyst Wireless Controllers are never `NOT AUTHORIZED`, because none of the available licenses are export-controlled or enforced (Only these licenses require authorization before use).

Account Information in the output

Starting with Cisco IOS XE Cupertino 17.7.1, every ACK includes the Smart Account and Virtual Account that was reported to, in CSSM. When it receives the ACK, the product instance securely stores only the latest version of this information - as determined by the timestamp in the ACK. The Smart Account and Virtual Account information that is displayed in the `Account Information` section of this command's output is therefore always as per the latest available ACK on the product instance.

If a product instance is moved from one Smart Account and Virtual Account to another, the next ACK after the move will have this updated information. The output of this command is updated once this ACK is available on the product instance.

The ACK may be received directly (where the product instance is connected to CSSM), or indirectly (where the product instance is connect to CSSM through CSLU, Cisco DNA Center, or SSM On-Prem), or by manually importing the ACK (where a product instance is in an air-gapped network).

Examples

See Table 14: show license summary Field Descriptions, on page 336 for information about fields shown in the display.

show license summary: IN USE (Smart Licensing Using Policy), on page 336

show license summary: NOT IN USE (Smart Licensing Using Policy), on page 336

Table 14: show license summary Field Descriptions

Field	Description
Account Information: Smart Account: Virtual Account:	The Smart Account and Virtual Account that the product instance is part of. This information is always as per the latest available ACK on the product instance. This field is displayed only if the software version on the product instance is Cisco IOS XE Cupertino 17.7.1 or a later release.
License	Name of the licenses in use
Entitlement Tag	Short name for license
Count	License count
Status	License status can be one of the following • In-Use: Valid license, and in-use. • Not In-Use • Not Authorized: Means that the license requires installation of SLAC before use.

show license summary: IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1:

```
Devide# show license summary

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

License Usage:
  License                 Entitlement Tag               Count Status
  -----------------------------------------------------------------------------
  air-network-essentials  (DNA_NWSTACK_E)                   1 IN USE
  air-dna-essentials      (AIR-DNA-E)                       1 IN USE
```

show license summary: NOT IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command, where no APs have joined the controller. Current consumption (Count) is therefore zero, and the `Status` field shows that the licenses are `NOT IN USE`:

```
Device# show license summary

Device#show license summary
License Reservation is ENABLED

License Usage:
  License                 Entitlement Tag               Count Status
  -----------------------------------------------------------------------------
  Aironet DNA Advantag... (AIR-DNA-A)                       0 NOT IN USE
  AP Perpetual Network... (DNA_NWStack)                     0 NOT IN USE
```

show license tech

To display licensing information to help the technical support team to solve a problem, enter the **show license tech** command in privileged EXEC mode. The output for this command includes outputs of several other **show license** commands and more.

show license tech { **message** | **rum** { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*] | **support** }

Syntax Description

message	Displays messages concerning trust establishment, usage reporting, result polling, authorization code requests and returns, and trust synchronization. This is the same information as displayed in the output of the **show license history message** command.
rum { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*]	Displays information about Resource Utilization Measurement reports (RUM reports) on the product instance, including report IDs, the current processing state of a report, error information (if any), and an option save the displayed RUM report information. **Note** This option saves the information *about* RUM reports and is not for reporting purposes. It does not save the RUM report, which is an XML file containing usage information.
support	Displays licensing information that helps the technical support team to debug a problem.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy.

Release	Modification
Cisco IOS XE Cupertino 17.7.1	The **rum** keyword and additional options under this keyword were added: { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } The output of the **show license tech support** command was enhanced to display the following information: • RUM report information, in section `License Usage` and `Usage Report Summary`. • Smart Account and Virtual account information, in section `Account Information:`. The **data conversion**, **eventlog** and **reservation** keywords were removed from this command. They continute to be available as separate show commands, that is, **show license data**, **show license eventlog**, and **show license reservation** respectively.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing (whether smart licensing is enabled, all associated licensing certificates, compliance status, and so on).

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy. Note the following guidelines:

- Troubleshooting with a Support Representative

  When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

- RUM Report Information in the output

  - The output of the **show license tech support** command displays the following sections pertaining to RUM reports:

    Table 15: show license tech support: Field Descriptions for Header "License Usage", on page 340

    ```
    <output truncated>
    License Usage
    =============
      Measurements:
        ENTITLEMENT:
          Interval: 00:15:00
          Current Value: 800
          Current Report: 1638055645       Previous: 0
     <output truncated>
    ```

    Table 16: show license tech support: Field Descriptions for Header "Usage Report Summary", on page 341

    ```
    <output truncated>
    Usage Report Summary:
    =====================
    Total: 4,  Purged: 0(0)
    ```

```
Total Acknowledged Received: 0,  Waiting for Ack: 0(4)
Available to Report: 4  Collecting Data: 2
Maximum Display: 4  In Storage: 4,  MIA: 0(0)
Report Module Status: Ready

<output truncated>
```

- The output of the **show license tech rum** command when used with the **detail** keyword, displays the following fields pertaining to RUM reports: Table 17: show license tech rum: Field Descriptions for Header "Smart Licensing Usage Report Detail", on page 341.

  The options available under the **show license tech rum** keyword are the same as the options available with the **show license rum** privileged EXEC command. The sample output that is displayed in the *simplified view* is also the same. But if you use the **detail** keyword (for example if you enter **show license tech rum feature** *license_name* **detail**), the detailed view is displayed and this has a few *additional* fields when compared to **show license rum**.

```
<output truncated>
Smart Licensing Usage Report Detail:
====================================
Report Id: 1638055644
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value:
regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 0,    Next Report Id: 1638055646
  Version: 2.0
  State: CLOSED,      State Change Reason: RELOAD
  Start Time: Nov 28 12:02:09 2021 UTC,      End Time: Nov 30 22:02:13 2021 UTC
  Storage State: EXIST,  Storage State Change Reason: None
  Transaction ID: 0
  Transaction Message: <none>
  Report Size: 54880(54987)
<output truncated>
```

Table 15: show license tech support: Field Descriptions for Header "License Usage"

Field Name	Description
Interval:	This is a fixed measurement duration and is always 15 minutes.
Current Value:	Information about the current license count.
Current Report:	ID of the currently OPEN report for the license.
Previous:	ID of the last OPEN report for the license. This report will have state CLOSED now.

Table 16: show license tech support: Field Descriptions for Header "Usage Report Summary"

Field Name	Description
Total:	Total number of reports that the product instance has ever generated. **Note** This total does not refer to the total number of reports *currently available* on and being tracked by the product instance. For this you must sum up the `Total Acknowledged Received:` and `Available to Report` fields.
Purged:	The number of reports deleted due to a system resource limitation. This number includes RUM reports where the product instance no longer has tracking information.
Total Acknowledged Received:	The number of RUM reports acknowledged on this product instance.
Waiting for Ack:	The number of RUM reports waiting for an ACK. This is the total number of reports in an `UNACK` state, where the product instance still has tracking information.
Available to Report:	The number of RUM reports that are available to send to CSSM. This is the total number of reports in an `OPEN` or `CLOSED` state, where the product instance still has tracking information.
Collecting Data:	Number of reports where the product instance is currently collecting measurements.
Maximum Display:	Number of reports available for display in a **show** command's output.
In Storage:	Number of reports currently stored on the disk
MIA:	The number of reports missing.

Table 17: show license tech rum: Field Descriptions for Header "Smart Licensing Usage Report Detail"

Field Name	Description
Version:	Displays the format of the report during transmission. Starting with Cisco IOS XE Cupertino 17.7.1, RUM reports are stored in a new format that reduces processing time. This field indicates if the product instance is using the old format or the new format.

Field Name	Description
Storage State:	Indicates if a given report is currently in storage. In addition to the displaying the current storage state of the RUM report, with these possible values: EXIST, DELETED, PURGED, MISSING, if a "(1)" is displayed next to the label (`Storage State (1)`), this means the RUM report is in the older (pre-17.7.1 format) and will be processed accordingly. If the RUM report is in the new format, the field is displayed as `Storage State` - without any extra information.
Storage State Change Reason:	Displays the reason for the change in the storage state change. Not all state changes provide a reason. • NONE: This means no reason was recorded for the the storage state change. • PROCESSED: This means the RUM report was deleted after CISCO has processed the data. • LIMIT_STORAGE: This means the RUM report was deleted because the product instance reached it's storage limit. • LIMIT_TIME: This means the RUM report was deleted because the report reached the persisted time limit.
Transaction ID: Transaction Message:	If the transaction ID displays a correlation ID and an error status is displayed, the product instance displays the error code field in this section. If there are no errors, no data is displayed here.
Report Size	This field displays two numbers. The first number is the size of raw report for communication, in bytes. The second number is the disk space used for saving the report, also in bytes. The second number is displayed only if report is stored in the new format.

show license tech support on Cisco Catalyst 9800-CL Wireless Controller

The following is sample output from the **show license tech support** command on a Cisco Catalyst 98000-CL Wireless Controller running software version Cisco IOS XE Cupertino 17.7.1:

```
Device# show license tech support
Smart Licensing Tech Support info

Smart Licensing Status
======================

Smart Licensing is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED
```

```
Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: <none>
  Virtual Account: <none>

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Address: <empty>
    Port: <empty>
    Username: <empty>
    Password: <empty>
  Server Identity Check: True
  VRF: <empty>

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting) State(1) InPolicy(0)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

License Usage
=============
Handle: 1
  License: air-network-advantage
  Entitlement Tag:
regid.2018-06.com.cisco.DNA_NWStack,1.0_e7244e71-3ad5-4608-8bf0-d12f67c80896
  Description: air-network-advantage
  Count: 0
```

```
  Version: 1.0
  Status: NOT IN USE(1)
  Status time: Oct 05 22:24:24 2021 UTC
  Request Time: None
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Measurements:
    ENTITLEMENT:
      Interval: 00:15:00
      Current Value: 0
      Current Report: 0       Previous: 0
  Soft Enforced: True

Handle: 2
  License: air-dna-advantage
  Entitlement Tag: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790

  Description: air-dna-advantage
  Count: 0
  Version: 1.0
  Status: NOT IN USE(1)
  Status time: Oct 05 22:24:24 2021 UTC
  Request Time: None
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Subscription
  Measurements:
    ENTITLEMENT:
      Interval: 00:15:00
      Current Value: 0
      Current Report: 0       Previous: 0
  Soft Enforced: True

Product Information
===================
UDI: PID:C9800-CL-K9,SN:9KGIXIDOXFE

HA UDI List:
    Active:PID:C9800-CL-K9,SN:9KGIXIDOXFE
    Standby:PID:C9800-CL-K9,SN:9UBKZU955E4

Agent Version
=============
Smart Agent for Licensing: 5.3.14_rel/47

Upcoming Scheduled Jobs
=======================
Current time: Oct 06 00:38:46 2021 UTC
Daily: Oct 06 21:24:22 2021 UTC (20 hours, 45 minutes, 36 seconds remaining)
Authorization Renewal: Expired Not Rescheduled
Init Flag Check: Expired Not Rescheduled
Reservation configuration mismatch between nodes in HA mode: Expired Not Rescheduled
Start Utility Measurements: Oct 06 00:39:25 2021 UTC (39 seconds remaining)
Send Utility RUM reports: Oct 06 22:24:54 2021 UTC (21 hours, 46 minutes, 8 seconds remaining)
Save unreported RUM Reports: Oct 06 01:24:35 2021 UTC (45 minutes, 49 seconds remaining)
Data Synchronization: Expired Not Rescheduled
External Event: Expired Not Rescheduled
Operational Model: Expired Not Rescheduled
```

```
Communication Statistics:
=========================
Communication Level Allowed: INDIRECT
Overall State: Insufficient trust for direct communication
Trust Establishment:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Trust Acknowledgement:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Usage Reporting:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Result Polling:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Request:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Confirmation:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Return:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Trust Sync:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Hello Message:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>

License Certificates
====================
Production Cert: False
Not registered. No certificates installed
```

```
HA Info
==========
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Message Flow Allowed: False

Reservation Info
================
License reservation: DISABLED

Overall status:
  Active: PID:C9800-CL-K9,SN:9KGIXIDOXFE
       Reservation status: NOT INSTALLED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: <none>
       Reservation authorization code: <none>
  Standby: PID:C9800-CL-K9,SN:9UBKZU955E4
       Reservation status: NOT INSTALLED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: <none>
       Reservation authorization code: <none>

Specified license reservations:

Purchased Licenses:
  No Purchase Information Available

Usage Report Summary:
=====================
Total: 0,  Purged: 0(0)
Total Acknowledged Received: 0,  Waiting for Ack: 0(0)
Available to Report: 0  Collecting Data: 0
Maximum Display: 0  In Storage: 0,  MIA: 0(0)
Report Module Status: Ready

Other Info
==========
Software ID: regid.2018-05.com.cisco.WLC_9500C,1.0_85665885-b865-4e32-8184-5510412fcb54
Agent State: authorized
TS enable: True
Transport: Smart
  Default URL: https://smartreceiver.cisco.com/licservice/license
Locale: en_US.UTF-8
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char)  : 1
sizeof(int)   : 4
sizeof(long)  : 4
sizeof(char *): 8
sizeof(time_t): 4
sizeof(size_t): 8
Endian: Big
Write Erase Occurred: False
XOS version: 0.12.0.0
Config Persist Received: False
Message Version: 1.3
```

```
connect_info.name: <empty>
connect_info.version: <empty>
connect_info.additional: <empty>
connect_info.prod: False
connect_info.capabilities: <empty>
agent.capabilities: UTILITY, DLC, AppHA, MULTITIER, EXPORT_2, OK_TRY_AGAIN
Check Point Interface: True
Config Management Interface: False
License Map Interface: True
HA Interface: True
Trusted Store Interface: True
Platform Data Interface: True
Crypto Version 2 Interface: False
SAPluginMgmtInterfaceMutex: True
SAPluginMgmtIPDomainName: True
SmartTransportVRFSupport: True
SmartAgentClientWaitForServer: 2000
SmartAgentCmReTrySend: True
SmartAgentClientIsUnified: True
SmartAgentCmClient: True
SmartAgentClientName: UnifiedClient
builtInEncryption: True
enableOnInit: True
routingReadyByEvent: True
systemInitByEvent: True
SmartTransportServerIdCheck: True
SmartTransportProxySupport: True
SmartAgentPolicyDisplayFormat: 0
SmartAgentReportOnUpgrade: False
SmartAgentIndividualRUMEncrypt: 2
SmartAgentMaxRumMemory: 2
SmartAgentConcurrentThreadMax: 10
SmartAgentPolicyControllerModel: False
SmartAgentPolicyModel: True
SmartAgentFederalLicense: True
SmartAgentMultiTenant: False
attr365DayEvalSyslog: True
checkPointWriteOnly: False
SmartAgentDelayCertValidation: False
enableByDefault: False
conversionAutomatic: True
conversionAllowed: False
storageEncryptDisable: False
storageLoadUnencryptedDisable: False
TSPluginDisable: False
bypassUDICheck: False
loggingAddTStamp: False
loggingAddTid: True
HighAvailabilityOverrideEvent: UnknownPlatformEvent
platformIndependentOverrideEvent: UnknownPlatformEvent
platformOverrideEvent: UnknownPlatformEvent
WaitForHaRole: False
standbyIsHot: True
chkPtType: 2
delayCommInit: False
roleByEvent: True
maxTraceLength: 150
traceAlwaysOn: True
debugFlags: 0
Event log max size: 5120 KB
Event log current size: 3 KB
P:C9800-CL-K9,S:9KGIXIDOXFE: No Trust Data
P:C9800-CL-K9,S:9UBKZU955E4: No Trust Data
Overall Trust: No ID
```

```
Clock sync-ed with NTP: True

Platform Provided Mapping Table
===============================
  C9800-CL-K9: Total licenses found: 5
Enforced Licenses:
  P:C9800-CL-K9,S:9KGIXIDOXFE:
    No PD enforced licenses
  P:C9800-CL-K9,S:9UBKZU955E4:
    No PD enforced licenses
```

Example (Smart Licensing Using Policy)

The following is sample output from the **show license tech support** command.

```
Device# show license tech support

Smart Licensing Tech Support info

Smart Licensing Status
======================

Smart Licensing is ENABLED
License Reservation is ENABLED

Registration:
  Status: REGISTERED - SPECIFIC LICENSE RESERVATION
  Export-Controlled Functionality: ALLOWED
  Initial Registration: SUCCEEDED on Nov 02 03:16:01 2020 IST

License Authorization:
  Status: AUTHORIZED - RESERVED on Nov 02 03:16:01 2020 IST

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license

Evaluation Period:
  Evaluation Mode: Not In Use
  Evaluation Period Remaining: 89 days, 23 hours, 42 minutes, 47 seconds

License Usage
=============
Handle: 1
  License: AP Perpetual Networkstack Advantage
  Entitlement tag:
regid.2018-06.com.cisco.DNA_NWStack,1.0_e7244e71-3ad5-4608-8bf0-d12f67c80896
  Description: AP Perpetual Network Stack entitled with DNA-A
  Count: 1
  Version: 1.0
```

```
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Handle: 2
  License: Aironet DNA Advantage Term Licenses
  Entitlement tag: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790

  Description: DNA Advantage for Wireless
  Count: 1
  Version: 1.0
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Product Information
===================
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN

Agent Version
=============
Smart Agent for Licensing: 4.8.7_rel/52

Upcoming Scheduled Jobs
=======================
Current time: Nov 02 03:17:23 2020 IST
Daily: Nov 03 02:47:04 2020 IST (23 hours, 29 minutes, 41 seconds remaining)
Certificate Renewal: Not Available
Certificate Expiration Check: Not Available
Authorization Renewal: Not Available
Authorization Expiration Check: Not Available
Init Flag Check: Not Available
Evaluation Expiration Check: Not Available
Ack Expiration Check: Not Available
Evaluation Expiration Warning: Not Available
IdCert Expiration Warning: Not Available
Reservation request in progress warning: Not Available
Reservation configuration mismatch between nodes in HA mode: Nov 09 03:16:30 2020 IST (6
days, 23 hours, 59 minutes, 7 seconds remaining)
Endpoint Report Request: Not Available

License Certificates
====================
Production Cert: True
Not registered. No certificates installed

HA Info
==========
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Message Flow Allowed: False
```

```
Reservation Info
================
License reservation: ENABLED

Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
       Reservation status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
       Export-Controlled Functionality: ALLOWED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: 102fc949
       Reservation authorization code:
<specificReservationContext><snVersion>1</snVersion><snId>93BBAH93MGS</snId><date>1604
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID><entitlement><entitlement><tagregid.2017-08.com.cisco.AIR-DNA-A,1.0_6b867-3b04-11-a9-5891a079</tag><qty>5</qty><startDate>2020-Jun-18
 UTC</startDate><endDate>2020-Dec-15
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID><entitlement><entitlement><tagregid.2018-06.com.cisco.DNA_Wireless,1.0_e7447-3a54-4088-bf0-12f67886</tag><qty>5</qty><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID><entitlement><entitlement><tagregid.2018-06.com.cisco.DNA_Wireless,1.0_e7447-3a54-4088-bf0-12f67886</tag><qty>5</qty><startDate>2020-Jun-18
 UTC</startDate><endDate>2020-Dec-15
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID></entitlement></entitlement><authorizationCode><signature>MIQG4AYJKoZIhvcNAQcCoIQG1TCCBtECAQMxDTALBglghkgBZQMEAgEwgfMGCyqGSIb3DQEJEAEEoIHjBIHgMIHdAgEBBgkrBgEEAYKXRgEwITAJBgUrDgMCGgUABBSJ0Ux+Ge3Ww0Ks/Ow2Ql+Ge3WwIVAMWaLQ2Q==</signature><devices><deviceId>PID:C9800-CL-K9,SN:93BBAH93MGS</deviceId></devices></authorizationCode></specificReservationContext>

  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
       Reservation status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
       Export-Controlled Functionality: ALLOWED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: ad4382fe
       Reservation authorization code:
<specificReservationContext><snVersion>1</snVersion><snId>9XECPSUU4XN</snId><date>1604
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID><entitlement><entitlement><tagregid.2017-08.com.cisco.AIR-DNA-A,1.0_6b867-3b04-11-a9-5891a079</tag><qty>10</qty><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID></entitlement></entitlement><authorizationCode><signature>MIQG4AYJKoZIhvcNAQcCoIQG1TCCBtECAQMxDTALBglghkgBZQMEAgEwgfMGCyqGSIb3DQEJEAEEoIHjBIHgMIHdAgEBBgkrBgEEAYKXRgEwITAJBgUrDgMCGgUABBSJ0Ux+Ge3Ww0Ks/Ow2Ql+Ge3WwIVAMWaLQ2Q==</signature><devices><deviceId>PID:C9800-CL-K9,SN:9XECPSUU4XN</deviceId></devices></authorizationCode></specificReservationContext>

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
          Subscription ID: <none>
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
          Subscription ID: <none>
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
```

```
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
          Subscription ID: <none>
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
          Subscription ID: <none>
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
          Subscription ID: <none>
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
          Subscription ID: <none>

Other Info
==========
Software ID: regid.2018-05.com.cisco.WLC_9500C,1.0_85665885-b865-4e32-8184-5510412fcb54
Agent State: authorized
TS enable: True
Transport: Smart
  Default URL: https://smartreceiver.cisco.com/licservice/license
Locale: en_US.UTF-8
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char)  : 1
sizeof(int)   : 4
sizeof(long)  : 4
sizeof(char *): 8
sizeof(time_t): 4
sizeof(size_t): 8
Endian: Big
Write Erase Occurred: False
XOS version: 0.12.0.0
Config Persist Received: False
Message Version: 1.3
connect_info.name: <empty>
connect_info.version: <empty>
connect_info.additional: <empty>
connect_info.prod: False
connect_info.capabilities: <empty>
agent.capabilities: UTILITY, DLC, AppHA, MULTITIER, EXPORT_2, OK_TRY_AGAIN
SmartAgentClientWaitForServer: 2000
SmartAgentCmReTrySend: True
SmartAgentClientIsUnified: True
SmartAgentCmClient: True
SmartAgentClientName: UnifiedClient
builtInEncryption: True
enableOnInit: True
routingReadyByEvent: True
```

```
systemInitByEvent: True
SmartAgentFederalLicense: True
SmartAgent_Crypto_Exit_CB: 0x55B353357A20
SmartAgent_Crypto_Start_CB: 0x55B353357A10
SmartAgentMultiTenant: False
attr365DayEvalSyslog: True
checkPointWriteOnly: False
SmartAgentDelayCertValidation: False
enableByDefault: False
conversionAutomatic: True
conversionAllowed: False
storageEncryptDisable: False
storageLoadUnencryptedDisable: False
TSPluginDisable: False
bypassUDICheck: False
loggingAddTStamp: False
loggingAddTid: True
platformOverrideEvent: UnknownPlatformEvent
WaitForHaRole: False
standbyIsHot: True
chkPtType: 2
delayCommInit: False
roleByEvent: True
maxTraceLength: 150
traceAlwaysOn: True
debugFlags: 0
Event log max size: 5120 KB
Event log current size: 21 KB

Platform Provided Mapping Table
================================
<empty>
```

show license udi

To display Unique Device Identifier (UDI) information for a product instance, enter the **show license udi** command in privileged EXEC mode. In a High Availability set-up, the output displays UDI information for all connected product instances.

show license udi

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Examples

show license udi with Standalone Product Instance, on page 353

show license udi with Active and Standby, on page 353

show license udi with Standalone Product Instance

The following is sample output from the **show license udi** command on a standalone product instance.

```
Device# show license udi

UDI: PID:C9800-L-F-K9,SN:FCW2323W016
```

show license udi with Active and Standby

The following is sample output from the **show license udi** command in a High Availability set-up where an active and a standby product instances exist. UDI information is displayed for both.

```
Device# show license udi

UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN
```

show license usage

To display license usage information such as status, a count of licenses being used, and enforcement type, enter the **show license usage** command in privileged EXEC mode.

show license usage

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC

Command History

Release	Modification
This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.3.2	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes the `Status`, `Enforcement type` fields. Command output was also updated to remove reservation related information, authorization status information, and export status information.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Examples

See Table 18: show license usage Field Descriptions, on page 354 for information about fields shown in the display.

show license usage with unenforced licenses (Smart Licensing Using Policy), on page 355

show license usage with unenforced SLR licenses (Smart Licensing Using Policy), on page 356

Table 18: show license usage Field Descriptions

Field	Description
License Authorization: Status:	Displays overall authorization status.
():	Name of the license as in CSSM. If this license is one that requires an authorization code, the name of the li the code.

Field	Description
Description	Description of the license as in CSSM.
Count	License count. If the license is not in-use, the count is reflected as ze
Version	Version.
Status	License status can be one of the following • In-Use: Valid license, and in-use. • Not In-Use • Not Authorized: Implies that the license requires installation of
Export Status:	Indicates if this license is export-controlled or not. Accordingly, one of is displayed: • RESTRICTED - ALLOWED • RESTRICTED - NOT ALLOWED • NOT RESTRICTED
Feature name	Name of the feature that uses this license.
Feature Description:	Description of the feature that uses this license.
Utility Subscription id:	ID Not applicable, because the corresponding confiuration option is not
Enforcement type	Enforcement type status for the license. This may be one of the follo • ENFORCED • NOT ENFORCED • EXPORT RESTRICTED - ALLOWED • EXPORT RESTRICTED - NOT ALLOWED

show license usage with unenforced licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Unenforced licenses are in-use here.

```
Device# show license usage

License Authorization:
  Status: Not Applicable

air-network-essentials (DNA_NWSTACK_E):
  Description: air-network-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-essentials
```

```
  Feature Description: air-network-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual

air-dna-essentials (AIR-DNA-E):
  Description: air-dna-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-essentials
  Feature Description: air-dna-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual
```

show license usage with unenforced SLR licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Migrated SLR licenses are in-use here:

```
Device# show license usage

air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20
```

show platform hardware chassis active qfp feature nat datapath pool

To view the NAT datapath pool details, use the **show platform hardware chassis active qfp feature nat datapath pool** command.

show platform hardware chassis active qfp feature nat datapath pool

Syntax Description

This command has no arguments

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the NAT datapath pool details.

```
Device# show platform hardware chassis active qfp feature nat datapath pool
pool_id 1 type 1 addroute 0 mask 0xfffffffc allocated 0 misses 0 rotary idx 0x0 ahash sz 4
size 1 max_pat_hash_size 1 next 0x0 hash_index 0x32, hilo ports 0x0 pool mem 0xde480010
flags 0x1 pool_name: test_nat_pool pat_wl 0 no_ports_wl 0 num_maps 1 num_overload_maps 1
vrf 0x0 port_used tcp 0 udp 0
Conf block info
start 62.1.1.102 end 62.1.1.102 flags 0x0 next 0x0 prev 0x0
TCP PAT block info
UDP PAT block info
ICMP PAT block info
GRE PAT block info
Alloced addr info
```

show platform hardware chassis active qfp feature nat datapath stats

To view the NAT datapath statistics, use the **show platform hardware chassis active qfp feature nat datapath stats** command.

show platform hardware chassis active qfp feature nat datapath stats

Syntax Description

This command has no arguments

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the NAT datapath statistics.

```
Device# show platform hardware chassis active qfp feature nat datapath stats
Counter Value
-------------------------------------------------------------------------------
number_of_session 0
udp 0
tcp 0
icmp 0
non_extended 0
statics 0
static_net 0
entry_timeouts 0
hits 0
misses 0
cgn_dest_log_timeouts 0
ipv4_nat_alg_bind_pkts 0
ipv4_nat_alg_sd_not_found 0
ipv4_nat_alg_sd_tail_not_found 0
ipv4_nat_rx_pkt 2043
ipv4_nat_tx_pkt 122169
ipv4_nat_flowdb_hits 0
ipv4_nat_stick_rx_pkts 0
ipv4_nat_stick_i2o_pkts 0
ipv4_nat_stick_o2i_pkts 0
ipv4_nat_stick_forus_hits_pkts 0
ipv4_nat_stick_hit_sb 0
ipv4_nat_stick_ha_divert_pkts 0
ipv4_nat_stick_ha_ar_pkts 0
ipv4_nat_stick_ha_tcp_fin 0
ipv4_nat_stick_ha_failed_pkts 0
ipv4_nat_non_natted_in2out_pkts 122165
ipv4_nat_non_nated_out2in_pkts 0
ipv4_nat_bypass_pkts 0
```

```
ipv4_nat_unmarked_pkts 0
ipv4_nat_res_port_in2out_pkts 0
ipv4_nat_res_port_out2in_pkts 0
ipv4_nat_ipc_retry_fail 0
ipv4_nat_cfg_rcvd 2
ipv4_nat_cfg_rsp 2
```

show platform software nat chassis active F0 translation

To verify the IP NAT statistics on active chassis, use the **show platform software nat chassis active F0 translation** command.

show platform software nat chassis active F0 translation

Syntax Description

nat	Displays information about NAT.
chassis	Displays information about the chassis.
active	Specifies the Active instance.
F0	Displays the audit log for the Embedded-Service-Processor slot 0.
translation	Displays the translation details.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the static NAT without VRF on active chassis.

```
Device# show platform software nat chassis active F0 translation
Pro Inside global Inside local Outside local Outside global
--- 62.1.1.15 155.1.100.1 --- ---
--- 62.1.1.16 155.1.0.4 --- ---
udp 62.1.1.16:33334 155.1.0.4:33334 62.1.1.11:33333 62.1.1.11:33333
udp 62.1.1.16:30000 155.1.0.4:30000 62.1.1.11:30000 62.1.1.11:30000
Total number of translations: 4
```

The following command displays the dynamic NAT without VRF on active chassis,.

```
Device# show platform software nat chassis active F0 translation
Pro Inside global Inside local Outside local Outside global
udp 62.1.1.101:30000 155.1.100.1:30000 62.1.1.11:30000 62.1.1.11:30000
Total number of translations: 1
```

The following command displays the static NAT with VRF on active chassis.

```
Device# show platform software nat chassis active F0 translation
Pro Inside global Inside local Outside local Outside global
--- 62.1.1.15 155.1.100.1 --- ---
--- 62.1.1.16 155.1.0.4 --- ---
udp 62.1.1.16:33334 155.1.0.4:33334 62.1.1.11:33333 62.1.1.11:33333
```

```
udp 62.1.1.16:30000 155.1.0.4:30000 62.1.1.11:30000 62.1.1.11:30000
Total number of translations: 4
```

The following command displays the dynamic NAT with VRF on active chassis.

```
Device# show platform software nat chassis active F0 translation
Pro Inside global Inside local Outside local Outside global
udp 62.1.1.101:30000 155.1.100.1:30000 62.1.1.11:30000 62.1.1.11:30000
Total number of translations: 1
```

show platform software nat chassis active r0 timeout

To view the NAT timeout details, use the **show platform software nat chassis active r0 timeout** command.

show platform software nat chassis active r0 timeout

Syntax Description

This command has no arguments

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following command displays the NAT timeout details.

```
Device# show platform software nat chassis active r0 timeout
Dump NAT timeout config
Type: generic, Timeout (sec): 86400, Enabled: Yes
Type: tcp, Timeout (sec): 86400, Enabled: Yes
Type: tcp-pptp, Timeout (sec): 86400, Enabled: Yes
Type: udp, Timeout (sec): 60, Enabled: Yes
Type: tcp-fin-reset, Timeout (sec): 60, Enabled: Yes
Type: tcp-syn, Timeout (sec): 60, Enabled: Yes
Type: dns, Timeout (sec): 60, Enabled: Yes
Type: icmp, Timeout (sec): 60, Enabled: Yes
Type: skinny, Timeout (sec): 60, Enabled: Yes
Type: icmp-error, Timeout (sec): 60, Enabled: Yes
Type: esp, Timeout (sec): 300, Enabled: Yes
Type: rtmap, Timeout (sec): 3600, Enabled: Yes
```

show platform software rif-mgr chassis active | standby r0 gateway-statistics

To view detailed statistics of the gateway that acts as the communication intermediary between the active and standby controller, use the **show platform software rif-mgr chassis { active | standby } r0 gateway-statistics** command.

show platform software rif-mgr chassis { active | standby} r0 gateway-statistics

Syntax Description

gateway-statistics	Displays the statistics related to the gateway.

Command Default

None

Command Modes

Privileged EXEC (#) mode

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

This example displays the statistics related to the **active** gateway.

```
Device# show platform software rif-mgr chassis active r0 gateway-statistics

Number of L2 (ARP/ND) probes sent        : 164890
Number of ICMP probes sent               : 20
Number of L2 (ARP/ND) responses received : 164878
Number of ICMP responses received        : 0
Number of L2 (ARP/ND) responses failed   : 12
Number of ICMP responses failed          : 20
Last fail count                          : 32  at (05/26/25 18:21:33)
Longest fail count                       : 32  at (05/26/25 18:21:33)
```

Examples

This example displays the statistics related to the **standby** gateway.

```
Device# show platform software rif-mgr chassis standby r0 gateway-statistics

Number of L2 (ARP/ND) probes sent        : 0
Number of ICMP probes sent               : 164760
Number of L2 (ARP/ND) responses received : 0
Number of ICMP responses received        : 164759
Number of L2 (ARP/ND) responses failed   : 0
Number of ICMP responses failed          : 1
Last fail count                          : 1  at (05/26/25 18:24:42)
Longest fail count                       : 1  at (01/01/70 00:00:00)
```

Field	Description
Last Fail Count	is the sum of the most recent continuous ICMP and ARP/ND failures, whereas the "longest fail count" represents the longest sequence of continuous failures recorded since the system booted.

Field	Description
Longest fail count	represents the longest sequence of continuous failures recorded since the system booted.

show platform software rif-mgr chassis active | standby r0 resource-status

To verify the Redundancy Port Interface (RIF) resource status in an active or standby instance, use the **show platform software rif-mgr chassis { active | standby } r0 resource-status** command.

show platform software rif-mgr chassis { active | standby } r0 resource-status

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
r0	Specifies the Route-Processor slot 0.
resource-status	Displays the resource status.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was modified. The output of this command is updated for enhanced gateway visibility.
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

The RIF resource status displays the RP status, RMI status, Current Chassis State, and Peer Chassis State.

Example

The following example shows how to verify the RIF resource status in **active** instance:

```
Device# show platform software rif-mgr chassis active r0 resource-status
RIF Resource Status

RP Status  : Up
RMI Status : Up
Current Chassis State : Active
Peer Chassis State    : Standby
Gateway Monitoring Configured  : True
Gateway Monitoring Interval    : 10
Gateway Status      : Up
Peer Gateway Status : Up
```

Table 19: Output Descriptions

Field	Description or Possible Values
RP Status	Indicates the operational status of the Route Processor (RP), which is responsible for device control and management functions.

Field	Description or Possible Values
Current Chassis State	Represents the current operational state of the local chassis within the device pair or redundant system. Values are: • Active • Active-Recovery
Peer Chassis State	Displays the operational state of the peer chassis, indicating its current role in redundancy or failover scenarios. Values are. Values for • Standby • Standby-Recovery • Standby-RP-Recovery • Unknown
Gateway Monitoring Configured	If this field is **True**, the device actively monitors the configured gateway(s) according to the monitoring policy. If **False**, no gateway monitoring is performed.
Gateway Monitoring Interval	The interval is between 8 and 12 seconds. A shorter interval means more frequent monitoring, while a longer interval reduces monitoring frequency.
Gateway Status	Shows the operational and connectivity status of the monitored gateway interface for this chassis.. • Up • Down • Likely Down • Untracked
Peer Gateway Status	Presents the current status of the monitored gateway on the peer chassis, which helps assess redundancy and failover readiness. • Up • Down • Likely Down • Untracked

The following example shows how to verify the RIF resource status in **standby** instance:

```
Device# show platform software rif-mgr chassis standby r0 resource-status
RIF Resource Status

RP Status  : Up
RMI Status : Up
Current Chassis State : Standby
Peer Chassis State    : Active
Gateway Monitoring Configured  : True
Gateway Monitoring Interval    : 10
Gateway Status      : Up
Peer Gateway Status : Up
```

Table 20: Output Descriptions for Standby

Field	Description or Possible Values
Current Chassis State	Represents the current operational state of the local chassis within the device pair or redundant system. Values are: • Standby • Standby-Recovery • Standby-RP-Recovery • Unknown
Peer Chassis State	Displays the operational state of the peer chassis, indicating its current role in redundancy or failover scenarios. Values are. • Active • Active-Recovery

show platform software rif-mgr chassis active R0 rmi-connection-details

To verify the RMI link re-establishment count and the time since it is Up or Down in an active instance, use the **show platform software rif-mgr chassis active R0 rmi-connection-details** command.

show platform software rif-mgr chassis active R0 rmi-connection-details

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
active	Specifies the Active instance.
R0	Specifies the Route-Processor slot 0.
rmi-connection-details	Displays the RMI connection details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to verify the RMI link re-establishment count and the time since it is Up in an active instance:

```
Device# show platform software rif-mgr chassis active R0 rmi-connection-details
RMI Connection Details
    RMI Link re-establish count : 2
    RMI Link Uptime             : 21 hours 8 minutes 43 seconds
    RMI Link Upsince            : 08/05/2021 13:46:01
```

The following example shows how to verify the RMI link re-establishment count and the time since it is Down in an active instance:

```
Device# show platform software rif-mgr chassis active R0 rmi-connection-details
RMI Connection Details
    RMI Link re-establish count : 1
    RMI Link Downtime           : 28 seconds
    RMI Link Downsince          : 07/16/2021 03:19:11
```

show platform software rif-mgr chassis standby R0 rmi-connection-details

To verify the RMI link re-establishment count and the time since it is Up or Down in a standby instance, use the **show platform software rif-mgr chassis standby R0 rmi-connection-details** command.

show platform software rif-mgr chassis standby R0 rmi-connection-details

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
standby	Specifies the Standby instance.
R0	Specifies the Route-Processor slot 0.
rmi-connection-details	Displays the RMI connection details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to verify the RMI link re-establishment count and the time since it is Up in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 rmi-connection-details
RMI Connection Details
    RMI Link re-establish count : 1
    RMI Link Uptime             : 1 hour 39 minute 9 seconds
    RMI Link Upsince            : 07/16/2021 01:31:41
```

The following example shows how to verify the RMI link re-establishment count and the time since it is Down in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 rmi-connection-details
RMI Connection Details
    RMI Link re-establish count : 1
    RMI Link Downtime           : 22 seconds
    RMI Link Downsince          : 07/16/2021 03:19:17
```

show platform software rif-mgr chassis active R0 rp-connection-details

To verify the RP link re-establishment count and the time since it is UP or Down in an active instance, use the **show platform software rif-mgr chassis active R0 rp-connection-details** command.

show platform software rif-mgr chassis active R0 rp-connection-details

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
active	Specifies the Active instance.
R0	Specifies the Route-Processor slot 0.
rp-connection-details	Displays the RP connection details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to verify the RP link re-establishment count and the time since it is UP for days in an active instance:

```
Device# show platform software rif-mgr chassis active R0 rp-connection-details
RP Connection Details
    RP Connection Uptime  : 12 days 17 hours 1 minute 39 seconds
    RP Connection Upsince : 07/03/2021 07:06:20
```

The following example shows how to verify the RP link re-establishment count and the time since it is Down in an active instance:

```
Device# show platform software rif-mgr chassis active R0 rp-connection-details
RP Connection Details
    RP Connection Downtime     : 4 seconds
    RP Connection Downsince    : 07/16/2021 03:33:04
```

show platform software rif-mgr chassis standby R0 rp-connection-details

To verify the RP link re-establishment count and the time since it is UP or Down in a standby instance, use the **show platform software rif-mgr chassis standby R0 rp-connection-details** command.

show platform software rif-mgr chassis standby R0 rp-connection-details

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
standby	Specifies the Standby instance.
R0	Specifies the Route-Processor slot 0.
rp-connection-details	Displays the RP connection details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to verify the RP link re-establishment count and the time since it is UP in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 rp-connection-details
RP Connection Details
    RP Connection Uptime  : 12 days 17 hours 2 minutes 1 second
    RP Connection Upsince : 07/03/2021 07:05:58
```

The following example shows how to verify the RP link re-establishment count and the time since it is Down in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 rp-connection-details
RP Connection Details
    RP Connection Downtime    : 22 seconds
    RP Connection Downsince   : 07/16/2021 03:19:17
```

show platform software rif-mgr chassis active R0 rif-stk-internal-stats

To verify the RIF and stack manager internal statistics in an active instance, use the **show platform software rif-mgr chassis active R0 rif-stk-internal-stats** command.

show platform software rif-mgr chassis active R0 rif-stk-internal-stats

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
active	Specifies the Active instance.
R0	Specifies the Route-Processor slot 0.
rif-stk-internal-stats	Displays the RIF and stack manager internal statistics.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Example

The following example shows how to verify the RIF and stack manager internal statistics in an active instance:

```
Device# show platform software rif-mgr chassis active R0 rif-stk-internal-stats
RIF Stack Manager internal stats

    Stack-mgr reported RP down            : False
    DAD link status reported to Stack-Mgr : True
```

show platform software rif-mgr chassis standby R0 rif-stk-internal-stats

To verify the RIF and stack manager internal statistics in a standby instance, use the **show platform software rif-mgr chassis standby R0 rif-stk-internal-stats** command.

show platform software rif-mgr chassis standby R0 rif-stk-internal-stats

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
standby	Specifies the Standby instance.
R0	Specifies the Route-Processor slot 0.
rif-stk-internal-stats	Displays the RIF and stack manager internal statistics.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Example

The following example shows how to verify the RIF and stack manager internal statistics in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 rif-stk-internal-stats
RIF Stack Manager internal stats

    Stack-mgr reported RP down           : False
    DAD link status reported to Stack-Mgr : True
```

show platform software rif-mgr chassis active R0 lmp-statistics

To verify the number of packets sent or received for each type in an active instance, use the **show platform software rif-mgr chassis active R0 lmp-statistics** command.

show platform software rif-mgr chassis active R0 lmp-statistics

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
active	Specifies the Active instance.
R0	Specifies the Route-Processor slot 0.
lmp-statistics	Displays the LMP statistics.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Example

The following example shows how to verify the number of packets sent or received for each type in an active instance:

```
Device# show platform software rif-mgr chassis active R0 lmp-statistics
LMP Statistics

Info Type Sent                    : 6
Solicit Info Type Sent            : 0
Unsolicit Info Type Sent          : 6
Reload Type Sent                  : 0
Recovery Type Sent                : 1
Gateway Info Type Sent            : 0
Enquiry Type Sent                 : 0
Solicit Enquiry Type Sent         : 0
Unsolicit Enquiry Type Sent       : 0

Info Type Received                : 5
Solicit Info Type Received        : 2
Unsolicit Info Type Received      : 3
Reload Type Received              : 0
Recovery Type Received            : 0
Gateway Info Type Received        : 4
Enquiry Type Received             : 0
Solicit Enquiry Type Received     : 0
Unsolicit Enquiry Type Received   : 0
```

show platform software rif-mgr chassis standby R0 lmp-statistics

To verify the number of packets sent or received for each type in a standby instance, use the **show platform software rif-mgr chassis standby R0 lmp-statistics** command.

show platform software rif-mgr chassis standby R0 lmp-statistics

Syntax Description

rif-mgr	Displays information about the RIF manager.
chassis	Displays information about the chassis.
standby	Specifies the Standby instance.
R0	Specifies the Route-Processor slot 0.
lmp-statistics	Displays the LMP statistics.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Example

The following example shows how to verify the number of packets sent or received for each type in a standby instance:

```
Device# show platform software rif-mgr chassis standby R0 lmp-statistics
LMP Statistics

Info Type Sent                  : 6
Solicit Info Type Sent          : 0
Unsolicit Info Type Sent        : 6
Reload Type Sent                : 0
Recovery Type Sent              : 0
Gateway Info Type Sent          : 4
Enquiry Type Sent               : 0
Solicit Enquiry Type Sent       : 0
Unsolicit Enquiry Type Sent     : 0

Info Type Received              : 5
Solicit Info Type Received      : 3
Unsolicit Info Type Received    : 2
Reload Type Received            : 0
Recovery Type Received          : 1
Gateway Info Type Received      : 0
Enquiry Type Received           : 0
```

```
Solicit Enquiry Type Received    : 0
Unsolicit Enquiry Type Received  : 0
```

show platform software selinux

To verify SELinux enablement, use the **show platform software selinux** command.

show platform software selinux

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 17.15.1	This command was introduced.

Examples

The following example shows you how to verify SELinux enablement:

```
Device# show platform software selinux
```

show platform software sl-infra

To display troubleshooting information and for debugging, enter the **show platform software sl-infra** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting and debugging.

show platform software sl-infra { **all** | **current** | **debug** | **stored** }

Syntax Description

all	Displays current, debugging, and stored information.
current	Displays current license-related information.
debug	Enables debugging
stored	Displays information that is stored on the product instance.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

show platform software tls client summary

To view the TLS client summary details, use the **show platform software tls client summary** command.

show platform software tls client summary

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls client summary

Name     ID     Gateway   Port   Auth     Trustpoint   DPD Time Rekey Time  Retry Time
-------------------------------------------------------------------------------------
fqdn     0               8443   PSK       N/A           60       300         20
```

show platform software client detail

To display a summary of TLS client session detail, session statistics, tunnel statistics, and DNS counters, use the **show platform software client detail** command.

show platform software client detail

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software client detail

TLS Client           : Session Detail
Session Name         : fqdn
FQDN resolved IP     : 10.194.234.149
ID                   : 0
Created              : 04/20/21 00:36:42
Updated              : 04/22/21 05:56:03
State                : Up (Rekey)
Up Time              : 04/21/21 20:30:21 ( 9 hours 25 minutes 45 seconds )
Down Time            : 04/21/21 20:30:01
Rekey Time           : 04/22/21 05:55:51 ( 15 seconds )

TLS Session Statistics

Up Notifications     : 3
Down Notifications   : 2
Rekey Notifications  : 636
DP State Updates     : 0
DPD Cleanups         : 0

Packets From     Packets To  Packet Errors To     Bytes From           Bytes To
-------------------------------------------------------------------------------
  BinOS              80           0                                      0
  IOSd                0           0                    0                 0

  TLS Client          0           0                    0                 0


TLS Tunnel Statistics
Type            Tx Packets      Rx Packets
-----------------------------------------
  Total              0               80
  CSTP Ctrl       3836             3836
  CSTP Data         80                0

Type            Requests         Responses
-----------------------------------------
```

```
CSTP Cfg          639                 639
CSTP DPD         3197                3197

Invalid CSTP Rx          : 0
Injected Packet Success  : 0
Injected Packet Failed   : 0
Consumed Packets         : 0

TLS Tunnel DNS Counters
DNS Resolve Request Success Count    : 641
DNS Resolve Request Failure Count    :  0
DNS Resolve Success Count            : 639
DNS Resolve Failure Count            :  2
```

show platform software tls statistics

To view the TLS client global statistic details, use the **show platform software tls statistics** command.

show platform software tls statistics

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls statistics

TLS Client - Global Statistics
Session Statistics
Up/Down           : 5/2
Rekeys            : 636
DP Updates        :   0
DPD Cleanups      :   0

Packets From    Packets To   Packet Errors To     Bytes From   Bytes To
-------------------------------------------------------------------------
BinOS              85             0                  0             0
IOSd 0             0              0                  0             0
TLS Client  0      0                                 0             0

Tunnel Statistics
SSL Handshake Init/Done     : 641/641
TCP Connection Req/Done     : 641/641

Tunnel Packets
Rx/Tx                       : 85/0
Injected / Failed           : 0/0
Consumed                    :  0

CSTP Packets
Control Rx/Tx               : 3839 / 3839
Data Rx/Tx                  : 0 / 85
Config Req/Resp             : 641 / 641
DPD Req/Resp                : 3198 / 3198
Invalid Rx                  : 0

FQDN Counters
Req/Resp/Success            : 0/0/0

NAT Counters
Transalte In/Out            : 0/0
Ignore    In/Out            : 0/0
Failed                      : 0
Invalid                     : 0
```

```
No Entry                    : 0
Unsupported                 : 0

Internal Counters
Type           Allocated            Freed
-------------------------------------------------
EV              1299                 1295
Tunnel           5                     4
Conn            643                   642
Sess             3                     2

Config Message Related Counters
Type               Success              Failed
-------------------------------------------------
Create                3                    0
Delete                2                    0
```

show platform software tls session summary

To view the tls client session summary, use the **show platform software tls session summary** command.

show platform software tls session summary

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls session summary

TLS Client - Session Summary
Name     ID      Created            State    Since               Elapsed
-------------------------------------------------------------------------------------------
fqdn     0      04/20/21 00:36:42    Up     04/21/21 20:30:21   9 hours 26 minutes 44 seconds
```

show product-analytics kpi report

To display the details of a particular product analytics engine report, use the **show product-analytics kpi report** command.

show product-analytics kpi report

Syntax Description

report-id	Report identifier.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example displays the details of a particular product analytics engine report:

```
Device# show product-analytics kpi report <report-id>

Product Analytics Engine KPIs

 Report ID     : 1662422400
 Computed at   : 09/06/2022 00:00:00
 KPI Name      : ap_mode
.
.
.
 Report ID     : 1662422400
 Computed at   : 09/06/2022 00:00:00
 KPI Name      : clients_distinct_wireless_lua
 KPI Value     : 0
```

show product-analytics kpi summary

To display the product analytics engine report summary, use the **show product-analytics kpi summary** command.

show product-analytics kpi summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example displays the product analytics engine report summary:

```
Device# show product-analytics kpi summary

Product Analytics Engine KPIs

Time                          Report ID                     KPI Name
----------------------------- ----------------------------- ----------------------------

09/06/2022 00:00:00            1662422400                     ap_mode

09/06/2022 00:00:00            1662422400                     ap_type

09/06/2022 00:00:00            1662422400                     fra_usage

.
.
.
09/15/2022 00:00:00            1663200000                     clients_concurrent_wireless

09/15/2022 00:00:00           1663200000                    clients_distinct_wireless_lua
```

show product-analytics report detail

To display the product analytics engine report details, use the **show product-analytics report detail** command.

show product-analytics report detail

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example displays the product analytics engine report details:

```
Device# show product-analytics report detail

Product Analytics Engine Reports

Report ID          : 1662422400
Policy Version     : 17.10.1
Engine Version     : 17.10.1
File version       : 1
Period start       :
Period End         :
Timezone           : 0

Event History
Timestamp               #Times   Event               RC Context
----------------------- -------- ------------------- --
----------------------------------------
09/14/2022 22:15:01.814 1        REPORT_SEND          5 DRAGONFLY

.
.
.


Report ID          : 1663200000
Policy Version     : 17.10.1
Engine Version     : 17.10.1
File version       : 1
Period start       :
Period End         :
Timezone           : 0

Event History
Timestamp               #Times   Event               RC Context
----------------------- -------- ------------------- --
----------------------------------------
09/15/2022 00:00:00.836 1        KPI_ADD              0 clients_distinct_wireless_lua
```

```
09/15/2022 00:00:00.824 1        KPI_ADD             0 client_auth_protocol_lua
09/15/2022 00:00:00.793 1        KPI_ADD             0 clients_concurrent_wireless
09/15/2022 00:00:00.793 1        KPI_ADD             0 network_ssid_count
09/15/2022 00:00:00.793 1        KPI_ADD             0 ap_type
09/15/2022 00:00:00.792 1        KPI_ADD             0 fra_enabled
09/15/2022 00:00:00.792 1        KPI_ADD             0 ap_software_version
09/15/2022 00:00:00.792 1        KPI_ADD             0 ap_mode
09/15/2022 00:00:00.792 1        KPI_ADD             0 fra_usage
09/15/2022 00:00:00.791 1        NEW_REPORT          0
```

show product-analytics stats

To display the product analytics engine statistics and event history, use the **show product-analytics stats** command.

show product-analytics stats

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example displays the product analytics engine statistics and event history:

```
Device# show product-analytics stats

Product Analytics Engine Statistics

Policy-Version
 File version                          : 1
Data-Store
 #Writes                               : 941442
 Total write time (us)                 : 754856891
 Average write time (us)               : 801
 #Single Writes                        : 1890439
 Total Single write time (us)          : 41098825
 Average Single write time (us)        : 21
 #Queries                              : 737
 Total query time (us)                 : 4534566
 Average query time (us)               : 6152
 #Query errors                         :

Data-Source
 #Periodic reads                       : 2195456
 Total periodic-read time (us)         : 7414384002
 Average periodic-read time (us)       : 3377
 #Periodic read batches                : 3136361
 Total periodic-read-batch time (us)   : 1826634998
 Average periodic-read-batch time (us) : 582
 #On-change reads                      : 604

KPI
 #SQL computatious                     : 66
 Total SQL KPI compute time (us)       : 202907
 Average SQL KPI compute time (us)     : 3074
 #LUA computatious                     : 66
 Total LUA KPI compute time (us)       : 3211022
 Average LUA KPI compute time (us)     : 48651

Event History
```

```
Timestamp               #Times   Event               RC Context
----------------------- -------- ------------------- --
----------------------------------------
09/15/2022 02:18:24.428 40323979 DSRC_PERIOD_RD       0
/services;serviceName=ewlc_oper/radio_oper_data
09/15/2022 01:18:07.561 941442   DST_STORE_END        0

09/15/2022 01:18:07.561 941442   DST_STORE_BEGIN      0

09/15/2022 01:18:07.560 941442   DSRC_NORMALIZE       0 rrmRadSlot

09/15/2022 00:00:03.583 604     DSRC_ONCHG_RD       0 /services;serviceName=ewlc/wlan_config
```

show lisp site detail

To see detailed Locator ID Separation Protocol (LISP) site information on a map server, use the **show lisp site detail** command.

show lisp site detail [**eid-table** {**default** | **vlan** *vlan-id* | **vrf** *vrf-name* } | **instance-id** *id-number* | **internal** {**eid-table** {**default** | **vlan** *vlan-id* | **vrf** *vrf-name*} | **instance-id** *id-number*}]

Syntax Description

eid-table	Option to enter the EID table.
default	Shows the information for the default VRF.
vlan *vlan-id*	Enter the VLAN information.
vrf *vrf-name*	Enter the VRF name.
instance-id *id-number*	Enter the EID instance ID.
internal	Shows the site's detailed internal information.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see detailed Locator ID Separation Protocol (LISP) site information on a map server:

```
Device# show lisp site detail
```

show logging profile wireless end timestamp

To specify log filtering end location timestamp for filtering, use the **show logging profile wireless end timestamp** command.

show logging profile wireless end timestamp *time-stamp*

Syntax Description

time-stamp	Time to end the filtering. For example, 2017/02/10 14:41:50.849.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable internal keyword using the **show logging profile wireless internal** command to get the trace output.

Example

The following example shows how to specify log filtering end location timestamp for filtering:

```
Device# show logging profile wireless end timestamp 2017/02/10 14:41:50.849
```

show logging profile wireless filter

To specify filter for logs, use the **show logging profile wireless filter** command.

show logging profile wireless filter { **ipv4** | **mac** | **string** | **uuid** }

Syntax Description

ipv4	Selects logs with specific IP address app context.
mac	Selects logs with specific MAC app context.
string	Selects logs with specific string app context.
uuid	Selects logs with specific Universally Unique Identifier (UUID) app context.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify filter for logs:

```
Device# show logging profile wireless filter ipv4 10.10.11.1
```

show logging profile wireless fru

To specify field-replaceable unit (FRU) specific commands, use the **show logging profile wireless fru** command.

show logging profile wireless fru {0 {reverse | to-file}| chassis} {**0** {**reverse** | **to-file**} | **chassis**}

Syntax Description

0	SPA-Inter-Processor slot 0.
reverse	Shows logs in reverse chronological order.
to-file	Decodes files stored in disk and write output to file.
chassis	Chassis name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify FRU specific commands:

```
Device# show logging profile wireless fru 0
```

show logging profile wireless internal

To select all the logs, use the **show logging profile wireless internal** command.

show logging profile wireless internal

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to display all the logs:

```
Device# show logging profile wireless internal
```

show logging profile wireless level

To select logs above a specific level, use the **show logging profile wireless level** command.

show logging profile wireless level { **debug** | **emergency** | **error** | **info** | **noise** | **notice** | **verbose** | **warning** }

Syntax Description

debug	Selects debug messages.
emergency	Selects emergency possible messags.
error	Selects error messages.
info	Selects informational messages.
noise	Selects maximum possible messages.
notice	Selects notice messages.
verbose	Selects verbose debug messages.
warning	Selects warning messages.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to select logs above a specific level:

```
Device# show logging profile wireless level info
```

show logging profile wireless module

To select logs for specific modules, use the **show logging profile wireless module** command.

show logging profile wireless module *module-name*

Syntax Description

module-name	A comma or space separated list of module names. For example, dbal, tdllib or "dbal tdllib".

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to select logs for specific modules:

```
Device# show logging profile wireless module dbal
```

show logging profile wireless reverse

To view logs in reverse chronological order, use the **show logging profile wireless reverse** command.

show logging profile wireless reverse

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to view logs in reverse chronological order:

```
Device# show logging profile wireless reverse
```

show logging profile wireless start

To specify log filtering start location, use the **show logging profile wireless start** command.

show logging profile wireless start {**marker** *marker* | **timestamp** *time-stamp*}

Syntax Description

marker	The marker to start filtering from. It must match with previously set marker.
timestamp	The timestamp for filtering. for example, "2017/02/10 14:41:50.849".

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify log filtering start location:

```
Device# show logging profile wireless start timestamp 2017/02/10 14:41:50.849
```

show logging profile wireless switch

To specify the switch to look for logs, use the **show logging profile wireless switch** command.

show logging profile wireless switch {*switch-num* | **active** | **standby**}

Syntax Description

chassis-num	Chassis number.
active	Selects the active instance.
standby	Selects the standby instance.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify the chassis number to look for logs:

```
Device# show logging profile wireless switch active
```

show logging profile wireless to-file

To decode files stored in disk and write the output to a file, use the **show logging profile wireless to-file** command.

show logging profile wireless to-file *output-file-name*

Syntax Description

output-file-name	Output file name. File with this name will be created in the flash memory.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to decode files stored in disk and write the output to a file:

```
Device# show logging profile wireless to-file testfile
```

show mdns-sd cache

To view mDNS cache details, use the **show mdns-sd cache** command.

show mdns-sd cache { **ap-mac** *mac-address (H.H.H)* | **client-mac** *client-mac-address (H.H.H)* | **detail** | **glan-id** *<1 - 5>* | **location-group** *<0 - 4096>* | **mdns-ap** *mdns-ap mac address (H.H.H)* | **rlan-id** *<1 - 128>* | **statistics** | **type** { **A-AAAA** | **PTR** | **SRV** | **TXT** } | **udn** { *<1 - 4294967295>* | **shared** } | **wired** | **wlan-id** *<0 - 4096>* }

Syntax Description

ap-mac *mac-address (H.H.H)*	Specifies the AP Ethernet MAC address.
client-mac *client-mac-address (H.H.H)*	Specifies the client MAC address.
detail	Specifes the cache in detail.
location-group *<0 - 4096>*	Specifies the location group. The value range is from 0 to 4096.
mdns-ap *mdns-ap mac address (H.H.H)*	Specifies the cache learnt from a specific mDNS AP.
rlan-id *<1 - 128>*	Specifies the remote LAN ID. The value range is from 1 - 128.
statistics	Specifies the mDNS cache statistics.
type	Specifies the mDNS record type. The record types are, A-AAAA, PTR, SRV, and TXT.
udn *<1 - 4294967295>*	Specifies the UDN ID. The value range is from 1 to 4294967295.
shared	Specifies the UDN shared services.
wired	Specifies the mDNS services from wired clients.
wlan-id *<0 - 4096>*	Specifies the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the mDNS cache details:

```
Device# show mdns-sd cache
```

show mdns-sd cache detail

To view the multicast DNS (mDNS) cache details, use the **show mdns-sd cache detail** command.

show mdns-sd cache detail

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache detail** command:

```
Device# show mdns-sd cache detail

Name: _printer._tcp.local
  Type: PTR
  TTL: 4500
  VLAN: 21
  Client MAC: ace2.d3bc.047e
  Remaining-Time: 4383
  mDNS Service Policy: default-mdns-service-policy
  Rdata: HP OfficeJet Pro 8720 [BC047E] (2)._printer._tcp.local
```

show mdns-sd cache upn shared

To view the multicast DNS (mDNS) cache user personal network shared services details, use the **show mdns-sd cache upn shared** command.

show mdns-sd cache upn shared

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache upn shared** command that displays the mDNS cache UPN shared services details:

```
Device# show mdns-sd cache upn shared

------------------------------------------------------------- PTR Records
------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
9.1.1.7.5.D.E.F.F.F.6.C.7.E.2.1.0.0.0.0.0.0.0  4500     WLAN      2     10e7.c6d5.7119
HP10E7C6D57119-2860.local
_services._dns-sd._udp.local                   4500     WLAN      2     10e7.c6d5.7119
_ipps._tcp.local
_universal._sub._ipps._tcp.local               4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_print._sub._ipps._tcp.local                   4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_ePCL._sub._ipps._tcp.local                    4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_ipps._tcp.local                               4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_services._dns-sd._udp.local                   4500     WLAN      2     10e7.c6d5.7119
_ipp._tcp.local
_universal._sub._ipp._tcp.local                4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_print._sub._ipp._tcp.local                    4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_ePCL._sub._ipp._tcp.local                     4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
.
.
.
------------------------------------------------------------- SRV Records
------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
```

```
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP DeskJet 5000 series [D57119] (3127)._ipp._  4500     WLAN      2     10e7.c6d5.7119   0
 0 631 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._http.  4500     WLAN      2     10e7.c6d5.7119   0
 0 80 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._ipps.  4500     WLAN      2     10e7.c6d5.7119   0
 0 631 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119   0
 0 8080 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._prive  4500     WLAN      2     10e7.c6d5.7119   0
 0 80 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119   0
 0 443 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._scann  4500     WLAN      2     10e7.c6d5.7119   0
 0 8080 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._pdl-d  4500     WLAN      2     10e7.c6d5.7119   0
 0 9100 HP10E7C6D57119-2860.local

------------------------------------------------------------- A/AAAA Records
-------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP10E7C6D57119-2860.local                      4500     WLAN      2     10e7.c6d5.7119
8.16.16.99

------------------------------------------------------------- TXT Records
-------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP DeskJet 5000 series [D57119] (3127)._ipp._  4500     WLAN      2     10e7.c6d5.7119
[502]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._http.  4500     WLAN      2     10e7.c6d5.7119
[1]''
HP DeskJet 5000 series [D57119] (3127)._ipps.  4500     WLAN      2     10e7.c6d5.7119
[502]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119
[280]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._prive  4500     WLAN      2     10e7.c6d5.7119
[124]'txtvers=1''ty=HP DeskJet 5000 series [D57119
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119
[280]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._scann  4500     WLAN      2     10e7.c6d5.7119
[177]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._pdl-d  4500     WLAN      2     10e7.c6d5.7119
[211]'txtvers=1''rp=''priority=40''UUID=9fe36149-9
```

show mdns-sd cache upn detail

To view the multicast DNS (mDNS) cache user personal network identifier details, use the **show mdns-sd cache upn detail** command.

show mdns-sd cache upn*upn-id* **detail**

Syntax Description

upn-id	User personal network identifier.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache upn detail** command that displays the mDNS cache UPN identifier details:

```
Device# show mdns-sd cache upn 777 detail

Name: _services._dns-sd._udp.local
  Type: PTR
  TTL: 4500
  WLAN: 2
  WLAN Name: mdns-psk
  VLAN: 16
  Client MAC: f4f9.51e2.a6a6
  AP Ethernet MAC: 002a.1087.d68a
  Remaining-Time: 4486
  Site-Tag: default-site-tag
  mDNS Service Policy: madhu-mDNS-Policy
  Overriding mDNS Service Policy: NO
  UPN-ID: 7777
  UPN-Status: Enabled
  Rdata: _airplay._tcp.local
```

show mdns-sd flexconnect summary

To view the summary of the mDNS flexconnect sites, use the **show mdns-sd flexconnect summary** command.

show mdns-sd flexconnect summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the summary of mDNS flexconnect sites:

```
Device# show mdns-sd flexconnect summary
```

show mdns-sd statistics

To view the mDNS statistics, use the **show mdns-sd statistics** command.

show mdns-sd statistics { **debug** | **flexconnect** | **rlan-id** *<1 - 128>* **wired** | **wlan-id** *<1 - 4096>* }

Syntax Description

debug	Specifies the mDNS debug statistics.
flexconnect	Specifies the mDNS flexconnect statistics.
rlan-id*<1 - 128>*	Specifies the remote LAN (RLAN) ID. The value range is from 1 to 128.
wired	Specifies the mDNS wired statistics.
wlan-id*<1 - 4096>*	Specifies the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the mDNS statistics:

```
Device# show mdns-sd statistics
```

show mdns-sd summary

To view the summary of mDNS service discovery configuration, use the **show mdns-sd summary** command.

show mdns-sd summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the summary of mDNS service discovery configuration:

```
Device# show mdns-sd summary
```

show mdns-sd sp-sdg statistics

To verify the Service-Peer SDG communication statistics, use the **show mdns-sd sp-sdg statistics** command.

show mdns-sd sp-sdg statistics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

The following example shows how to verify the Service-Peer SDG communication statistics:

```
Device# show mdns-sd sp-sdg statistics
                         One min, 5 mins, 1 hour
Average Input rate (pps) :    0,       0,    0
Average Output rate (pps) :   0,       0,    0
Messages sent:
Query : 0
ANY query : 0
Advertisements : 0
Advertisement Withdraw : 0
Interface down : 0
Vlan down : 0
Service-peer ID change : 0
Service-peer cache clear : 0
Resync response : 0
Keep-Alive : 1
Messages received:
Query response : 0
ANY Query response : 0
Cache-sync : 0
Get service-instance : 0
Keep-Alive response : 1
```

show meraki connect

To verify the Cloud ID (Cisco Meraki Serial Number) fetched as part of the registration and status of the operation, use the **show meraki connect** command.

show meraki connect

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.15.1	This command was introduced.

Example

This example shows how to view the Cloud ID (Cisco Meraki Serial Number) fetched as part of the registration and status of the operation:

```
Device# show meraki connect
Service meraki connect: enable

Meraki Tunnel Config
------------------------------------
  Fetch State:                Config fetch succeeded
  Fetch Fail:
  Last Fetch(UTC):            2024-07-11 15:13:07
  Next Fetch(UTC):            2024-07-11 16:39:21
  Config Server:              cs594-2037.meraki.com
  Primary:                    apa.nt.meraki.com
  Secondary:                  aps.nt.meraki.com
  Client IPv6 Addr:           FD0A:9B09:1F7:1:8E1E:80FF:FE68:B100
  Network Name:               WLC - wireless controller

Meraki Tunnel State
------------------------------------
  Primary:                    Up
  Secondary:                  Up
  Primary Last Change(UTC):   2024-07-09 19:02:09
  Secondary Last Change(UTC): 2024-07-09 19:02:09
  Client Last Restart(UTC):   2024-07-05 19:56:58

Meraki Tunnel Interface
------------------------------------
  Status:                     Enable
  Rx Packets:                 26595318
  Tx Packets:                 32514152
  Rx Errors:                  0
  Tx Errors:                  0
  Rx Drop Packets:            0
  Tx Drop Packets:            0
```

```
Meraki Device Registration
-----------------------------------
  url:                          https://catalyst.meraki.com/nodes/register
  Device Number:                1
  PID:                          C9800-L-F-K9
  Serial Number:                FCL264000NN
  Cloud ID:                     Q2ZZ-3HC4-5R5A
  Mac Address:                  8C:1E:80:68:B1:00
  Status:                       Registered
  Timestamp(UTC):               2024-06-03 11:54:28
  Device Number:                2
  PID:                          C9800-L-F-K9
  Serial Number:                FCL263900RW
  Cloud ID:                     Q2ZZ-GC8U-Y24D
  Mac Address:                  8C:1E:80:68:BD:00
  Status:                       Registered
  Timestamp(UTC):               2024-06-03 11:23:55
```

show mobility

To display information about the Layer 3 mobility and the wireless network, use the **showmobility** command in privileged EXEC mode.

show mobility {**ap** [*ip-address*] | **mn** [**ip** *ip-address*] | **mac** *mac-address* | **network** *network-id* | **status**}

Syntax Description

ap	Displays information about the access point.
ip-address	(Optional) IP address.
mn	Displays information about the mobile node.
ip *ip-address*	(Optional) Displays information about the IP database thread.
mac *mac-address*	Displays information about the MAC database thread.
network *network-id*	Displays information for a specific wireless network ID.
status	Displays status information.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(18)SXD	This command was introduced on the Supervisor Engine 720.
12.2(18)SXD3	The output of this command was changed to include the TCP adjust-mss status.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

This command is supported on Cisco 7600 series routers that are configured with a WLSM only.

Examples

This example shows how to display information about the access point:

```
Router# show mobility
 ap
AP IP Address   AP Mac Address Wireless Network-ID
--------------- -------------- --------------------
10.1.1.2 000d.29a2.a852 101 102 109 103
```

This example shows how to display information about the access points for a specific network ID:

```
Router# show mobility
 ap 172.16.1.2 detail
IP Address : 172.16.1.2
MAC Address : 000d.29a2.a852
Participating Wireless Tunnels: 101, 102, 109, 103
Registered Mobile Nodes on AP {172.16.1.2, 000d.29a2.a852} :
MN Mac Address MN IP Address AP IP Address Wireless Network-ID
-------------- --------------- --------------- --------------------
000a.8afa.85c9 10.1.3.11 172.16.1.2 103
```

```
000d.bdb7.83f7 10.1.2.11 172.16.1.2 102
000d.bdb7.83fb 10.1.1.11 172.16.1.2 101
Router# show mobility
 network-id 101
Wireless Network ID : 101
Wireless Tunnel Source IP Address : 10.1.1.1
Wireless Network Properties : Trusted
Wireless Network State : Up
Registered Access Point on Wireless Network 101:
AP IP Address AP Mac Address Wireless Network-ID
--------------- -------------- -------------------
176.16.1.2 000d.29a2.a852 101 102 109 103
Registered Mobile Nodes on Wireless Network 101:
MN Mac Address MN IP Address AP IP Address Wireless Network-ID
-------------- --------------- --------------- -------------------
000d.bdb7.83fb 10.1.1.11 176.16.1.2 101
Router# show mobility
 status
WLAN Module is located in Slot: 4 (HSRP State: Active) LCP
Communication status      : up
MAC address used for Proxy ARP: 0030.a349.d800
Number of Wireless Tunnels    : 1
Number of Access Points       : 2
Number of Mobile Nodes        : 0
Wireless Tunnel Bindings:
Src IP Address   Wireless Network-ID  Flags
---------------  -------------------  -------
10.1.1.1          101                  B
Flags: T=Trusted, B=IP Broadcast enabled, A=TCP Adjust-mss enabled
```

Related Commands

Command	Description
mobility	Configures the wireless mGRE tunnels.

show monitor capture

To display the contents of a monitor capture buffer or a capture point, use the **show monitor capture** command in privileged EXEC mode.

show monitor capture [*epc-capture-name* [**parameter** | **buffer** [**brief** | **detailed** | **dump**]]]

Syntax Description

epc-capture-name	Specifies the name of the embedded packet capture.
buffer	Displays the contents of the specified capture buffer.
dump	(Optional) Displays a hexadecimal dump of the captured packet in addition to the metadata.
brief	(Optional) Provides a brief output of the captured packet information.
detail	(Optional) Provides a detailed output of the captured packet information.
parameter	Reconstructs and displays EXEC commands that were used to specify the capture.
detailed	Provides a detailed output of the captured packet information.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You can enter the **show monitor capture** command when the capture buffer is not in the running state.

If you enter the **detail** keyword, packets are decoded to the Layer 4 protocol level and displayed. If you enter the **dump** keyword, non-IP packets are displayed in hexadecimal dump format. An ACL can be configured as a display filter so that only packets permitted by the ACL are displayed.

The following example shows how to display all the packets in a capture buffer. The output is self-explanatory.

```
Device# show monitor capture mycap buffer

buffer size (KB) : 2048000
buffer used (KB) : 128
packets in buf : 17
packets dropped : 0
packets per sec : 3
```

The following example shows how to display the list of commands that were used to specify the capture:

```
Device# show monitor capture cap1 parameter

  monitor capture cap1 interface GigabitEthernet 1/0/1 both
```

```
monitor capture cap1 match any
monitor capture cap1 buffer size 10
monitor capture cap1 limit pps 1000
```

The following example shows how to display brief output from the captured packet information. The output is self-explanatory.

```
Device# show monitor capture cap1 buffer brief

------------------------------------------------------------------
#   size   timestamp     source             destination   protocol
------------------------------------------------------------------
   0   62    0.000000   10.0.0.1         ->  203.0.113.254  UDP
   1   46    0.267992   10.0.1.2         ->  203.0.113.204  IGMP
   2   76    0.428979   172.16.255.3     ->  172.16.255.3   UDP
   3   62    1.613982   10.0.29.1        ->  172.16.200.2   UDP
   4   74    1.659970   10.0.1.3         ->  10.0.0.10      EIGRP
   5   90    2.016006   10.29.0.4        ->  203.0.113.224  UDP
   6   74    2.088008   10.1.9.2         ->  203.0.113.10   EIGRP
   7   76    2.114008   172.17.254.1     ->  172.16.255.1   UDP
   8   74    2.245990   10.29.0.3        ->  203.0.113.10   EIGRP
   9   46    2.262987   10.0.0.0         ->  203.0.113.1    IGMP
  10   77    2.362988   10.1.9.2         ->  203.0.113.10   EIGRP
  11   62    2.631971   10.29.0.2        ->  203.0.113.2    UDP
  12   74    2.934009   10.29.0.5        ->  203.0.113.10   EIGRP
  13   74    3.331984   10.29.0.6        ->  203.0.113.10   EIGRP
  14   46    3.499974   10.0.0.0         ->  203.0.113.1    IGMP
  15   46    4.304992   10.0.0.0         ->  203.0.113.1    IGMP
  16   76    5.157005   172.16.255.3     ->  172.17.255.3   UDP
```

The following example shows how to display all the packets in a capture buffer. The output is self-explanatory.

```
Device# show monitor capture cap1 buffer detailed

 ------------------------------------------------------------------
#   size   timestamp     source             destination   protocol
------------------------------------------------------------------
   0   62    0.000000   10.29.0.2        ->  172.16.255.3   UDP
  0000:  01005E00 00020000 0C07AC1D 080045C0   ..^...........E.
  0010:  00300000 00000111 CFDC091D 0002E000   .0..............
  0020:  000207C1 07C1001C 802A0000 10030AFA   .........*......
  0030:  1D006369 73636F00 0000091D 0001       ..example.......

   1   46    0.267992   10.0.0.0         ->  172.16.255.1   IGMP
  0000:  01005E00 0002001B 2BF69280 080046C0   ..^.....+.....F.
  0010:  00200000 00000102 44170000 0000E000   . ......D.......
  0020:  00019404 00001700 E8FF0000 0000       ..............

   2   76    0.428979   172.16.255.3     ->  172.17.255.3    UDP
  0000:  00000C07 AC1DB414 89031124 080045C0   ...........$..E.
  0010:  003E0000 0000FF11 64C5AC10 FF03AC11   .>......d.......
  0020:  FF030286 0286002A 84A40001 001EAC10   .......*........
  0030:  FF030000 01000014 00000000 04000004   ................

   3   62    1.613982   10.26.11.3       ->  172.16.255.1    UDP
  0000:  01005E00 0002001B 2BF68680 080045C0   ..^.....+.....E.
  0010:  00300000 00000111 CFDB091D 0003E000   .0..............
  0020:  000207C1 07C1001C 88B50000 08030A6E   ..............n
  0030:  1D006369 73636F00 0000091D 0001       ..example.......

   4   74    1.659970   10.29.3.2        ->  172.16.255.2   EIGRP
  0000:  01005E00 000A001B 2BF69280 080045C0   ..^.....+.....E.
```

```
  0010:  003C0000 00000258 CE81091D 0002E000   .<.....X........
  0020:  000A0205 F3000000 00000000 00000000   ................
  0030:  00000000 00D10001 000C0100 01000000   ................

   5   90    2.016006   10.22.1.4         ->  203.0.113.1     UDP
  0000:  FFFFFFFF FFFF001C 0F2EDC00 080045C0   ..............E.
  0010:  004C0000 00000111 AFC1091D 0004FFFF   .L..............
  0020:  FFFF007B 007B0038 5B14E500 06E80000   ...{.{.8[.......
  0030:  00000021 BE23494E 49540000 00000000   ...!.#INIT......
```

The following example shows how to display a hexadecimal dump of the captured packet:

```
Device# show monitor capture cap1 buffer dump
0
 0000:  01005E00 00020000 0C07AC1D 080045C0   ..^...........E.
 0010:  00300000 00000111 CFDC091D 0002E000   .0..............
 0020:  000207C1 07C1001C 802A0000 10030AFA   .........*......
 0030:  1D006369 73636F00 0000091D 0001       ..example.......

1
 0000:  01005E00 0002001B 2BF69280 080046C0   ..^.....+.....F.
 0010:  00200000 00000102 44170000 0000E000   . ......D.......
 0020:  00019404 00001700 E8FF0000 0000       ..............

2
 0000:  01005E00 0002001B 2BF68680 080045C0   ..^.....+.....E.
 0010:  00300000 00000111 CFDB091D 0003E000   .0..............
 0020:  000207C1 07C1001C 88B50000 08030A6E   ..............n
 0030:  1D006369 73636F00 0000091D 0001       ..example.......

3
 0000:  01005E00 000A001C 0F2EDC00 080045C0   ..^...........E.
 0010:  003C0000 00000258 CE7F091D 0004E000   .<.....X........
 0020:  000A0205 F3000000 00000000 00000000   ................
 0030:  00000000 00D10001 000C0100 01000000   ................
 0040:  000F0004 00080501 0300                ..........
```

show nmsp

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmsp** command.

show nmsp {**attachment** | {**suppress interfaces**} | **capability** | **notification interval** | **statistics** {**connection** | **summary**} | **status** | **subscription detail** [*ip-addr*] | **summary**}

Syntax Description

attachment suppress interfaces	Displays attachment suppress interfaces.
capability	Displays NMSP capabilities.
notification interval	Displays the NMSP notification interval.
statistics connection	Displays all connection-specific counters.
statistics summary	Displays the NMSP counters.
status	Displays status of active NMSP connections.
subscription detail *ip-addr*	The details are only for the NMSP services subscribed to by a specific IP address.
subscription summary	Displays details for all of the NMSP services to which the controller is subscribed. The details are only for the NMSP services subscribed to by a specific IP address.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show nmsp notification interval** command:

```
Device#  show nmsp notification interval
NMSP Notification Intervals
---------------------------

RSSI Interval:
 Client               : 2 sec
 RFID                 : 2 sec
 Rogue AP             : 2 sec
 Rogue Client         : 2 sec
Attachment Interval   : 30 sec
Location Interval     : 30 sec
```

show nmsp cloud-services statistics

To see NMSP cloud-service statistics, use the **show nmsp cloud-services statistics** command.

show nmsp cloud-services statistics [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the active NMSP cloud services in Route-processor slot 0.
standby R0	Standby instance of the active NMSP cloud services in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

This example shows how to see NMSP cloud-service statistics:

```
Device# show nmsp cloud-services statistics
```

show nmsp cloud-services summary

To see a summary of information about NMSP cloud-services, use the **show nmsp cloud-services summary** command.

show nmsp cloud-services summary [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the NMSP cloud services in Route-processor slot 0.
standby R0	Standby instance of the active NMSP cloud services in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

This example shows how to see NMSP cloud-service summary information:

```
Device# show nmsp cloud-services summary
```

show nmsp subscription group detail all

To display the mobility services group subscription details of all CMX connections, use the **show nmsp subscription group detail all** command.

show nmsp subscription group detail all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to display the mobility services group subscription details of all CMX connections:

```
Device# show nmsp subscription group detail all
```

show nmsp subscription group detail ap-list

To display the AP MAC list subscribed for a group by a CMX connection, use the **show nmsp subscription group detail ap-list** command.

show nmsp subscription group detail ap-list *group-name cmx-IP-addrress*

Syntax Description

group-name	CMX AP group name.
cmx-IP-addrress	CMX IP address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the AP MAC list subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail ap-list Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group AP MACs:
: 00:00:00:00:70:02  00:00:00:00:66:02  00:99:00:00:00:02  00:00:00:bb:00:02
  00:00:00:00:55:02  00:00:00:00:50:02  00:33:00:00:00:02  00:d0:00:00:00:02
  00:10:00:10:00:02  00:00:00:06:00:02  00:00:00:02:00:02  00:00:00:00:40:02
  00:00:00:99:00:02  00:00:00:00:a0:02  00:00:77:00:00:02  00:22:00:00:00:02
  00:00:00:00:00:92  00:00:00:00:00:82  00:00:00:00:03:02  aa:00:00:00:00:02
  00:00:00:50:00:42  00:00:0d:00:00:02  00:00:00:00:00:32  00:00:00:cc:00:02
  00:00:00:88:00:02  20:00:00:00:00:02  10:00:00:00:00:02  01:00:00:00:00:02
  00:00:00:00:00:02  00:00:00:00:00:01  00:00:00:00:00:00
```

show nmsp subscription group detail services

To display the services subscribed for a group by a CMX connection, use the **show nmsp subscription group detail services** command.

show nmsp subscription group detail services *group-name cmx-IP-addrress*

Syntax Description

group-name	CMX AP group name.
cmx-IP-addrress	CMX IP address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the services subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail services Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group filtered services:
Service            Subservice
----------------------------
RSSI               Mobile Station,
Spectrum
Info
Statistics
```

show nmsp subscription group summary

To display the mobility services group subscription summary of all CMX connections, use the **show nmsp subscription group summary** command.

show nmsp subscription group summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the mobility services group subscription summary of all CMX connections.

```
Device# show nmsp subscription group summary

CMX IP address: 127.0.0.1
  Groups subscribed by this CMX server:
  Group name: Group1
```

show ntp associations

To display the status of Network Time Protocol (NTP) associations, use the **show ntp associations** command in privileged EXEC mode.

show ntp associations

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to view NTP associations. :

```
Device# show ntp associations
  address         ref clock       st   when   poll reach  delay  offset   disp
*~10.1.1.99       72.163.32.44     2    918   1024   377  0.177   7.618  1.102
* sys.peer, # selected, + candidate, - outlyer, x falseticker, ~ configured
--
```

show parameter-map type webauth name

To verify the webauth parameters of a parameter map, use the **show parameter-map type webauth name** command.

show parameter-map type webauth name *parameter-map name*

Syntax Description

parameter-map name	Name of the parameter map.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to verify the webauth parameters of a parameter map:

```
Device# configure terminal
Device(config)# show parameter-map type webauth name parameter-map-name
```

show platform conditions

To see information about conditional debugs, use the **show platform conditions** command.

show platform conditions

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see information about conditional debugs:

```
Device# show platform conditions
```

show platform hardware

To see the hardware platform Quantum flow processor datapath statistics, use the **show platform hardware chassis active qfp feature wireless wlclient datapath cpp-if-handle statistics** command.

show hardware chassis active qfp feature wireless wlclient datapath cpp-if-handle *client-cpp-value* **statistics** {**clear** | **start** | **stop**}

Syntax Description

active	Active instance.
qfp	Quantum Flow Processor.
wlclient	QFP wireless client.
cpp-if-handle	client cpp interface handle.
client-cpp-value	Client cpp if-handle value. The range is between 1 and 4294967295.
statistics	Show Client Statistics.
clear	Shows and Clears the Client Statistics.
start	Start Client Statistics collection.
stop	Stop Client Statistics collection.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to start client statistics collection:

```
Device# show platform hardware chassis active qfp feature wireless wlclient datapath
cpp-if-handle cpp-if-handle value statistics start
```

show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf

To view the DSA enabled interfaces, use the **show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf** command.

show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA enabled interfaces:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf
Interface name: GigabitEthernet0/0/0, handle: 5
```

show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list

To view the OpenDNS string or FQDN filter for the pattern list, use the **show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list** command.

show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list {**fqdn-filter** *fqdn_filter_ID* | **odns_string**}

Syntax Description

fqdn-filter	Displays the FQDN filter for the pattern list.
fqdn_filter_ID	Refers to the FQDN filter ID. The valid range is from 1 to 16.
odns_string	Displays the OpenDNS string for the pattern list.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the FQDN filter for the pattern list:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client
hw-pattern-list fqdn-filter 1
Filter Name: urllist_flex_preauth

Name: url1.dns.com
Feature mask: 16, Dirty: 0, Ref count: 0, Match count: 0
```

show platform hardware chassis active qfp feature dns-snoop-agent client info

To view the DSA client details, use the **show platform hardware chassis active qfp feature dns-snoop-agent client info** command.

show platform hardware chassis active qfp feature dns-snoop-agent client info

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA client details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client info
Number of patterns added/deleted/total: 2/0/2
Number of re_table rebuilt : : 0
Number of str_table rebuilt: : 2
Registered clients: 0x001ffff0
Number of transaction started/ended: 2/2
Memory pool size/limit: 512/81920
Pending Deletion Pattern List:
```

show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list

To view the OpenDNS string or FQDN filter for the pattern list, use the **show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list** command.

show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list {**fqdn-filter** *fqdn_filter_ID* | **odns_string**}

Syntax Description

fqdn-filter	Displays the FQDN filter for the pattern list.
fqdn_filter_ID	Refers to the FQDN filter ID. The valid range is from 1 to 16.
odns_string	Displays the OpenDNS string for the pattern list.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the FQDN filter for the pattern list:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list
 fqdn-filter 1
Filter Name: urllist_flex_preauth
Pattern List in CPP client: 1

Name: url1.dns.com
feature_mask: 0x00000010, hw_ptr: 0xdf86d510
```

show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache

To view the DSA IP cache table details, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache** command.

show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache {**address** [**ipv4** *ipv4_address* | **ipv6** *ipv6_address*] | **all** | **pattern** *regex_pattern*}

Syntax Description

address [**ipv4** *ipv4_address* | **ipv6** *ipv6_address*]	Displays the DSA address entry details
all	Displays all the DSA IP cache address details
pattern *regex_pattern*	Displays the DSA IP cache pattern details

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA address entry details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
 address ipv4 104.122.2.194
IP address: 104.122.2.194, client(s): 32, regex: www.adobe.com, expire in 0 seconds
```

This example shows how to view all the DSA IP cache address details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
 all
IP Address        Client(s) Expire     Match         RegexId      Dirty
------------------------------------------------------------------------
172.217.13.228      2       132     .*google.com    0x4d7f9e20     0x0
```

This example shows how to view the DSA IP cache pattern details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
 pattern .*google*
1 IP Addresses matching pattern .*google*
IP Address                    Client(s)  Expire   Match       RegexId    Dirty
-------------------------------------------------------------------------------
2607:f8b0:4004:800:0:0:0:2004   32         13    .*google*   0x31156220   0x0
```

show platform hardware chassis active qfp feature dns-snoop-agent datapath memory

To view the DSA datapath memory details, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath memory** command.

show platform hardware chassis active qfp feature dns-snoop-agent datapath memory

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA datapath memory details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath memory
Table-Name   Address      Size
----------------------------------------
IP Cache DB   0xda5bb420   512
IP Hash       0xda41f400   1024
String Table  0xdec6ac10
String Table  0xda41f010

==DSA Chunk info==
Chunk-Pool   Allocated     Total_Free   Init-Num     Low_Wat
------------------------------------------------------------
ip cache chunk   0             512          512          512

==DSA Runtime Info==
------------------------------------------------------------
dsa init state 0x7   dsa client mask 0x100010
```

show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table

To view the DSA regular expression table, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table** command.

show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA regular expression table:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath
regexp-table
String Table 0xdec6ac10     WLS_FQDN_GRP_1
String Table 0xda41f010     ODNS String
```

show platform hardware chassis active qfp feature dns-snoop-agent datapath stats

To view the DSA statistics, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath stats** command.

show platform hardware chassis active qfp feature dns-snoop-agent datapath stats

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA statistics:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath stats
DNS Snoop Agent Stats:
  parser unknown pkt: 0
  parser not needed: 0
  parser fmt error: 0
  parser pa error: 0
  parser non resp: 0
  parser multiple name: 0
  parser dns name err: 0
  parser matched ip: 0
  parser redirect: 0
  parser whitelist redirect: 0
  parser blacklist redirect: 0
  parser invalid redirect ip: 0
  parser skip: 0
  regex locked: 0
  regex not matched: 0
  pkt drop whitelist no redirect ip: 0
  pkt drop blacklist no redirect ip: 0
  entries in use: 0
  ip cache allocation fail: 0
  ip addr add: 0
  ip addr update: 0
  ip addr delete: 0
  ip addr cache hit: 0
  ip addr cache miss: 0
  ip addr bad param: 0
  ip addr delete not found: 0
  ip cache not initialized: 0
```

show platform hardware chassis active qfp feature et-analytics datapath runtime

To view the ETA global state in datapath, use the **show platform hardware chassis active qfp feature et-analytics datapath runtime** command.

show platform hardware chassis active qfp feature et-analytics datapath runtime

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath runtime
ET-Analytics run-time information:
   Feature state: initialized (0x00000004)
   Inactive timeout : 15 secs (default 15 secs)
   WhiteList information :
      flag: False
      cgacl w0 : n/a
      cgacl w1 : n/a
   Flow CFG information :
      instance ID : 0x0
      feature ID : 0x1
      feature object ID : 0x1
      chunk ID : 0xC
```

show platform hardware chassis active qfp feature et-analytics datapath memory

To view the ETA memory details, use the **show platform hardware chassis active qfp feature et-analytics datapath memory** command.

show platform hardware chassis active qfp feature et-analytics datapath memory

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA memory details:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath memory
ET-Analytics memory information:
   Size of FO : 3200 bytes
   No. of FO allocs : 0
   No. of FO frees : 0
```

show platform hardware chassis active qfp feature et-analytics datapath stats export

To view the ETA flow export in datapath, use the **show platform hardware chassis active qfp feature et-analytics datapath stats export** command.

show platform hardware chassis active qfp feature et-analytics datapath stats export

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA flow export in datapath:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath stats export
ET-Analytics 192.168.5.2:2055 vrf 0 Stats:
   Export statistics:
      Total records exported : 5179231
      Total packets exported : 3124873
      Total bytes exported : 3783900196
      Total dropped records : 0
      Total dropped packets : 0
      Total dropped bytes : 0
      Total IDP records exported :
            initiator->responder : 1285146
            responder->initiator : 979284
      Total SPLT records exported:
            initiator->responder : 1285146
            responder->initiator : 979284
      Total SALT records exported:
            initiator->responder : 0
            responder->initiator : 0
      Total BD records exported :
            initiator->responder : 0
            responder->initiator : 0
      Total TLS records exported :
            initiator->responder : 309937
            responder->initiator : 329469
```

show platform hardware chassis active qfp feature et-analytics datapath stats flow

To view the ETA flow statistics, use the **show platform hardware chassis active qfp feature et-analytics datapath stats flow** command.

show platform hardware chassis active qfp feature et-analytics datapath stats flow

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA flow statistics:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath stats flow
ET-Analytics Stats:
   Flow statistics:
      feature object allocs : 0
      feature object frees : 0
      flow create requests : 0
      flow create matching : 0
      flow create successful: 0
      flow create failed, CFT handle: 0
      flow create failed, getting FO: 0
      flow create failed, malloc FO : 0
      flow create failed, attach FO : 0
      flow create failed, match flow: 0
      flow create, aging already set: 0
      flow ageout requests : 0
      flow ageout failed, freeing FO: 0
      flow ipv4 ageout requests : 0
      flow ipv6 ageout requests : 0
      flow whitelist traffic match : 0
```

show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree

To view clients in the ETA pending wireless client tree, use the **show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree** command.

show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view clients in the ETA pending wireless client tree:

```
Device# show platform hardware chassis active qfp feature wireless et-analytics
eta-pending-client-tree
CPP IF_H    DPIDX        MAC Address    VLAN   AS  MS  WLAN        POA
------------------------------------------------------------------------------
0X2A      0XA0000001    2c33.7a5b.827b  160    RN  LC ewlc_ssid 0x90000003
0X2B      0XA0000002    2c33.7a5b.80fb  160    RN  LC ewlc_ssid 0x90000003
```

show platform hardware chassis active qfp feature wireless et-analytics statistics

To view the ETA pending wireless client tree statistics, use the **show platform hardware chassis active qfp feature wireless et-analytics statistics** command.

show platform hardware chassis active qfp feature wireless et-analytics statistics

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA pending wireless client tree statistics:

```
Device# show platform hardware chassis active qfp feature wireless et-analytics statistics
Wireless ETA cpp-client plumbing statistics
Number of ETA pending clients : 2
Counter                                                    Value
-------------------------------------------------------------------
Enable ETA on wireless client called                         0
Delete ETA on wireless client called                         0
ETA global cfg init cb TVI FIA enable error                  0
ETA global cfg init cb output SB read error                  0
ETA global cfg init cb output SB write error                 0
ETA global cfg init cb input SB read error                   0
ETA global cfg init cb input SB write error                  0
ETA global cfg init cb TVI FIA enable success                0
ETA global cfg uninit cb ingress feat disable                0
ETA global cfg uninit cb ingress cfg delete                  0
ETA global cfg uninit cb egress feat disable                 0
ETA global cfg uninit cb egress cfg delete er                0
ETA pending list insert entry called                         4
ETA pending list insert invalid arg error                    0
ETA pending list insert entry exists error                   0
ETA pending list insert no memory error                      0
ETA pending list insert entry failed                         0
ETA pending list insert entry success                        4
ETA pending list delete entry called                         2
ETA pending list delete invalid arg error                    0
ETA pending list delete entry missing                        0
ETA pending list delete entry remove error                   0
ETA pending list delete entry success                        2
```

show platform hardware slot R0 ha_port interface stats

To see the HA port interface setting status, use the **show platform hardware slot R0 ha_port interface stats** command.

show platform hardware slot R0 ha_port interface stats

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Examples

This example shows how to see the HA port interface setting status:

```
Device# show platform hardware slot R0 ha_port interface stats
HA Port
ha_port   Link encap:Ethernet  HWaddr 70:18:a7:c8:80:70
          UP BROADCAST MULTICAST  MTU:1500  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 B)  TX bytes:0 (0.0 B)
          Memory:e0900000-e0920000


Settings for ha_port:
        Supported ports:            [ TP ]
        Supported link modes:       10baseT/Half 10baseT/Full
                                    100baseT/Half 100baseT/Full
                                    1000baseT/Full
        Supported pause frame use:   Symmetric
        Supports auto-negotiation:   Yes
        Supported FEC modes:         Not reported
        Advertised link modes:       10baseT/Half 10baseT/Full
                                     100baseT/Half 100baseT/Full
                                     1000baseT/Full
        Advertised pause frame use:  Symmetric
        Advertised auto-negotiation: Yes
        Advertised FEC modes:        Not reported
        Speed:                       Unknown!
        Duplex:                      Unknown! (255)
        Port:                        Twisted Pair
        PHYAD:                       1
        Transceiver:                 internal
        Auto-negotiation:            on
        MDI-X:                       off (auto)
        Supports Wake-on:            pumbg
        Wake-on:                     g
        Current message level:       0x00000007 (7)
                                     drv probe link
        Link detected:               no
```

```
NIC statistics:
     rx_packets:             0
     tx_packets:             0
     rx_bytes:               0
     tx_bytes:               0
     rx_broadcast:           0
     tx_broadcast:           0
     rx_multicast:           0
     tx_multicast:           0
     multicast:              0
     collisions:             0
     rx_crc_errors:          0
     rx_no_buffer_count:     0
     rx_missed_errors:       0
     tx_aborted_errors:      0
     tx_carrier_errors:      0
     tx_window_errors:       0
     tx_abort_late_coll:     0
     tx_deferred_ok:         0
     tx_single_coll_ok:      0
     tx_multi_coll_ok:       0
     tx_timeout_count:       0
     rx_long_length_errors:  0
     rx_short_length_errors: 0
     rx_align_errors:        0
     tx_tcp_seg_good:        0
     tx_tcp_seg_failed:      0
     rx_flow_control_xon:    0
     rx_flow_control_xoff:   0
     tx_flow_control_xon:    0
     tx_flow_control_xoff:   0
     rx_long_byte_count:     0
     tx_dma_out_of_sync:     0
     tx_smbus:               0
     rx_smbus:               0
     dropped_smbus:          0
     os2bmc_rx_by_bmc:       0
     os2bmc_tx_by_bmc:       0
     os2bmc_tx_by_host:      0
     os2bmc_rx_by_host:      0
     tx_hwtstamp_timeouts:   0
     rx_hwtstamp_cleared:    0
     rx_errors:              0
     tx_errors:              0
     tx_dropped:             0
     rx_length_errors:       0
     rx_over_errors:         0
     rx_frame_errors:        0
     rx_fifo_errors:         0
     tx_fifo_errors:         0
     tx_heartbeat_errors:    0
     tx_queue_0_packets:     0
     tx_queue_0_bytes:       0
     tx_queue_0_restart:     0
     tx_queue_1_packets:     0
     tx_queue_1_bytes:       0
     tx_queue_1_restart:     0
     rx_queue_0_packets:     0
     rx_queue_0_bytes:       0
     rx_queue_0_drops:       0
     rx_queue_0_csum_err:    0
     rx_queue_0_alloc_failed:0
     rx_queue_1_packets:     0
```

```
rx_queue_1_bytes:       0
rx_queue_1_drops:       0
rx_queue_1_csum_err:    0
rx_queue_1_alloc_failed:0
```

show platform integrity

To view the checksum record for boot stages, use the **show platform integrity** command.

show platform integrity [sign [nonce *nonce* **]]**

Syntax Description

sign	(Optional). Show signature.
nonce	(Optional). Enter a nonce value.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to view the checksum record for boot stages:

```
Device# show platform integrity sign nonce 123
Platform: C9800-L-F-K9
Boot 0 Version: R04.1173930452019-06-11
Boot 0 Hash: A6C92C44976FC77DD42234444FFD87798FB9036A2762FAA4999A190A0258B18C
Boot Loader Version: 16.12(1r)
Boot Loader Hash:
FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
OS Version: 2020-03-19_20.26
OS Hashes:
C9800-L-universalk9_wlc.2020-03-19_20.26.SSA.bin:
53E2DF1A1A082E36EA4CAB817C1794EC9D69AC0E90BCCBFECF9BCD0BCA9385AA9E9372ABF7431E4A08FC5E5B9670131C09D158E5B8A7B457501FE77AB9F1C26D
C9800-L-mono-universalk9_wlc.2020-03-19_20.26.SSA.pkg:
1D3279D53B0311CE42C669824DF86FB5596CD7CA45CA8D7FDC3D10657B8C9A48F4B0508D7BCFFD645CB6571AC1E674A57A82414E3D6E1666BE64E6132F707671
PCR0: EE14A2D5099DA343B3941C54A429C4AC1D3EE8E9B609F1AC00049768A470734E
PCR8: 78794D0F5667F8FA4E425E3CA2AF3CD99B90B219FD90222D622B3D563416BBAA
```

show platform software audit

To display the Security Enhanced Linux (SELinux) audit logs, use the **show platform software audit** command in privileged EXEC mode.

show platform software audit {**all** | **summary** | **0** | **1** | **2** | **F0** | **R0** | **FP active** | **RP active**}

Syntax Description

all	Shows the audit log from all the slots.
summary	Shows the audit log summary count from all the slots.
0	Shows the audit log for the SM-Inter-Processor slot 0.
1	Shows the audit log for the SM-Inter-Processor slot 1.
2	Shows the audit log for the SM-Inter-Processor slot 2.
F0	Shows the audit log for the Embedded-Service-Processor slot 0.
R0	Shows the audit log for the Route-Processor slot 0.
FP active	Shows the audit log for the active Embedded-Service-Processor slot.
RP active	Shows the audit log for the active Route-Processor slot.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced on Cisco ISR 4000 series routers, Cisco CSR 1000V series routers, and Cisco 1000 ISR series routers running time-sensitive networking (TSN).
Cisco IOS XE Gibraltar 16.12.1	This command was implemented on Cisco Catalyst 9800 Series Wireless Controller.

Usage Guidelines

The **show platform software audit** command displays the system logs containing the access violation events.

In Cisco IOS XE Gibraltar 16.11.1, operation in a permissive mode is available - with the intent of confining specific components (process or application) of the IOS-XE platform. In the permissive mode, access violation events are detected and system logs are generated, but the event or operation itself is not blocked. The solution operates mainly in an access violation detection mode.

The following is a sample output of the **show software platform software audit summary** command:

```
Device# show platform software audit summary
=====================================
AUDIT LOG ON ACTIVE
-------------------------------------
AVC Denial count: 7
```

The following is a sample output of the **show software platform software audit all** command. This command displays the information in the `audit.log` file.

```
Device# show platform software audit all
==================================
AUDIT LOG ON ACTIVE
----------------------------------
========== START ============
type=DAEMON_START msg=audit(1553837190.262:3031): op=start ver=2.6.6 format=raw kernel=4.4.172
 auid=4294967295 pid=446 subj=system_u:system_r:auditd_t:s0 res=success
type=NETFILTER_CFG msg=audit(1553837185.956:2): table=nat family=2 entries=0
type=MAC_STATUS msg=audit(1553837186.523:3): enforcing=1 old_enforcing=0 auid=4294967295
ses=4294967295
type=SYSCALL msg=audit(1553837186.523:3): arch=c000003e syscall=1 success=yes exit=1 a0=3
a1=7ffcf1c22070 a2=1 a3=0 items=0 ppid=203 pid=205 auid=4294967295 uid=0 gid=0 euid=0 suid=0
 fsuid=0 egid=0 sgid=0 fsgid=0 tty=(none) ses=4294967295 comm="load_policy"
exe="/usr/sbin/load_policy" subj=kernel key=(null)
type=PROCTITLE msg=audit(1553837186.523:3):
proctitle=2F7573722F7362696E2F6C6F61645F706F6C696379002D69
type=MAC_POLICY_LOAD msg=audit(1553837186.528:4): policy loaded auid=4294967295 ses=4294967295
type=SYSCALL msg=audit(1553837186.528:4): arch=c000003e syscall=1 success=yes exit=1693637
 a0=4 a1=7f792d1d6000 a2=19d7c5 a3=f items=0 ppid=203 pid=205 auid=4294967295 uid=0 gid=0
euid=0 suid=0 fsuid=0 egid=0 sgid=0 fsgid=0 tty=(none) ses=4294967295 comm="load_policy"
exe="/usr/sbin/load_policy" subj=system_u:system_r:kernel_t:s0 key=(null)
…
```

You can use the output of this command to copy the contents of `audit.log` to a file to then transfer to a remote host.

```
Device# show platform software audit all | redirect bootflash:audi_123.log

Device#dir bootflash:audi_123.log
Directory of bootflash:/audi_123.log
   27  -rw-            35305  Mar 29 2019 22:16:36 +00:00  audi_123.log

3249049600 bytes total (538112000 bytes free)
```

show platform software arp broadcast

To display the Address Resolution Protocol (ARP) broadcast status on an access point (AP), use the **show platform software arp broadcast** command.

show platform software arp broadcast

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.8.1	This command was introduced.

Examples

The following example shows the ARP broadcast on an AP:

```
Device# show platform software arp broadcast

Arp broadcast is enabled on vlans:
20,50
```

show platform software system all

To check status of the current virtual machine and look for performance issues due to inadequate resources (or other issues with the hosting environment), use the **set platform software system all** command in privileged EXEC mode.

show platform software system all

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

This example shows how to check status of the current virtual machine and its resources:

```
Device# show platform software system all

Processor Details
=================
Number of Processors : 6
Processor : 1 - 6
vendor_id : GenuineIntel
cpu MHz  : 2593.750
cache size : 35840 KB
Crypto Supported : Yes
model name : Intel(R) Xeon(R) CPU E5-2690 v4 @ 2.60GHz

Memory Details
==============
Physical Memory : 16363904KB

VNIC Details
============
Name   Mac Address  Status Platform MTU
GigabitEthernet1 000c.2964.7126  UP 1500
GigabitEthernet2 000c.2964.7130  UP 1500

Hypervisor Details
==================
Hypervisor: VMWARE
Manufacturer: VMware, Inc.
Product Name: VMware Virtual Platform
Serial Number: VMware-56 4d e5 0a a7 dd 27 2b-0e 2f 36 6e 0f 64 71 26
UUID: 564DE50A-A7DD-272B-0E2F-366E0F647126
image_variant :

Boot Details
==================
Boot mode: BIOS
Bootloader version: 1.1
```

show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

show platform software trace filter-binary*modules* [**context** *mac-address*]

Syntax Description

context*mac-address*	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

This command collates and sorts all the logs present in the `/tmp/.../` across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named `collated_log_{system time}` with the same content, in the `/crashinfo/tracelogs` directory.

Examples

This example shows how to display the trace information for a wireless module:

```
Device# show platform software trace filter-binary wireless
```

show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

show platform software trace filter-binary*modules* [**context** *mac-address*]

Syntax Description

context*mac-address*	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

This command collates and sorts all the logs present in the `/tmp/.../` across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named `collated_log_{system time}` with the same content, in the `/crashinfo/tracelogs` directory.

Examples

This example shows how to display the trace information for a wireless module:

```
Device# show platform software trace filter-binary wireless
```

show platform software trace level

To view the trace levels for all the modules under a specific process, use the **show platform software trace level** command in privileged EXEC or user EXEC mode.

show platform software trace level wireless [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

process	Process whose tracing level is being set. Options include: • **chassis-manager**—The Chassis Manager process. • **cli-agent**—The CLI Agent process. • **cmm**—The CMM process. • **dbm**—The Database Manager process. • **emd**—The Environmental Monitoring process. • **fed**—The Forwarding Engine Driver process. • **forwarding-manager**—The Forwarding Manager process. • **geo**—The Geo Manager process. • **host-manager**—The Host Manager process. • **interface-manager**—The Interface Manager process. • **iomd**—The Input/Output Module daemon (IOMd) process. • **ios**—The IOS process. • **license-manager**—The License Manager process. • **logger**—The Logging Manager process. • **platform-mgr**—The Platform Manager process. • **pluggable-services**—The Pluggable Services process. • **replication-mgr**—The Replication Manager process. • **shell-manager**—The Shell Manager process. • **sif**—The Stack Interface (SIF) Manager process. • **smd**—The Session Manager process. • **stack-mgr**—The Stack Manager process. • **table-manager**—The Table Manager Server. • **thread-test**—The Multithread Manager process. • **virt-manager**—The Virtualization Manager process. • **wireless**—The wireless controller module process.

slot	Hardware slot where the process for which the trace level is set, is running. Options include: • *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2. • *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2. • **F0**—The Embedded Service Processor in slot 0. • **F1**—The Embedded Service Processor in slot 1. • **FP active**—The active Embedded Service Processor. • **R0**—The route processor in slot 0. • **RP active**—The active route processor. • **switch** <*number*> —The switch, with its number specified. • **switch active**—The active switch. • **switch standby**—The standby switch. • *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2. • *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2. • **F0**—The Embedded Service Processor in slot 0. • **FP active**—The active Embedded Service Processor. • **R0**—The route processor in slot 0. • **RP active**—The active route processor.

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

This example shows how to view the trace level:

```
Device# show platform software trace level dbm switch active R0
Module Name                      Trace Level
-------------------------------------------------
binos                            Notice
binos/brand                      Notice
bipc                             Notice
btrace                           Notice
bump_ptr_alloc                   Notice
cdllib                           Notice
chasfs                           Notice
dbal                             Informational
dbm                              Debug
evlib                            Notice
evutil                           Notice
file_alloc                       Notice
green-be                         Notice
ios-avl                          Notice
klib                             Debug
services                         Notice
sw_wdog                          Notice
syshw                            Notice
tdl_cdlcore_message              Notice
tdl_dbal_root_message            Notice
tdl_dbal_root_type               Notice
```

show platform software utd chassis active F0 et-analytics global

To view the ETA global and interface details, use the **show platform software utd chassis active F0 et-analytics global** command.

show platform software utd chassis active F0 et-analytics global

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform software utd chassis active F0 et-analytics global
ET Analytics Global Configuration
ID: 1
All Interfaces: Off
IP address and port and vrf: 192.168.5.2:2055:0
```

show platform software et-analytics global

To view the ETA global configuration, use the **show platform software et-analytics global** command.

Note The **show platform software et-analytics global** command does not display the ETA enabled wireless client interfaces.

show platform software et-analytics global

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform software et-analytics global
ET-Analytics Global state
=========================
All Interfaces : Off
IP Flow-record Destination: 192.168.5.2 : 2055
Inactive timer: 15
```

show platform sudi certificate

To view the checksum record for a specific SUDI, use the **show platform sudi certificate** command.

show platform sudi certificate [sign [nonce *nonce* **]]**

Syntax Description

sign	(Optional). Show signature.
nonce	(Optional). Enter a nonce value.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to view the checksum record for the specific SUDI:

```
Device# show platform sudi certificate sign nonce 123
-----BEGIN CERTIFICATE-----
MIIDQzCCAiugAwIBAgIQX/h7KCtU3I1CoxW1aMmt/zANBgkqhkiG9w0BAQUFADA1
MRYwFAYDVQQKEw1DaXNjbyBTeXN0ZW1zMRswGQYDVQQDExJDaXNjbyBSb290IENB
IDIwNDgwHhcNMDQwNTE0MjAxNzEyWhcNMjkwNTE0MjAyNTQyWjA1MRYwFAYDVQQK
Ew1DaXNjbyBTeXN0ZW1zMRswGQYDVQQDExJDaXNjbyBSb290IENBIDIwNDgwggEg
MA0GCSqGSIb3DQEBAQUAA4IBDQAwggEIAoIBAQCwmrmrp68Kd6ficba0ZmKUeIhH
xmJVhEAyv8CrLqUccda8bnuoqrpu0hWISEWdovyD0My5jOAmaHBKeN8hF570YQXJ
FcjPFto1YYmUQ6iEqDGYeJu5Tm8sUxJszR2tKyS7McQr/4NEb7Y9JHcJ6r8qqB9q
VvYgDxFUl4F1pyXOWWqCZe+36ufijXWLbvLdT6ZeYpzPEApk0E5tzivMW/VgpSdH
jWn0f84bcN5wGyDWbs2mAag8EtKpP6BrXruOIIt6keO1aO6g58QBdKhTCytKmg9l
Eg6CTY5j/e/rmxrbU6YTYK/CfdfHbBcl1HP7R2RQgYCUTOG/rksc35LtLgXfAgED
o1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAdBgNVHQ4EFgQUJ/PI
FR5umgIJFq0roIlgX9p7L6owEAYJKwYBBAGCNxUBBAMCAQAwDQYJKoZIhvcNAQEF
BQADggEBAJ2dhISjQal8dwy3U8pORFBi71R803UXHOjgxkhLtv5MOhmBVrBW7hmW
Yqpao2TB9k5UM8Z3/sUcuuVdJcr18JOagxEu5sv4dEX+5wW4q+ffy0vhN4TauYuX
cB7w4ovXsNgOnbFp1iqRe6lJT37mjpXYgyc81WhJDtSd9i7rp77rMKSsH0T81lasz
Bvt9YAretIpjsJyp8qS5UwGH0GikJ3+r/+n6yUA4iGe0OcaEb1fJU9u6ju7AQ7L4
CYNu/2bPPu8Xs1gYJQk0XuPL1hS27PKSb3TkL4Eq1ZKR4OCXPDJoBYVL0fdX4lId
kxpUnwVwwEpxYB5DC2Ae/qPOgRnhCzU=
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
MIIEPDCCAySgAwIBAgIKYQlufQAAAAADDANBgkqhkiG9w0BAQUFADA1MRYwFAYD
VQQKEw1DaXNjbyBTeXN0ZW1zMRswGQYDVQQDExJDaXNjbyBSb290IENBIDIwNDgw
HhcNMTEwNjMwMTc1NjU3WhcNMjkwNTE0MjAyNTQyWjAnMQ4wDAYDVQQKEwVDaXNj
bzEVMBMGA1UEAxMMQUNUMiBTVURJIENBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8A
MIIBCgKCAQEA0m5l3THIxA9tN/hS5qR/6UZRpdd+9aE2JbFkNjht6gfHKd477AkS
5XAtUs5oxDYVt/zEbslZq3+LR6qrqKKQVu6JYvH05UYLBqCj38s76NLk53905Wzp
9pRcmRCPuX+a6tHF/qRuOiJ44mdeDYZo3qPCpxzprWJDPclM4iYKHumMQMqmgmg+
xghHIooWS80BOcdiynEbeP5rZ7qRuewKMpl1TiI3WdBNjZjnpfjg66F+P4SaDkGb
BXdGj13oVeF+EyFWLrFjj97fL2+8oauV43Qrvnf3d/GfqXj7ew+z/sXlXtEOjSXJ
URsyMEj53Rdd9tJwHky8neapszS+r+kdVQIDAQABo4IBWjCCAVYwCwYDVR0PBAQD
AgHGMB0GA1UdDgQWBBRI2PHxwnDVW7t8cwmTr7i4MAP4fzAfBgNVHSMEGDAWgBQn
88gVHm6aAgkWrSugiWBf2nsvqjBDBgNVHR8EPDA6MDigNqA0hjJodHRwOi8vd3d3
```

```
LmNpc2NvLmNvbS9zZWN1cml0eS9wa2kvY3JsL2NyY2EyMDQ4LmNybDBQBggrBgEF
BQcBAQREMEIwQAYIKwYBBQUHMAKGNGh0dHA6Ly93d3cuY2lzY28uY29tL3NlY3Vy
aXR5L3BraS9jZXJ0cy9jcmNhMjA0OC5jZXIwXAYDVR0gBFUwUzBRBgorBgEEAQkV
AQwAMEMwQQYIKwYBBQUHAgEWNWh0dHA6Ly93d3cuY2lzY28uY29tL3NlY3VyaXR5
L3BraS9wb2xpY2llcy9pbmRleC5odG1sMBIGA1UdEwEB/wQIMAYBAf8CAQAwDQYJ
KoZIhvcNAQEFBQADggEBAGh1qclr9tx4hzWgDERm371yeuEmqcIfi9b9+GbMSJbi
ZHc/CcCl0lJu0a9zTXA9w47H9/t6leduGxb4WeLxcwCiUgvFtCa51Iklt8nNbcKY
/4dw1ex+7amATUQO4QggIE67wVIPu6bgAE3Ja/nRS3xKYSnj8H5TehimBSv6TECi
i5jUhOWryAK4dVo8hCjkjEkzu3ufBTJapnv89g9OE+H3VKM4L+/KdkUO+52djFKn
hyl47d7cZR4DY4LIuFM2P1As8YyjzoNpK/urSRI14WdIlplR1nH7KNDl5618yfVP
0IFJZBGrooCRBjOSwFv8cpWCbmWdPaCQT2nwIjTfY8c=
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
MIIDfTCCAmWgAwIBAgIEAwQD7zANBgkqhkiG9w0BAQsFADAnMQ4wDAYDVQQKEwVD
aXNjbzEVMBMGA1UEAxMMQUNUMiBTVURJIENBMB4XDTE4MDkyMzIyMzIwNloXDTI5
MDUxNDIwMjU0MVowaTEnMCUGA1UEBRMeUElEOkM5NjAwLVNVUC0xIFNOOkNBVDIy
MzZMMFE5MQ4wDAYDVQQKEwVDaXNjbzEYMBYGA1UECxMPQUNULTIgTGl0ZSBTVURJ
MRQwEgYDVQQDEwtDOTYwMC1TVVAtMTCCASIwDQYJKoZIhvcNAQEBBQADggEPADCC
AQoCggEBANsh0jcvgh1pdOjP9KnffDnDc/zEHDzbCTWPJi2FZcsaSE5jvq6CUqc4
MYpNAZU2Jym7NSD8iQbMXwbnCtoL64QtxQeFhRYmc4d5o933M7GwpEH0I7HUSbO/
Fxyp7JBmGPPgAkY7rKsYENiNK2hiR7Q2O7X2BidOKknEuofWdJMNyMaZgLYLOHbJ
5oXaORxhUy3VRaxNl6qI7kYxuugg2LcAbZ539sRXe8JtHyK8llURNSGMiQ0S17pS
idGmrJJ0pEHA0EUVTZqEny3z+NW9uxLVSzu6+hEJYlqfI+YEf0DbVZly1cy5r/jF
yNdGuGKvd5agvgCly8aYMZa3P+D5S8sCAwEAAaNvMG0wDgYDVR0PAQH/BAQDAgXg
MAwGA1UdEwEB/wQCMAAwTQYDVR0RBEYwRKBCBgkrBgEEAQkVAgOgNRMzQ2hpcElE
PVUxUk5TVEl3TVRjd05qSTFBQUFwZndBQUFBQUFBQUFBQUFBQUFBQUhtSlU9MA0G
CSqGSIb3DQEBCwUAA4IBAQCrpHo/CUyk5Hs/asIcYW0ep8KocSkbNh8qamyd4oWD
e/MGJW9Bs5f09IEbILWPdytCCS2lSyJbxz2HvVDzdxQdxjDwUNiWuu3dWMXN/i67
yuCGM+lA1AAG5dT6lNgWYHh+YzsZm9eoq1+4NM+JuMXWsnzAK8rSy+dSpBxqFsBq
E0OlPsaK7y2h8gs+XrV9x+D48OZQkTRXpxhJfiWvs+EbdgsAM/vBxTAoTJPVmXWN
Cmcj9X52Xl3i4MdOUXocZLO2kh6JSgOYGkFeZifJ0iDvMfAf0cJ6+cEF6bSxAqBL
veel+8LmeiE/2O9h6qGHPPDacCaXA2oJCDHveAt8iPTG
-----END CERTIFICATE-----

Signature version: 1
Signature:
[redacted]
```

show platform sudi pki

To validate whether a hardware unit is programmed correctly or not, use the **show platform sudi pki** command.

show platform sudi pki

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to check whether a hardware unit is programmed correctly or not:

```
Device# show platform sudi pki

CMCA3 cert status : Enabled / Disabled

SUDI Issuer                          Validity status
-------------------------------------------------------------------------
Cisco Manufacturing CA III           Valid / Not-valid
Cisco Manufacturing CA SHA2          Valid / Not-valid
Cisco Manufacturing CA               Valid / Not-valid
```

show parameter-map type umbrella global

To view the Umbrella global parameter map details, use the **show parameter-map type umbrella global** command.

show parameter-map type umbrella global

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella global parameter map details:

```
Device# show parameter-map type umbrella global
parameter-map type umbrella global
   token   57CC80106C087FB1B2A7BAB4F2F4373C00247166
   local-domain dns_wl
   dnscrypt
   udp-timeout 2
   resolver ipv4 208.67.220.220
   resolver ipv4 208.67.222.222
   resolver ipv6 2620:119:53::53
   resolver ipv6 2620:119:35::35
```

show policy-map

To display quality of service (QoS) policy maps, which define classification criteria for incoming traffic, use the **show policy-map** command in EXEC mode.

show policy-map [*policy-map-name* | **interface** *interface-id*]

show policy-map interface {**Auto-template** | **Capwap** | **GigabitEthernet** | **GroupVI** | **InternalInterface** | **Loopback** | **Lspvif** | **Null** | **Port-channel** | **TenGigabitEthernet** | **Tunnel** | **Vlan** | **brief** | **class** | **input** | **output**

show policy-map interface {**ap name** *ap_name* | **client mac** *mac_address* | **radio type** {**24ghz** | **5ghz**} **ap name** *ap_name* | **ssid name** *ssid_name* {**ap name** *ap_name* | **radio type** {**24ghz** | **5ghz**} **ap name** *ap_name*} }

Syntax Description

policy-map-name	(Optional) Name of the policy-map.
interface *interface-id*	(Optional) Displays the statistics and the configurations of the input and output policies that are attached to the interface.
ap name *ap_name*	Displays SSID policy configuration of an access point.
client mac *mac_address*	Displays information about the policies for all the client targets.
radio type {**24ghz**	**5ghz**	Displays policy configuration of the access point in the specified radio type.
ssid name *ssid_name*	Displays policy configuration of an SSID.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command w

Usage Guidelines

Policy maps can include policers that specify the bandwidth limitations and the action to take if the limits are exceeded.

Note Though visible in the command-line help string, the **control-plane**, **session**, and **type** keywords are not supported, and the statistics shown in the display should be ignored.

To display classification counters for ternary content addressable memory (TCAM) (marking or policing) based policies, enter the interface ID. Classification counters have the following restrictions:

- Classification counters are supported only on wired ports (in the ingress and egress directions).
- Classification counters count packets instead of bytes.
- Only QoS configurations with marking or policing trigger the classification counter.
- As long as there is policing or marking action in the policy, the class-default will have classification counters.
- Classification counters are not port based. The counters are shared across targets sharing the same policy map. This means that the classification counter aggregates all packets belonging to the same class of the same policy which attach to different interfaces.

This is an example of output from the **show policy-map interface** command, where classification counters are displayed:

```
Device# show policy-map interface gigabitethernet1/0/1

  GigabitEthernet1/0/1

  Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

    Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
      0 packets
      Match: cos  5
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        dscp ef
      police:
          cir 128000 bps, bc 8000 bytes
        conformed 0 bytes; actions:
          transmit
        exceeded 0 bytes; actions:
          set-dscp-transmit dscp table policed-dscp
        conformed 0000 bps, exceed 0000 bps

    Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
      0 packets
      Match: cos  3
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        dscp cs3
      police:
          cir 32000 bps, bc 8000 bytes
        conformed 0 bytes; actions:
          transmit
        exceeded 0 bytes; actions:
          set-dscp-transmit dscp table policed-dscp
        conformed 0000 bps, exceed 0000 bps
```

```
  Class-map: AutoQos-4.0-Default-Class (match-any)
    0 packets
    Match: access-group name AutoQos-4.0-Acl-Default
      0 packets, 0 bytes
      5 minute rate 0 bps
    QoS Set
      dscp default

  Class-map: class-default (match-any)
    0 packets
    Match: any
      0 packets, 0 bytes
      5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

  queue stats for all priority classes:
    Queueing
    priority level 1

    (total drops) 0
    (bytes output) 0

  Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
    0 packets
    Match:  dscp cs4 (32) cs5 (40) ef (46)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  5
      0 packets, 0 bytes
      5 minute rate 0 bps
    Priority: 30% (300000 kbps), burst bytes 7500000,

    Priority Level: 1

  Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
    0 packets
    Match:  dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  3
      0 packets, 0 bytes
      5 minute rate 0 bps
    Queueing
    queue-limit dscp 16 percent 80
    queue-limit dscp 24 percent 90
    queue-limit dscp 48 percent 100
    queue-limit dscp 56 percent 100

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 10%

    queue-buffers ratio 10

  Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
    0 packets
    Match:  dscp af41 (34) af42 (36) af43 (38)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  4
      0 packets, 0 bytes
      5 minute rate 0 bps
    Queueing
```

```
  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match:  dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos  2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match:  dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos  1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match:  dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match:  dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
```

```
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

show processes cpu

To display detailed CPU utilization statistics of IOS tasks, use the **show processes cpu** command.

show processes cpu [**autoprofile** | **extended** | **history** [**table**] | **sorted** [**1min** | **5min** | **5sec**]]

Syntax Description

autoprofile	(Optional) Displays IOS(d) 'automatic CPUHOG profiling' information.
extended	(Optional) Displays extended CPU usage report of last 5 seconds for IOS(d) process.
history	(Optional) Displays CPU history in a graph format.
monitor	(Optional) Displays CPU utilization of IOS(d) processes continuously.
platform	(Optional) Displays CPU usage per IOS-XE process.
table	(Optional) Displays CPU history in a table format.
sorted	(Optional) Displays sorted output based on percentage of usage for IOS(d) processes.
history	(Optional) Sorts CPU utilization history. See Usage Guidelines for details.
1min	(Optional) Sorts CPU utilization based on 1-minute utilization.
5min	(Optional) Sorts CPU utilization based on 5-minute utilization.
5sec	(Optional) Sorts CPU utilization based on 5-second utilization.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was integrated into Cisco IOS XE Amsterdam 17.3.1.

Usage Guidelines

If you use the **history** keyword, three graphs are displayed for Cisco IOS images:

- CPU utilization for the last 60 seconds
- CPU utilization for the last 60 minutes
- CPU utilization for the last 72 hours

Maximum usage is measured and recorded every second. The average usage is calculated on periods of more than one second. Consistently high CPU utilization over an extended period indicates a problem.

To enable standby console, ensure that the following configuration is in place:

```
redundancy
main-cpu
secondary console enable
```

Example

The following is a sample output from the **show processes cpu** command without keywords:

```
Device# show processes cpu

CPU utilization for five seconds: 0%/0%; one minute: 0%; five minutes: 0%
 PID Runtime(ms)     Invoked      uSecs   5Sec   1Min   5Min TTY Process
  10     1576556      281188       5606  0.15%  0.05%  0.05%   0 Check heaps
 232      845057    54261160         15  0.07%  0.05%  0.06%   0 IPAM Manager
 595         177         300        590  0.07%  0.02%  0.01%   2 Virtual Exec
 138     1685973   108085955         15  0.07%  0.08%  0.08%   0 L2 LISP Punt Pro
 193       19644      348767         56  0.07%  0.00%  0.00%   0 DTP Protocol
   5           0           1          0  0.00%  0.00%  0.00%   0 CTS SGACL db cor
   4          24          15       1600  0.00%  0.00%  0.00%   0 RF Slave Main Th
   6           0           1          0  0.00%  0.00%  0.00%   0 Retransmission o
   7           0           1          0  0.00%  0.00%  0.00%   0 IPC ISSU Dispatc
   2      117631      348801        337  0.00%  0.00%  0.00%   0 Load Meter
   8           0           1          0  0.00%  0.00%  0.00%   0 EDDRI_MAIN
.
.
.
```

show rate-limit client

To configure the rate-limit for a client on the AP, use the **show rate-limit client** command.

show rate-limit client

Syntax Description

This command has no arguments.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following example shows how to configure the rate-limit for a client on the AP:

```
Device# show rate-limit client
Config:
mac vap rt_rate_out rt_rate_in rt_burst_out rt_burst_in nrt_rate_out nrt_rate_in nrt_burst_out
 nrt_burst_in
00:1C:F1:09:85:E7 0 8001 8002 8003 8004 8005 8006 8007 8008
Statistics:
name up down
Unshaped 0 0
Client RT pass 0 0
Client NRT pass 0 0
Client RT drops 0 0
Client NRT drops 0 0
Per client rate limit:
mac vap rate_out rate_in policy
```

show remote-lan all

To view the detailed output of all RLANs, use the **show remote-lan all** command.

show remote-lan all

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the detailed output of all RLANs:

```
Device# show remote-lan all
Remote-LAN Profile Name      : rlan_test_1
================================================
Identifier                          : 1
Status                              : Enabled
Mac-filtering                       : Not Configured
Number of Active Clients            : 1
Security_8021X                      : Disabled
8021.x Authentication list name     : Not Configured
Local Auth eap Profile Name         : Not Configured
Web Auth Security                   : Disabled
Webauth Authentication list name    : Not Configured
Web Auth Parameter Map              : Not Configured
Client association limit            : 0
Ipv4 Web Pre Auth Acl               : Not Configured
Ipv6 Web Pre Auth Acl               : Not Configured

Remote-LAN Profile Name      : rlan_test_2
================================================
Identifier                          : 2
Status                              : Enabled
Mac-filtering                       : Not Configured
Number of Active Clients            : 1
Security_8021X                      : Disabled
8021.x Authentication list name     : Not Configured
Local Auth eap Profile Name         : Not Configured
Web Auth Security                   : Disabled
Webauth Authentication list name    : Not Configured
Web Auth Parameter Map              : Not Configured
Client association limit            : 0
Ipv4 Web Pre Auth Acl               : Not Configured
Ipv6 Web Pre Auth Acl               : Not Configured
```

show remote-lan id

To view the RLAN configuration by ID, use the **show remote-lan id** command.

show remote-lan id *id*

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the RLAN configuration by ID:

```
Device# show remote-lan id <id>
Remote-LAN Profile Name      : rlan_test_1
================================================
Identifier                                    : 1
Status                                        : Enabled
Mac-filtering                                 : Not Configured
Number of Active Clients                   : 1
Security_8021X                                : Disabled
8021.x Authentication list name         : Not Configured
Local Auth eap Profile Name             : Not Configured
Web Auth Security                              : Disabled
Webauth Authentication list name      : Not Configured
Web Auth Parameter Map                   : Not Configured
Client association limit                       : 0
Ipv4 Web Pre Auth Acl                       : Not Configured
Ipv6 Web Pre Auth Acl                        : Not Configured
```

show remote-lan name

To view the RLAN configuration by profile name, use the **show remote-lan name** command.

show remote-lan name *profile-name*

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the RLAN configuration by profile name:

```
Device# show remote-lan name <profile-name>
Remote-LAN Profile Name      : rlan_test_1
================================================
Identifier                          : 1
Status                              : Enabled
Mac-filtering                       : Not Configured
Number of Active Clients            : 1
Security_8021X                      : Disabled
8021.x Authentication list name     : Not Configured
Local Auth eap Profile Name         : Not Configured
Web Auth Security                   : Disabled
Webauth Authentication list name    : Not Configured
Web Auth Parameter Map              : Not Configured
Client association limit            : 0
Ipv4 Web Pre Auth Acl               : Not Configured
Ipv6 Web Pre Auth Acl               : Not Configured
```

show remote-lan policy detail

To view the RLAN policy profile details by profile name, use the **show remote-lan policy detail** command.

show remote-lan policy detail *rlan_profile_name*

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the RLAN policy profile details by profile name:

```
Device# show remote-lan policy detail <rlan_profile_name>
Profile Name                    : rlan_named_pp1
Status                                : Enabled
Description                           :
REMOTE-LAN ACL
  IPv4 ACL name                       : Not Configured
  IPv6 ACL name                 : Not Configured
AAA Policy Params
  AAA Override                  : Disabled
  AAA Policy name               : default-aaa-policy
RLAN Switching policy
  Central Switching             : Enabled
  Central Dhcp                  : Enabled
VLAN                            : 20
Pre Authentication              : Disabled
Session Time out                : 1800
Violation Mode                  : REPLACE
Host Mode                       : SINGLE_HOST_MODE
Host mode VLANs
  Voice Vlan Id                 : Not Configured
  Data Vlan Id                  : Not Configured
Exclusionlist Params
  Exclusionlist                 : Enabled
  Exclusion Timeout             : 60
Flow Monitor IPv4
  Flow Monitor Ingress Name     : Not Configured
  Flow Monitor Egress Name      : Not Configured
  Flow Moniter Ingress status   : Disabled
  Flow Moniter egress status    : Disabled
Flow Monitor IPv6
  Flow Monitor Ingress Name     : Not Configured
  Flow Monitor Egress Name      : Not Configured
  Flow Moniter Ingress status   : Disabled
  Flow Moniter egress status    : Disabled
Split Tunnel Parameters
  Status                        : Disabled
  ACL name                      : Not Configured
  Override Status               : Disabled
  Gateway Address               : Not Configured
  Netmask Address               : Not Configured
DHCP
```

```
  DHCP Required                : Disabled
  DHCP Server                  : Not Configured
Accounting List                : Not Configured
```

show remote-lan policy summary

To view the summary of policy profile for all RLANs, use the **show remote-lan policy summary** command.

show remote-lan policy summary

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of policy profile for all RLANs:

```
Device# show remote-lan policy summary
Number of Policy Profiles: 1

Profile Name                    Description                          Status

-------------------------------------------------------------------------------------------
rlan_named_pp1                Testing RLAN policy profile              Enabled
```

show remote-lan summary

To view the summary of all RLANs, use the **show remote-lan summary** command.

show remote-lan summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of all RLANs:

```
Device# show remote-lan summary
Number of RLANs: 1

RLAN   Profile Name                     Status
------------------------------------------------------------------
1      rlan_test_1                      Enabled
```

show rrm receive configuration

To verify the available channel list in AP console, use the **show rrm receive configuration** command.

show rrm receive configuration

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Usage Guidelines

This command needs to be run on the AP console.

Examples

The following command displays the available channel list in AP console.

```
cisco-ap# show rrm receive configuration
RRM configuration slot 1
=================================
Group Id
Switch Id            :0904640500ff
Group Cnt            :57454
IP address           :9.4.100.5
Encrypted            :0
Version              :1
Key                  :ff3fff55ffffff42ffff2cff6d0affff
Domain               :default
Key Name             :
Channel Count        :19
TX Chans             :36 40 44 48 52 56 60 64 100 104 108 112 116 120 124 128 13
2 136 140
```

show sdavc ap download status

To view the per access point (per-AP) download status for Software-Defined Application Visibility and Control (SD-AVC), use the **show sdavc ap download status** command.

show sdavc ap download status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the per-AP download status for SD-AVC:

```
Device# show sdavc ap download status

AP  MAC         Latest filename    Status
-------------------------------------------------------------
00d7.8f58.2f80      xyz            SUCCESS
00d7.8f58.2d82      abc            FAILED
```

show sdavc status ap

To view the Software-Defined Application Visibility and Control (SD-AVC) status for an access point (AP), use the **show sdavc status ap** command.

show sdavc status ap *ap-name*

Syntax Description

ap-name	AP name or MAC address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the SD-AVC status for an AP:

```
Device# show sdavc status ap 00d7.8f58.2f80

AP MAC                Status
-------------------------------------
00d7.8f58.2f80        ENABLED
```

show ssh

To see the SSH connection status, use the **show ssh** command.

show ssh {*connection-number* | {**vty** *connection-number* }}

Syntax Description

connection-number	SSH connection number. Valid range is 0 to 530.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the SSH connection status:

```
Device# show ssh connection-number
```

show split-tunnel client access-list

To verify split tunneling Domain Name System (DNS) Access Control Lists (ACLs) per wireless client, use the **show split-tunnel client access-list** command.

show split-tunnel client *mac-address* **access-list**

Syntax Description

mac-address	Wireless client MAC address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.1.1	This command was introduced.

Examples

The following example shows how to verify the split tunneling DNS ACLs for a wireless client:

```
Device# show split-tunnel client 00:11:22:33:44:55 access-list

Split tunnel ACLs for Client: 00:11:22:33:44:55

IP ACL: SplitTunnelACL

Tunnel packets Tunnel bytes NAT packets NAT bytes
             1          242           3       768

URL ACL: SplitTunnelACL

Tunnel packets Tunnel bytes NAT packets NAT bytes
             3          778           0         0

Resolved IPs for Client: 00:11:22:33:44:55 for Split tunnel

HIT-COUNT       URL             ACTION  IP-LIST

1               base1.com       deny.   209.165.200.224
                                        209.165.200.225

2               base2.com       deny.   209.165.200.226

3               base3.com       deny.   209.165.200.227
```

show tech-support diagnostic

To view the diagnostic information for technical support, use the **show tech-support diagnostic** command.

show tech-support diagnostic

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE 17.14.1	The output of the command is modified.

Usage Guidelines

From Cisco IOS-XE 17.14.1 release onwards, the following commands are supported. The output of this command is very long. To better manage this output, you can redirect the output to a file (for example, **show tech-support diagnostic** | **redirect flash:** filename) in the local writable storage file system or remote file system.

Table 21: Supported Commands

Commands	Cisco Catalyst 9800-CL Controller	Cisco Catalyst 9800-L Wireless Controller	Cisco Catalyst 9800-40 Wireless Controller	Cisco Catalyst 9800-80 Wireless Controller
show platform	✓	✓	✓	✓
show platform diag	✓	✓	✓	✓
show interfaces status	✓	✓	✓	✓
show facility-alarm status	✓	✓	✓	✓
show chassis	✓	✓	✓	✓
show ip interface brief	✓	✓	✓	✓
show interfaces	✓	✓	✓	✓
show diag all eeprom detail	✓	✓	✓	✓
show inventory raw	✓	✓	✓	✓

Commands	Cisco Catalyst 9800-CL Controller	Cisco Catalyst 9800-L Wireless Controller	Cisco Catalyst 9800-40 Wireless Controller	Cisco Catalyst 9800-80 Wireless Controller
show platform resources	✓	✓	✓	✓
show reload history	✓	✓	✓	✓
show history all	✓	✓	✓	✓
show environment all	x	✓	✓	✓
show platform integrity	x	✓	✓	✓
show platform hardware slot R0 led status	x	✓	✓	✓
show rom-monitor chassis active/standby R0	x	✓	✓	✓
show interfaces <interface> <> transceiver	x	✓	✓	✓
show interfaces <interface> <> transceiver detail	x	✓	✓	✓
show platform hardware slot R0 ha_port interface stats	x	x	✓	✓
show platform hardware port <> ezman info	x	x	✓	✓
show platform hardware port <> ezman autotune status	x	x	✓	✓
show platform hardware port <> ezman statistics	x	x	✓	✓
show hw-module subslot <> transceiver <> status	x	x	✓	✓

Commands	Cisco Catalyst 9800-CL Controller	Cisco Catalyst 9800-L Wireless Controller	Cisco Catalyst 9800-40 Wireless Controller	Cisco Catalyst 9800-80 Wireless Controller
show hw-module subslot <> transceiver <> idprom detail	x	x	✓	✓
show platform software system all	✓	x	x	x

Examples

The following example shows how to view the diagnostic information for technical support:

```
Device# show tech-support diagnostic
--- show clock ---

--- show switch ---

--- show module ---

--- show version ---
Cisco IOS XE Software, Version 17.03.05b
Cisco IOS Software [Amsterdam], C9800 Software (C9800_IOSXE-K9), Version 17.3.5b, RELEASE
SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2022 by Cisco Systems, Inc.
Compiled Fri 15-Jul-22 06:36 by mcpre

---- show running-config ----
Current configuration : 9880 bytes
!
! Last configuration change at 08:22:39 UTC Thu Nov 16 2023
!
version 17.14
service timestamps debug datetime msec
service timestamps log datetime msec

--- show inventory ---
NAME: "Chassis 1", DESCR: "Cisco C9800-L-C-K9 Chassis"
PID: C9800-L-C-K9      , VID: P2   , SN: FCW2309M034

--- show diagnostic bootup level ---
<BU> - Bootup Diagnostics, <HM> - Health Monitoring Diagnostics,
<OD> - OnDemand Diagnostics, <SCH> - Scheduled Diagnostics

====== ================================ ================================ ======
Card   Description                      Current Running Test             Run by
------ -------------------------------- -------------------------------- ------
R0                                      N/A                              N/A

F0                                      N/A                              N/A

0      C9800-L-C-K9                     N/A                              N/A

====== ================================ ================================ ======

------------------ show diagnostic status ------------------
<BU> - Bootup Diagnostics, <HM> - Health Monitoring Diagnostics,
<OD> - OnDemand Diagnostics, <SCH> - Scheduled Diagnostics
```

```
====== ================================= ================================ ======
Card   Description                       Current Running Test             Run by
------ --------------------------------- -------------------------------- ------
R0                                       N/A                              N/A

F0                                       N/A                              N/A

0      C9800-L-C-K9                      N/A                              N/A

====== ================================= ================================ ======

--- show platform ---
Chassis type: C9800-L-C-K9

Slot      Type                State                 Insert time (ago)
--------- ------------------- --------------------- -----------------
0         C9800-L-C-K9        ok                    00:04:00
 0/0      BUILT-IN-4x2_5GE    ok                    00:02:54
 0/1      BUILT-IN-2x10GE-C   ok                    00:02:54
R0        C9800-L-C-K9        ok, active            00:04:00
F0        C9800-L-C-K9        ok, active            00:04:00
P0        PWR-12V             ok                    00:03:40
P1        C9800-L-C-K9-FAN    ok                    00:03:40

Slot      CPLD Version        Firmware Version
--------- ------------------- ----------------------------------------
0         19050618            17.12(3r)
R0        19050618            17.12(3r)
F0        19050618            17.12(3r)

--- show platform diag ---
Chassis type: C9800-L-C-K9
Slot: 0, C9800-L-C-K9
  Running state               : ok
  Internal state              : online
  Internal operational state  : ok

--- show interfaces status ---
Port         Name         Status     Vlan       Duplex       Speed Type
Tw0/0/0     notconnect    1          full      2500        1000/2.5GBaseTX
Tw0/0/1     notconnect    1          full      2500        1000/2.5GBaseTX
Tw0/0/2     notconnect    1          full      2500        1000/2.5GBaseTX
Tw0/0/3     notconnect    1          full      2500        1000/2.5GBaseTX
Te0/1/0     notconnect    1          full      10G         1000/2.5G/5G/10GBaseTX
Te0/1/1     notconnect    1          full      10G         1000/2.5G/5G/10GBaseTX

-- show facility-alarm status ---
System Totals  Critical: 6  Major: 0  Minor: 1

Source                    Time                   Severity      Description [Index]
------                    ------                 --------      -------------------

TwoGigabitEthernet0/0/0   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]

TwoGigabitEthernet0/0/1   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]

TwoGigabitEthernet0/0/2   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]

TwoGigabitEthernet0/0/3   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]

TenGigabitEthernet0/1/0   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]

TenGigabitEthernet0/1/1   Nov 16 2023 08:22:43   CRITICAL      Physical Port Link Down [1]
```

```
Temp: TEMP-1   R0/0        Nov 16 2023 08:23:27   MINOR         Temp Above Normal [4]

---- show chassis ----
Chassis/Stack Mac Address : 7018.a7c8.8070 - Local Mac Address
Mac persistency wait time: Indefinite
Redundancy Port Type: None
                                          H/W   Current
Chassis#   Role    Mac Address     Priority Version  State                 IP
--------------------------------------------------------------------------------
*1       Active   7018.a7c8.8070     1      V02     Ready                0.0.0.0

---- show ip interface brief ---
Interface              IP-Address      OK? Method Status                Protocol
Tw0/0/0                unassigned      YES unset  down                  down
Tw0/0/1                unassigned      YES unset  down                  down
Tw0/0/2                unassigned      YES unset  down                  down
Tw0/0/3                unassigned      YES unset  down                  down
Te0/1/0                unassigned      YES unset  down                  down
Te0/1/1                unassigned      YES unset  down                  down
GigabitEthernet0       10.65.124.160   YES NVRAM  up                    up
Vlan1                  unassigned      YES NVRAM  administratively down down

--- show interfaces ---
TwoGigabitEthernet0/0/0 is down, line protocol is down
Hardware is BUILT-IN-4x2_5GE, address is 7018.a7c8.807c (bia 7018.a7c8.807c)
MTU 1500 bytes, BW 2500000 Kbit/sec, DLY 10 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ARPA, loopback not set
Keepalive not supported

--- show diag all eeprom detail ---
MIDPLANE EEPROM data:

EEPROM version           : 4
Compatible Type          : 0xFF
Controller Type          : 4276
Hardware Revision        : 0.1

---- show inventory raw ----
NAME: "Multi Chassis System", DESCR: "Cisco C9800 Dual Chassis"
PID:                   , VID:      , SN:
NAME: "Chassis 1", DESCR: "Cisco C9800-L-C-K9 Chassis"
PID: C9800-L-C-K9      , VID: P2   , SN: FCW2309M034

--- show platform resources ----
**State Acronym: H - Healthy, W - Warning, C - Critical

Resource                 Usage                Max             Warning         Critical
     State
------------------------------------------------------------------------------------------------------
RP0 (ok, active)
     H
 Control Processor       5.52%                100%            80%             90%
     H
  DRAM                   5948MB(38%)          15489MB         88%             93%
     H

--- show reload history ---
Reload History:
Unit ID: rp0
Reload Index: 1
Reload Code: Reload
Reload Severity: Normal Reboot
Reload Description: Reload Command
```

```
Crash Data: -NA-
HA Status: Active
Software Version: 17.14.20231115:112747101
Reload Time: 08:22:25 UTC Thu Nov 16 2023

--- show history all ---
ov 16 2023
speed auto
% Invalid input detected at '^' marker.
CMD: ' no negotiation auto' 08:22:32 UTC Thu Nov 16 2023
CMD: ' mop enabled' 08:22:32 UTC Thu Nov 16 2023

--- show platform integrity ---
Platform: C9800-L-C-K9
Boot 0 Version: MA1011R06.1503172017
Boot 0 Hash: 86461DE5728618657DDF80FBFE1694B065EA3CA4627C0F020DC77E074CFFDB5D
Boot Loader Version: 17.12(3r)
Boot Loader Hash: 893A00C46AD6D711CED5127D42AC37653BE307B922D626B07BE040027E5421D1
OS Version: 2023-11-14_20.45_srimoort

--- show platform hardware slot R0 led status ---
Current LED States
LED               State
---------------------------
System            Green
Alarm             Red
HA                Green

--- show rom-monitor chassis active R0 ---
System Bootstrap, Version 17.12(3r), RELEASE SOFTWARE
Copyright (c) 1994-2023 by cisco Systems, Inc.

---- show interfaces TwoGigabitEthernet 0/0/0 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/0 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/1 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/1 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/2 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/2 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/3 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TwoGigabitEthernet 0/0/3 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.
```

```
--- show interfaces TenGigabitEthernet 0/1/0 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

---show interfaces TenGigabitEthernet 0/1/0 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

--- show interfaces TenGigabitEthernet 0/1/1 transceiver ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.

---- show interfaces TenGigabitEthernet 0/1/1 transceiver detail ---
Tranceiver is not present
Diagnostic Monitoring is not implemented.
```

show tech-support wireless

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless** command in privileged EXEC mode.

show tech-support wireless

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show tech-support wireless** command:

```
Device# show tech-support wireless
 *** show ap capwap timers ***

Cisco AP CAPWAP timers

AP Discovery timer       : 10
AP Heart Beat timeout    : 30
Primary Discovery timer  : 120
Primed Join timeout      : 0
Fast Heartbeat           : Disabled
Fast Heartbeat timeout   : 1
*** show ap capwap retransmit ***
Global control packet retransmit interval : 3
Global control packet retransmit count : 5

AP Name                          Retransmit Interval             Retransmit Count
-----------------------------------------------------------------------------------------
TSIM_AP-2                        3                               5
TSIM_AP-3                        3                               5
*** show ap dot11 24ghz cleanair air-quality summary ***

AQ = Air Quality
DFS = Dynamic Frequency Selection

*** show ap dot11 24ghz cleanair air-quality worst ***

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name             Channel   Avg AQ  Min AQ  Interferers  DFS
-----------------------------------------------------------------
                    0         0       0       0            No
*** show ap dot11 24ghz cleanair config ***

Clean Air Solution................................ : Disabled
Air Quality Settings:
    Air Quality Reporting......................... : Disabled
    Air Quality Reporting Period (min)............ : 15
```

```
    Air Quality Alarms..................... : Enabled
    Air Quality Alarm Threshold............ : 10
Interference Device Settings:
    Interference Device Reporting.......... : Enabled
        Bluetooth Link..................... : Enabled
        Microwave Oven..................... : Enabled
        802.11 FH.......................... : Enabled
        Bluetooth Discovery................ : Enabled
        TDD Transmitter.................... : Enabled
        Jammer............................. : Enabled
        Continuous Transmitter............. : Enabled
        DECT-like Phone.................... : Enabled
        Video Camera....................... : Enabled
        802.15.4........................... : Enabled
        WiFi Inverted...................... : Enabled
        WiFi Invalid Channel............... : Enabled
        SuperAG............................ : Enabled
        Canopy............................. : Enabled
        Microsoft Device................... : Enabled
        WiMax Mobile....................... : Enabled
        WiMax Fixed........................ : Enabled
    Interference Device Types Triggering Alarms:
        Bluetooth Link..................... : Disabled
        Microwave Oven..................... : Disabled
        802.11 FH.......................... : Disabled
        Bluetooth Discovery................ : Disabled
        TDD Transmitter.................... : Disabled
        Jammer............................. : Disabled
        Continuous Transmitter............. : Disabled
        DECT-like Phone.................... : Disabled
        Video Camera....................... : Disabled
  802.15.4............................... : Disabled
        WiFi Inverted...................... : Enabled
        WiFi Invalid Channel............... : Enabled
        SuperAG............................ : Disabled
        Canopy............................. : Disabled
        Microsoft Device................... : Disabled
        WiMax Mobile....................... : Disabled
        WiMax Fixed........................ : Disabled
    Interference Device Alarms............. : Enabled
Additional Clean Air Settings:
    CleanAir Event-driven RRM State........ : Disabled
    CleanAir Driven RRM Sensitivity........ : LOW
    CleanAir Persistent Devices state...... : Disabled
```

show tech-support wireless ap

To display specific information about the Cisco APs variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless ap** command in privileged EXEC mode.

show tech-support wireless ap

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless ap**command:

- show ap session termination statistics
- show ap status
- show ap tag summary
- show platform software bssid chassis active F0 statistics
- show platform software bssid chassis active R0 statistics
- show platform software capwap chassis active F0 statistics
- show platform software capwap chassis active R0 statistics
- show platform software dtls chassis active F0 statistics
- show platform software dtls chassis active R0 statistics
- show platform software radio chassis active F0 statistics
- show platform software radio chassis active R0 statistics

Example

The following is sample output from the **show tech-support wireless ap** command

```
Device# show tech-support wireless ap

------------------ show platform software dtls chassis active R0 statistics ------------------


DTLS Counters     (Success/Failure)
-----------------------------------
Create                  0/0
```

```
Delete                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
Ack Nack Notify         0/0


------------------ show platform software radio chassis active R0 statistics
------------------



Switch 1:
NACK Notify             0/0
  Create Failure        0
  Delete Failure        0


------------------ show platform software bssid chassis active R0 statistics
------------------



Switch 1:
NACK Notify             0/0
  Create Failure        0
  Delete Failure        0


------------------ show platform software capwap chassis active R0 statistics
------------------


Capwap Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
Modify                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
ACK-NACK Notify         0/0
  Tunnel State          0/0
  Tunnel Create         0/0
  Tunnel Modify         0/0
  Tunnel Delete         0/0


------------------ show platform software dtls chassis active F0 statistics ------------------


DTLS Counters     (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Ack Ack Notify          0/0
```

```
Ack Nack Notify         0/0
Nack Notify             0/0
HA Seq GET              665/0
HA Seq SET              0/0
HA Seq Crypto GET       0/0
HA Seq Crypto SET       0/0
HA Seq Crypto Callback  0/0

HA Seq last Responsed   0
HA Seq Pending          0
HA Seq Outstanding cb   0


------------------ show platform software radio chassis active F0 statistics
------------------


Radio Counters    (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Nack Notify             0/0


------------------ show platform software bssid chassis active F0 statistics
------------------


Bssid Counters    (Success/Failure)
-----------------------------------
Create                 0/0
Delete                 0/0
HW Create              0/0
HW Modify              0/0
HW Delete              0/0
Create Ack             0/0
Modify Ack             0/0
Delete Ack             0/0
Nack Notify            0/0


------------------ show platform software capwap chassis active F0 statistics
------------------


Capwap Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Ack Ack Notify          0/0
Ack Nack Notify         0/0
Nack Notify             0/0
```

```
------------------ show ap auto-rf dot11 24ghz ------------------


------------------ show ap auto-rf dot11 5ghz ------------------


------------------ show ap capwap retransmit ------------------


------------------ show ap config dot11 dual-band summary ------------------


------------------ show ap config general ------------------



------------------ show ap dot11 24ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 25 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 10 dB
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown


------------------ show ap dot11 24ghz group ------------------


Radio RF Grouping

  802.11b Group Mode               : AUTO
  802.11b Group Update Interval    : 600 seconds
  802.11b Group Leader             : ewlc-doc (9.12.32.10)
  802.11b Last Run                 : 26 seconds ago


RF Group Members

Controller name                  Controller IP
```

```
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 24ghz load-info ------------------


------------------ show ap dot11 24ghz monitor ------------------


Default 802.11b AP monitoring
  802.11b Monitor Mode                 : Enabled
  802.11b Monitor Channels             : Country channels
  802.11b RRM Neighbor Discover Type   : Transparent
  802.11b AP Coverage Interval         : 180 seconds
  802.11b AP Load Interval             : 60 seconds
  802.11b AP Noise Interval            : 180 seconds
  802.11b AP Signal Strength Interval  : 60 seconds
  802.11b NDP RSSI Normalization       : Enabled


------------------ show ap dot11 24ghz network ------------------


802.11b Network                          : Enabled
11gSupport                               : Enabled
11nSupport                               : Enabled
802.11b/g Operational Rates
  802.11b 1M                             : Mandatory
  802.11b 2M                             : Mandatory
  802.11b 5.5M                           : Mandatory
  802.11b 11M                            : Mandatory
  802.11g 6M                             : Supported
  802.11g 9M                             : Supported
  802.11g 12M                            : Supported
  802.11g 18M                            : Supported
  802.11g 24M                            : Supported
  802.11g 36M                            : Supported
  802.11g 48M                            : Supported
  802.11g 54M                            : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported


------------------ show ap dot11 24ghz profile ------------------


Default 802.11b AP performance profiles
  802.11b Global Interference threshold    : 10 %
  802.11b Global noise threshold           : -70 dBm
  802.11b Global RF utilization threshold  : 80 %
  802.11b Global throughput threshold      : 1000000 bps
  802.11b Global clients threshold         : 12 clients


------------------ show ap dot11 24ghz summary ------------------
```

```
------------------ show ap dot11 24ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 27 seconds ago


------------------ show ap dot11 5ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 27 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 15 dB
  DCA 802.11n/ac Channel Width              : 20 MHz
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown


------------------ show ap dot11 5ghz group ------------------


Radio RF Grouping

  802.11a Group Mode               : AUTO
  802.11a Group Update Interval    : 600 seconds
  802.11a Group Leader             : ewlc-doc (9.12.32.10)
  802.11a Last Run                 : 28 seconds ago


RF Group Members

Controller name                  Controller IP
```

```
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 5ghz load-info ------------------


------------------ show ap dot11 5ghz monitor ------------------


Default 802.11a AP monitoring
  802.11a Monitor Mode                 : Enabled
  802.11a Monitor Channels             : Country channels
  802.11a RRM Neighbor Discover Type   : Transparent
  802.11a AP Coverage Interval         : 180 seconds
  802.11a AP Load Interval             : 60 seconds
  802.11a AP Noise Interval            : 180 seconds
  802.11a AP Signal Strength Interval  : 60 seconds
  802.11a NDP RSSI Normalization       : Enabled


------------------ show ap dot11 5ghz network ------------------


802.11a Network                            : Enabled
11nSupport                                 : Enabled
  802.11a Low Band                         : Enabled
  802.11a Mid Band                         : Enabled
  802.11a High Band                        : Enabled
802.11a Operational Rates
  802.11a 6M                               : Mandatory
  802.11a 9M                               : Supported
  802.11a 12M                              : Mandatory
  802.11a 18M                              : Supported
  802.11a 24M                              : Mandatory
  802.11a 36M                              : Supported
  802.11a 48M                              : Supported
  802.11a 54M                              : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported


------------------ show ap dot11 5ghz profile ------------------


Default 802.11a AP performance profiles

  802.11a Global Interference threshold          : 10 %
  802.11a Global noise threshold                 : -70 dBm
  802.11a Global RF utilization threshold        : 80 %
  802.11a Global throughput threshold            : 1000000 bps
  802.11a Global clients threshold               : 12 clients


------------------ show ap dot11 5ghz summary ------------------
```

```
------------------ show ap dot11 5ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 28 seconds ago


------------------ show ap image ------------------



------------------ show wireless stats ap join summary ------------------

Number of APs: 0

Base MAC        Ethernet MAC    AP Name                             IP Address       Status
     Last Failure Type     Last Disconnect Reason
-----------------------------------------------------------------------------------------------


------------------ show ap rf-profile summary ------------------


Number of RF-profiles: 6

RF Profile Name                  Band     Description                          State
------------------------------------------------------------------------------------
Low_Client_Density_rf_5gh        5 GHz    pre configured Low Client Density rf Up
High_Client_Density_rf_5gh       5 GHz    pre configured High Client Density r Up
Low_Client_Density_rf_24gh       2.4 GHz  pre configured Low Client Density rf Up
High_Client_Density_rf_24gh      2.4 GHz  pre configured High Client Density r Up
Typical_Client_Density_rf_5gh    5 GHz    pre configured Typical Density rfpro Up
Typical_Client_Density_rf_24gh   2.4 GHz  pre configured Typical Client Densit Up


------------------ show ap slots ------------------


------------------ show ap summary ------------------


Number of APs: 0
```

```
------------------ show ap uptime ------------------

Number of APs: 0


------------------ show ap tag summary ------------------

Number of APs: 0


------------------ show ap status ------------------


------------------ show ap cdp neighbors ------------------

Number of neighbors: 0


------------------ show ap ap-join-profile summary ------------------


Number of AP Profiles: 1
AP Profile Name                  Description
------------------------------------------------------------------------
default-ap-profile               default ap profile

------------------ show ap link-encryption ------------------


------------------ show wireless stats ap session termination ------------------


------------------ show wireless loadbalance ap affinity wncd 0 ------------------


------------------ show wireless loadbalance ap affinity wncd 1 ------------------


------------------ show wireless loadbalance ap affinity wncd 2 ------------------


------------------ show wireless loadbalance ap affinity wncd 3 ------------------


------------------ show wireless loadbalance ap affinity wncd 4 ------------------


------------------ show wireless loadbalance ap affinity wncd 5 ------------------
```

```
------------------ show wireless loadbalance ap affinity wncd 6 ------------------

------------------ show wireless loadbalance ap affinity wncd 7 ------------------
```

show tech-support wireless client

To print the data related to all clients or a particular client, use the **show tech-support wireless client** command in privileged EXEC mode.

show tech-support wireless client

Syntax Description

mac-address	Client MAC address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless client** command:

- show platform software wireless-client chassis active F0 statistics
- show platform software wireless-client chassis active R0 statistics
- show wireless client calls active
- show wireless client calls rejected
- show wireless client client-statistics summary
- show wireless client device summary
- show wireless client mac <mac-addr> details
- show wireless client probing
- show wireless client sleeping-client
- show wireless client statistic
- show wireless client steering
- show wireless client summary
- show wireless exclusionlist
- show wireless pmk-cache

Note The **show tech-support wireless client** command does not display the output of **show wireless client summary detail** command.

Example

The following is sample output from the **show tech-support wireless client** command

```
Device# show tech-support wireless client

------------------ show wireless stats client summary ------------------

Number of Local Clients : 0


MAC Address    AP Name                          WLAN UpTime(secs) Rx Pkts Tx Pkts RSSI SNR
  Data Retries
-----------------------------------------------------------------------------------------





------------------ show wireless client summary ------------------

Number of Local Clients: 0


Number of Excluded Clients: 0



------------------ show wireless client device summary ------------------



------------------ show wireless client steering ------------------


Client Steering Configuration Information
  Macro to micro transition threshold                   : -55 dBm
  Micro to Macro transition threshold                   : -65 dBm
  Micro-Macro transition minimum client count           : 3
  Micro-Macro transition client balancing window        : 3
  Probe suppression mode                                : Disabled
  Probe suppression validity window                     : 100 s
  Probe suppression aggregate window                    : 200 ms
  Probe suppression transition aggressiveness           : 3
  Probe suppression hysteresis                          : -6 dBm

WLAN Configuration Information



------------------ show wireless client calls active ------------------



------------------ show wireless client calls rejected ------------------



------------------ show wireless client sleeping-client ------------------

Total number of sleeping-client entries: 0
```

```
------------------ show wireless client probing ------------------


------------------ show wireless client ap dot11 24ghz ------------------




------------------ show wireless client ap dot11 5ghz ------------------




------------------ show wireless pmk-cache ------------------

Number of PMK caches in total : 0

Type      Station             Entry Lifetime  VLAN Override         IP Override
Audit-Session-Id
-----------------------------------------------------------------------------------------------------


------------------ show wireless exclusionlist ------------------


------------------ show wireless country  configured ------------------


Configured Country.........................   US - United States
Configured Country Codes
        US  - United States                 802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor


------------------ show wireless tag rf summary ------------------


Number of RF Tags: 1

RF tag name                     Description
------------------------------------------------------------------------
default-rf-tag                  default RF tag


------------------ show platform software wireless-client chassis active R0 statistics
------------------


Client Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
Modify                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
```

```
NACK Notify             0/0
  Create Failure        0
  Modify Failure        0
  Delete Failure        0


------------------ show platform software wireless-client chassis active F0 statistics
------------------


Client Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
NACK Notify             0/0


------------------ show platform hardware chassis active qfp feature wireless wlclient
cpp-client summary ------------------


------------------ show platform hardware chassis active qfp feature wireless wlclient
datapath summary ------------------

Vlan   pal_if_hdl   mac            Input Uidb Output Uidb
------ ------------ -------------- ---------- -----------
```

show tech-support wireless datapath

To print the data related to CPP datapath, use the **show tech-support wireless datapath** command in privileged EXEC mode.

show tech-support wireless datapath

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

This command is available only on the platforms that have CPP datapath architecture, such as Cisco vEWLC, Cisco 9540 WLC, and Cisco 9880 WLC.

The output of the following commands are displayed as part of **show tech-support wireless datapath** command:

- show platform hardware chassis active qfp feature wireless bssid summary
- show platform hardware chassis active qfp feature wireless capwap cpp-client statistics
- show platform hardware chassis active qfp feature wireless capwap cpp-client summary
- show platform hardware chassis active qfp feature wireless capwap datapath statistics drop
- show platform hardware chassis active qfp feature wireless capwap datapath statistics fragmentation
- show platform hardware chassis active qfp feature wireless capwap datapath statistics reassembly
- show platform hardware chassis active qfp feature wireless capwap datapath summary
- show platform hardware chassis active qfp feature wireless dtls cpp-client statistics
- show platform hardware chassis active qfp feature wireless dtls cpp-client summary
- show platform hardware chassis active qfp feature wireless dtls datapath statistics
- show platform hardware chassis active qfp feature wireless dtls datapath summary
- show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree
- show platform hardware chassis active qfp feature wireless et-analytics statistics
- show platform hardware chassis active qfp feature wireless fqdn-filter summary
- show platform hardware chassis active qfp feature wireless halo statistics
- show platform hardware chassis active qfp feature wireless ipsg cpp-client statistics

- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv4 all
- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv6 all
- show platform hardware chassis active qfp feature wireless ipsg datapath statistics global
- show platform hardware chassis active qfp feature wireless ipsg datapath table ipv4 all
- show platform hardware chassis active qfp feature wireless ipsg datapath table ipv6 all
- show platform hardware chassis active qfp feature wireless mgmt-intf cpp-client summary
- show platform hardware chassis active qfp feature wireless mgmt-intf datapath summary
- show platform hardware chassis active qfp feature wireless punt statistics
- show platform hardware chassis active qfp feature wireless wlan summary
- show platform hardware chassis active qfp feature wireless wlclient cpp-client statistics
- show platform hardware chassis active qfp feature wireless wlclient cpp-client summary
- show platform hardware chassis active qfp feature wireless wlclient datapath statistic drop
- show platform hardware chassis active qfp feature wireless wlclient datapath summary
- show platform hardware chassis active qfp feature wireless wlclient datapath table dataglean all
- show platform hardware chassis active qfp infrastructure punt statistics type per-cause
- show platform hardware chassis active qfp statistics drop
- show platform software bssid chassis active F0
- show platform software bssid chassis active F0 statistics
- show platform software capwap chassis active F0
- show platform software capwap chassis active F0 statistics
- show platform software dtls chassis active F0
- show platform software dtls chassis active F0 statistics
- show platform software wireless-client chassis active F0
- show platform software wireless-client chassis active F0 statistics
- show platform software wlan chassis active F0

In the presence of standby node, the following datapath commands are also displayed:

- show platform hardware chassis standby qfp feature wireless bssid summary
- show platform hardware chassis standby qfp feature wireless capwap cpp-client statistics
- show platform hardware chassis standby qfp feature wireless capwap cpp-client summary
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics drop
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics fragmentation
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics reassembly

- show platform hardware chassis standby qfp feature wireless capwap datapath summary
- show platform hardware chassis standby qfp feature wireless dtls cpp-client statistics
- show platform hardware chassis standby qfp feature wireless dtls cpp-client summary
- show platform hardware chassis standby qfp feature wireless dtls datapath statistics
- show platform hardware chassis standby qfp feature wireless dtls datapath summary
- show platform hardware chassis standby qfp feature wireless halo statistics
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client statistics
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client table ipv4 all
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client table ipv6 all
- show platform hardware chassis standby qfp feature wireless ipsg datapath statistics global
- show platform hardware chassis standby qfp feature wireless ipsg datapath table ipv4 all
- show platform hardware chassis standby qfp feature wireless ipsg datapath table ipv6 all
- show platform hardware chassis standby qfp feature wireless mgmt-intf cpp-client summary
- show platform hardware chassis standby qfp feature wireless mgmt-intf datapath summary
- show platform hardware chassis standby qfp feature wireless punt statistics
- show platform hardware chassis standby qfp feature wireless wlan summary
- show platform hardware chassis standby qfp feature wireless wlclient cpp-client statistics
- show platform hardware chassis standby qfp feature wireless wlclient cpp-client summary
- show platform hardware chassis standby qfp feature wireless wlclient datapath statistic drop
- show platform hardware chassis standby qfp feature wireless wlclient datapath summary
- show platform hardware chassis standby qfp feature wireless wlclient datapath table dataglean all
- show platform hardware chassis standby qfp statistics drop
- show platform software bssid chassis standby F0
- show platform software bssid chassis standby F0 statistics
- show platform software capwap chassis standby F0
- show platform software capwap chassis standby F0 statistics
- show platform software dtls chassis standby F0
- show platform software dtls chassis standby F0 statistics
- show platform software wireless-client chassis standby F0
- show platform software wireless-client chassis standby F0 statistics
- show platform software wlan chassis standby F0

Example

The following is sample output from the **show tech-support wireless datapath** command

```
Device# show tech-support wireless datapath


------------------ show platform hardware chassis active qfp statistics drop
------------------

-------------------------------------------------------------------------
Global Drop Stats                          Packets                 Octets
-------------------------------------------------------------------------
Disabled                                     22230                2045194
InvL2Hdr                                   4765368              744492240
Ipv4NoAdj                                        6                    736
Ipv4NoRoute                                     18                   2358
Ipv6mcNoRoute                                    3                    270
SWPortDrop                                   14432                2886027
SWPortSrcFilter                              53265               53992718
SWPortStpState                               42041                3269790
SWPortVlanNotCfg                           5515542              674079804
SwitchL2m                                        78                  10062
SwitchL2mIGMP                                18866                1283348
SwitchL2mUnconfigWireless                       78                  11622
WlsCapwapNoTunnel                                3                    627


------------------ show platform hardware chassis active qfp feature wireless punt statistics
 ------------------


CPP Wireless Punt stats:

                                App Tag     Packet Count
                                -------     ------------
         CAPWAP_PKT_TYPE_DOT11_PROBE_REQ               0
              CAPWAP_PKT_TYPE_DOT11_MGMT              56
              CAPWAP_PKT_TYPE_DOT11_IAPP           22177
              CAPWAP_PKT_TYPE_DOT11_RFID               0
               CAPWAP_PKT_TYPE_DOT11_RRM               0
             CAPWAP_PKT_TYPE_DOT11_DOT1X               0
       CAPWAP_PKT_TYPE_CAPWAP_KEEPALIVE               0
     CAPWAP_PKT_TYPE_MOBILITY_KEEPALIVE               0
           CAPWAP_PKT_TYPE_CAPWAP_CNTRL          303661
            CAPWAP_PKT_TYPE_CAPWAP_DATA               0
        CAPWAP_PKT_TYPE_MOBILITY_CNTRL               0
                      WLS_SMD_WEBAUTH               0
                    SISF_PKT_TYPE_ARP             303
                   SISF_PKT_TYPE_DHCP             282
                  SISF_PKT_TYPE_DHCP6               0
                SISF_PKT_TYPE_IPV6_ND               0
              SISF_PKT_TYPE_DATA_GLEAN               0
           SISF_PKT_TYPE_DATA_GLEAN_V6               0
              SISF_PKT_TYPE_DHCP_RELAY               0
         CAPWAP_PKT_TYPE_CAPWAP_RESERVED               0


------------------ show platform hardware chassis active qfp infrastructure punt statistics
 type per-cause ------------------

Global Per Cause Statistics
```

```
Number of punt causes =   136

Per Punt Cause Statistics
                                                                    Packets              Packets
Counter ID  Punt Cause Name                                         Received             Transmitted

-------------------------------------------------------------------------------------------------

000         Reserved                                                0                    0

001         MPLS ICMP Can't Fragment                                0                    0

002         IPv4 Options                                            0                    0

003         Layer2 control and legacy                               0                    0

004         PPP Control                                             0                    0

005         CLNS IS-IS Control                                      0                    0

006         HDLC keepalives                                         0                    0

007         ARP request or response                                 2687                 2687

008         Reverse ARP request or repsonse                         0                    0

009         Frame-relay LMI Control                                 0                    0

010         Incomplete adjacency                                    0                    0

011         For-us data                                             0                    0

012         Mcast Directly Connected Source                         0                    0

013         Mcast IPv4 Options data packet                          0                    0

014         Skip egress processing                                  0                    0

015         MPLS TTL expired                                        0                    0

016         MPLS Reserved label (ie: 0-15)                          0                    0

017         IPv6 Bad hop limit                                      0                    0

018         IPV6 Hop-by-hop Options                                 0                    0

019         Mcast Internal Copy                                     0                    0

020         Generic QFP generated packet                            0                    0

021         RP<->QFP keepalive                                      46691                46691

022         QFP Fwall generated packet                              0                    0

023         Mcast IGMP Unroutable                                   0                    0

024         Glean adjacency                                         2557                 2556

025         Mcast PIM signaling                                     0                    0

026         QFP ICMP generated packet                               0                    0

027         Subscriber session control                              0                    0
```

028	Subscriber data switching back	0	0
029	RP handled ICMP	0	0
030	RP injected For-us data	0	0
031	Punt adjacency	0	0
032	SBC RTP DTMF	0	0
033	Pseudowire VCCV control channel	0	0
034	Generic QFP generated packet (keep GPM)	0	0
035	Ethernet slow protocol (ie: LACP, OAM)	0	0
036	Ethernet OAM Loopback	0	0
037	UNUSED	0	0
038	SPA IPC packet	0	0
039	Punt and replicate	0	0
040	PPPoE control	0	0
041	PPPoE session	0	0
042	L2TP control	0	0
043	IP Subscriber control (ie: FSOL, keepali	0	0
044	L2TP session	0	0
045	BFD control	0	0
046	MVPN non-RPF signaling packet	0	0
047	MVPN PIM signalling packet	0	0
048	Mcast punt to RP	0	0
049	SBC generated packet	0	0
050	IPv6 packet	0	0
051	DMVPN NHRP redirect	0	0
052	PFR monitored prefix logging	0	0
053	PFR top talkers logging	0	0
054	PFR top talkers application logging	0	0
055	For-us control	0	0
056	RP injected for-us control	0	0
057	QFP VTCP generated packet	0	0
058	Layer2 bridge domain data packet	0	0
059	QFP Stile generated packet	0	0

060	IP subnet or broadcast packet	167	167
061	Ethernet CFM packet	0	0
062	Ethernet CFM notify packet	0	0
063	LISP LSB NOTIFICATION	0	0
064	Service Engine packet	0	0
065	L2BD Control packet from FIA	0	0
066	L2BD Control Message from CPP	0	0
067	MFR_LIP_CONTROL	0	0
068	Media Monitoring record punted from CPP	0	0
069	OTV Control packet	0	0
070	OTV ARP packet	0	0
071	REP control	0	0
072	IP MTU EXCEPTION	0	0
073	STP BPDU's	186832	186832
074	ACL log	0	0
075	EPC	0	0
076	Lisp Dynamic eid	0	0
077	L2 Control packet	122389	122389
078	WAAS CPP to CPP punt	0	0
079	dhcp snoop	0	0
080	Metric Mediation Agent record punted fro	0	0
081	IPv6 DMVPN NHRP redirect	0	0
082	Ethernet CFM packet from core	0	0
083	Ethernet CFM punt fwd packet	0	0
084	PTP punt fwd packet	0	0
085	ISDN D-Channel raw packet	0	0
086	Service controller SCG punt pkt	0	0
087	IPv6 FHS SG dropped packet	0	0
088	IPv6 FHS Data glean packet	0	0
089	SBC DSP pkts	0	0
090	Raw Socket Data packet	0	0
091	SSLVPN session control	0	0

092	ICMP unreachables for ACL denied packets	0	0
093	CENT Smart Probe packet	0	0
094	AppNav vPATH pktless API generated pkt	0	0
095	Autonomic Network Channel Discovery pack	0	0
096	Layer2 control protocols	0	0
097	Packets to LFTS	22177	22177
098	VLAN Auto Sense FSOL	0	0
099	ZTP Discovery packet	0	0
100	cable arp filter	0	0
101	Cable L3 mobility	0	0
102	Source Verify inconclusive	0	0
103	cable modem pre reg	0	0
104	mpls receive adj	0	0
105	MKA EAPoL packet	0	0
106	ICMP Unreachable	0	0
107	Cable DHCP	0	0
108	Snooping packet	0	0
109	snoop packets	0	0
110	msg Indicating ppp intf assigned ip addr	0	0
111	msg indicating there is another common h	0	0
112	QoS CAC Flow Report	0	0
113	Active identity	0	0
114	BGP Overlay Tunnel packet	0	0
115	Lisp gsmr enabled	0	0
116	Async TS	0	0
117	Metric Mediation Agent Packet	0	0
118	Cable DHCPV6 Solicit	0	0
119	Cable DHCPV6 Request	0	0
120	SBC RTP FWD DTMF	0	0
121	Path Manager	0	0
122	L2 LISP VXLAN	0	0
123	dialer-list	0	0

```
124         Dialer update time                          0                   0
125         Cable RPHY CTRL                             0                   0
126         OpenFlow SDN                                0                   0
127         Path Manager TTL expired                    0                   0
128         L3 PTP message                              0                   0
129         wls 802.11 Packets to LFTS                  56                  56
130         wls CAPWAP Packets to LFTS                  303661              303661
131         wls MOBILITY Packets to LFTS                0                   0
132         wls SISF Packets to LFTS                    585                 585
133         cable DHCPv6 subscriber-side                0                   0
134         cable DHCPv4 subscriber-side                0                   0
135         cable DHCPv4 sub-side disc/req              0                   0


Number of inject causes = 49

Per Inject Cause Statistics
                                                        Packets             Packets
Counter ID  Inject Cause Name                           Received            Transmitted

-------------------------------------------------------------------------------------------

000         RESERVED                                    0                   0
001         L2 control/legacy                           3115                3115
002         QFP destination lookup                      0                   0
003         QFP IPv4/v6 nexthop lookup                  0                   0
004         QFP generated packet                        0                   0
005         QFP <->RP keepalive                         46691               0
006         QFP Fwall generated packet                  0                   0
007         QFP adjacency-id lookup                     0                   0
008         Mcast specific inject packet                0                   0
009         QFP ICMP generated packet                   0                   0
010         QFP/RP->QFP Subscriber data packet          0                   0
011         SBC DTMF                                    0                   0
012         ARP request or response                     3637                3637
013         Ethernet OAM loopback packet                0                   0
```

014	UNUSED	0	0
015	PPPoE discovery packet	0	0
016	PPPoE session packet	0	0
017	QFP inject for pp_index lookup	0	0
018	QFP inject replicate	0	0
019	QFP inject PIT lookup	0	0
020	SBC generated packets	0	0
021	QFP VTCP generated packet	0	0
022	QFP Stile generated packet	0	0
023	Service Engine generated packet	0	0
024	Layer2 frame to EFP	0	0
025	Layer2 frame to BD	0	0
026	QfP Asym Routing redirected pkt	0	0
027	Compressed packet from WAAS	0	0
028	Media (e.g. voice) associated with a ses	0	0
029	service controller scg packet	0	0
030	Packet for 14 port Serial IM	0	0
031	Subscriber generated TCP reset packet	0	0
032	Layer2 frame to INPUT EFP	0	0
033	SSLVPN inject control	0	0
034	injected packet from UTD SP	0	0
035	injected packet from DPSS SN	0	0
036	injected packet by AppNav vPath	0	0
037	Uncompressed packet from WAAS	0	0
038	Autonomic Network Channel Discovery pack	0	0
039	Cable Bundle Flood Inject	0	0
040	Cable L2 unicast inject	0	0
041	downstream jib packet	0	0
042	switch port layer 2 control packet	6254	6253
043	Applications Injecting Pkts using LFTS	303874	303269
044	Enhanced ping and traceroute	0	0
045	Applications Injecting packets with SGT	0	0

```
  046         CoPP packets from EPC_WS                  0                    0

  047         Async TS                                  0                    0

  048         Layer2 frame to VLAN                      0                    0


------------------ show platform hardware chassis active qfp feature wireless mgmt-intf
cpp-client summary ------------------

Wireless Management Interface Info
 CPP IF_H   VLAN   MAC Address
--------------------------------
   0XF       78   001e.1405.2bff


------------------ show platform hardware chassis active qfp feature wireless mgmt-intf
datapath summary ------------------

Wireless Management Interface Info
IF_H       VLAN   MAC Address
--------------------------------------
0xF        78     001e.1405.2bff


------------------ show platform software wlan chassis active F0 ------------------

WLAN Interface ID  WLAN ID     WLAN Name                                AOM ID  Status

-----------------------------------------------------------------------------------------------

0xf0400001         1           att                                        275  Done

0xf0400002         2           verizon                                    292  Done



------------------ show platform hardware chassis active qfp feature wireless wlan summary
 ------------------

CPP Wlan Database Summary
Total number of wlan interfaces : 2
         if_name             cpp_if_hdl    pal_if_hdl     in_uidb       out_uidb
        ssid
-----------------------------------------------------------------------------------------------

   WLAN-IF-0x00f0400001         0X74       0XF0400001     0X1768E       0X1768C
        att
   WLAN-IF-0x00f0400002         0X78       0XF0400002     0X1768A       0X17688
      verizon


------------------ show platform software bssid chassis active F0 statistics
------------------


Bssid Counters    (Success/Failure)
-----------------------------------
Create                 0/0
Delete                 0/0
HW Create              0/0
```

```
HW Modify              0/0
HW Delete              0/0
Create Ack             0/0
Modify Ack             0/0
Delete Ack             0/0
Nack Notify            0/0


------------------ show platform software bssid chassis active F0 ------------------


------------------ show platform hardware chassis active qfp feature wireless bssid summary
 -------------------


------------------ show platform software capwap chassis active F0 statistics
------------------


Capwap Counters   (Success/Failure)
-----------------------------------
Create                  424/0
Delete                  420/0
HW Create               424/0
HW Modify               0/0
HW Delete               420/0
Create Ack              424/0
Modify Ack              0/0
Delete Ack              420/0
Ack Ack Notify          0/0
Ack Nack Notify         0/0
Nack Notify             0/0


------------------ show platform software capwap chassis active F0 ------------------


 Tunnel ID  AP MAC          Type            IP               Port      AOM ID  Status

-----------------------------------------------------------------------------------------------

0x90000042  00a8.2200.0200  Data            78.1.50.1        52345        3271  Done

0xa0000002  0000.0000.0000  Mobility Data   78.1.1.23        16667        1426  Done

0xa0000003  0000.0000.0000  Mobility Data   78.1.1.24        16667        1427  Done

0xa0000004  0000.0000.0000  Mobility Data   78.1.1.25        16667        1428  Done


------------------ show platform hardware chassis active qfp feature wireless capwap
cpp-client statistics ------------------


CAPWAP cpp-client plumbing statistics
Number Msg in = ack + nak + ack fail + nak fail + errors

Counter                                        Value
-------------------------------------------------------------------
Create from fp                                 424
```

```
Modify from fp                                  0
Delete from fp                                  420
Create ack to fp                                424
Create ack fail to fp                           0
Create nack to fp                               0
Create nack fail to fp                          0
Modify ack to fp                                0
Modify ack fail to fp                           0
Modify nack to fp                               0
Modify nack fail to fp                          0
Delete ack to fp                                420
Delete ack fail to fp                           0
Delete nack to fp                               0
Delete nak fail to fp                           0


------------------ show platform hardware chassis active qfp feature wireless capwap
cpp-client summary ------------------

 cpp_if_hdl    pal_if_hdl       AP MAC           Src IP            Dst IP       Dst Port
Tun Type
-------------------------------------------------------------------------------------------------

   0X108       0X90000042   00a8.2200.0200      78.1.1.7         78.1.50.1       52345
  DATA
   0X10B       0XA0000002   0000.0000.0000      78.1.1.7         78.1.1.23       16667
MOBILITY
   0X10C       0XA0000003   0000.0000.0000      78.1.1.7         78.1.1.24       16667
MOBILITY
   0X10D       0XA0000004   0000.0000.0000      78.1.1.7         78.1.1.25       16667
MOBILITY


------------------ show platform hardware chassis active qfp feature wireless capwap datapath
 summary -------------------

Vrf Src Port Dst IP          Dsp Port Input Uidb Output Uidb Instance Id
--- -------- ------          -------- ---------- ----------- -----------
0   16667    78.1.1.25       16667    95733      95731       0
0   5247     78.1.50.1       52345    95738      95736       3
0   16667    78.1.1.24       16667    95734      95732       0
0   16667    78.1.1.23       16667    95735      95733       0


------------------ show platform hardware chassis active qfp feature wireless capwap datapath
 statistics drop ------------------


Drop Cause                                                                      Packets
      Octets
================================================================================
====================
Wls Capwap unsupported link type Error                                             0
           0
Wls Capwap invalid tunnel Error                                                    0
           0
Wls Capwap input config missing Error                                              0
           0
Wls Capwap invalid TPID Error                                                      0
           0
Wls Capwap ingress parsing Error                                                   0
           0
```

```
Wls Capwap invalid FC subtype Error                                          0
           0
Wls Capwap SNAP Invalid HLEN Error                                           0
           0
Wls Client V6 Max Address Error                                              0
           0


------------------ show platform hardware chassis active qfp feature wireless capwap datapath
 statistics fragmentation ------------------


CPP Wireless Fragmentation stats:

                             Description         Packet Count          Octet Count

                             -----------         ------------          -----------
 Capwap Packets to be Fragmented (RX)                       0                    0
 Capwap Fragments to be Recycled                            0                    0
 Capwap Fragments Recycled (TX)                             0                    0
 Error: Original Packet Too Big                             0                    0
 Error: CAPWAP MTU Not Valid                                0                    0
 Error: Recycle Queue Full                                  0                    0
 Error: Recycle Queue Not Valid                             0                    0
 Error: GPM Memory Init Failure                             0                    0
 Error: Multipass Requeue Failure                           0                    0


------------------ show platform hardware chassis active qfp feature wireless capwap datapath
 statistics reassembly ------------------


CPP Wireless Reassembly Memory stats:

                             Description            Count
                             -----------            -----
                          Free info chunk            32768
                     Allocated info chunks           32768
                       Free fragment chunks         131072
                  Allocated fragment chunks         131072


CPP Wireless Reassembly Packet stats: (outstanding pkt_cnt 0)

                             Description     Packet Count      Octet Count
                             -----------     ------------      -----------
     Capwap Reassembled Packets                          0                0
     Capwap Fragments Received                           0                0
     Capwap Fragments Consumed (Saved)                   0                0
     Capwap Fragments Dropped                            0                0
     Capwap Reassembly Timeouts                          0                0
     Error - Early-drop fragments                        0                0
     Error - Invalid packet size                         0                0
     Error - Fragment size too big                       0                0
     Error - Too many fragments                          0                0
     Error - Overlap offset fragments                    0                0
     Error - Duplicated fragments                        0                0
     Error - Allocate info chunk memory                  0                0
     Error - Allocate frag chunk memory                  0                0
     Error - Hash bucket threshold                       0                0
     Error - Cannot save and gather pkts                 0                0
     Error - Get recycle reass_info NULL                 0                0
     Error - BQS memory alloc NULL                       0                0
     Error - BQS memory free NULL                        0                0
```

```
     DEBUG - # of lock sync aquired                    2               2
     DEBUG - # of lock released                        2               2
     DEBUG - CPP_CW_BQS_MX_ALLOC #                     0               0
     DEBUG - CPP_CW_BQS_MX_FREE  #                     0               0
     DEBUG - CPP_REASS_INFO_ALLOC #                    0               0
     DEBUG - CPP_REASS_INFO_FREE  #                    0               0
     DEBUG - CPP_REASS_FRAG_ALLOC #                    0               0
     DEBUG - CPP_REASS_FRAG_FREE  #                    0               0


------------------ show platform software dtls chassis active F0 statistics ------------------


DTLS Counters     (Success/Failure)
-----------------------------------
Create                  847/0
Delete                  424/0
HW Create               425/0
HW Modify               422/0
HW Delete               424/0
Create Ack              425/0
Modify Ack              422/0
Delete Ack              424/0
Ack Ack Notify          1271/0
Ack Nack Notify         0/0
Nack Notify             0/0
HA Seq GET              782/0
HA Seq SET              0/0
HA Seq Crypto GET       1542/0
HA Seq Crypto SET       0/0
HA Seq Crypto Callback  1542/0

HA Seq last Responsed   0
HA Seq Pending          0
HA Seq Outstanding cb   0
Total DTLS CTX count    1


------------------ show platform software dtls chassis active F0 ------------------


Forwarding Manager DTLS Session Summary

Session ID          Type        Peer IP          Port   AOM ID      Status

-------------------------------------------------------------------------------------------

0x0300000000000001  AP Control  78.1.50.1        52345  3270        Done



------------------ show platform hardware chassis active qfp feature wireless dtls cpp-client
 statistics ------------------


DTLS cpp-client plumbing statistics
Number Msg in = ack + nak + ack fail + nak fail + errors

Counter                                          Value
-----------------------------------------------------------------
Create from fp                                   425
Modify from fp                                   422
Delete from fp                                   424
```

```
Create ack to fp                              425
Create ack fail to fp                         0
Create nack to fp                             0
Create nack fail to fp                        0
Modify ack to fp                              422
Modify ack fail to fp                         0
Modify nack to fp                             0
Modify nack fail to fp                        0
Delete ack to fp                              424
Delete ack fail to fp                         0
Delete nack to fp                             0
Delete nak fail to fp                         0


------------------ show platform hardware chassis active qfp feature wireless dtls cpp-client
 summary ------------------

    Session ID          CDH Handle      Session Type     Parent if-h        Instance id

-----------------------------------------------------------------------------------------

0x0300000000000001  0x00000000D902D9E0   AP Control           0                  3


------------------ show platform hardware chassis active qfp feature wireless dtls datapath
 summary ------------------

Src IP          Dst IP          Src Port Dst Port   Crypto HDL         Instance Id
------          ------          -------- -------    ------------       ----------
78.1.1.7        78.1.50.1       5246     52345      0xd902d9e0           3

------------------ show platform hardware chassis active qfp feature wireless dtls datapath
 statistics ------------------


CPP Wireless DTLS Feature Stats

                           Description     Packet Count      Octet Count
                           -----------     ------------      -----------
   DTLS Packets To Encrypt                       286494          8860778
   DTLS Packets Encrypted                        286494         35681366
   DTLS Packets To Decrypt                       286734         41001830
   DTLS Packets Decrypted                        286734         33401602
   Skip Encryption - Handshake                        0                0
   Skip Encryption - Not AppData                      0                0
   Skip Encryption - No Hash Entry                    0                0
   Skip Encryption - No Crypto Handle                 0                0
   Skip Encryption - No DTLS header                 563            76419
   Skip Encryption - Requested by RP              16234          5042852
   Skip Decryption - Handshake                        0                0
   Skip Decryption - Not AppData                   2949           996248
   Skip Decryption - No Hash Entry                  447            56474
   Skip Decryption - No Crypto Handle             13024          3626640
   Skip Decryption - No DTLS header                 507           116600
   Skip Decryption - Multiple Records                 0                0
   Error - Encrypt Invalid Length                     0                0
   Error - Encrypt Header Restore                     0                0
   Error - DataEncrypt No Crypto Handle               0                0
   Error - DataEncrypt Header Restore                 0                0
   Error - Decrypt Invalid Length                     0                0
   Error - Decrypt Header Restore                     0                0
   Error - DataDecrypt Zero Epoch                     0                0
```

```
   Error - DataDecrypt No Hash Entry                    0               0
   Error - DataDecrypt No Crypto Handle                 0               0
   Error - DataDecrypt Header Restore                   0               0


------------------ show platform software wireless-client chassis active F0 statistics
------------------


Client Counters   (Success/Failure)
-----------------------------------
Create                  112/0
Delete                  55/0
HW Create               56/0
HW Modify               56/0
HW Delete               55/0
Create Ack              56/0
Modify Ack              56/0
Delete Ack              55/0
NACK Notify             0/0


------------------ show platform software wireless-client chassis active F0 ------------------


        ID  MAC Address     WLAN  Client State           AOM ID  Status
-------------------------------------------------------------------------------
0xa0000001  0028.b122.0001     1  Run                      3272  Done


------------------ show platform hardware chassis active qfp feature wireless wlclient
cpp-client statistics ------------------


Wlclient cpp-client plumbing statistics
Number Msg in = ack + nak + ack fail + nak fail + errors

Counter                                          Value
-----------------------------------------------------------------
Create from fp                                   56
Modify from fp                                   56
Delete from fp                                   55
Create ack to fp                                 56
Create ack fail to fp                            0
Create nack to fp                                0
Create nack fail to fp                           0
Modify ack to fp                                 56
Modify ack fail to fp                            0
Modify nack to fp                                0
Modify nack fail to fp                           0
Delete ack to fp                                 55
Delete ack fail to fp                            0
Delete nack to fp                                0
Delete nak fail to fp                            0


------------------ show platform hardware chassis active qfp feature wireless wlclient
cpp-client summary ------------------

Auth State Abbreviations:
  UK - UNKNOWN IP - LEARN IP
  L3 - L3 AUTH RN - RUN
```

```
  IV - INVALID
Mobility State Abbreviations:
  UK - UNKNOWN IN - INIT
  LC - LOCAL   AN - ANCHOR
  FR - FOREIGN MT - MTE
  IV - INVALID
 CPP IF_H     DPIDX      MAC Address    VLAN  AS  MS                WLAN
  POA
------------------------------------------------------------------------------------------------------

  0X102     0XA0000001  0028.b122.0001  177   RN  LC                 att
0x90000042


------------------ show platform hardware chassis active qfp feature wireless wlclient
datapath summary ------------------


Vlan   pal_if_hdl   mac            Input Uidb Output Uidb
------ ------------ -------------- ---------- -----------
177    0xa0000001   0028.b122.0001 95744      95742


------------------ show platform hardware chassis active qfp feature wireless wlclient
datapath statistic drop ------------------


Drop Cause                                                                  Packets
      Octets
============================================================ ====================
====================
Wls Client V6 Max Address Error                                               0
           0
Wls Client IPGlean Counter Index Error                                        0
           0
Wls Client IPGlean Counter Unchanged Error                                    0
           0
Wls Client IPGlean alloc no memory Error                                      0
           0
Wls Client invalid punt packet error                                          0
           0
Wls Client input subblock missing error                                       0
           0
Wls Client input config missing                                               0
           0
Wls Client global mac address fetch error                                     0
           0
Wls Client header add error                                                   0
           0
Wls Client IP entry theft error                                               0
           0
Wls Client IPSG input subblock missing error                                  0
           0
Wls Client DOT1Q Hdr add anchor error                                         0
           0
Wls Client DOT1Q Hdr add anchor avc error                                     0
           0
Wls Client Guest Foreign Multicast error                                      0
           0


------------------ show platform hardware chassis active qfp feature wireless wlclient
datapath table dataglean all ------------------
```

```
CPP Wireless IPv6 Data Gleaning Table:

IP Address                                VLAN    uIDB   Interface
----------------------------------------  ----  ------  -------------


------------------ show platform hardware chassis active qfp feature wireless ipsg cpp-client
 statistics ------------------

CPP Wireless IPSG CPP-client Statistics
Counter                          Value
-------------------------------------------------
Total IPv4 Address Count         1
Total IPv6 Address Count         0
IPv4 Entry Add Success           56
IPv4 Entry Add Fail              0
IPv4 Entry Delete Success        55
IPv4 Entry Delete Fail           0
IPv6 Entry Add Success           0
IPv6 Entry Add Fail              0
IPv6 Entry Delete Success        0
IPv6 Entry Delete Fail           0
IP Entry Override                0
IP Entry Add Req Skip            0
Data Glean Memory Req Recv       0
Data Glean Memory Req Fail       0
Data Glean Memory Req Send       0
Data Glean Memory Ret Recv       0
Data Glean Memory Ret Send       0
Data Glean Entry Send            0
IPSG Subblock Allocate           0
IPSG Subblock Allocate Fail      0
IPSG Subblock Free               0
IPSG Subblock Free Fail          0
IPSG FIA Enable                  0
IPSG FIA Enable Fail             0
IPSG FIA Disable                 0
IPSG FIA Disable Fail            0
IPSG Feature Enable              0
IPSG Feature Enable Fail         0
IPSG Feature Disable             0
IPSG Feature Disable Fail        0


------------------ show platform hardware chassis active qfp feature wireless ipsg cpp-client
 table ipv4 all ------------------

CPP Wireless IPSG Table Summary
Total number of address entries: 1
IP Address                                VLAN  uIDB
-----------------------------------------------------
177.1.0.7                                 177   95744


------------------ show platform hardware chassis active qfp feature wireless ipsg cpp-client
 table ipv6 all ------------------

CPP Wireless IPSG Table Summary
Total number of address entries: 0


------------------ show platform hardware chassis active qfp feature wireless ipsg datapath
```

```
 statistics global ------------------


  Wireless IPSG Global Statistics
  --------------------------------
    IPv6 Dataglean entry add          :  0
    IPv6 Dataglean entry remove       :  0
    IPv6 Dataglean allocation fail    :  0
    IPv6 Dataglean pool req send      :  0
    IPv6 Dataglean pool req send fail :  0
    IPv6 Dataglean pool req resp      :  0
    IPv6 Dataglean pool ret send      :  0
    IPv6 Dataglean pool ret send fail :  0
    IPv6 Dataglean punt packet        :  0
    IPv6 Dataglean drop packet        :  0


------------------ show platform hardware chassis active qfp feature wireless ipsg datapath
 table ipv4 all ------------------


CPP Wireless IPSG IPv4 Table:

IP Address                                VLAN    uIDB   Interface
----------------------------------------  ----  ------  -------------
177.1.0.7                                  177   95744  WLCLIENT-IF-0x00a0000001


------------------ show platform hardware chassis active qfp feature wireless ipsg datapath
 table ipv6 all ------------------


CPP Wireless IPSG IPv6 Table:

IP Address                                VLAN    uIDB   Interface
----------------------------------------  ----  ------  -------------


------------------ show platform hardware chassis active qfp feature wireless halo statistics
 ------------------


Wireless HALO Statistics
                        Rx Packet Count               0
                        Rx Packet Bytes               0


------------------ show platform hardware chassis active qfp feature wireless fqdn-filter
summary ------------------


CPP Wireless FQDN Filter Info:
ID   Type     DSA_hdl    Redirect_IPv4    Virtual_IPv4
---- -------- ---------- ---------------- ----------------


------------------ show platform hardware chassis active qfp feature wireless et-analytics
 statistics ------------------


Wireless ETA cpp-client plumbing statistics
Number of ETA pending clients : 0

Counter                                       Value
```

```
-------------------------------------------------------------------
Enable ETA on wireless client called           0
Delete ETA on wireless client called           0
ETA global cfg init cb TVI FIA enable error    0
ETA global cfg init cb output SB read error    0
ETA global cfg init cb output SB write error   0
ETA global cfg init cb input SB read error     0
ETA global cfg init cb input SB write error    0
ETA global cfg init cb TVI FIA enable success  0
ETA global cfg uninit cb ingress feat disable  0
ETA global cfg uninit cb ingress cfg delete e  0
ETA global cfg uninit cb egress feat disable   0
ETA global cfg uninit cb egress cfg delete er  0
ETA pending list insert entry called           0
ETA pending list insert invalid arg error      0
ETA pending list insert entry exists error     0
ETA pending list insert no memory error        0
ETA pending list insert entry failed           0
ETA pending list insert entry success          0
ETA pending list delete entry called           0
ETA pending list delete invalid arg error      0
ETA pending list delete entry missing          0
ETA pending list delete entry remove error     0
ETA pending list delete entry success          0


------------------ show platform hardware chassis active qfp feature wireless et-analytics
 eta-pending-client-tree ------------------
```

show tech-support wireless fabric

To display global fabric parameters, use the **show tech-support wireless fabric** command in privileged EXEC mode.

show tech-support wireless fabric

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless fabric** command:

- show wireless fabric summary
- show wireless profile fabric summary
- show fabric wlan summary
- show fabric ap summary
- show wireless fabric client summary
- show wireless fabric media-stream client summary
- show wireless stats fabric memory
- show wireless stats fabric control-plane all

Example

The following is sample output from the **show tech-support wireless fabric** command

show tech-support wireless mobility

To print the data related to mobility, use the **show tech-support wireless mobility** command in privileged EXEC mode.

show tech-support wireless mobility

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless mobility** command:

- show platform hardware chassis active qfp feature wireless capwap cpp-client summary
- show platform hardware chassis active qfp feature wireless capwap datapath summary
- show platform hardware chassis active qfp feature wireless dtls cpp-client summary
- show platform hardware chassis active qfp feature wireless dtls datapath statistics
- show platform hardware chassis active qfp feature wireless dtls datapath summary
- show platform software capwap chassis active f0
- show platform software capwap chassis active r0
- show platform software dtls chassis active f0
- show platform software dtls chassis active r0
- show platform software ipc queue-based mobilityd chassis active R0 connection
- show platform software memory messaging mobilityd chassis active R0
- show platform software memory mobilityd chassis active R0 brief
- show wireless mobility ap-list
- show wireless mobility summary
- show wireless stats mobility
- show wireless stats mobility messages

In the presence of standby node, the output of the following mobility commands are also be displayed:

- show platform hardware chassis standby qfp feature wireless capwap cpp-client summary

- show platform hardware chassis standby qfp feature wireless capwap datapath summary
- show platform hardware chassis standby qfp feature wireless dtls cpp-client summary
- show platform hardware chassis standby qfp feature wireless dtls datapath statistics
- show platform hardware chassis standby qfp feature wireless dtls datapath summary
- show platform software capwap chassis standby f0
- show platform software capwap chassis standby r0
- show platform software dtls chassis standby f0
- show platform software dtls chassis standby r0
- show platform software ipc queue-based mobilityd chassis standby R0 connection
- show platform software memory messaging mobilityd chassis standby R0
- show platform software memory mobilityd chassis standby R0 brief
- show wireless stats mobility messages chassis standby r0

Example

The following is sample output from the **show tech-support wireless mobility** command

```
Device# show tech-support wireless mobility

------------------ show wireless stats mobility ------------------


Mobility event statistics:
     Joined as
         Local                          : 0
         Foreign                        : 0
         Export foreign                 : 0
         Export anchor                  : 0
     Delete
         Local                          : 0
         Remote                         : 0
     Role changes
         Local to anchor                : 0
         Anchor to local                : 0
     Roam stats
         L2 roam count                  : 0
         L3 roam count                  : 0
         Flex client roam count         : 0
         Inter-WNCd roam count          : 0
         Intra-WNCd roam count          : 0
     Anchor Request
         Sent                           : 0
           Grant received               : 0
           Deny received                : 0
         Received                       : 0
           Grant sent                   : 0
           Deny  sent                   : 0
     Handoff Status Received
         Success                        : 0
         Group mismatch                 : 0
```

```
            Client unknown                : 0
            Client blacklisted            : 0
            SSID mismatch                 : 0
            Denied                        : 0
        Handoff Status Sent
            Success                       : 0
            Group mismatch                : 0
            Client unknown                : 0
            Client blacklisted            : 0
            SSID mismatch                 : 0
            Denied                        : 0
        Export Anchor
            Request Sent                  : 0
            Response Received             :
                Ok                        : 0
                Deny - generic            : 0
                Client blacklisted        : 0
                Client limit reached      : 0
                Profile mismatch          : 0
                Deny - unknown reason     : 0
            Request Received              : 0
            Response Sent                 :
                Ok                        : 0
                Deny - generic            : 0
                Client blacklisted        : 0
                Client limit reached      : 0
                Profile mismatch          : 0
MM mobility event statistics:
        Event data allocs                 : 0
        Event data frees                  : 0
        FSM set allocs                    : 0
        FSM set frees                     : 0
        Timer allocs                      : 0
        Timer frees                       : 0
        Timer starts                      : 0
        Timer stops                       : 0
        Invalid events                    : 0
        Internal errors                   : 0


MMIF mobility event statistics:
        Event data allocs                 : 0
        Event data frees                  : 0
        Invalid events                    : 0
        Unkown events                     : 0
        Event schedule errors             : 0
        Internal errors                   : 0


------------------ show wireless stats mobility messages ------------------


MM datagram message statistics:
  Message Type               Built  Tx    Rx    Processed  Tx Error  Rx Error  Forwarded
Retry  Drops  Allocs  Frees

-------------------------------------------------------------------------------------------------------------

  Mobile Announce            0      0     0     0          0         0         0
0      0      0       0
  Mobile Announce Nak        0      0     0     0          0         0         0
0      0      0       0
```

```
  Static IP Mobile Annc      0      0      0      0          0          0          0
0       0       0       0
  Static IP Mobile Annc Rsp  0      0      0      0          0          0          0
0       0       0       0
  Handoff                    0      0      0      0          0          0          0
0       0       0       0
  Handoff End                0      0      0      0          0          0          0
0       0       0       0
  Handoff End Ack            0      0      0      0          0          0          0
0       0       0       0
  Anchor Req                 0      0      0      0          0          0          0
0       0       0       0
  Anchor Grant               0      0      0      0          0          0          0
0       0       0       0
  Anchor Xfer                0      0      0      0          0          0          0
0       0       0       0
  Anchor Xfer Ack            0      0      0      0          0          0          0
0       0       0       0
  Export Anchor Req          0      0      0      0          0          0          0
0       0       0       0
  Export Anchor Rsp          0      0      0      0          0          0          0
0       0       0       0
  AAA Handoff                0      0      0      0          0          0          0
0       0       0       0
  AAA Handoff Ack            0      0      0      0          0          0          0
0       0       0       0
  IPv4 Addr Update           0      0      0      0          0          0          0
0       0       0       0
  IPv4 Addr Update Ack       0      0      0      0          0          0          0
0       0       0       0
  IPv6 ND Packet             0      0      0      0          0          0          0
0       0       0       0
  IPv6 Addr Update           0      0      0      0          0          0          0
0       0       0       0
  IPv6 Addr Update Ack       0      0      0      0          0          0          0
0       0       0       0
  Client Add                 0      0      0      0          0          0          0
0       0       0       0
  Client Delete              0      0      0      0          0          0          0
0       0       0       0
  Keepalive Ctrl Req         0      0      0      0          0          0          0
0       0       0       0
  Keepalive Ctrl Resp        0      0      0      0          0          0          0
0       0       0       0
  AP List Update             0      0      0      0          0          0          0
0       0       0       0
  Client Device Profile Info 0      0      0      0          0          0          0
0       0       0       0
  PMK Update                 0      0      0      0          0          0          0
0       0       0       0
  PMK Delete                 0      0      0      0          0          0          0
0       0       0       0
  PMK 11r Nonce Update       0      0      0      0          0          0          0
0       0       0       0
  Device cache Update        0      0      0      0          0          0          0
0       0       0       0
  HA SSO Announce            0      0      0      0          0          0          0
0       0       0       0
  HA SSO Announce Resp       0      0      0      0          0          0          0
0       0       0       0

MM IPC message statistics:
  Message Type               Built  Tx    Rx    Processed  Tx Error  Rx Error  Forwarded
Drops  Allocs  Frees
```

```
---------------------------------------------------------------------------------------------------------------------

  Mobile Announce            0      0      0      0          0          0          0
0       0       0
  Mobile Announce Nak        0      0      0      0          0          0          0
0       0       0
  Static IP Mobile Annc      0      0      0      0          0          0          0
0       0       0
  Static IP Mobile Annc Rsp  0      0      0      0          0          0          0
0       0       0
  Handoff                    0      0      0      0          0          0          0
0       0       0
  Handoff End                0      0      0      0          0          0          0
0       0       0
  Handoff End Ack            0      0      0      0          0          0          0
0       0       0
  Anchor Req                 0      0      0      0          0          0          0
0       0       0
  Anchor Grant               0      0      0      0          0          0          0
0       0       0
  Anchor Xfer                0      0      0      0          0          0          0
0       0       0
  Anchor Xfer Ack            0      0      0      0          0          0          0
0       0       0
  Export Anchor Req          0      0      0      0          0          0          0
0       0       0
  Export Anchor Rsp          0      0      0      0          0          0          0
0       0       0
  AAA Handoff                0      0      0      0          0          0          0
0       0       0
  AAA Handoff Ack            0      0      0      0          0          0          0
0       0       0
  IPv4 Addr Update           0      0      0      0          0          0          0
0       0       0
  IPv4 Addr Update Ack       0      0      0      0          0          0          0
0       0       0
  IPv6 ND Packet             0      0      0      0          0          0          0
0       0       0
  IPv6 Addr Update           0      0      0      0          0          0          0
0       0       0
  IPv6 Addr Update Ack       0      0      0      0          0          0          0
0       0       0
  Client Add                 0      0      0      0          0          0          0
0       0       0
  Client Delete              0      0      0      0          0          0          0
0       0       0
  Keepalive Ctrl Req         0      0      0      0          0          0          0
0       0       0
  Keepalive Ctrl Resp        0      0      0      0          0          0          0
0       0       0
  AP List Update             0      0      0      0          0          0          0
0       0       0
  Client Device Profile Info 0      0      0      0          0          0          0
0       0       0
  PMK Update                 0      0      0      0          0          0          0
0       0       0
  PMK Delete                 0      0      0      0          0          0          0
0       0       0
  PMK 11r Nonce Update       0      0      0      0          0          0          0
0       0       0
  Device cache Update        0      0      0      0          0          0          0
0       0       0
  HA SSO Announce            0      0      0      0          0          0          0
```

```
0       0       0
  HA SSO Announce Resp       0       0     0     0          0          0          0
0       0       0

MMIF IPC message statistics:
  Message Type              Built  Tx    Rx    Processed  Tx Error  Rx Error  Drops  Allocs
  Frees

-------------------------------------------------------------------------------------------------

  Mobile Announce            0       0     0     0          0          0          0       0
    0
  Mobile Announce Nak        0       0     0     0          0          0          0       0
    0
  Static IP Mobile Annc      0       0     0     0          0          0          0       0
    0
  Static IP Mobile Annc Rsp  0       0     0     0          0          0          0       0
    0
  Handoff                    0       0     0     0          0          0          0       0
    0
  Handoff End                0       0     0     0          0          0          0       0
    0
  Handoff End Ack            0       0     0     0          0          0          0       0
    0
  Anchor Req                 0       0     0     0          0          0          0       0
    0
  Anchor Grant               0       0     0     0          0          0          0       0
    0
  Anchor Xfer                0       0     0     0          0          0          0       0
    0
  Anchor Xfer Ack            0       0     0     0          0          0          0       0
    0
  Export Anchor Req          0       0     0     0          0          0          0       0
    0
  Export Anchor Rsp          0       0     0     0          0          0          0       0
    0
  AAA Handoff                0       0     0     0          0          0          0       0
    0
  AAA Handoff Ack            0       0     0     0          0          0          0       0
    0
  IPv4 Addr Update           0       0     0     0          0          0          0       0
    0
  IPv4 Addr Update Ack       0       0     0     0          0          0          0       0
    0
  IPv6 ND Packet             0       0     0     0          0          0          0       0
    0
  IPv6 Addr Update           0       0     0     0          0          0          0       0
    0
  IPv6 Addr Update Ack       0       0     0     0          0          0          0       0
    0
  Client Add                 0       0     0     0          0          0          0       0
    0
  Client Delete              0       0     0     0          0          0          0       0
    0
  Keepalive Ctrl Req         0       0     0     0          0          0          0       0
    0
  Keepalive Ctrl Resp        0       0     0     0          0          0          0       0
    0
  AP List Update             0       0     0     0          0          0          0       0
    0
  Client Device Profile Info 0       0     0     0          0          0          0       0
    0
  PMK Update                 0       0     0     0          0          0          0       0
    0
```

```
  PMK Delete                0      0      0      0          0          0          0       0
    0
  PMK 11r Nonce Update      0      0      0      0          0          0          0       0
    0
  Device cache Update       0      0      0      0          0          0          0       0
    0
  HA SSO Announce           0      0      0      0          0          0          0       0
    0
  HA SSO Announce Resp      0      0      0      0          0          0          0       0
    0


------------------ show wireless mobility summary ------------------


Mobility Summary

Wireless Management VLAN: 32
Wireless Management IP Address: 9.12.32.10
Mobility Control Message DSCP Value: 48
Mobility Keepalive Interval/Count: 10/3
Mobility Group Name: default
Mobility Multicast Ipv4 address: 0.0.0.0
Mobility Multicast Ipv6 address: ::
Mobility MAC Address: 001e.f6c1.f6ff

Controllers configured in the Mobility Domain:

 IP               Public Ip         Group Name                      Multicast IPv4
Multicast IPv6                                Status                        PMTU
-------------------------------------------------------------------------------------------------
9.12.32.10        N/A               default                         0.0.0.0          ::
                                           N/A                        N/A


------------------ show wireless mobility ap-list ------------------


------------------ show platform software capwap chassis active r0 ------------------


------------------ show platform software capwap chassis active f0 ------------------


------------------ show platform software dtls chassis active r0 ------------------


------------------ show platform software dtls chassis active f0 ------------------


------------------ show platform hardware chassis active qfp feature wireless capwap
cpp-client summary ------------------


------------------ show platform hardware chassis active qfp feature wireless dtls cpp-client
 summary ------------------
```

```
------------------ show platform hardware chassis active qfp feature wireless capwap datapath
 summary ------------------

Vrf Src Port Dst IP          Dsp Port Input Uidb Output Uidb Instance Id
--- -------- ------          -------- ---------- ----------- -----------


------------------ show platform hardware chassis active qfp feature wireless dtls datapath
 statistics ------------------

CPP Wireless DTLS Feature Stats

                            Description     Packet Count      Octet Count
                            -----------     ------------      -----------
   DTLS Packets To Encrypt                              0                0
   DTLS Packets Encrypted                               0                0
   DTLS Packets To Decrypt                              0                0
   DTLS Packets Decrypted                               0                0
   Skip Encryption - Handshake                          0                0
   Skip Encryption - Not AppData                        0                0
   Skip Encryption - No Hash Entry                      0                0
   Skip Encryption - No Crypto Handle                   0                0
   Skip Encryption - No DTLS header                     0                0
   Skip Encryption - Requested by RP                    0                0
   Skip Decryption - Handshake                          0                0
   Skip Decryption - Not AppData                        0                0
   Skip Decryption - No Hash Entry                      0                0
   Skip Decryption - No Crypto Handle                   0                0
   Skip Decryption - No DTLS header                     0                0
   Skip Decryption - Multiple Records                   0                0
   Error - Encrypt Invalid Length                       0                0
   Error - Encrypt Header Restore                       0                0
   Error - DataEncrypt No Crypto Handle                 0                0
   Error - DataEncrypt Header Restore                   0                0
   Error - Decrypt Invalid Length                       0                0
   Error - Decrypt Header Restore                       0                0
   Error - DataDecrypt Zero Epoch                       0                0
   Error - DataDecrypt No Hash Entry                    0                0
   Error - DataDecrypt No Crypto Handle                 0                0
   Error - DataDecrypt Header Restore                   0                0


------------------ show platform hardware chassis active qfp feature wireless dtls datapath
 summary ------------------

Src IP          Dst IP          Src Port Dst Port   Crypto HDL         Instance Id
------          ------          -------- -------    ----------         ----------

------------------ show platform software ipc queue-based mobilityd chassis active R0
connection ------------------

Name: -mobilityd_to_wncd-b0
  Number     : 0
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
               360 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%
```

```
Name: -mobilityd_to_wncd-b1
  Number     : 1
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
               360 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_wncd-b2
  Number     : 2
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
               360 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_fman_rp-b0
  Number     : 3
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 0 msgs, 0 bytes, 0 err, 0 back-pressures,
               0 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_iosd_rp-b0
  Number     : 4
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 204647 msgs, 15757819 bytes, 0 err, 0 back-pressures,
               81 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_wncmgrd-b0
  Number     : 5
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 524288 bytes, 0 bytes currently used
  Enqueued   : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
               360 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -odm_clnt2svr_data-mobilityd-000-1
  Number     : 6
  Mode       : writer
  Created on : 03/22/18 05:35:06
  Queue Size : 2097152 bytes, 0 bytes currently used
  Enqueued   : 33 msgs, 12535 bytes, 0 err, 0 back-pressures,
               3769 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -odm_svr2clnt_data-mobilityd-000-1
  Number     : 7
  Mode       : reader
  Created on : 03/22/18 05:35:06
  Queue Size : 2097152 bytes, 0 bytes currently used
  Dequeued   : 0 msgs, 0 bytes, 0 err

Name: -fman_rp_to_mobilityd-b0
  Number     : 8
  Mode       : reader
```

```
  Created on : 03/22/18 05:35:08
  Queue Size : 524288 bytes, 0 bytes currently used
  Dequeued   : 0 msgs, 0 bytes, 0 err

Name: -wncd_to_mobilityd-b0
  Number     : 9
  Mode       : reader
  Created on : 03/22/18 05:35:13
  Queue Size : 524288 bytes, 0 bytes currently used
  Dequeued   : 39 msgs, 1404 bytes, 0 err

Name: -wncd_to_mobilityd-b1
  Number     : 10
  Mode       : reader
  Created on : 03/22/18 05:35:13
  Queue Size : 524288 bytes, 0 bytes currently used
  Dequeued   : 39 msgs, 1404 bytes, 0 err

Name: -wncd_to_mobilityd-b2
  Number     : 11
  Mode       : reader
  Created on : 03/22/18 05:35:14
  Queue Size : 524288 bytes, 0 bytes currently used
  Dequeued   : 39 msgs, 1404 bytes, 0 err

Name: -wncmgrd_to_mobilityd-b0
  Number     : 12
  Mode       : reader
  Created on : 03/22/18 05:35:14
  Queue Size : 524288 bytes, 0 bytes currently used
  Dequeued   : 18 msgs, 648 bytes, 0 err

Name: -iosd_rp_to_mobilityd-b0
  Number     : 13
  Mode       : reader
  Created on : 03/22/18 05:35:30
  Queue Size : 1048576 bytes, 0 bytes currently used
  Dequeued   : 204647 msgs, 18827524 bytes, 0 err

Name: -odm_clnt2svr_data-ifid-005-1
  Number     : 14
  Mode       : writer
  Created on : 03/22/18 05:35:37
  Queue Size : 2097152 bytes, 0 bytes currently used
  Enqueued   : 0 msgs, 0 bytes, 0 err, 0 back-pressures,
               0 bytes max queue utilization,
               0 times reached above 90%, 0 times reached above 75%

Name: -odm_svr2clnt_data-ifid-005-1
  Number     : 15
  Mode       : reader
  Created on : 03/22/18 05:35:37
  Queue Size : 2097152 bytes, 0 bytes currently used
  Dequeued   : 0 msgs, 0 bytes, 0 err



------------------ show platform software memory messaging mobilityd chassis active R0
------------------

[tdl_toc] type toc_table_info/47da701cd9c36de7e888ca6d8dd80390/0 created:3 destroyed:3
diff:0
[tdl_sr] type repl_table_name/29184a6d15c1ba11acb2d0bd22eb6e36/0 created:33 destroyed:33
diff:0
```

```
[tdl_sr] type repl_database_name/e9118a691a20b4b8f1118bc37a894603/0 created:33 destroyed:33
 diff:0
[tdl_sr] type repl_pkey_tdl/83de2d20ec3ca19b8ae9a89147480a25/1 created:33 destroyed:33
diff:0
[tdl_sr] type repl_blob_tdl/016a67083ea407334130436c855ae237/0 created:33 destroyed:33
diff:0
[tdl_sr] type repl_luid/b9c9d9f4876af528cb82273df98479d6/0 created:33 destroyed:33 diff:0
[tdl_sr] type repl_objinfo/6c8800fedf8d71512f9b6c9754db3a70/0 created:33 destroyed:33 diff:0
[tdl_sr] message repl_trec_update/15fe2a39409473179c9e7111851b2196/0 created:33 destroyed:33
 diff:0
[pki_ssl] type buff/941d8a519d6f23d27067617119f1bb38/0 created:613944 destroyed:613944
diff:0
[pki_ssl] type get_certid_params/0d7bcce690f74649c2e33bbf341e2229/0 created:204648
destroyed:204648 diff:0
[pki_ssl] type get_certid_callback_params/708b7fb964ace7971d90a452c830488c/0 created:204648
 destroyed:204648 diff:0
[pki_ssl] message get_certid/ee3bfe6b93901440346417a4ad67fa63/0 created:204648
destroyed:204648 diff:0
[pki_ssl] message get_certid_callback/372218059d7a753ba73f7b06f18532e9/0 created:204648
destroyed:204648 diff:0
[svc_defs] type svc_loc/929237802cf26e862f8e8716169e31ef/0 created:40952 destroyed:40951
diff:1
[ui_shr] type ui_client/bec7457db0c33cae9eeebbf80073b771/0 created:3 destroyed:2 diff:1
[ui] type ui_info/4b8b42a883fabbb98ec8b919f60e4ad6/0 created:40949 destroyed:40949 diff:0
[ui] type ui_req/69f1e2a5943e050f0aa12df8639ba442/0 created:3 destroyed:2 diff:1
[ui] type event_statistics/7f346ee47165c035a72e139b84afb2a0/0 created:40948 destroyed:40948
 diff:0
[ui] type hostinfo_data/54d5a8b0cd4d29d575b2fc0d91695b5e/0 created:3 destroyed:3 diff:0
[ui] message ui_info_msg/bec533dd713e0222cb8fe5df868031f0/0 created:1 destroyed:1 diff:0
[ui] message ui_req_msg/ac9905cc4488c976847affab56d8b50c/0 created:3 destroyed:2 diff:1
[ui] message process_event_statistics/65d07aa3a04ad950cddd46444df6bc02/0 created:40948
destroyed:40948 diff:0
[ui] message hostinfo_notify/2e9d975712b85b41bc489a6adbc4a46c/0 created:3 destroyed:3 diff:0
[uipeer_comm_ui] type mqipc_enqueue_stats/8f41e408c97a799a5e431d2279acd8de/0 created:8
destroyed:8 diff:0
[uipeer_comm_ui] type mqipc_dequeue_stats/aafe5d0a37ba9652d68550efa26eb0b6/0 created:8
destroyed:8 diff:0
[uipeer_comm_ui] type mqipc_connection_properties/35bd274fd85f7359066f898f25c853ee/0
created:16 destroyed:16 diff:0
[uipeer_comm_ui] message mqipc_connection/a1b22c74b279335b895531ce708c804b/0 created:16
destroyed:16 diff:0
[mem_stats_ui] type tdl_variant_stat/bd85e4b89fb10501e68c1a3cedb9f321/0 created:1 destroyed:0
 diff:1
[mem_stats_ui] message tdl_mem_stats/60ffd9d51213767d041b543869df15d2/0 created:1 destroyed:0
 diff:1
[cdlcore] type cdl_params/a3e74327d37abf27f799f2b5155f4923/0 created:2 destroyed:1 diff:1
[cdlcore] message cdl_message/35205e535c7ab2cdcb3c265ac788f973/0 created:2 destroyed:1
diff:1
[odm_defs] type odm_context/73aeecb77a1ccb6e44f690745cdafe0d/1 created:23 destroyed:23
diff:0
[odm_defs] type odm_register_info/48a7d590e9df0cc9d150801315c50307/1 created:4 destroyed:4
 diff:0
[odm_defs] type odm_table_register_info/4f355a34615affd49af9f90b679d8ce5/1 created:17
destroyed:17 diff:0
[odm_defs] type odm_register_result/53ba304bc0a71a7d2a044518c21f662a/0 created:2 destroyed:2
 diff:0
[odm_defs] message odm_register/2c98272b43d973fa08bbf5acdf3106b0/0 created:2 destroyed:2
diff:0
[odm_defs] message odm_table_register/46694ec1005c3b084337748eeb3768cd/0 created:17
destroyed:17 diff:0
[odm_defs] message odm_register_done/1f6c8f81fcbb8a3052428bab7588e8b5/0 created:2 destroyed:2
 diff:0
[odm_defs] message odm_register_ack/03b8040ed4f7b03517b410c32568ecaa/0 created:2 destroyed:2
 diff:0
```

```
------------------ show platform software memory mobilityd chassis active R0 brief
------------------

  module                  allocated     requested     allocs        frees
  ------------------------------------------------------------------------------
  Summary                 620441        617113        233           25
  unknown                 198515        198435        5             0
  chunk                   139689        139209        30            0
  eventutil               118939        118299        48            8
  process                 67642         67594         3             0
  odm-db-ctx              29950         28430         100           5
  uipeer                  22672         22592         11            6
  odm-ipc-ctx             20272         19984         18            0
  unknown                 18024         18008         1             0
  odm-client-ctx          1872          1824          3             0
  cdllib                  1688          1672          3             2
  trccfg                  512           496           5             4
  bidb                    472           456           1             0
  unknown                 96            48            3             0
  bcrdu_avl               72            56            1             0
  orchestrator_main       26            10            1             0
```

show tech-support wireless radio

To print the data related to the radio, use the **show tech-support wireless radio** command in privileged EXEC mode.

show tech-support wireless radio

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless radio** command:

- show ap auto-rf dot11 24ghz
- show ap auto-rf dot11 5ghz
- show ap config dot11 dual-band summary
- show ap config general
- show ap dot11 24ghz channel
- show ap dot11 24ghz coverage
- show ap dot11 24ghz group
- show ap dot11 24ghz high-density
- show ap dot11 24ghz load-info
- show ap dot11 24ghz monitor
- show ap dot11 24ghz network
- show ap dot11 24ghz summary
- show ap dot11 24ghz txpower
- show ap dot11 5ghz channel
- show ap dot11 5ghz coverage
- show ap dot11 5ghz group
- show ap dot11 5ghz high-density
- show ap dot11 5ghz load-info

- show ap dot11 5ghz monitor
- show ap dot11 5ghz network
- show ap dot11 5ghz summary
- show ap dot11 5ghz txpower
- show ap fra
- show ap rf-profile name Rf1 detail
- show ap rf-profile summary
- show ap summary
- show wireless band-select

Example

The following is sample output from the **show tech-support wireless radio** command

```
Device# show tech-support wireless radio

------------------ show ap summary ------------------

Number of APs: 0


------------------ show ap dot11 24ghz summary ------------------


------------------ show ap dot11 5ghz summary ------------------


------------------ show ap config dot11 dual-band summary ------------------


------------------ show ap dot11 24ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 550 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 10 dB
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
```

```
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
  802.11b 2.4 GHz Auto-RF Channel List
    Allowed Channel List                    : 1,6,11
    Unused Channel List                     : 2,3,4,5,7,8,9,10


------------------ show ap dot11 5ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 552 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 15 dB
  DCA 802.11n/ac Channel Width              : 20 MHz
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
  802.11a 5 GHz Auto-RF Channel List
    Allowed Channel List                    :
36,40,44,48,52,56,60,64,100,104,108,112,116,120,124,128,132,136,140,144,149,153,157,161
    Unused Channel List                     : 165


------------------ show ap dot11 24ghz coverage ------------------


Coverage Hole Detection
  802.11b Coverage Hole Detection Mode            : Enabled
  802.11b Coverage Voice Packet Count             : 100 packet(s)
  802.11b Coverage Voice Packet Percentage        : 50%
  802.11b Coverage Voice RSSI Threshold           : -80 dBm
  802.11b Coverage Data Packet Count              : 50 packet(s)
  802.11b Coverage Data Packet Percentage         : 50%
  802.11b Coverage Data RSSI Threshold            : -80 dBm
  802.11b Global coverage exception level         : 25 %
  802.11b Global client minimum exception level   : 3 clients


------------------ show ap dot11 5ghz coverage ------------------


Coverage Hole Detection
```

```
  802.11a Coverage Hole Detection Mode          : Enabled
  802.11a Coverage Voice Packet Count           : 100 packet(s)
  802.11a Coverage Voice Packet Percentage      : 50 %
  802.11a Coverage Voice RSSI Threshold         : -80dBm
  802.11a Coverage Data Packet Count            : 50 packet(s)
  802.11a Coverage Data Packet Percentage       : 50 %
  802.11a Coverage Data RSSI Threshold          : -80dBm
  802.11a Global coverage exception level       : 25 %
  802.11a Global client minimum exception level : 3 clients


------------------ show ap dot11 24ghz group ------------------


Radio RF Grouping

  802.11b Group Mode               : AUTO
  802.11b Group Update Interval    : 600 seconds
  802.11b Group Leader             : ewlc-doc (9.12.32.10)
  802.11b Last Run                 : 553 seconds ago


RF Group Members

Controller name                   Controller IP
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 5ghz group ------------------


Radio RF Grouping

  802.11a Group Mode               : AUTO
  802.11a Group Update Interval    : 600 seconds
  802.11a Group Leader             : ewlc-doc (9.12.32.10)
  802.11a Last Run                 : 553 seconds ago


RF Group Members

Controller name                   Controller IP
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 24ghz high-density ------------------


------------------ show ap dot11 5ghz high-density ------------------


------------------ show ap dot11 5ghz load-info ------------------


------------------ show ap dot11 24ghz load-info ------------------
```

```
------------------ show ap dot11 24ghz profile ------------------


Default 802.11b AP performance profiles
  802.11b Global Interference threshold    : 10 %
  802.11b Global noise threshold           : -70 dBm
  802.11b Global RF utilization threshold  : 80 %
  802.11b Global throughput threshold      : 1000000 bps
  802.11b Global clients threshold         : 12 clients


------------------ show ap dot11 5ghz profile ------------------


Default 802.11a AP performance profiles

  802.11a Global Interference threshold          : 10 %
  802.11a Global noise threshold                 : -70 dBm
  802.11a Global RF utilization threshold        : 80 %
  802.11a Global throughput threshold            : 1000000 bps
  802.11a Global clients threshold               : 12 clients


------------------ show ap dot11 24ghz monitor ------------------


Default 802.11b AP monitoring
  802.11b Monitor Mode                 : Enabled
  802.11b Monitor Channels             : Country channels
  802.11b RRM Neighbor Discover Type   : Transparent
  802.11b AP Coverage Interval         : 180 seconds
  802.11b AP Load Interval             : 60 seconds
  802.11b AP Noise Interval            : 180 seconds
  802.11b AP Signal Strength Interval  : 60 seconds
  802.11b NDP RSSI Normalization       : Enabled


------------------ show ap dot11 5ghz monitor ------------------


Default 802.11a AP monitoring
  802.11a Monitor Mode                 : Enabled
  802.11a Monitor Channels             : Country channels
  802.11a RRM Neighbor Discover Type   : Transparent
  802.11a AP Coverage Interval         : 180 seconds
  802.11a AP Load Interval             : 60 seconds
  802.11a AP Noise Interval            : 180 seconds
  802.11a AP Signal Strength Interval  : 60 seconds
  802.11a NDP RSSI Normalization       : Enabled


------------------ show ap dot11 24ghz network ------------------



802.11b Network                          : Enabled
11gSupport                               : Enabled
11nSupport                               : Enabled
802.11b/g Operational Rates
  802.11b 1M                             : Mandatory
```

```
    802.11b 2M                                : Mandatory
    802.11b 5.5M                              : Mandatory
    802.11b 11M                               : Mandatory
    802.11g 6M                                : Supported
    802.11g 9M                                : Supported
    802.11g 12M                               : Supported
    802.11g 18M                               : Supported
    802.11g 24M                               : Supported
    802.11g 36M                               : Supported
    802.11g 48M                               : Supported
    802.11g 54M                               : Supported
  802.11n MCS Settings:
    MCS 0 : Supported
    MCS 1 : Supported
    MCS 2 : Supported
    MCS 3 : Supported
    MCS 4 : Supported
    MCS 5 : Supported
    MCS 6 : Supported
    MCS 7 : Supported
    MCS 8 : Supported
    MCS 9 : Supported
    MCS 10 : Supported
    MCS 11 : Supported
    MCS 12 : Supported
    MCS 13 : Supported
    MCS 14 : Supported
    MCS 15 : Supported
    MCS 16 : Supported
    MCS 17 : Supported
    MCS 18 : Supported
    MCS 19 : Supported
    MCS 20 : Supported
    MCS 21 : Supported
    MCS 22 : Supported
    MCS 23 : Supported
    MCS 24 : Supported
    MCS 25 : Supported
    MCS 26 : Supported
    MCS 27 : Supported
    MCS 28 : Supported
    MCS 29 : Supported
    MCS 30 : Supported
    MCS 31 : Supported
  802.11n Status:
    A-MPDU Tx:
      Priority 0                              : Enabled
      Priority 1                              : Disabled
      Priority 2                              : Disabled
      Priority 3                              : Disabled
      Priority 4                              : Enabled
      Priority 5                              : Enabled
      Priority 6                              : Disabled
      Priority 7                              : Disabled
      Aggregation scheduler                   : Enabled
      Realtime timeout                        : 10
    A-MSDU Tx:
      Priority 0                              : Enable
      Priority 1                              : Enable
      Priority 2                              : Enable
      Priority 3                              : Enable
      Priority 4                              : Enable
      Priority 5                              : Enable
      Priority 6                              : Disable
```

```
    Priority 7                              : Disable
  Guard Interval                            : Any
  Rifs Rx                                   : Enabled
Beacon Interval                             : 100
CF Pollable mandatory                       : Disabled
CF Poll Request Mandatory                   : Disabled
CFP Period                                  : 4
CFP Maximum Duration                        : 60
Default Channel                             : 1
Default Tx Power Level                      : 1
DTPC Status                                 : Enabled
Call Admission Limit                        :
G711 CU Quantum                             :
ED Threshold                                : -50
Fragmentation Threshold                     : 2346
RSSI Low Check                             : Disabled
RSSI Threshold                              : -127 dbm
PBCC Mandatory                              : unknown
Pico-Cell-V2 Status                         : unknown
RTS Threshold                               : 2347
Short Preamble Mandatory                    : Enabled
Short Retry Limit                           : 7
Legacy Tx Beamforming setting               : Disabled
Traffic Stream Metrics Status               : Disabled
Expedited BW Request Status                 : Disabled
EDCA profile type check                     : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM)        : Disabled
  Voice Stream-Size                         : 84000
  Voice Max-Streams                         : 2
  Voice Max RF Bandwidth                    : 75
  Voice Reserved Roaming Bandwidth          : 6
  Voice Load-Based CAC mode                 : Enabled
  Voice tspec inactivity timeout            : Enabled
CAC SIP-Voice configuration
  SIP based CAC                             : Disabled
  SIP call bandwidth                        : 64
  SIP call bandwith sample-size             : 20
Maximum Number of Clients per AP Radio      : 200


------------------ show ap dot11 5ghz network ------------------


802.11a Network                             : Enabled
11nSupport                                  : Enabled
  802.11a Low Band                          : Enabled
  802.11a Mid Band                          : Enabled
  802.11a High Band                         : Enabled
802.11a Operational Rates
  802.11a 6M                                : Mandatory
  802.11a 9M                                : Supported
  802.11a 12M                               : Mandatory
  802.11a 18M                               : Supported
  802.11a 24M                               : Mandatory
  802.11a 36M                               : Supported
  802.11a 48M                               : Supported
  802.11a 54M                               : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
```

```
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported
  MCS 6 : Supported
  MCS 7 : Supported
  MCS 8 : Supported
  MCS 9 : Supported
  MCS 10 : Supported
  MCS 11 : Supported
  MCS 12 : Supported
  MCS 13 : Supported
  MCS 14 : Supported
  MCS 15 : Supported
  MCS 16 : Supported
  MCS 17 : Supported
  MCS 18 : Supported
  MCS 19 : Supported
  MCS 20 : Supported
  MCS 21 : Supported
  MCS 22 : Supported
  MCS 23 : Supported
  MCS 24 : Supported
  MCS 25 : Supported
  MCS 26 : Supported
  MCS 27 : Supported
  MCS 28 : Supported
  MCS 29 : Supported
  MCS 30 : Supported
  MCS 31 : Supported
802.11n Status:
  A-MPDU Tx:
    Priority 0                          : Enabled
    Priority 1                          : Disabled
    Priority 2                          : Disabled
    Priority 3                          : Disabled
    Priority 4                          : Enabled
    Priority 5                          : Enabled
    Priority 6                          : Disabled
    Priority 7                          : Disabled
    Aggregation scheduler               : Enabled
    Realtime timeout                    : 10
  A-MSDU Tx:
    Priority 0                          : Enable
    Priority 1                          : Enable
    Priority 2                          : Enable
    Priority 3                          : Enable
    Priority 4                          : Enable
    Priority 5                          : Enable
    Priority 6                          : Disable
    Priority 7                          : Disable
  Guard Interval                        : Any
  Rifs Rx                               : Enabled
802.11ac                                : Enabled
  Frame burst                           : Automatic
802.11ac MCS Settings:
Beacon Interval                         : 100
CF Pollable mandatory                   : Disabled
CF Poll Request Mandatory               : Disabled
CFP Period                              : 4
CFP Maximum Duration                    : 60
Default Channel                         : 36
Default Tx Power Level                  : 1
DTPC Status                             : Enabled
Fragmentation Threshold                 : 2346
```

```
RSSI Low Check                           : Disabled
RSSI Threshold                           : -127 dbm
Pico-Cell-V2 Status                      : unknown
TI Threshold                             :
Legacy Tx Beamforming setting            : Disabled
Traffic Stream Metrics Status            : Disabled
Expedited BW Request Status              : Disabled
EDCA profile type check                  : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM)     : Disabled
  Voice Stream-Size                      : 84000
  Voice Max-Streams                      : 2
  Voice Max RF Bandwidth                 : 75
  Voice Reserved Roaming Bandwidth       : 6
  Voice Load-Based CAC mode              : Enabled
  Voice tspec inactivity timeout         : Enabled
CAC SIP-Voice configuration
  SIP based CAC                          : Disabled
  SIP call bandwidth                     : 64
  SIP call bandwith sample-size          : 20
Maximum Number of Clients per AP Radio   : 200


------------------ show ap dot11 24ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 558 seconds ago


------------------ show ap dot11 5ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 558 seconds ago
```

```
------------------ show ap auto-rf dot11 5ghz ------------------


------------------ show ap auto-rf dot11 24ghz ------------------


------------------ show ap config general ------------------



------------------ show ap dot11 5ghz optimized-roaming ------------------

802.11a OptimizedRoaming

  Mode                                : Disabled
  Reporting Interval                  : 90 seconds
  Rate Threshold                      : Disabled
  Hysteresis                          : 6 db


------------------ show ap rf-profile summary ------------------


Number of RF-profiles: 6

RF Profile Name                  Band     Description                            State
------------------------------------------------------------------------------------
Low_Client_Density_rf_5gh        5 GHz    pre configured Low Client Density rf Up
High_Client_Density_rf_5gh       5 GHz    pre configured High Client Density r Up
Low_Client_Density_rf_24gh       2.4 GHz  pre configured Low Client Density rf Up
High_Client_Density_rf_24gh      2.4 GHz  pre configured High Client Density r Up
Typical_Client_Density_rf_5gh    5 GHz    pre configured Typical Density rfpro Up
Typical_Client_Density_rf_24gh   2.4 GHz  pre configured Typical Client Densit Up


------------------ show ap fra ------------------

FRA State                                          : Disabled
FRA Sensitivity                                    : medium (95%)
FRA Interval                                       : 1 Hour(s)
  Last Run                                         : 2299 seconds ago
  Last Run time                                    : 0 seconds

AP Name              MAC Address       Slot ID  Current-Band      COF %      Suggested Mode
------------------------------------------------------------------------------------------

COF : Coverage Overlap Factor


------------------ show wireless band-select ------------------


Band Select Probe Response   : per WLAN enabling
Cycle Count                  : 2
Cycle Threshold (millisec)   : 200
Age Out Suppression (sec)    : 20
Age Out Dual Band (sec)      : 60
Client RSSI (dBm)            : -80
Client Mid RSSI (dBm)        : -80
```

```
------------------ show wireless  country  configure ------------------


Configured Country.....................   US - United States
Configured Country Codes
        US  - United States                 802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor


------------------ show wireless tag rf summary ------------------


Number of RF Tags: 1

RF tag name                     Description
------------------------------------------------------------------------
default-rf-tag                  default RF tag


------------------ show ap tag summary ------------------

Number of APs: 0


------------------ show ap status ------------------


------------------ show ap uptime ------------------

Number of APs: 0
```

show telemetry connection all

To view the telemetry connection all status, use the **show telemetry connection all** command.

show telemetry connection all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Example

This example show the telemetry connection all status in the privileged exec mode:

```
Device# show telemetry connection all

Telemetry connections

Index Peer Address               Port  VRF Source Address             State      State
Description
----- -------------------------- ----- --- -------------------------- ----------
--------------------
    0 70.0.0.132                  8184 0   70.0.0.2                   Active     Connection
 up
    1 70.0.0.132                  8004 0   70.0.0.2                   Active     Connection
 up
  395 172.19.20.125              25103 1 M 172.20.209.40              Connecting Connection
 request made to transport handler
```

show tunnel eogre global-configuration

To display the Ethernet over GRE (EoGRE) global configuration, use the **show tunnel eogre global-configuration** command.

show tunnel eogre global-configuration

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the EoGRE global configuration:

```
Device# show tunnel eogre global-configuration

Heartbeat interval       : 60
Max Heartbeat skip count : 3
Source Interface         : (none)
```

show tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain detailed** command.

show tunnel eogre domain detailed *domain-name*

Syntax Description

domain-name	EoGRE domain name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain detailed eogre_domain

Domain Name    : eogre_domain
 Primary GW    : Tunnel1
 Secondary GW  : Tunnel2
 Active GW     : Tunnel1
 Redundancy    : Non-Revertive
```

show tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain summary** command.

show tunnel eogre domain summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain summary

Domain Name          Primary GW   Secondary GW      Active GW      Redundancy
-------------------------------------------------------------------------------
domain1              Tunnel1      Tunnel2           Tunnel1        Non-Revertive
eogre_domain         Tunnel1      Tunnel2           Tunnel1        Non-Revertive
```

show tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway, use the **show tunnel eogre gateway summary** command.

show tunnel eogre gateway summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre gateway summary

Name               Type  Address                                    AdminState  State  Clients
-------------------------------------------------------------------------------------------------
Tunnel1             IPv4  9.51.1.11                                   Up          Up     0

Tunnel2             IPv4  9.51.1.12                                   Up          Down   0

Tunnel10            IPv6  fd09:9:8:21::90                             Down        Down   0

Tunnel11            IPv4  9.51.1.11                                   Up          Up     0

Tunnel12            IPv6  fd09:9:8:21::90                             Up          Down   0

Tunnel100           IPv4  9.51.1.100                                  Up          Down   0
```

show tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre gateway detailed** command.

show tunnel eogre gateway detailed *gateway-name*

Syntax Description

gateway-name	EoGRE gateway name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre domain detailed Tunnel1

Gateway : Tunnel1
 Mode   : IPv4
 IP     : 9.51.1.11
 Source : Vlan51 / 9.51.1.1
 State  : Up
 SLA ID : 56
 MTU    : 1480
 Up Time: 4 minutes 45 seconds

 Clients
  Total Number of Wireless Clients      : 0
 Traffic
  Total Number of Received Packets      : 0
  Total Number of Received Bytes        : 0
  Total Number of Transmitted Packets   : 0
  Total Number of Transmitted Bytes     : 0
 Keepalives
  Total Number of Lost Keepalives       : 0
  Total Number of Received Keepalives   : 5
  Total Number of Transmitted Keepalives: 5
  Windows                               : 1
  Transmitted Keepalives in last window : 2
  Received Keepalives in last window    : 2
```

show tunnel eogre manager stats global

To display the global tunnel manager statistics, use the **show tunnel eogre manager stats global** command.

show tunnel eogre manager stats global

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the global tunnel manager statistics:

```
Device# show tunnel eogre manager stats global

Tunnel Global Statistics
Last Updated                    : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                      : 6
  Domains                       : 2

EoGRE Flex Objects
  AP Gateways                   : 2
  AP Domains                    : 1
  AP Gateways HA inconsistencies : 0
  AP Domains HA inconsistencies  : 0

Config events
  IOS Tunnel updates            : 806
  IOS Domain updates            : 88
  Global updates                : 48
  Tunnel Profile updates        : 120
  Tunnel Rule updates           : 16
  AAA proxy key updates         : 0

AP events
  Flex AP Join                  : 1
  Flex AP Leave                 : 0
  Local AP Join                 : 0
  Local AP leave                : 0
  Tunnel status (rx)            : 4
  Domain status (rx)            : 1
  IAPP stats msg (rx)           : 3
  Client count (rx)             : 6
  VAP Payload msg (tx)          : 4
  Domain config (tx)            : 1
  Global config (tx)            : 1
  Client delete (tx)            : 1
```

```
  Client delete per domain (tx)  : 3
  DHCP option 82 (tx)            : 4

Client events
  Add-mobile                     : 2
  Run-State                      : 3
  Delete                         : 1
  Cleanup                        : 0
  Join                           : 2
  Plumb                          : 0
  Join Errors                    : 0
  HandOff                        : 0
  MsPayload                      : 2
  FT Recover                     : 0
  Zombie GW counter increase     : 0
  Zombie GW counter decrease     : 0
  Tunnel Profile reset           : 88
  Client deauth                  : 0
  HA reconciliation              : 0

Client Join Events
  Generic Error                  : 0
  MSPayload Fail                 : 0
  Invalid VLAN                   : 0
  Invalid Domain                 : 0
  No GWs in Domain               : 0
  Domain Shut                    : 0
  Invalid GWs                    : 0
  GWs Down                       : 0
  Rule Match Error               : 0
  AAA-override                   : 0
  Flex No Active GW              : 0
  Open Auth join attempt         : 2
  Dot1x join attempt             : 2
  Mobility join attempt          : 0
  Tunnel Profile not valid       : 2
  Tunnel Profile valid           : 2
  No rule match                  : 0
  Rule match                     : 2
  AAA proxy                      : 0
  AAA proxy accounting           : 0
  AAA eogre attributes           : 0
  Has aaa override               : 0
  Error in handoff payload       : 0
  Handoff AAA override           : 0
  Handoff no AAA override        : 0
  Handoff payload received       : 0
  Handoff payload sent           : 0

SNMP Traps
  Client                         : 0
  Tunnel                         : 2
  Domain                         : 0

IPC
  IOSd TX messages               : 0

Zombie Client
  Entries                        : 0
```

show tunnel eogre manager stats instance

To display the tunnel manager statistics for a specific WNCd instance, use the **show tunnel eogre manager stats instance** command.

show tunnel eogre manager stats instance *instance-number*

Syntax Description

instance-number	WNCd instance number.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the tunnel manager statistics for a specific WNCd instance:

```
Device# show tunnel eogre manager stats instance 0

Tunnel Manager statistics for process instance : 0
Last Updated                      : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                        : 6
  Domains                         : 2

EoGRE Flex Objects
  AP Gateways                     : 2
  AP Domains                      : 1
  AP Gateways HA inconsistencies  : 0
  AP Domains HA inconsistencies   : 0

Config events
  IOS Tunnel updates              : 102
  IOS Domain updates              : 11
  Global updates                  : 6
  Tunnel Profile updates          : 15
  Tunnel Rule updates             : 2
  AAA proxy key updates           : 0

AP events
  Flex AP Join                    : 1
  Flex AP Leave                   : 0
  Local AP Join                   : 0
  Local AP leave                  : 0
  Tunnel status (rx)              : 4
  Domain status (rx)              : 1
  IAPP stats msg (rx)             : 3
  Client count (rx)               : 6
  VAP Payload msg (tx)            : 4
```

```
  Domain config (tx)             : 1
  Global config (tx)             : 1
  Client delete (tx)             : 1
  Client delete per domain (tx)  : 3
  DHCP option 82 (tx)            : 4

Client events
  Add-mobile                     : 2
  Run-State                      : 3
  Delete                         : 1
  Cleanup                        : 0
  Join                           : 2
  Plumb                          : 0
  Join Errors                    : 0
  HandOff                        : 0
  MsPayload                      : 2
  FT Recover                     : 0
  Zombie GW counter increase     : 0
  Zombie GW counter decrease     : 0
  Tunnel Profile reset           : 11
  Client deauth                  : 0
  HA reconciliation              : 0

Client Join Events
  Generic Error                  : 0
  MSPayload Fail                 : 0
  Invalid VLAN                   : 0
  Invalid Domain                 : 0
  No GWs in Domain               : 0
  Domain Shut                    : 0
  Invalid GWs                    : 0
  GWs Down                       : 0
  Rule Match Error               : 0
  AAA-override                   : 0
  Flex No Active GW              : 0
  Open Auth join attempt         : 2
  Dot1x join attempt             : 2
  Mobility join attempt          : 0
  Tunnel Profile not valid       : 2
  Tunnel Profile valid           : 2
  No rule match                  : 0
  Rule match                     : 2
  AAA proxy                      : 0
  AAA proxy accounting           : 0
  AAA eogre attributes           : 0
  Has aaa override               : 0
  Error in handoff payload       : 0
  Handoff AAA override           : 0
  Handoff no AAA override        : 0
  Handoff payload received       : 0
  Handoff payload sent           : 0

SNMP Traps
  Client                         : 0
  Tunnel                         : 2
  Domain                         : 0

IPC
  IOSd TX messages               : 0

Zombie Client
  Entries                        : 0
```

show umbrella config

To view the Umbrella configuration details, use the **show umbrella config** command.

show umbrella config

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella configuration details:

```
Device# show umbrella config
Umbrella Configuration
=======================
   Token: 57CC80106C087FB1B2A7BAB4F2F4373C00247166
   OrganizationID: 1892929
   Local Domain Regex parameter-map name: dns_wl
   DNSCrypt: Enabled
  Public-key: B735:1140:206F:225D:3E2B:D822:D7FD:691E:A1C3:3CC8:D666:8D0C:BE04:BFAB:CA43:FB79

   UDP Timeout: 2 seconds
   Resolver address:
       1. 208.67.220.220
       2. 208.67.222.222
       3. 2620:119:53::53
       4. 2620:119:35::35
```

show umbrella deviceid

To view the device registration details, use the **show umbrella deviceid** command.

show umbrella deviceid

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the device registration details:

```
Device# show umbrella deviceid
Device registration details
Profile Name             Tag             Status            Device-id
GigabitEthernet0/0/0    guest          200 SUCCESS     010a470b042a072d
```

show umbrella deviceid detailed

To view the detailed description for the Umbrella device ID, use the **show umbrella deviceid detailed** command.

show umbrella deviceid *detailed*

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the detailed description for the Umbrella device ID:

```
Device# show umbrella deviceid detailed
Device registration details
 1.GigabitEthernet0/0/0
      Tag               : guest
      Device-id         : 010a470b042a072d
      Description       : Device Id recieved successfully
```

show umbrella dnscrypt

To view the Umbrella DNScrypt details, use the **show umbrella dnscrypt** command.

show umbrella dnscrypt

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella DNScrypt details:

```
Device# show umbrella dnscrypt
DNSCrypt: Enabled
  Public-key: B735:1140:206F:225D:3E2B:D822:D7FD:691E:A1C3:3CC8:D666:8D0C:BE04:BFAB:CA43:FB79

   Certificate Update Status:
        Last Successfull Attempt: 17:45:57 IST Nov 9 2017
   Certificate Details:
       Certificate Magic     : DNSC
       Major Version         : 0x0001
       Minor Version         : 0x0000
       Query Magic           : 0x713156774457306E
       Serial Number         : 1490391488
       Start  Time           : 1490391488 (03:08:08 IST Mar 25 2017)
       End Time              : 1521927488 (03:08:08 IST Mar 25 2018)
       Server Public Key     :
E7F8:4477:BF89:1434:1ECE:23F0:D6A6:6EB9:4F45:3167:D71F:80BB:4E80:A04F:F180:F778
       Client Secret Key Hash:
F1A5:1993:F729:5416:53B7:94E3:6509:8182:A708:0561:8050:6CE0:DFA1:5C94:6EE4:0010
       Client Public key     :
BC6D:3758:48B6:120B:D2F5:F25B:2979:564D:F52C:5EFA:B0BD:76FE:3CD6:828B:44D2:FF3A
       NM key Hash           :
1FF7:2E1E:EFB9:7987:9CB4:3EF8:A25B:4DAD:10FC:7DF7:6985:6E8E:6E4D:D56A:1C70:B9EB
```

show vlan

To display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch, use the **show vlan** command in user EXEC mode.

show vlan [**brief** | **group** | **id** *vlan-id* | **mtu** | **name** *vlan-name* | **remote-span** | **summary**]

Syntax Description

brief	(Optional) Displays one line for each VLAN with the VLAN name, status, and its ports.
group	(Optional) Displays information about VLAN groups.
id *vlan-id*	(Optional) Displays information about a single VLAN identified by the VLAN ID number. For *vlan-id*, the range is 1 to 4094.
mtu	(Optional) Displays a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN. **Note** Traceback occurs in the VLAN CLI parser when Controller-PI does VLAN lookup for each interface.
name *vlan-name*	(Optional) Displays information about a single VLAN identified by the VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.
remote-span	(Optional) Displays information about Remote SPAN (RSPAN) VLANs.
summary	(Optional) Displays VLAN summary information.

Note The **ifindex** keyword is not supported, even though it is visible in the command-line help string.

Command Default

None

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

In the **show vlan mtu** command output, the MTU_Mismatch column shows whether all the ports in the VLAN have the same MTU. When yes appears in the column, it means that the VLAN has ports with different MTUs, and packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have an SVI, the hyphen (-) symbol appears in the SVI_MTU column. If the MTU-Mismatch column displays yes, the names of the ports with the MinMTU and the MaxMTU appear.

This is an example of output from the **show vlan** command. See the table that follows for descriptions of the fields in the display.

```
Device> show vlan
VLAN Name                             Status    Ports
---- -------------------------------- --------- -------------------------------
1    default                          active    Gi1/0/2, Gi1/0/3, Gi1/0/4
                                                Gi1/0/5, Gi1/0/6, Gi1/0/7
                                                Gi1/0/8, Gi1/0/9, Gi1/0/10
                                                Gi1/0/11, Gi1/0/12, Gi1/0/13
                                                Gi1/0/14, Gi1/0/15, Gi1/0/16
                                                Gi1/0/17, Gi1/0/18, Gi1/0/19
                                                Gi1/0/20, Gi1/0/21, Gi1/0/22
                                                Gi1/0/23, Gi1/0/24, Gi1/0/25
                                                Gi1/0/26, Gi1/0/27, Gi1/0/28
                                                Gi1/0/29, Gi1/0/30, Gi1/0/31
                                                Gi1/0/32, Gi1/0/33, Gi1/0/34
                                                Gi1/0/35, Gi1/0/36, Gi1/0/37
                                                Gi1/0/38, Gi1/0/39, Gi1/0/40
                                                Gi1/0/41, Gi1/0/42, Gi1/0/43
                                                Gi1/0/44, Gi1/0/45, Gi1/0/46
                                                Gi1/0/47, Gi1/0/48
2    VLAN0002                         active
40   vlan-40                          active
300  VLAN0300                         active
1002 fddi-default                     act/unsup
1003 token-ring-default               act/unsup
1004 fddinet-default                  act/unsup
1005 trnet-default                    act/unsup

VLAN Type  SAID       MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
---- ----- ---------- ----- ------ ------ -------- ---- -------- ------ ------
1    enet  100001     1500  -      -      -        -    -        0      0
2    enet  100002     1500  -      -      -        -    -        0      0
40   enet  100040     1500  -      -      -        -    -        0      0
300  enet  100300     1500  -      -      -        -    -        0      0
1002 fddi  101002     1500  -      -      -        -    -        0      0
1003 tr    101003     1500  -      -      -        -    -        0      0
1004 fdnet 101004     1500  -      -      -        ieee -        0      0
1005 trnet 101005     1500  -      -      -        ibm  -        0      0
2000 enet  102000     1500  -      -      -        -    -        0      0
3000 enet  103000     1500  -      -      -        -    -        0      0

Remote SPAN VLANs
------------------------------------------------------------------------------
2000,3000

Primary Secondary Type              Ports
------- --------- ----------------- ------------------------------------------
```

Table 22: show vlan Command Output Fields

Field	Description
VLAN	VLAN number.
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.

Field	Description
Type	Media type of the VLAN.
SAID	Security association ID value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.
Trans1	Translation bridge 1.
Trans2	Translation bridge 2.
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.

This is an example of output from the **show vlan summary** command:

```
Device> show vlan summary
Number of existing VLANs              : 45
 Number of existing VTP VLANs         : 45
 Number of existing extended VLANS    : 0
```

This is an example of output from the **show vlan id** command:

```
Device# show vlan id 2
VLAN Name                             Status    Ports
---- -------------------------------- --------- -------------------------------
2    VLAN0200                         active    Gi1/0/7, Gi1/0/8
2    VLAN0200                         active    Gi2/0/1, Gi2/0/2

VLAN Type  SAID       MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
---- ----- ---------- ----- ------ ------ -------- ---- -------- ------ ------
2    enet  100002     1500  -      -      -        -    -        0      0

Remote SPAN VLANs
------------------------------------------------------------------------------
Disabled
```

show vlan access-map

To display information about a particular VLAN access map or for all VLAN access maps, use the **show vlan access-map** command in privileged EXEC mode.

show vlan access-map [*map-name*]

Syntax Description

map-name	(Optional) Name of a specific VLAN access map.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This is an example of output from the **show vlan access-map** command:

```
Device# show vlan access-map
Vlan access-map "vmap4"  10
  Match clauses:
    ip  address: al2
  Action:
    forward
Vlan access-map "vmap4"  20
  Match clauses:
    ip  address: al2
  Action:
    forward
```

show vlan filter

To display information about all VLAN filters or about a particular VLAN or VLAN access map, use the **show vlan filter** command in privileged EXEC mode.

show vlan filter {**access-map** *name* | **vlan** *vlan-id*}

Syntax Description

access-map *name*	(Optional) Displays filtering information for the specified VLAN access map.
vlan *vlan-id*	(Optional) Displays filtering information for the specified VLAN. The range is 1 to 4094.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This is an example of output from the **show vlan filter** command:

```
Device# show vlan filter
VLAN Map map_1 is filtering VLANs:
  20-22
```

show vlan group

To display the VLANs that are mapped to VLAN groups, use the **show vlan group** command in privileged EXEC mode.

show vlan group [**group-name** *vlan-group-name* [**user_count**]]

Syntax Description

group-name *vlan-group-name*	(Optional) Displays the VLANs mapped to the specified VLAN group.
user_count	(Optional) Displays the number of users in each VLAN mapped to a specified VLAN group.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The **show vlan group** command displays the existing VLAN groups and lists the VLANs and VLAN ranges that are members of each VLAN group. If you enter the **group-name** keyword, only the members of the specified VLAN group are displayed.

This example shows how to display the members of a specified VLAN group:

show vrrp events

To display Virtual Router Redundancy Protocol (VRRP) events, use the **show vrrp events** command.

show vrrp events

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Usage Guidelines

VRRP commands are displayed only in ME mode; it is hidden in other AP modes.

Examples

This example shows how to view the VRRP events:

```
Device# show vrrp events

VRRP Events:
Dec 7 2019 01:17:23: Current state : backup, My Eth : A4:53:0E:7B:CD:84, event : VRRP Element
 is started. Start
sending KeepAlive Pkts to check if Ether link is up
Dec 7 2019 01:17:28: Current state : backup, My Eth : A4:53:0E:7B:CD:84, event : Detected
Link is up. Now
waiting for 30 seconds to participate in VRRP election
Dec 7 2019 01:18:01: Current state : master, My Eth : A4:53:0E:7B:CD:84, event : Current
master
(00:00:00:00:00:00) went down (lost 3 advertisement). Moving to master state. And starting
 election
Dec 7 2019 01:18:05: Current state : master, My Eth : A4:53:0E:7B:CD:84, event : Launched
controller process on
this ap
```

show vrrp statistics

To display the Virtual Router Redundancy Protocol (VRRP) statistics, use the **show vrrp statistics** command in privileged EXEC mode.

show vrrp statistics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Usage Guidelines

VRRP commands are displayed only in ME mode; it is hidden in other AP modes.

Examples

This example shows how to view the VRRP statistics:

```
Device# show vrrp statistics

VRRP Statistics :
VRRP Statistics :
Invalid VRRP packets recvd:0
Number of incoming VRRP Pkts:0
Number of VRRP Pkts transmitted:148054
Number of VRRP Pkts recvd from Master:0
Number of VRRP Pkts recvd in Init state:0
Number of VRRP Pkts with STOP Priority:0
```

show vrrp status

To display the Virtual Router Redundancy Protocol (VRRP) status, use the **show vrrp status** command.

show vrrp status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Usage Guidelines

VRRP commands are displayed only in ME mode; it is hidden in other AP modes.

Examples

This example shows how to view the VRRP status:

```
Device# show vrrp status

 VRRP Status : MASTER
Preferred AP : 00:00:00:00:00:00
My Eth : A4:53:0E:7B:CD:84
AP Type : VANCOUVER
VRRP Instance : vrid state priority vrrp_ip_vlans adver_ival
1 master 1 0.0.0.0:0 3.000000
```

show wireless active testing configuration

To view the status of wireless active testing configuration parameters, use the **show wireless active testing configuration** command.

show wireless active testing configuration

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

This example shows the status of wireless active testing configuration parameters in the privileged EXEC mode:

```
Device# show wireless active testing configuration

Wireless Active Testing (WAT) Management - Configuration
============================================================
Administrative State                          : Enabled

ThousandEyes Endpoint Agent
---------------------------
  Connection String                           :
S3FD77CY+VOrk+4fbbgjBap3gUfZeQWyxSVMna1EpnsJgxX/mZ9k3ycRPXFFcTzPAMbkdMRaAIHqeETsXX2v+EIn2qgNhX3HBhL6I1P3e+8=

  Download URL                                :
https://downloads.thousandeyes.com/endpointagent/iox/arm64/latest.tar
```

show wireless afc ap

To check whether Automated Frequency Coordination (AFC) service request can be sent, use the **show wireless afc ap** command.

show wireless afc ap

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to check whether the AFC service request can be sent:

```
Device# show wireless afc ap

-------------------------------------------------------------------------------------------------------------
AP Name            Radio MAC        AFC          Power Mode  Current          AP        6GHz
Radio   RF-Profile   RF-Profile    AFC Country  Location  Height
                                    Status       Capability  Power Mode  Admin State  Admin
 State  Admin State  tx-power std  allowed      known     known
-------------------------------------------------------------------------------------------------------------

APCC9C.3EF1.1620   10f9.20fe.36a0   Inactive    SP/LPi      LPi         Up           Down
        Yes           Yes           Yes          Yes       Yes
AP687D.B45C.17AC   687d.b45f.1af0   Active      SP/LPi      SP          Up           Up
        Yes           Yes           Yes          Yes       Yes
AP-ARCTIC          fc58.9a18.c890   Inactive    SP/LPi      LPi         Up           Up
        Yes           Yes           Yes          Yes       No
```

show wireless afc channels

To view the Automated Frequency Coordination (AFC) system's channel information, use the **show wireless afc channels** command.

show wireless afc channels { **20mhz** | **40mhz** | **80mhz** | **160mhz** }

Syntax Description

20mhz	Displays 20MHz-band channel information.
40mhz	Displays 40MHz-band channel information.
80mhz	Displays 80MHz-band channel information.
160mhz	Displays 1600MHz-band channel information.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the AFC system's channel information:

```
Device# show wireless afc channels 20mhz

802.11 6ghz   :  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1  1

Channel IDs   :  1  1  2  2  2  3  3  4  4  4  5  5  6  6  6  7  7  8  8  8  9  9  0  0  0

(20MHz width) :  1  5  9  3  7  1  5  9  3  7  1  5  9  3  7  1  5  9  3  7  1  5  9  3  7

------------------:+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--+--
AP687D.B45C.08F0 : 36 33 36 36 35 36 36 36 26 27 36 36 36 36 36 36 33 33 36 36 36 36 36 36
 36
AP687D.B45C.1824 : 36 33 36 36 35 36 36 36 24 26 27 36 36 36 36 36 33 33 36 36 36 36 36 36
 36

! Due to space constraints, the channel IDs (for 2-digit and 3-digit channel IDs)
! are given vertically in the output. The output is also truncated to fit the page width.
```

show wireless afc geolocation

To view the geolocation information of the Automated Frequency Coordination (AFC) system, use the **show wireless afc geolocation** command.

show wireless afc geolocation

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the geolocation information of the AFC system:

```
Device# show wireless afc geolocation

AP Name           Radio MAC      Location    Longitude   Latitude     Major-axis Minor-axis
 Orientation Area-of-uncert Height Height   Uncertainty
                                  Type        (degrees)   (degrees)    (meters)   (meters)
   (degrees)    (sq. meters)    Type    (meters) (meters)
-------------------------------------------------------------------------------------------
AP687D.B45C.16A4   687d.b45f.0e90 Lin Polygon -122.400140 37.794910
               1122           AGL    150      6
                                                          -122.399340 37.795020
                                                          -122.399180 37.794390
                                                          -122.400040 37.794270
AP687D.B45C.17AC   687d.b45f.1af0 Ellipse     -73.977760  40.760168    9          9
   5.340000    254            AGL    129      3


! The afc geolocation information given in the output refers to coordinates to be used for
 future AFC requests.
! They do not represent the coordinates used by past AFC requests; for such info see AFC
responses in 'show wireless afc response' command.
.
.
.
```

show wireless afc request

To view the status of the request sent to the Automated Frequency Coordination (AFC) system, use the **show wireless afc request** command.

show wireless afc request

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the status request information sent to the AFC system:

```
Device# show wireless afc request

-----------------------------------------------------------------------------------------------

                                    Last AFC Request Sent to AFC Service:
AP Name               Radio MAC      Request Id           AFC Request Status   Status
Timestamp
-----------------------------------------------------------------------------------------------
APCC9C.3EF1.1620      10f9.20fe.36a0 12195125900336565035 Response Received    08/07/2023
13:20:39
AP687D.B45C.17AC      687d.b45f.1af0 12195125900336565037 Response Received    08/07/2023
16:07:01
AP687D.B45C.321B      fc58.9a18.c840 12195125900336566836 Sent                 08/07/2023
17:36:11
AP687D.B45C.321F      fc58.9a18.c850 12195125900336566832 Timeout              08/07/2023
17:36:08
.
.
.
```

show wireless afc response

To view Automated Frequency Coordination (AFC) system's response to requests, use the **show wireless afc response** command.

show wireless afc response

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the response information of the AFC system:

```
Device# show wireless afc response
-------------------------------------------------------------------------------------------------------------
AP Name                  Radio MAC        Request Id      Expire Time           Last Rcvd
    Time       Response Code
-------------------------------------------------------------------------------------------------------------
AP687D.B45C.16A4         687d.b45f.0e90     1             11/14/2021 21:56:29   11/14/2021
   17:56:29     SUCCESS
AP687D.B45C.17AC         687d.b45f.1af0     2             11/14/2021 21:56:30   11/14/2021
   17:56:29     SUCCESS
AP687D.B45C.2276         687d.b45f.3190     3             11/14/2021 21:56:30   11/14/2021
   17:56:29     INVALID VALUE
```

show wireless afc statistics

To view the Automated Frequency Coordination (AFC) system's statistical information, use the **show wireless afc statistics** command.

show wireless afc statistics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.13.1	This command was introduced.

Examples

The following example shows how to view the AFC system's statistics information:

```
Device# show wireless afc statistics

Total number of 6GHz APs : 4
Number of APs requiring AFC service : 4
Messages sent to AFC : 229
Successful messages received from AFC : 229
Errored AFC messages : 0
AFC messages pending : 0
Last InquiredChannel message sent:
requestId : 12195125900336565222
AP MAC : 10f9.20fd.54e0
Sent timestamp : 08/09/2023 15:14:20
Last InquiredChannel message received:
requestId : 12195125900336565222
AP MAC : 10f9.20fd.54e0
Received timestamp : 08/09/2023 15:14:21
Minimum response time (ms) : 337
Maximum response time (ms) : 40842
Average response time (ms) : 1315
Health check query : Idle
Health check status : OK
Health check timestamp : 08/09/2023 14:58:50
Number of times health check went down : 0

Health check event history
Timestamp #Times Event State RC Context
--------------------------- -------- ---------------------- ------------------------------
08/09/2023 14:58:50.348063 53 Response received OK 0
08/09/2023 14:58:48.271529 58 Scheduled 0 Timer: 3600s
08/09/2023 14:58:48.271507 53 Sent 0
08/07/2023 09:33:55.990412 6 Not sent No token 0
```

show wireless stats ap history

To verify historical statistics of an AP, use the **show wireless stats ap history** command.

show wireless stats ap history

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC#

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

This example shows how to verify the statistics of the access point hisory:

```
Device# show wireless stats ap history
AP Name             Radio MAC       Event      Time               Recent      Disconnect
Reason          Disconnect
                                                                  Disconnect  Reason
               Count
                                                                  Time
-------------------------------------------------------------------------------------------------
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/26/21 10:11:52  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/26/21 10:05:18  NA          Heart beat
timer expiry    1
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/22/21 17:00:39  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/22/21 16:54:54  NA          Heart beat
timer expiry    1
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/21/21 23:01:17  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/21/21 22:56:21  NA          Image Download
 Success     1
```

show wireless stats ap join summary

To verify the statistics of the access point join summary, use the **show wireless stats ap join summary** command.

show wireless stats ap join summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

This example shows how to verify the statistics of the access point join summary:

```
Device# show wireless stats ap join summary
Number of APs: 001

Base MAC        Ethernet MAC    AP Name           IP Address  Status  Last           Last
                                                                      Failure Phase
Disconnect Reason
-----------------------------------------------------------------------------------------------------
002a.1075.47c0  002a.104d.c9fc  AP002a.104d.c9fc  8.9.10.222  Joined   Run            High
 CPU usage
003a.1475.57c0  002a.104d.c9fc  AP003a.144d.59fc  7.8.09.111  Joined   Run            High
 Memory usage
```

show wireless stats ap join summary sort

To view the sorted wireless statistics access point (AP) join summary, use the **show wireless stats ap join summary sort** command.

show wireless stats ap join summary sort

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Usage Guidelines

Wireless AP statistics can be sorted in ascending or descending order by AP name.

- Ascending: Displays the ten APs from the bottom.
- Descending: Displays the APs from the top.
- Name: Displays the APs list sorted by name.

Examples

This example shows how to view the sorted wireless statistics AP join summary:

```
Device# show wireless stats ap join summary sort
Number of APs: 8

Base MAC        Ethernet MAC      AP Name                                IP Address   Status
Last Failure Phase Last Disconnect Reason
-----------------------------------------------------------------------------------------------
7872.5dee.4960  7872.5ded.cb74   4800-abcdefghijklmnopqrstuvwxyz1   1.11.22.11  Joined
Image-Download     Image Download Success
10f9.2077.6140  10f9.2076.2c58   9105-abcdefghijklmnopqrstuvwxyz1   1.11.22.11  Joined
Image-Download     Image Download Success
00ee.ab18.bf00  7069.5a74.9670   9115-abcdefghijklmnopqrstuvwxyz1   1.11.22.11  Joined
Image-Download     Image Download Success
1416.9d82.ef40  2c57.4152.5e60   9130-abcdefghijklmnopqrstuvwxyz1   1.11.22.11  Joined
Image-Download     Image Download Success
00d7.8f4e.7040  002a.1087.d68a   AP2800                             1.11.22.11  Joined
Config             DTLS close alert from peer
687d.b45e.3ed0  687d.b45c.0554   AP687D.B45C.0554                   1.11.22.11  Joined
Image-Download     Image Download Success
687d.b45e.4c50  687d.b45c.0674   AP687D.B45C.0674                   1.11.22.11  Joined
Config             DTLS close alert from peer
687d.b45e.53d0  687d.b45c.0714   AP687D.B45C.0714                   1.11.22.11  Joined
Config             DTLS close alert from peer
```

show wireless stats ap packet

To verify the CAPWAP control packets aggregated in the controller, use the **show wireless stats ap packet** command.

show wireless stats ap packet

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.14.1	This command was introduced.

Examples

The following command displays the CAPWAP control packets aggregated in the controller.

```
Device# show wireless stats ap packet

Packet stats

Capwap Control Packets Received* : 11183016
Capwap Data Keep Alive Packets Received : 160399
Capwap Data DOT1X EAP Packets Received: 549
Capwap Data DOT1X Mgmt Packets Received: 6003
Capwap Data DOT1X Key Type Packets Received: 0
Capwap Data DOT1X Control Packets Received: 0
Capwap Data ARP Packets Received: 0
Capwap Data IP Packets Received: 0
Capwap Data IPV6 Packets Received: 0
Capwap Data RRM Packets Received: 0
Capwap Data DHCP Packets Received: 0
Capwap Data RFID Packets Received: 0
Capwap Data IAPP Packets Received: 2531939
Capwap Dgram Input Errors : 0
Capwap Discovery Packets Received : 22299
Capwap Discovery Dgram Input Errors : 0
Aggregated Capwap Control Packets Sent: 119337
**** Note: Capwap control packets exclude discovery/primary discovery packets ****
```

show wireless stat redundancy statistics client-recovery mobilityd

To view the statistics of Mobilityd configuration database, use the **show wireless stat redundancy statistics client-recovery mobilityd** command.

show wireless stat redundancy statistics client-recovery mobilityd

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the statistics of Mobilityd configuration database:

```
Device# show wireless stat redundancy statistics client-recovery mobilityd

Mobility Client Deletion Reason Statistics
------------------------------------------
Mobility Incomplete State         : 0
Inconsistency in WNCD & Mobility  : 0
Partial Delete                    : 0
General statistics
--------------------
```

show wireless stat redundancy statistics client-recovery sisf

To view the statistics for Switch Integrated Security Features (SISF) configuration database, use the **show wireless stat redundancy statistics client-recovery sisf** command.

show wireless stat redundancy statistics client-recovery sisf

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the statistics for SISF configuration database:

```
Device# show wireless stat redundancy statistics client-recovery sisf
Client SSO statistics for SISF
------------------------------
Number of recreate attempted post switchover    : 0
Number of recreate succeeded post switchover    : 0
Number of recreate failed because of no mac     : 0
Number of recreate failed because of no ip      : 0
Number of ipv4 entry recreate success           : 0
Number of ipv4 entry recreate failed            : 0
Number of ipv6 entry recreate success           : 0
Number of ipv6 entry recreate failed            : 0
Number of partial delete received               : 0
Number of client purge attempted                : 0
Number of heap and db entry purge success       : 0
Number of purge success for db entry only       : 0
Number of client purge failed                   : 0
Number of garp sent                             : 0
Number of garp failed                           : 0
Number of IP table create callbacks on standby  : 0
Number of IP table modify callbacks on standby  : 0
Number of IP table delete callbacks on standby  : 0
Number of MAC table create callbacks on standby : 0
Number of MAC table modify callbacks on standby : 0
Number of MAC table delete callbacks on standby : 0
```

show wireless stat redundancy client-recovery wncd

To view the redundancy configuration statistics for all the Wireless Network Control Daemon (WNCd) instances, use the **show wireless stat redundancy client-recovery wncd** command.

show wireless stat redundancy client-recovery wncd { *instance-id* | **all** }

Syntax Description

instance-id	Instance ID. Valid values range from 0 to 7.
all	Specifies the statistics for all WNCd instances.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the redundancy configuration statistics for all the WNCd instances:

```
Device# show wireless stat redundancy statistics client-recovery wncd all

Client SSO statistics
---------------------
No. of Clients                            : 0
No. of Clients recovered successfully     : 0
No. of Clients failed to recover          : 0
No. of Reconcile messages received from AP : 0
WNCD instance  : 0
Reconcile messages received from AP                   : 0
Reconcile clients received from AP                    : 0
Recreate attempted post switchover                    : 0
Recreate attempted by SANET                           : 0
Recreate attempted by DOT1x                           : 0
Recreate attempted by SISF                            : 0
Recreate attempted by SVC CO                          : 0
Recreate attempted by Unknown module                  : 0
Recreate succeeded post switchover                    : 0
Recreate Failed post switchover                       : 0
Recreate Failure in mmif                              : 0
Recreate Failure in co                                : 0
Recreate Failure in sanet                             : 0
Recreate Failure in authmgr                           : 0
Recreate Failure in dot1x                             : 0
Recreate Failure in mab                               : 0
Recreate Failure in sanet_accounting                  : 0
Recreate Failure in sisf                              : 0
Recreate Failure in web auth                          : 0
Recreate Failure in lisp                              :
Recreate Failure in ipv6                              : 0
Recreate Failure in qos                               : 0
```

show wireless band-select

To display the status of the band-select configuration, use the **show wireless band-select** command in privileged EXEC mode.

show wireless band-select

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless band-select** command:

```
Device# show wireless band-select
Band Select Probe Response    : per WLAN enabling
Cycle Count                   : 2
Cycle Threshold (millisec)    : 200
Age Out Suppression (sec)     : 20
Age Out Dual Band (sec)       : 60
Client RSSI (dBm)             : 80
```

show wireless certification config

To display the wireless certification configuration summary, use the **show wireless certification config** command.

show wireless cerification config

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Example

This example shows how to display the wireless certification configuration summary:

```
Device# show wireless certification config
Wireless Certification Configurations

WLANCC                                    : Not Configured
FIPS                                      : Not Configured

AP DTLS Version                           : DTLS v1.0 - v1.2
AP DTLS Cipher Suite List:

                          Ciphersuite (Implicit list)
--------------------------------------------------------------------------------
                          AES128-SHA
                          DHE-RSA-AES128-SHA
                          DHE-RSA-AES256-SHA
                          DHE-RSA-AES256-SHA256
                          ECDHE-RSA-AES128-GCM-SHA256
                          ECDHE-ECDSA-AES128-GCM-SHA256
                          ECDHE-ECDSA-AES256-GCM-SHA384
The output can vary depending on the various security modes and AP DTLS configurations.
```

show wireless client

To see the summary of the classified devices, use the **show wireless client** command.

show wireless client device {**cache** | **count** | **summary** } | **{steering**}[**chassis** {*chassis-number* | **active** | **standby** }]**R0**

Syntax Description

device	Shows classified devices.
steering	Wireless client steering information
cache	Shows the cached classified device summary.
count	Shows the wireless device count.
summary	Shows the active classified device summary.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the summary of the classified devices:

```
Device# show wireless client device summary
```

show wireless client mac-address

To view detailed information of a client using its mac-address, use the **show wireless client mac-addressdetail** command.

show wireless client mac-address *mac-address* **detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

mac-address	Client MAC address.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The Client Scan Reports section in the output of the **show wireless client mac-address detail** is populated only for the following Apple devices:

- Any iPhone 7 and running iOS 11.0 or higher
- Any iPad after iPad Pro (1st gen, 12.9-inch, 2015) and running iOS 11.0 or higher

Other client devices, even if it supports 802.11k or is Wi-Fi Agile Multiband (MBO) certified, are not currently supported to populate the Client Scan Reports section.

Client ACLs shown under **show wireless client mac-address** <*mac address*> **detail** are ACLs applied on the client in Flexconnect local authentication case with MAB+Web authentication WLAN with AAA override enabled. This is applicable only for Express Wi-Fi by Facebook Policy on Controller. For more information about Facebook policy, see Express Wi-Fi by Facebook.

From Cisco IOS XE Amsterdam 17.3.1 onwards, the controller retains client session for 10 seconds. This feature is applicable for clients in the RUN state and is supported on central authentication with local and flex mode.

In idle state, 10 sec represents idle state timeout and 09 sec represent remaining time out of 10 sec. An example is given below:

```
Idle state timeout : 10 sec (Remaining time: 09 sec)
```

Examples

The following example shows how to see detailed client information using its MAC address:

```
Device# show wireless client mac-address 98-XX-7B-XX-EF-XX detail
```

show wireless client mac-address (Call Control)

To view call control information related to clients, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **call-control call-info**

Syntax Description

mac-address	The client MAC address.
call-control call-info	Displays the call control and IP-related information about a client.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display call control and IP-related information about a client:

```
Device# show wireless client mac-address  30e4.db41.6157 call-control call-info
Client MAC Address        : 30E4DB416157

Call 1 Statistics

Uplink IP Address         : 209.165.200.225
Downlink IP Address       : 209.165.200.226
Uplink Port               : 29052
Downlink Port             : 27538
Call ID                   : c40acb4d-3b3b0.3d27da1e-356bed03
Called Party              : sip:1011
Calling Party             : sip:1012
Priority                  : 6
Call On Hold              : false
Call Duration             : 30

Call 2 Statistics

No Active Call
```

show wireless client mac-address (TCLAS)

To view information about TCLAS and user priority, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **tclas**

Syntax Description

mac-address	The client MAC address.
tclas	Displays TCLAS and user priority-related information about a client.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the TCLAS and user priority-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 tclas
MAC Address      UP TID Mask Source IP Addr  Dest IP Addr    SrcPort DstPort Proto
-------------------------------------------------------------------------------
30e4.db41.6157    4   4   95 167838052       2164326668      5060     5060      6
30e4.db41.6157    6   1   31 0               2164326668      0        27538    17
```

show wireless client mac-address mobility history

To see roam history of an active client in subdomain, use the **show wireless client mac-address** *mac-address* **mobility history** command.

show wireless client mac-address *mac-address* **mobility history**[**chassis** {*chassis-number* | **active** | **standby**} **R0**] | **events** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]]

Syntax Description

mac-address	MAC address of the client.
chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the client in Route-processor slot 0.
standby R0	Standby instance of the client in Route-processor slot 0.
events	Shows client FSM event history.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

This example shows how to see roam history of an active client in subdomain:

```
Device# show wireless client mac-address 00:0d:ed:dd:35:80 mobility history
```

show wireless client mac-address stats latency

To view a wireless client's statistics using the client's MAC address, use the **show wireless client mac-address** *mac-address* **stats latency** command.

show wireless client mac-address *mac-address* **stats latency** [**chassis** { *chassis-number* | **active** | **standby** } **R0**]

Syntax Description

mac-address	Client MAC address.
stats	Specifies the statistics of the wireless client's MAC address.
latency	Specifies the latency statistics of the wireless client's MAC address.
chassis	Specifies the chassis for statistics latency.
chassis-number	Chassis number, which can be either 1 or 2.
active	Specifies an active instance.
standby	Specifies a standby instance.
R0	Specifies the route processor for Slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to view the statistics of a wireless client using its MAC address:

```
Device# show wireless client mac-address aaaa.bbbb.cccc stats latency
```

show wireless client summary

To display a summary of active clients associated with the controller, use the **show wireless client summary** command in privileged EXEC mode.

show wireless client summary

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The following is sample output from the **show wireless client summary** command:

Use the **show wireless exclusionlist** command to display clients on the exclusion list.

```
Device# show wireless client summary

Number of Clients: 1

MAC Address       AP Name                Type ID  State  Protocol  Method  Role
------------------------------------------------------------------------------
6c40.0899.0466    9115i-r4-sw2-te1-0-37  WLAN 7   Run    11ac      None    Local
```

show wireless client timers

To display 802.11 system timers, use the **show wireless client timers** command in privileged EXEC mode.

show wireless client timers

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless client timers** command:

```
Device# show wireless client timers
 Authentication Response Timeout (seconds)      : 10
```

show wireless country

To display the configured country and the radio types supported, use the **show wireless country** command in privileged EXEC mode.

show wireless country {**channels** | **configured** | **supported** [**tx-power**]}

Syntax Description

channels	Displays the list of possible channels for each band, and the list of channels allowed in the configured countries.
configured	Display configured countries.
supported tx-power	Displays the list of allowed Tx powers in each supported country.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless country channels** command:

```
Device# show wireless country channels
  Configured Country.............................: US  - United States
      KEY: * = Channel is legal in this country and may be configured manually.
           A = Channel is the Auto-RF default in this country.
           . = Channel is not legal in this country.
           C = Channel has been configured for use by Auto-RF.
           x = Channel is available to be configured for use by Auto-RF.
         (-,-) = (indoor, outdoor) regulatory domain allowed by this country.
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
    802.11bg     :
    Channels     :                   1 1 1 1 1
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-A   ,-AB  )  US  :  A * * * * A * * * * A . . .
 Auto-RF         : . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 802.11a         :                         1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
 Channels        : 3 3 3 4 4 4 4 4 5 5 6 6 0 0 0 1 1 2 2 2 3 3 4 4 5 5 6 6
                 : 4 6 8 0 2 4 6 8 2 6 0 4 0 4 8 2 6 0 4 8 2 6 0 9 3 7 1 5
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-A   ,-AB  )  US  :  . A . A . A . A A A A A * * * * * . . . * * * A A A A *
 Auto-RF         : . . . . . . . . . . . . . . . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 4.9GHz 802.11a  :
   Channels      :                   1 1 1 1 1 1 1 1 1 1 2 2 2 2 2 2 2
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 US (-A   ,-AB  ): * * * * * * * * * * * * * * * * * * * A * * * * * A
 Auto-RF         : . . . . . . . . . . . . . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
```

The following is sample output from the **show wireless country configured** command:

```
Device# show wireless country configured
 Configured Country.............................: US  - United States
 Configured Country Codes
        US  - United States : 802.11a Indoor,Outdoor/ 802.11b / 802.11g
```

The following is sample output from the **show wireless country supported tx-power** command:

```
Device# show wireless country supported tx-power
      KEY: ##    = Tx Power in dBm.
           ##*   = Channel supports radar detection .
           .     = Channel is not legal in this country.
           (-)   = Regulatory Domains allowed by this country.
           (-,-) = (indoor, outdoor) regulatory Domains allowed by this country.
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
    802.11bg     :
    Channels     :                   1 1 1 1 1
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-CE  ,-CE  )  AE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  AL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AR  )  AR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  AT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-NA  )  AU  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  BA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  BE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  BG  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-    )  BH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-A   )  BO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-AR  )  BR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  BY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-ABN )  CA  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-ABN )  CA2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  CH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-AER ,-AR  )  CL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  CM  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-CE  ,-CE  )  CN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AR  )  CO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-AB  )  CR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  CY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  CZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  DE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  DK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-ABN )  DO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  DZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AB  )  EC  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  EE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  EG  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  ES  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  FI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  FR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GB  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-NA  )  HK  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  HR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  HU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-ER  )  ID  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  IE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-EI  ,-IE  )  IL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
```

```
(-I   ,-I   )  ILO :   .  .  .  . 20 20 20 20 20 20 20 20 20  .
(-A   ,-AN  )  IN  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  IQ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  IS  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  IT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-JPU ,-JPU )  J2  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPU ,-JPU )  J3  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPQU,-PQ  )  J4  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-E   ,-    )  JO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-JPU ,-JPU )  JP  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-ACE ,-ACEK)  KE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-ACE ,-ACEK)  KR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KW  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LB  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,     )  LK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LV  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MC  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  ME  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,     )  MO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-NA  )  MX  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-ACE ,-AEC )  MY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  NL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  NO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-NA  )  NZ  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  OM  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-AR  )  PA  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AR  )  PE  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-ABN )  PH  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-ABN )  PH2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  PK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  PL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-A   )  PR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  PT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-A   )  PY  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  QA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  RO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  RS  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-AER ,-ER  )  RU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-AE  ,-AE  )  SA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  SE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-SE  )  SG  :  20 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E   ,-E   )  SI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  SK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-ER  )  TH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  TN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-EI  ,-E   )  TR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-ANT )  TW  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  UA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-AB  )  US  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AB  )  US2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AB  )  USL :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-    )  USX :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-A   )  UY  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AR  )  VE  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  VN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  ZA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
```

show wireless detail

To display the details of the wireless parameters configured, use the **show wireless detail** command in privileged EXEC mode.

show wireless detail

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The following parameters are displayed:

- The wireless user idle timeout
- The controller configured RF group name
- Fast SSID change

The following is sample output from the **show wireless detail** command:

```
Device# show wireless detail
User Timeout               : 300
RF network                 : default
Fast SSID                  : Disabled
```

show wireless dhcp relay statistics

To configure the wireless DHCP relay on the AP, use the **show wireless dhcp relay statistic** command.

show wireless dhcp relay statistic

Syntax Description

A.B.C.D	Indicates the target IPv4 address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.3.1	This command was introduced.

Examples

The following example shows how to configure the wireless DHCP relay on the AP:

```
Device# show wireless dhcp relay statistics ip-address 10.1.1.1
```

show wireless dot11h

To see 802.11h configuration details, use the **show wireless dot11h** command.

show wireless dot11h [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the 802.11h configuration details:

```
Device# show wireless dot11h
```

show wireless dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show wireless dtls connections** command in privileged EXEC mode.

show wireless dtls connections

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless dtls connections** command:

```
Device# show wireless dtls connections
 AP Name         Local Port   Peer IP    Peer Port  Ciphersuite
------------------------------------------------------------------------
  AP-2       Capwap_Ctrl   10.0.0.16     52346      TLS_RSA_WITH_AES_128_CBC_SHA
  AP-3       Capwap_Ctrl   10.0.0.17     52347      TLS_RSA_WITH_AES_128_CBC_SHA
```

show wireless exclusionlist

To see the wireless exclusion list, use the **show wireless exclusionlist** command.

show wireless exclusionlist [**client mac-address** *client-mac-addr* **detail**] [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

client-mac-addr	Client MAC address.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.
Cisco IOS XE Cupertino 17.9.1	The output of the command was modified to include ARP activity information.

Examples

The following example shows how to see the wireless exclusion list:

```
Device# show wireless exclusionlist

Excluded Clients

MAC Address       Description          Exclusion Reason               Time Remaining
---------------------------------------------------------------------------------------
10da.4320.cce9                         Client Policy  failure          59
```

The following example shows the exclusion reason for the clients, which has changed from *Client Policy failure* to *Excess ARP activity* from Cisco IOS XE Cupertino 17.9.x onwards:

```
Device# show wireless exclusionlist


MAC Address       Description         Exclusion Reason               Time Remaining
-------------------------------------------------------------------------------------
6c96.cff2.889a                        Excess ARP activity             53
```

show wireless exclusionlist client mac-address detail

To see the detailed information for active clients, use the **show wireless exclusionlist client mac-address detail**command.

show wireless exclusionlist client mac-address *client-mac-addr* **detail**

Syntax Description

client-mac-addr	Client MAC address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.
Cisco IOS XE Cupertino 17.9.1	The output of the command was modified to include ARP activity information.

Examples

The following example shows how to see the detailed information for active clients:

```
Device# show wireless exclusionlist client mac-address 12da.4820.cce9 detail

Client State : Excluded
Client MAC Address : 12da.4820.cce9
Client IPv4 Address: 20.20.20.6
Client IPv6 Address: N/A
Client Username: N/A
Exclusion Reason :  Client Policy  failure
Authentication Method : None
Protocol: 802.11ac
AP MAC Address : 58ac.780e.08f0
AP Name: charlie2
AP slot : 1
Wireless LAN Id : 2
Wireless LAN Name: mhe-ewlc
VLAN Id : 20
```

The following example shows how to see the detailed information for active clients, where ARP rate limit exclusion that has changed from *Client Policy failure* to *Excess ARP activity* from Cisco IOS XE Cupertino 17.9.x onwards is shown:

```
Device# show wireless exclusionlist client mac-address 6c96.cff2.889a detail

Client State : Excluded
Client MAC Address : 6c96.cff2.889a
Client IPv4 Address: N/A
Client IPv6 Address: N/A
Client Username: N/A
Exclusion Reason : Excess ARP activity
```

```
Authentication Method : None
Protocol: 802.11ac
AP MAC Address : 4001.7aca.5680
AP Name: AP40CE.2485.D5E8
AP slot : 1
Wireless LAN Id : N/A
VLAN Id : 63
```

show wireless fabric summary

To view the fabric status, use the **show wireless fabric summary** command.

show wireless fabric summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE 17.14.1	The output of the command was modified to include IPv6 address.

This example shows how to view fabric status:

```
Device# show wireless fabric summary
Fabric Status      : Enabled


Control-plane:
Name                              IP-address        Key                               Status
-------------------------------------------------------------------------------------------
test-map                          10.12.13.14       test1                             Down


Fabric VNID Mapping:
  Name               L2-VNID        L3-VNID        IP Address             Subnet
Control plane name
-------------------------------------------------------------------------------------------------------


  test1               12             10             10.6.8.9            255.255.255.236
 test2
```

This example shows how to view fabric status for IPv6:

```
Device# show wireless fabric summary
Fabric Status      : Enabled


Control-plane:
Name                                 IP-address                                  Key
                         Status
-------------------------------------------------------------------------------------------------------
default-control-plane                2001:192:168:1::3                           cisco123
                         Up


Fabric VNID Mapping:
  Name               L2-VNID       L3-VNID       IP Address
  Subnet                                      Control plane name
-------------------------------------------------------------------------------------------------------
```

```
130_120_0_INFRA    8188          4097          2003:2000:130:120::1
ffff:ffff:ffff:ffff::                      default-control-plane
```

show wireless fabric client summary

To see the summary of a fabric enabled wireless client, use the **show wireless fabric client summary** command.

show wirelessv fabric client summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.
Cisco IOS XE 17.14.1	The output of the command was modified to include IPv6 address.

Examples

The following example shows how to see the fabric enabled wireless client summary:

```
Device# show wireless fabric client summary
```

The following example shows how to see the fabric enabled wireless client summary for IPv6:

```
Device# show wireless fabric client summary
Number of Fabric Clients : 2
MAC Address          AP Name              Type      ID     State     Protocol     Method
  L2 VNID      RLOC IP

2c33.7a5b.8fc5     APC4F7.D54D.0B94       WLAN      22      Run       11n(2.4)     None
    8190    1100:10:10:10:1:1:1:6
40ec.995a.434e    APC4F7.D54D.0B94        WLAN      20      Run       11ac         None
    8190    1100:10:10:10:1:1:1:6
```

show wireless fabric vnid mapping

To view all the VNID mapping details, use the **show wireless fabric vnid mapping** command.

show wireless fabric vnid mapping

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view all the VNID mapping details:

```
Device# show wireless fabric vnid mapping
Fabric VNID Mapping:
  Name               L2-VNID        L3-VNID        IP Address              Subnet
Control plane name
------------------------------------------------------------------------------------------------------------

  test1               12             10             10.6.8.9            255.255.255.236
 test2
```

show wireless flow-control

To display the information about flow control on a particular channel, use the **show wireless flow-control** command in privileged EXEC mode.

show wireless flow-control *channel-id*

Syntax Description

channel-id	Identification number for a channel through which flow control is monitored.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless flow-control** *channel-id* command:

```
Device# show wireless flow-control 3
Channel Name                          : CAPWAP
FC State                              : Disabled
Remote Server State                   : Enabled
Pass-thru Mode                        : Disabled
EnQ Disabled                          : Disabled
Queue Depth                           : 2048
Max Retries                           : 5
Min Retry Gap (mSec)                  : 3
```

show wireless flow-control statistics

To display the complete information about flow control on a particular channel, use the **show wireless flow-control statistics** command in privileged EXEC mode.

show wireless flow-control *channel-id* **statistics**

Syntax Description

channel-id	Identification number for a channel through which flow control is monitored.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless flow-control** *channel-id* **statistics** command:

```
Device# show wireless flow-control 3 statistics
 Channel Name                                : CAPWAP
# of times channel went into FC              : 0
# of times channel came out of FC            : 0
Total msg count received by the FC Infra     : 1
Pass-thru msgs send count                    : 0
Pass-thru msgs fail count                    : 0
# of msgs successfully queued                : 0
# of msgs for which queuing failed           : 0
# of msgs sent thru after queuing            : 0
# of msgs sent w/o queuing                   : 1
# of msgs for which send failed              : 0
# of invalid EAGAINS received                : 0
Highest watermark reached                    : 0
# of times Q hit max capacity                : 0
Avg time channel stays in FC (mSec)          : 0
```

show wireless load-balancing

To display the status of the load-balancing feature, use the **show wireless load-balancing** command in privileged EXEC mode.

show wireless load-balancing

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless load-balancing** command:

```
 > show wireless load-balancing
Aggressive Load Balancing.........................: per WLAN enabling
Aggressive Load Balancing Window (clients)..................:: 5
Aggressive Load Balancing Denial Count.....................:: 3

Statistics
Total Denied Count (clients)................................:: 0
Total Denial Sent (messages)................................:: 0
Exceeded Denial Max Limit Count (times).....................:: 0
None 5G Candidate Count (times).............................:: 0
None 2.4G Candidate Count (times)...........................:: 0
```

show wireless mesh ap fabric summary

To view the mesh AP fabric summary, use the **show wireless mesh ap fabric summary** command.

show wireless mesh ap fabric summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Example

This example shows how to view the mesh AP fabric summary:

```
Device# show wireless mesh ap fabric summary
```

show wireless mesh rrm dca changed

To display the Dynamic Channel Assignment (DCA) information for the last channel change on mesh backhaul, use the **show wireless mesh rrm dca changed** command.

show wireless mesh rrm dca changed

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Examples

This example shows how to display the Dynamic Channel Assignment (DCA) information for the last channel change on mesh backhaul:

```
Device# show wireless mesh rrm dca changed
Mesh Tree        : AP-E1-CXXX subtree
  Root AP Name     : AP-E1-CXXX
  Root AP slot MAC : 4xxx.0xxx.cxxx
  Radio slot id    : 1
  Radio Type       : 802.11a
  DCA reason       : Auto-DCA configured

  Mesh RRM DCA status
    Backhaul channel before DCA run : 60
    Backhaul channel width          : 40

    Mesh RRM DCA outcome
      DCA run start                  : 11/23/2023 11:28:41
      DCA run end                    : 11/23/2023 11:28:49
      DCA proposed best Channel      : 140
      Channel width                  : 40
      DCA proposed next best Channel : 52
      Channel width                  : 40
      Outcome of DCA run             : Channel change proposed
      Channel change status          : Channel change initiated

  DCA input data for latest run
    Noise Information
      Channel  36:  -82 dBm
      Channel  40:  -82 dBm
      Channel  44:  -79 dBm
      Channel  48:  -81 dBm
      Channel  52:  -82 dBm
      Channel  56:  -81 dBm
      Channel  60:  -81 dBm
      Channel  64:  -79 dBm
      Channel 100:  -81 dBm
      Channel 104:  -80 dBm
```

```
  Channel 108:  -80 dBm
  Channel 112:  -80 dBm
  Channel 116:  -79 dBm
  Channel 120:  -80 dBm
  Channel 124:  -79 dBm
  Channel 128:  -79 dBm
  Channel 132:  -80 dBm
  Channel 136:  -80 dBm
  Channel 140:  -80 dBm
  Channel 144:  -78 dBm
  Channel 149:  -80 dBm
  Channel 153:  -81 dBm
  Channel 157:  -80 dBm
  Channel 161:  -80 dBm
  Channel 165:  -81 dBm
Interference Information
  Channel  36:  -51 dBm @  3% busy
  Channel  40:  -52 dBm @  1% busy
  Channel  44:  -60 dBm @  3% busy
  Channel  48: -128 dBm @  0% busy
  Channel  52: -128 dBm @  0% busy
  Channel  56: -128 dBm @  0% busy
  Channel  60:  -53 dBm @  3% busy
  Channel  64: -128 dBm @  0% busy
  Channel 100:  -41 dBm @  2% busy
  Channel 104: -128 dBm @  0% busy
  Channel 108:  -55 dBm @  1% busy
  Channel 112: -128 dBm @  0% busy
  Channel 116: -128 dBm @  0% busy
  Channel 120: -128 dBm @  0% busy
  Channel 124: -128 dBm @  0% busy
  Channel 128:  -31 dBm @  1% busy
  Channel 132: -128 dBm @  0% busy
  Channel 136: -128 dBm @  0% busy
  Channel 140: -128 dBm @  0% busy
  Channel 144: -128 dBm @  0% busy
  Channel 149: -128 dBm @  0% busy
  Channel 153:  -52 dBm @  2% busy
  Channel 157: -128 dBm @  0% busy
  Channel 161: -128 dBm @  0% busy
  Channel 165: -128 dBm @  0% busy
Rogue Histogram (20)
  Channel  36                                :  0/ 2/ 7
  Channel  40                                :  1/ 0/ 2
  Channel  44                                :  0/ 2/ 4
  Channel  48                                :  0/ 0/ 2
  Channel  52                                :  1/ 0/ 0
  Channel  56                                :  0/ 0/ 0
  Channel  60                                :  0/ 0/ 2
  Channel  64                                :  0/ 0/ 0
  Channel 100                                :  2/ 4/ 0
  Channel 104                                :  2/ 0/ 0
  Channel 108                                :  2/ 3/ 2
  Channel 112                                :  0/ 0/ 0
  Channel 116                                :  1/ 0/ 0
  Channel 120                                :  0/ 0/ 0
  Channel 124                                :  1/ 0/ 0
  Channel 128                                :  0/ 0/ 0
  Channel 132                                :  1/ 2/ 0
  Channel 136                                :  4/ 0/ 0
  Channel 140                                :  5/ 1/ 0
  Channel 144                                :  0/ 0/ 0
  Channel 149                                :  0/ 0/ 0
  Channel 153                                :  0/ 0/ 6
```

```
  Channel 157                                 :  0/ 0/ 0
  Channel 161                                 :  0/ 0/ 0
  Channel 165                                 :  0/ 0/ 0
Load Information
  Receive Utilization  : 0%
  Transmit Utilization : 0%
  Channel Utilization  : 6%
  Attached Clients     : 0 clients
Radar Information
  Channel  36: Not detected
  Channel  40: Not detected
  Channel  44: Not detected
  Channel  48: Not detected
  Channel  52: Not detected
  Channel  56: Not detected
  Channel  60: Not detected
  Channel  64: Not detected
  Channel 100: Not detected
  Channel 104: Not detected
  Channel 108: Not detected
  Channel 112: Not detected
  Channel 116: Not detected
  Channel 120: Not detected
  Channel 124: Not detected
  Channel 128: Not detected
  Channel 132: Not detected
  Channel 136: Not detected
  Channel 140: Not detected
  Channel 144: Not detected
  Channel 149: Not detected
  Channel 153: Not detected
  Channel 157: Not detected
  Channel 161: Not detected
  Channel 165: Not detected
Client Data
  802.11ac clients     : 0
  802.11n clients      : 0
  802.11a clients      : 0
  Voice clients        : 0
  Video clients        : 0
  802.11ac 160 clients : 0
  Total Clients        : 0
```

show wireless media-stream client detail

To see the media stream clients information by stream name, use the **show wireless media-stream client detail** command.

show wireless media-stream client detail

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see media stream clients information by stream name:

```
Device# show wireless media-stream client detail
```

show wireless media-stream group

To display the wireless media-stream group information, use the **show wireless media-stream group** command.

show wireless media-stream group {**detail** *groupName* | **summary**}

Syntax Description

detail *groupName*	Display media-stream group configuration details of the group mentioned in the command.
summary	Display media-stream group configuration summary

Command Default

None

Command Modes

User EXEC mode or Privileged EXEC mode

Usage Guidelines

None.

The following is a sample output of the **show wireless media-stream group detail GRP1** command.

```
Device#show wireless media-stream group detail GRP1
```

```
Device#show wireless media-stream group detail GRP1
Media Stream Name : GRP1
Start IP Address : 234.1.1.1
End IP Address : 234.1.1.5
RRC Parameters:
Avg Packet Size(Bytes) : 1200
Expected Bandwidth(Kbps) : 1000
Policy : Admitted
RRC re-evaluation : Initial
QoS : video
Status : Multicast-direct
```

The following is a sample output of the **show wireless media-stream group summary** command.

```
Device#show wireless media-stream group summary
Number of Groups:: 1
Stream Name          Start IP                              End IP
Status
------------------------------------------------------------------------------------------------
GRP1                 234.1.1.1                             234.1.1.5
Enabled
```

show wireless media-stream message details

To see the wireless multicast-direct session announcement message details, use the **show wireless media-stream message details** command.

show wireless media-stream message details

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the wireless multicast-direct session announcement message details:

```
Device# show wireless media-stream message details
```

show wireless mobility controller ap

To display the list of access points which have joined the sub-domain, use the **wireless mobility controller ap** command.

show wireless mobility controller ap

Syntax Description

ap	Show joined Access Point in sub-domain.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to list the access points which have joined the sub-domain.

```
Device#show wireless mobility controller ap
Number of AP entries in the sub-domain     : 2

AP name                          AP radio MAC      Controller IP     Location
-------------------------------------------------------------------------------------------------
bos2kk                           00f2.8c42.f520    default-group     default-group
IosAP1                           34ed.522f.7e60    default-group     default-group
```

show wireless media-stream multicast-direct state

To see the state of the wireless multicast-direct configuration, use the **show wireless media-stream multicast-direct state** command.

show wireless media-stream multicast-direct state

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the state of the wireless multicast-direct configuration:

```
Device# show wireless media-stream multicast-direct state
```

show wireless mesh ap

To see the mesh AP related information, use the **show wireless mesh ap** command.

show wireless mesh ap { **summary** | **tree** | **backhaul** } [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

summary	Shows the summary of all connected mesh APs.
tree	Shows the Mesh AP tree.
backhaul	Shows the mesh APs backhaul info.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the summary of all the connected mesh APs:

```
Device# show wireless mesh ap summary
```

show wireless mesh ap summary

To see the summary of all connected mesh APs, use the **show wireless mesh ap summary** command.

show wireless mesh ap summary [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

summary	Shows the summary of all connected mesh APs.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the summary of all connected mesh APs:

```
Device# wireless mesh ap summaryAP Name                              AP Model             BVI
MAC        BGN        AP Role
-------                          -------------------- -------        ---        -------
AP-E1-CBA0                       C9124AXE-B           488b.0a76.1ac4 gp3Mesh    Root AP
AP-D4-5060                       C9124AXI-B           3c57.31c5.8058 gp3Mesh    Root AP
AP-F5-CC00                       C9124AXI-B           3c57.31c5.8fd0 gp3Mesh    Root AP
AP-E1-E940                       C9124AXE-B           3c57.31c5.9378 gp3Mesh    Mesh AP
AP-E3-0220                       AIR-AP2802I-A-K9     502f.a871.45f2 gp3Mesh    Mesh AP
AP-E3-0980                       AIR-AP2802I-A-K9     7079.b333.d068 gp3Mesh    Mesh AP
AP-D2-2C00                       C9130AXI-E           1416.9d56.1e00 gp3Mesh    Root AP
AP-B1-87a0                       AIR-AP4800-A-K9      4c71.0def.ec78 gp3Mesh    Mesh AP

Number of Bridge APs         :   0
Number of RAPs               :   0
Number of MAPs               :   0
Number of Flex+Bridge APs    :   8
Number of Flex+Bridge RAPs   :   4
Number of Flex+Bridge MAPs   :   4
```

show wireless mesh ap tree

To see the mesh AP tree, use the **show wireless mesh ap tree** command.

show wireless mesh ap tree

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to view the wireless mesh AP tree:

```
Device # show wireless mesh ap
tree=================================================================================
AP Name [Hop Ctr,Link SNR,BG Name,Channel,Pref Parent,Chan Util,Clients]
=================================================================================

[Sector 1]
-----------
AP-D2-2C00 [0, 0, gp3Mesh, (64), 0000.0000.0000, 0%, 0]

[Sector 2]
-----------
AP-D4-5060 [0, 0, gp3Mesh, (124,128), 0000.0000.0000, 9%, 0]

[Sector 3]
-----------
AP-F5-CC00 [0, 0, gp3Mesh, (149,153), 0000.0000.0000, 9%, 0]
   |-AP-E1-E940 [1, 68, gp3Mesh, (149,153), 0000.0000.0000, 12%, 0]
   |-AP-B1-87a0 [1, 47, gp3Mesh, (149,153), 0000.0000.0000, 13%, 0]
   |-AP-E3-0220 [1, 62, gp3Mesh, (149,153), 0000.0000.0000, 22%, 0]
   |-AP-E3-0980 [1, 57, gp3Mesh, (149,153), 0000.0000.0000, 23%, 0]

[Sector 4]
-----------
AP-E1-CBA0 [0, 0, gp3Mesh, (112,108), 0000.0000.0000, 12%, 0]

Number of Bridge APs : 8
Number of RAPs : 4
Number of MAPs : 4

(*)  Wait for 3 minutes to update or Ethernet Connected Mesh AP.
(**) Not in this Controller
```

show wireless mesh cac summary

To view the total number of voice calls and bandwidth utilization of APs in the Mesh network, use the **show wireless mesh cac summary** command.

show wireless mesh cac summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Example

This example shows how to display the total number of voice calls and bandwidth utilization of APs in the Mesh network:

```
Device# show wireless mesh cac summary

AP Name                          Slot  Radio      BW Used  Call
-------------------------------  ----  ---------  -------  ----
APA023.9FA9.B702                 0     802.11b/g  0        0
                                 1     802.11a    0        0
APA023.9FA9.D920                 0     802.11b/g  1140     2
                                 1     802.11a    0        0
AP380E.4DBF.C6A6                 0     802.11b/g  0        0
                                 1     802.11a    0        0
AP380E.4DBF.C80C                 0     802.11b/g  570      0
                                 1     802.11a    2144     2
AP380E.4DBF.C816                 0     802.11b/g  0        0
                                 1     802.11a    0        0
```

show wireless mesh config

To see the mesh configurations, use the **show wireless mesh config** command.

show wireless mesh config [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

config	Shows the mesh configurations.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the mesh configurations:

```
Device# wireless mesh config
Mesh Config
  Backhaul RRM                                  : ENABLED
  Mesh CAC                                      : DISABLED
  Outdoor Ext. UNII B Domain channels(for BH)   : DISABLED
  Mesh Ethernet Bridging STP BPDU Allowed       : DISABLED
  Rap Channel Sync                              : DISABLED

Mesh Alarm Criteria
  Max Hop Count                                 :  4
  Recommended Max Children for MAP              : 10
  Recommended Max Children for RAP              : 20
  Low Link SNR                                  : 12
  High Link SNR                                 : 60
  Max Association Number                        : 10
  Parent Change Number                          :  3

Mesh PSK Config
  PSK Provisioning                              : ENABLED
  Default PSK                                   : ENABLED
  PSK In-use key number                         : 1
  Provisioned PSKs(Maximum 5)

  Index    Description
  ------   ------------
  1    first key
```

show wireless mesh rrm dca status

To display the status of the last DCA run per radio, use the **show wireless mesh rrm dca status** command.

show wireless mesh rrm dca status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to display the status of the last DCA run per radio:

```
Device# show wireless mesh rrm dca status
Mesh Tree        : AP-E1-CBA0 subtree
  Root AP Name     : AP-E1-CBA0
  Root AP slot MAC : 488b.0a78.cba0
  Radio slot id    : 1
  Radio Type       : 802.11a
  DCA status       : Not Running
  DCA reason       : N/A

  Mesh RRM DCA status
    Backhaul channel before DCA run : 112
    Backhaul channel width          : 40

    Mesh RRM DCA outcome
      DCA run start                  : 06/04/2025 11:25:03
      DCA run end                    : 06/04/2025 11:25:11
      DCA proposed best Channel      : 112
      Channel width                  : 40
      DCA proposed next best Channel : 149
      Channel width                  : 40
      Outcome of DCA run             : Channel change not proposed
      Channel change status          : Channel change not applicable

  DCA input data for latest run
    Noise Information
      Channel  36:  -78 dBm
      Channel  40:  -77 dBm
      Channel  44:  -81 dBm
      Channel  48:  -81 dBm
      Channel  52:  -80 dBm
      Channel  56:  -80 dBm
      Channel  60:  -80 dBm
      Channel  64:  -78 dBm
      Channel 100:  -79 dBm
      Channel 104:  -78 dBm
```

```
  Channel 108:  -79 dBm
  Channel 112:  -80 dBm
  Channel 116:  -80 dBm
  Channel 120:  -80 dBm
  Channel 124:  -79 dBm
  Channel 128:  -79 dBm
  Channel 132:  -80 dBm
  Channel 136:  -77 dBm
  Channel 140:  -79 dBm
  Channel 144:  -78 dBm
  Channel 149:  -80 dBm
  Channel 153:  -76 dBm
  Channel 157:  -80 dBm
  Channel 161:  -78 dBm
  Channel 165:  -79 dBm
Interference Information
  Channel  36:  -48 dBm @ 12% busy
  Channel  40:  -52 dBm @  1% busy
  Channel  44:  -50 dBm @  7% busy
  Channel  48:  -54 dBm @  2% busy
  Channel  52:  -41 dBm @  1% busy
  Channel  56:  -54 dBm @  2% busy
  Channel  60:  -44 dBm @  1% busy
  Channel  64:  -51 dBm @  9% busy
  Channel 100:  -46 dBm @  1% busy
  Channel 104: -128 dBm @  0% busy
  Channel 108: -128 dBm @  0% busy
  Channel 112:  -59 dBm @  2% busy
  Channel 116:  -46 dBm @  2% busy
  Channel 120: -128 dBm @  0% busy
  Channel 124: -128 dBm @  0% busy
  Channel 128: -128 dBm @  0% busy
  Channel 132:  -47 dBm @  2% busy
  Channel 136:  -55 dBm @  2% busy
  Channel 140:  -43 dBm @  1% busy
  Channel 144: -128 dBm @  0% busy
  Channel 149:  -49 dBm @  4% busy
  Channel 153:  -50 dBm @  4% busy
  Channel 157:  -46 dBm @  2% busy
  Channel 161:  -54 dBm @  2% busy
  Channel 165:  -41 dBm @  1% busy
Rogue Histogram (20)
  Channel  36                                : 18/ 5/ 4
  Channel  40                                :  3/ 0/ 3
  Channel  44                                :  2/ 1/ 2
  Channel  48                                :  1/ 0/ 3
  Channel  52                                :  0/ 0/ 0
  Channel  56                                :  0/ 0/ 1
  Channel  60                                :  0/ 0/ 0
  Channel  64                                :  0/ 0/10
  Channel 100                                :  0/ 1/ 0
  Channel 104                                :  0/ 0/ 0
  Channel 108                                :  0/ 0/ 0
  Channel 112                                :  0/ 0/ 0
  Channel 116                                :  1/ 2/ 0
  Channel 120                                :  0/ 0/ 0
  Channel 124                                :  0/ 1/ 0
  Channel 128                                :  0/ 0/ 0
  Channel 132                                :  1/ 2/ 0
  Channel 136                                :  1/ 0/ 0
  Channel 140                                :  2/ 1/ 0
  Channel 144                                :  0/ 0/ 0
  Channel 149                                :  0/ 1/10
  Channel 153                                :  0/ 0/ 0
```

```
  Channel 157                                 :  0/ 0/ 0
  Channel 161                                 :  0/ 0/ 2
  Channel 165                                 :  1/ 0/ 0
Load Information
  Receive Utilization  : 0%
  Transmit Utilization : 0%
  Channel Utilization  : 14%
  Attached Clients     : 0 clients
Radar Information
  Channel  36: Not detected
  Channel  40: Not detected
  Channel  44: Not detected
  Channel  48: Not detected
  Channel  52: Not detected
  Channel  56: Not detected
  Channel  60: Not detected
  Channel  64: Not detected
  Channel 100: Not detected
  Channel 104: Not detected
  Channel 108: Not detected
  Channel 112: Not detected
  Channel 116: Not detected
  Channel 120: Not detected
  Channel 124: Not detected
  Channel 128: Not detected
  Channel 132: Not detected
  Channel 136: Not detected
  Channel 140: Not detected
  Channel 144: Not detected
  Channel 149: Not detected
  Channel 153: Not detected
  Channel 157: Not detected
  Channel 161: Not detected
  Channel 165: Not detected
Client Data
  802.11ac clients     : 0
  802.11n clients      : 0
  802.11a clients      : 0
  Voice clients        : 0
  Video clients        : 0
  802.11ac 160 clients : 0
  Total Clients        : 0
```

show wireless mesh neighbor

To see the neighbors of all connected mesh APs, use the **show wireless mesh neighbor** command.

show wireless mesh neighbor [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

neighbor	Shows the neighbors of all connected mesh APs.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Definition of the field State is as follows:

- **UPDATED**: Adjacency is reachable: communication is symmetric, we can exchange frames with that AP.
- **NEIGH**: Adjacency is parent capable. Local criterion: reachability, strict BGN config, valid cost, potential loops, and so on.
- **CHILD**: Adjacency is actually a child mesh AP (associated to the considered AP).
- **PARENT**: Adjacency is actually the parent mesh AP.
- **DEFAULT**: Adjacency BGN is different than our backhaul configured one.
- **BLOCK**: Adjacency is currently blocklisted due to: auth failures, capwap teardown, and so on.

Examples

The following example shows how to see the neighbors of all connected mesh APs:

```
Device# show wireless mesh neighbor

AP Name/Radio             Channel   Rate      Link-snr   Flags   State
-----------------------------------------------------------------------------------------------------


AP Name : Mesh-AP01

54:9f:c6:fa:5c:71         149       auto      0          40
```

```
b0:c5:3c:e5:d9:71        149       auto      22        49      UPDATED NEIGH
e8:eb:34:d5:88:d1        149       auto      0         40
e8:eb:34:d5:8d:d1        149       auto      18        49      UPDATED CHILD
e8:eb:34:d5:94:d1        149       auto      37        4b      UPDATED NEIGH PARENT
e8:eb:34:d5:d3:11        149       auto      31        49      UPDATED NEIGH
e8:eb:34:d5:d8:91        149       auto      0         41      UPDATED
e8:eb:34:d5:da:31        149       auto      18        49      UPDATED NEIGH
e8:eb:34:d5:da:51        149       auto      0         1040    DEFAULT
e8:eb:34:d5:dc:d1        149       auto      9         49      UPDATED NEIGH
e8:eb:34:d5:ef:51        149       auto      0         40
e8:eb:34:d5:f6:51        149       auto      9         49      UPDATED NEIGH
e8:eb:34:d5:fd:51        149       auto      21        49      UPDATED NEIGH
ec:ce:13:9a:89:91        149       auto      19        49      UPDATED NEIGH
ec:ce:13:d7:6f:91        149       auto      18        49      UPDATED NEIGH
ec:ce:13:d7:75:71        149       auto      19        49      UPDATED NEIGH
ec:ce:13:d7:87:91        149       auto      0         41      UPDATED
ec:ce:13:d7:8e:51        149       auto      6         49      UPDATED NEIGH
```

show wireless profile ap priming summary

To view the summary of priming APs, the **show wireless profile ap priming summary** command.

show wireless profile ap priming summary

Syntax Description

The command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

The following example shows how to view the summary of priming APs:

```
Device# show wireless profile ap priming summary
```

show wireless mobility

To view the wireless mobility summary, use the **show wireless mobility** command.

show wireless mobility { **agent** *mobility-agent-ip* **client summary** | **ap-list ip-address** *ip-address* | **controller client summary** | **dtls connections** | **statistics summary** }

Syntax Description

agent *mobility-agent-ip* **client summary**	Shows the active clients on a mobility agent.
ap-list ip-address *ip-address*	Shows the list of Cisco APs known to the mobility group.
controller client summary	Shows the active clients in the subdomain.
dtls connections	Shows the DTLS server status.
statistics	Shows the statistics for the Mobility manager.
summary	Shows the summary of the mobility manager.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display a summary of the mobility manager:

```
Device (config)# show wireless mobility ap-list

AP name                          AP radio MAC      Controller IP     Learnt from
-------------------------------------------------------------------------------------------------
TSIM_AP-101                      0000.2000.6600    9.9.9.2           Self
TSIM_AP-102                      0000.2000.6700    9.9.9.2           Self
TSIM_AP-103                      0000.2000.6800    9.9.9.2           Self
TSIM_AP-400                      0000.2001.9100    9.9.9.2           Self
TSIM_AP-402                      0000.2001.9300    9.9.9.2           Self
TSIM_AP-403                      0000.2001.9400    9.9.9.2           Self
TSIM_AP-406                      0000.2001.9700    9.9.9.2           Self
TSIM_AP-407                      0000.2001.9800    9.9.9.2           Self
TSIM_AP-409                      0000.2001.9a00    9.9.9.2           Self
```

show wireless mobility peer ip

To see the details of the mobility peer using its IP address, use the **show wireless mobility peer ip** command.

show wireless mobility peer ip *ip-address*

Syntax Description

ip-address	Mobility peer IPv4 IP address.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of the wireless mobility peer using its IP address:

```
Device# show wireless mobility peer ip 209.165.200.224
```

show wireless multicast group summary

To see the wireless multicast group summary, use the **show wireless multicast group summary** command.

show wireless multicast group summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the summary of the wireless multicast group:

```
Device# show wireless multicast group summary
```

show wireless mobility summary

To see the wireless mobility manager summary, use the **show wireless mobility summary** command.

show wireless mobility summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the wireless mobility manager's summary:

```
Device# show wireless mobility summary
```

show wireless multicast

To display wireless multicast information, use the **show wireless multicast** command in privileged EXEC mode.

show wireless multicast [**source** *source-ip* **group** *group-ip* **vlan** *vlan-id* | **group** *group-ip* **vlan** *vlan-id*]

Syntax Description

source *source-ip*	(Optional) Specifies the source IPv4 and IPv6 address of multicast traffic.
group *group-ip*	(Optional) Specifies the destination group and group IP of mutlicast traffic.
vlan *vlan-id*	Displays the client information on VLAN with the specific VLAN ID.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None

This example shows how to display the wireless multicast information:

```
Device# show wireless multicast

Multicast                                : Enabled
AP Capwap Multicast                      : Unicast
Wireless Broadcast                       : Disabled
Wireless Multicast non-ip-mcast          : Disabled

Vlan        Non-ip-mcast     Broadcast        MGID
------------------------------------------------------
1           Enabled          Enabled          Enabled
2           Enabled          Enabled          Disabled
94          Enabled          Enabled          Disabled

Device# show wireless multicast
Multicast                                : Disabled
AP Capwap Multicast                      : Unicast
Wireless Broadcast                       : Disabled
Wireless Multicast non-ip-mcast          : Disabled
Wireless Multicast link-local            : Enabled
```

show wireless multicast group

To display the information of the wireless-multicast non-ip VLANs or the group, use the **show wireless multicast group** command in privileged EXEC mode.

show wireless multicast group {**summary** | *group-ip* **vlan** *vlan-id*}

Syntax Description

summary	Displays wireless-multicast non-ip group summary.
group-ip	Specifies the group IP address.
vlan *vlan-id*	Specifies the destination group IPv4/IPv6 Address of multicast traffic.

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to display the wireless-multicast non-ip group summary.

```
Device# show wireless multicast group summary
```

show wireless mesh ethernet daisy-chain summary

To verify the ethernet daisy chain summary, use the **show wireless mesh ethernet daisy-chain summary** command.

show wireless mesh ethernet daisy-chain summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to verify the ethernet daisy chain summary:

```
Device# show wireless mesh ethernet daisy-chain summary

AP Name BVI MAC         BGN   Backhaul   Ethernet      STP Red
-----------------------------------------------------------------------------------------------------
RAP4    683b.78bf.15f0  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP3    683b.78bf.1634  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP1    6c8b.d383.b4d4  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP2    6c8b.d383.b4e8  IOT  Ethernet0   Up Up Up Dn   Enabled
```

show wireless mesh ethernet daisy-chain bgn

To verify the ethernet daisy chain Bridge Group Name (BGN) details, use the **show wireless mesh ethernet daisy-chain bgn** command.

show wireless mesh ethernet daisy-chain bgn *bridge-group-name*

Syntax Description

bridge-group-name	Enter the bridge group name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to verify the ethernet daisy chain Bridge Group Name (BGN) details:

```
Device# show wireless mesh ethernet daisy-chain bgn <IOT>

AP Name   BVI MAC       BGN  Backhaul    Ethernet      STP Red
-----------------------------------------------------------------------------------------------------
RAP4    683b.78bf.15f0  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP3    683b.78bf.1634  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP1    6c8b.d383.b4d4  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP2    6c8b.d383.b4e8  IOT  Ethernet0   Up Up Up Dn   Enabled
```

show wireless performance

To display aggressive load balancing configuration, use the **show wireless performance** command in privileged EXEC mode.

show wireless performance {**ap** | **client**} **summary**

Syntax Description

ap summary	Displays aggressive load balancing configuration of access points configured to the controller.
client summary	Displays aggressive load balancing configuration details of the clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless performance ap summary** command.

```
Device# show wireless performance ap summary
Number of APs:
```

The following is sample output from the **show wireless performance client summary** command.

```
Device# show wireless performance client summary
Number of Clients:

MAC Address        AP Name           Status        WLAN/Guest-Lan Auth Protocol Port Wired
-------------------------------------------------------------------------------------------
```

show wireless pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show wireless pmk-cache** command in privileged EXEC mode.

show wireless pmk-cache[**mac-address** *mac-addr*]

Syntax Description

mac-address *mac-addr*	(Optional) Information about a single entry in the PMK cache.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless pmk-cache mac-address** command:

```
Device# show wireless pmk-cache mac-address H.H.H
Number of PMK caches in total : 0
```

show wireless probe

To display the advanced probe request filtering configuration and the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show wireless probe** command in privileged EXEC mode.

show wireless probe

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless probe** command:

```
Device# show wireless probe
Probe request filtering                          : Enabled
Number of probes per client per radio fwd from AP: 2
Probe request rate-limiting interval             : 500 msec
Aggregate probe request interval                 : 500 msec
```

show wireless profile ap priming all

To display the details of priming profiles, use the **show wireless profile ap priming all** command.

show wireless profile ap priming all

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.2	This command was introduced.

Examples

The following example shows how to display the details of priming profiles:

```
Device# show wireless profile ap priming all

Profile Name  Primary Controller Name  Primary Controller IP  Secondary Controller Name
Secondary Controller IP  Tertiary Controller Name  Tertiary Controller IP  Override
------------------------------------------------------------------------------------------------------------------------
AP-PRIMING-1  BGL18-wlc                209.165.201.1          BGL17-wlc
209.165.201.2                                   0.0.0.0                Disabled
AP-PRIMING-2  BGL18-wlc                209.165.201.2          BGL17-wlc
209.165.201.2            BGL12-wlc                 209.165.201.3          Disabled
```

show wireless profile ap priming all

To display the details of priming profiles, use the **show wireless profile ap priming all** command.

show wireless profile ap priming all

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.2	This command was introduced.

Examples

The following example shows how to display the details of priming profiles:

```
Device# show wireless profile ap priming all

Profile Name  Primary Controller Name  Primary Controller IP  Secondary Controller Name
Secondary Controller IP  Tertiary Controller Name  Tertiary Controller IP  Override
------------------------------------------------------------------------------------------------------------------------
AP-PRIMING-1  BGL18-wlc                209.165.201.1          BGL17-wlc
209.165.201.2                                   0.0.0.0                Disabled
AP-PRIMING-2  BGL18-wlc                209.165.201.2          BGL17-wlc
209.165.201.2            BGL12-wlc                 209.165.201.3          Disabled
```

show wireless profile airtime-fairness mapping

To view the ATF policy mapping with the wireless profiles, use the **show wireless profile airtime-fairness mapping** command.

show wireless profile airtime-fairness mapping

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ATF policy mapping with the wireless profiles:

```
Device# show wireless profile airtime-fairness mapping
Policy Profile                  Band      ATF Policy                      Weight
Client Sharing    Availability
-------------------------------------------------------------------------------------------------------------
WGB                             2.4GHz                                    -         -
                No
WGB                             5GHz                                      -         -
                No
Policy1                         2.4GHz                                    -         -
                No
Policy1                         5GHz                                      -         -
                No
Test WBG                        2.4GHz                                    -         -
                No
Test WBG                        5GHz                                      -         -
                No
profile-name                    2.4GHz    atf-policy-name                 5
Enabled           Yes
```

show wireless profile airtime-fairness summary

To view the summary of air time fairness profiles, use the **show wireless profile airtime-fairness summary** command.

show wireless profile airtime-fairness summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of air time fairness profiles:

```
Device# show wireless profile airtime-fairness summary
Policy Id      Policy Name                      Weight      Client Sharing
------------------------------------------------------------------------------
1              atf-policy-name                   5           Enabled
```

show wireless profile ap packet-capture

To view the AP packet capture information, use the **show wireless profile ap packet-capture** command.

show wireless profile ap packet-capture {**detailed** *profile-name* | **summary**}

Syntax Description

profile-name	AP packet capture profile.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to view the AP packet capture information:

```
Device# show wireless profile ap packet-capture summary
Number of AP packet capture profiles: 3

Profile Name               Buffer   Duration(M Packet Len FTP IP
------------------------------------------------------------------------
test                        1200        20         0      9.1.0.101
test1                       2048        10         0      0.0.0.0
tets1                       1024        10         0      0.0.0.0
```

Example

The following example shows how to view the detailed AP packet capture information of an AP profile:

```
Device# show wireless profile ap packet-capture detailed test1

Profile Name : test1
Description  :
-----------------------------------------------------
Buffer Size       : 2048 KB
Capture Duration  : 10 Minutes
Truncate Length   : packet length
FTP Server IP     : 0.0.0.0
FTP path          :
FTP Username      :

Packet Classifiers
  802.11 Control  : Enabled
  802.11 Mgmt     : Enabled
  802.11 Data     : Disabled
  Dot1x           : Disabled
```

```
ARP             : Disabled
IAPP            : Disabled
IP              : Disabled
TCP             : Disabled
TCP port        : all
UDP             : Disabled
UDP port        : all
Broadcast       : Disabled
Multicast       : Disabled
```

show wireless profile calendar-profile detailed

To view the calendar profile details for a specific profile name, use the **show wireless profile calendar-profile detailed** command.

show wireless profile calendar-profile detailed *profile-name*

Syntax Description

profile-name	Specifies the calendar profile name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to view the calendar profile details for a specific profile name:

```
Device# show wireless profile calendar-profile detailed daily_calendar_profile
Calendar profiles : daily_calendar_profile
-------------------------------------------------------------------
Recurrence : DAILY
Start Time : 09:00:00
End Time : 17:00:00
```

show wireless profile calendar-profile summary

To view the summary of calendar profiles, use the **show wireless profile calendar-profile summary** command.

show wireless profile calendar-profile summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the summary of calendar profiles:

```
Device# show wireless profile calendar-profile summary
Number of Calendar Profiles: 3
Profile-Name
---------------------------------
monthly_25_profile
weekly_mon_profile
daily_calendar_profile
```

show wireless profile dot11be detailed

To display 802.11be profile parameters with MLO mapping, run the **show wireless profile dot11be detailed** *11be-prof-name* command.

show wireless profile dot11be detailed *11be-prof-name*

Syntax Description

11be-prof-name	Specifies the dot11be wireless profile name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to display 802.11be profile parameters with MLO mapping in your wireless profile:

```
Device# show wireless profile dot11be detailed 24ghz_disable_11be
Dot11be profile name            : 24ghz_disable_11be
-------------------------------------------------
Description                     : disabling 11be on 2.4GHz band
802.11be parameters
    OFDMA Downlink              : Enabled
    OFDMA Uplink                : Enabled
    MU-MIMO Downlink            : Enabled
    MU-MIMO Uplink              : Enabled
    OFDMA Multi-RU              : Enabled
MLO Group
    24ghz link                  : Disabled
    5ghz link                   : Enabled
    5ghz secondary link         : Enabled
    6ghz link                   : Enabled
```

show wireless profile dot11be summary

To display 802.11be profile details, run the **show wireless profile dot11be summary** command.

show wireless profile dot11be summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to display 802.11be profile details in your wireless profile:

```
Device# show wireless profile dot11be summary
Number of dot11be profiles: 7
Dot11be profile name Description
------------------------------------------------------------------------
6ghz@disable@11be 24ghz_disable_11be all^bands^11be^disable
5ghz!slot2!disable!11be disabling 11be on 6ghz band
disabling 11be on 2.4GHz band
disabling 11be on all bands
disabling 11be on slot 2
5ghz*slot1*disable*11be
default-dot11be-profile Default 802.11be profile
1234567890abcdefghijklmnopqrstuv
```

show wireless profile fabric detailed

To view the details of a given fabric profile name, use the **show wireless profile fabric detailed** command.

show wireless profile fabric detailed *fabric_profile_name*

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the details of a given fabric profile name:

```
Device# show wireless profile fabric detailed test1
Profile-name      : test-fabric
VNID              : 12
SGT               : 5
```

show wireless profile flex

To see the flex parameters of an wireless profile, use the **show wireless profile flex** command.

show wireless profile flex { **detailed** *flex-profile-name* **chassis** {*chassis-number* | **active** | **standby** }**R0** } | **summary chassis** {*chassis-number* | **active** | **standby**}**R0**}

Syntax Description

detailed	Shows the flex-profile detailed parameters
summary	Show the flex-profile summary.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the flex parameter's summary of the wireless profile:

```
Device# show wireless profile flex summary
```

show wireless profile policy all

To display detailed output of all policy profiles, use the **show wireless profile policy all** command.

show wireless profile policy all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privilege EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.5	The output of the command was modified to include ARP activity information.

Example

This example shows how to view the detailed output of all policy profiles:

```
Device# show wireless profile policy all

Policy Profile Name                : policy_name
Description                        :
Status                             : ENABLED
.
.
.
!the section of the output that shows whether ARP is enabled or disabled in the policy
profile.
ARP Activity Limit
  Exclusion                        : ENABLED
  PPS                              : 100
  Burst Interval                   : 5
```

show wireless profile policy detailed

To display the wireless policy profile details, use the **show wireless profile policy detailed** command.

show wireless profile policy detailed *policy-profile-name*

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privilege EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example displays the wireless policy profile details:

```
Device#show wireless profile policy detailed policy-profile-name
```

show wireless profile mesh detailed

To verify the mesh profile, use the **show wireless profile mesh detailed** command.

show wireless profile mesh detailed *profile-name*

Syntax Description

profile-name	Enter the profile name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to verify the mesh profile:

```
Device# show wireless profile mesh detailed default-mesh-profile

Mesh Profile Name : default-mesh-profile
-------------------------------------------------
Description : default mesh profile
Bridge Group Name : IOT
Strict match BGN : ENABLED
Amsdu : ENABLED
Background Scan : ENABLED
Channel Change Notification : ENABLED
Backhaul client access : ENABLED
Ethernet Bridging : ENABLED
Ethernet Vlan Transparent : DISABLED
Daisy Chain STP Redundancy : ENABLED
Full Sector DFS : ENABLED
IDS : ENABLED
Multicast Mode : In-Out
Range in feet : 12000
Security Mode : EAP
Convergence Method : Standard
LSC only Authentication : DISABLED
Battery State : ENABLED
Authorization Method : eap_methods
Authentication Method : eap_methods
Backhaul tx rate(802.11bg) : auto
Backhaul tx rate(802.11a) : auto
```

show wireless profile radio detailed wat-radio-profile

To view the status of radio profile detailed parameters, use the **show wireless profile radio detailed wat-radio-profile** command.

show wireless profile radio detailed wat-radio-profile

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

This example shows the status of radio profile detailed parameters in the privileged EXEC mode:

```
Device# show wireless profile radio detailed wat-radio-profile
…
Wireless Active Testing (WAT) Configuration
  WAT Admin State (Radio Selection)               : Enabled (Always)
…
```

show wireless profile radio summary

To display the wireless radio profile summary, use the **show wireless profile radio summary** command.

show wireless profile radio summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to display the wireless radio profile summary:

```
Device# show wireless profile radio summary
```

show wireless profile tunnel summary

To display the wireless tunnel-profile summary, use the **show wireless profile tunnel summary** command.

show wireless profile tunnel summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the wireless tunnel profile summary:

```
Device# show wireless profile tunnel summary

Profile Name                     AAA-Override AAA-Proxy DHCP Opt82 Enabled
-------------------------------- ------------ --------- ---------- ---------
eogre_tunnel                              No        No        Yes       Yes
eogre_tunnel_set                          No        No        Yes        No
eogre_tunnel_snmp                         No        No         No        No
```

show wireless profile urwb detailed

To view the detailed parameters of the URWB profile, use the **show wireless profile urwb detailed** *urwb-profile-name*

show wireless profile radio detailed *urwb-profile-name*

Syntax Description

urwb-profile-name	Specifies the name of the URWB profile.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the detailed parameters of the URWB profile:

```
Device# show wireless profile radio detailed urwb-profile-name
```

show wireless redundancy statistics

To see the high availability statistics, use the **show wireless redundancy statistics** command.

show wireless redundancy statistics {**ap-group** | **wncdallchassis** {*chassis-num* | **active** | **standby**}**R0**} {**ap-recovery** | {*instance-id* | **all** | **chassis** {*chassis-num* | **active** | **standby**}**R0**}} {**client-group** | **wncdallchassis** {*chassis-num* | **active** | **standby**}**R0**} {**client-recovery** | {**mobilityd** | **sisf**}**chassis** {*chassis-num* | **active** | **standby**}**R0**} {**wncd** | {*instance-id* | **all** | **chassis** {*chassis-num* | **active** | **standby**}**R0**}}

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see all the statistics for WNCD :

show wireless rfid

To display RFID tag information, use the **show wireless rfid** command in privileged EXEC mode.

show wireless rfid {**client** | **detail** *rfid-mac-address* | **stats** | **summary**}

Syntax Description

client	Displays the summary of RFID tags that are clients.
detail	Displays information about a particular RFID tag.
stats	Displays RFID statistics.
summary	Displays summary information for all known RFID tags.
rfid-mac-address	RFID MAC address.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to view RFID information:

```
Device# show wireless rfid summary

Total RFID entries: : 16
Total Unique RFID entries : 16
RFID ID VENDOR Closet AP RSSI Time Since Last Heard
0012.b80a.c791 Cisco 7069.5a63.0520 -31 1 minute 40 seconds ago
0012.b80a.c953 Cisco 7069.5a63.0460 -33 2 minutes 15 seconds ago
0012.b80b.806c Cisco 7069.5a63.0260 -45 22 seconds ago
0012.b80d.e9f9 Cisco 7069.5a63.0460 -38 2 minutes 37 seconds ago
0012.b80d.ea03 Cisco 7069.5a63.0520 -43 2 minutes 38 seconds ago
0012.b80d.ea6b Cisco 7069.5a63.0460 -39 2 minutes 35 seconds ago
0012.b80d.ebe8 Cisco 7069.5a63.0520 -43 1 minute 31 seconds ago
0012.b80d.ebeb Cisco 7069.5a63.0520 -43 2 minutes 37 seconds ago
0012.b80d.ec48 Cisco 7069.5a63.0460 -42 2 minutes 16 seconds ago
0012.b80d.ec55 Cisco 7069.5a63.0520 -41 1 second ago
```

show wireless stats ap name

To display the wireless AP BSSID statistics, use the **show wireless stats ap name** *ap-name* **dot11 24ghz slot 0** *wlan-name 1-4096* **statistics**

show wireless stats ap name *ap-name* **dot11 24ghz slot 0** *wlan-name 1-4096* **statistics**

Syntax Description

ap-name	Specifies the name of the AP.
wlan-name	Specifies the name of the WLAN.
wlan-id	Specifies the WLAN ID. The value range is 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example show how to display the wireless AP BSSID statistics:

```
Device#show wireless stats ap name ap-name dot11 24ghz slot 0 wlan-name  1-4096 statistics
BSSID                  : 7069.5a38.112e
WLAN ID                : 18
Client Count           : 1
TX Statistics
---------------------------------------------------------------------------------
Mgmt          Retries      Data Bytes      Data Retries       Subframe Retries
---------------------------------------------------------------------------------
12            18           16081           18                 0
RX Statistics
---------------------------------------------------------------------------------
Mgmt          Data Bytes
---------------------------------------------------------------------------------
74            17693
Data Distribution
---------------------------------------------------------------------------------
Bytes                       RX                         TX
---------------------------------------------------------------------------------
0-64                        55                         93
65-128                      66                         40
129-256                     21                         5
257-512                     10                         3
513-1024                    1                          9
1025-2048                   0                          1
2049-4096                   0                          0
4097-8192                   0                          0
8193-16384                  0                          0
16385-32768                 0                          0
32769-65536                 0                          0
```

```
65537-131072                0                           0
131073-262144               0                           0
262145-524288               0                           0
524289-1048576              0                           0
WMM Statistics
-------------------------------------------------------------------------------
                            RX                          TX
-------------------------------------------------------------------------------
Voice                       0                           43
Video                       0                           0
Best Effort                 154                         39
Background                  0                           0
MCS
-------------------------------------------------------------------------------
MCS                         RX                          TX
-------------------------------------------------------------------------------
mcs0                        39                           0
mcs1                        2                            0
mcs2                        5                            0
mcs3                        7                            0
mcs4                        25                           0
mcs5                        59                           0
mcs6                        290                          0
mcs7                        1148                         3
mcs8                        2288                         0
mcs9                        4440                         2
```

show wireless stats ap image-download

To verify the AP image download statistics, use the **show wireless stats ap image-download** command in privileged EXEC mode..

show wireless stats ap image-download [**chassis** { *chassis_number* | **active** | **standby** } **R0**]

Syntax Description

chassis	Specifies the chassis for AP image download.
chassis_number	Chassis number, which can be either 1 or 2.
active	Specifies an active instance.
standby	Specifies a standby instance.
R0	Specifies the route processor for Slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to verify the AP image download statistics:

```
Device# show wireless stats ap image-download

AP image download info for last attempt
AP Name  Count  ImageSize   StartTime          EndTime            Diff(secs)  Predownload
 Aborted  Method
-------------------------------------------------------------------------------------------------------
JK3800   1      59228160    09/06/21 15:20:53  09/06/21 15:21:36  43          No
 No       HTTPS
mysore1  4      40509440    08/30/21 22:51:08  08/30/21 22:51:51  44          No
 No       HTTPS
```

show wireless stats ap packet

To verify the CAPWAP control packets aggregated in the controller, use the **show wireless stats ap packet** command.

show wireless stats ap packet

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE 17.14.1	This command was introduced.

Examples

The following command displays the CAPWAP control packets aggregated in the controller.

```
Device# show wireless stats ap packet

Packet stats

Capwap Control Packets Received* : 11183016
Capwap Data Keep Alive Packets Received : 160399
Capwap Data DOT1X EAP Packets Received: 549
Capwap Data DOT1X Mgmt Packets Received: 6003
Capwap Data DOT1X Key Type Packets Received: 0
Capwap Data DOT1X Control Packets Received: 0
Capwap Data ARP Packets Received: 0
Capwap Data IP Packets Received: 0
Capwap Data IPV6 Packets Received: 0
Capwap Data RRM Packets Received: 0
Capwap Data DHCP Packets Received: 0
Capwap Data RFID Packets Received: 0
Capwap Data IAPP Packets Received: 2531939
Capwap Dgram Input Errors : 0
Capwap Discovery Packets Received : 22299
Capwap Discovery Dgram Input Errors : 0
Aggregated Capwap Control Packets Sent: 119337
**** Note: Capwap control packets exclude discovery/primary discovery packets ****
```

show wireless stats client delete reasons

To display client-deletion statistics categorized by the source and reason for deletion, use the **show wireless stats client delete reasons** command.

show wireless stats client delete reasons

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.1.1	This command was introduced.
Cisco IOS XE 26.2.1	The command output was modified to include client-deletion reasons reported by access points using the LocalMAC architecture

The following example displays client-deletion statistics, including deletion reasons reported by the access point:

```
Device# show wireless stats client delete reasons

Total client delete reasons
---------------------------
Controller deletes
---------------------------
---------------------------
No Operation                                                    : 0
Unknown                                                         : 0
Session Manager                                                 : 0
Connection timeout                                              : 0
Datapath plumb                                                  : 0
WPA key exchange timeout                                        : 0
802.11w MAX SA queries reached                                  : 0
Client deleted during HA recovery                               : 0
Inter instance roam failure                                     : 0
Inter instance roam success                                     : 0
Inter controller roam success                                   : 0
Due to mobility failure                                         : 0
NAS error                                                       : 0
Policy Manager internal error                                   : 0
80211v smart roam failed                                        : 0
DOT11v association failed                                       : 0
DOT11r pre-authentication failure                               : 0
SAE authentication failure                                      : 0
DOT11 failure                                                   : 0
DOT11 SAE invalid message                                       : 0
DOT11 denied data rates                                         : 0
802.11v Client RSSI lower than the association RSSI threshold   : 0
invalid QoS parameter                                           : 0
DOT11 IE validation failed                                      : 0
```

```
DOT11 group cipher in IE validation failed                    : 0
DOT11 invalid pairwise cipher                                 : 0
DOT11 invalid AKM                                             : 0
DOT11 unsupported RSN version                                 : 0
DOT11 invalid RSNIE capabilities                              : 0
DOT11 received invalid PMKID in the received RSN IE           : 0
DOT11 received invalid PMK length                             : 0
DOT11 invalid MDIE                                            : 0
DOT11 invalid FT IE                                           : 0
DOT11 AID allocation conflicts                                : 0
AVC client re-anchored at the foreign controller              : 0
Client EAP ID timeout                                         : 0
Client DOT1x timeout                                          : 0
Malformed EAP key frame                                       : 0
EAP key install bit is not expected                           : 0
EAP key error bit is not expected                             : 0
EAP key ACK bit is not expected                               : 0
Invalid key type                                              : 0
EAP key secure bit is not expected                            : 0
key description version mismatch                              : 0
wrong replay counter                                          : 0
EAP key MIC bit expected                                      : 0
MIC validation failed                                         : 0
MAC theft                                                     : 0
IP theft                                                      : 0
Policy bind failure                                           : 0
Web authentication failure                                    : 0
802.1X authentication credential failure                      : 0
802.1X authentication timeout                                 : 0
802.11 authentication failure                                 : 0
802.11 association failure                                    : 0
Manually excluded                                             : 0
DB error                                                      : 0
Anchor creation failure                                       : 0
Anchor invalid Mobility BSSID                                 : 0
Anchor no memory                                              : 0
Call admission controller at anchor node                      : 0
Supplicant restart                                            : 0
Port admin disabled                                           : 0
Reauthentication failure                                      : 0
Client connection lost                                        : 0
Error while PTK computation                                   : 0
MAC and IP theft                                              : 0
QoS policy failure                                            : 0
QoS policy send to AP failure                                 : 0
QoS policy bind on AP failure                                 : 0
QoS policy unbind on AP failure                               : 0
Static IP anchor discovery failure                            : 0
VLAN failure                                                  : 0
ACL failure                                                   : 0
Redirect ACL failure                                          : 0
Accounting failure                                            : 0
Security group tag failure                                    : 0
FQDN filter definition does not exist                         : 0
Wrong filter type, expected postauth FQDN filter              : 0
Wrong filter type, expected preauth FQDN filter               : 0
Invalid group id for FQDN filter valid range  1..16           : 0
Policy parameter mismatch                                     : 0
Reauth failure                                                : 0
Wrong PSK                                                     : 0
Policy failure                                                : 0
AAA server unavailable                                        : 0
AAA server not ready                                          : 0
No dot1x method configuration                                 : 0
```

```
Association connection timeout                                  : 0
MAC-AUTH connection timeout                                     : 0
L2-AUTH connection timeout                                      : 0
L3-AUTH connection timeout                                      : 0
Mobility connection timeout                                     : 0
static IP connection timeout                                    : 0
SM session creation timeout                                     : 0
IP-LEARN connection timeout                                     : 0
NACK IFID exists                                                : 0
Guest-LAN invalid MBSSID                                        : 0
Guest-LAN no memory                                             : 0
Guest-LAN ceate request failed                                  : 0
EoGRE Reset                                                     : 0
EoGRE Generic Join Failure                                      : 0
EoGRE HA-Reconciliation                                         : 0
Wired idle timeout                                              : 0
IP Update timeout                                               : 0
SAE Commit received in Associated State                         : 0
NACK IFID mismatch                                              : 0
EoGRE Invalid VLAN                                              : 0
EoGRE Empty Domain                                              : 0
EoGRE Invalid Domain                                            : 0
EoGRE Domain Shut                                               : 0
EoGRE Invalid Gateway                                           : 0
EoGRE All Gateways down                                         : 0
EoGRE Flex - no active gateway                                  : 0
EoGRE Rule Matching error                                       : 0
EoGRE AAA Override error                                        : 0
EoGRE client onboarding error                                   : 0
EoGRE Mobility Handoff error                                    : 0
L3 VLAN Override connection timeout                             : 0
Delete received from AP                                         : 0
QoS failure                                                     : 0
WPA group key update timeout                                    : 0
DOT11 unsupported client capabilities                           : 0
DOT11 association denied unspecified                            : 0
DOT11 AP have insufficient bandwidth                            : 0
DOT11 invalid QoS parameter                                     : 0
Client not allowed by assisted roaming                          : 0
Wired client deleted due to WGB delete                          : 0
Client Abort                                                    : 0
Mobility peer delete                                            : 0
No IP                                                           : 0
BSSID down                                                      : 0
DOT11 QoS policy                                                : 0
Roam across policy profile deny                                 : 0
4WAY handshake failure - M1 issue                               : 0
4WAY handshake failure - M3 issue                               : 0
Exclusion policy template fail                                  : 0
DOT11 Cipher Suite Rejected                                     : 0
WLAN-ID mismatch in access accept failures                      : 0
EasyPSK AAA unknown error                                       : 0
EasyPSK unspecified error                                       : 0
EasyPSK PSK mismatch error                                      : 0
EasyPSK radius busy error                                       : 0
EasyPSK limit reached error                                     : 0
EasyPSK bad 802.1X frame error                                  : 0
EasyPSK missing parameter error                                 : 0
Supplicant name failure                                         : 0
User name failure                                               : 0
Service set ID failure                                          : 0
Anchor VLAN ID failure                                          : 0
PSK failure                                                     : 0
PSK mode failure                                                : 0
```

```
Interim interval failure                                        : 0
Link-local bridging VLAN failure                                : 0
Link-local bridging VLAN failure                                : 0
Maximum client limit reached on AP                              : 0
Maximum client limit reached on AP per wlan                     : 0
Maximum client limit reached on AP radio per wlan               : 0
Maximum client limit reached on AP radio                        : 0
L3 Access Roam across policy profile deny                       : 0
L3 Access Inter controller roam deny                            : 0
-----------------------------
Informational Delete Reason
-----------------------------
Mobility WLAN down                                              : 0
AP upgrade                                                      : 0
L3 authentication failure                                       : 0
AP down/disjoin                                                 : 0
MAC authentication failure                                      : 0
Due to SSID change                                              : 0
Due to VLAN change                                              : 0
Admin deauthentication                                          : 0
Session timeout                                                 : 0
Idle timeout                                                    : 0
Supplicant request                                              : 0
Mobility tunnel down                                            : 0
DOT11v timer timeout                                            : 0
DOT11 max STA                                                   : 0
IAPP disassociation for wired client                            : 0
Wired WGB change                                                : 0
Wired VLAN change                                               : 0
WGB Wired client joins as a direct wireless client              : 0
Incorrect credentials                                           : 0
Wired client cleanup due to WGB roaming                         : 0
Radio Down                                                      : 0
Mobility failure on fast roam                                   : 0
Due to IP Zone change                                           : 0
Access denied due to Locally Administered MAC Address           : 0
-----------------------------
-----------------------------
Client initiate delete
-----------------------------
Deauthentication or disassociation request                      : 0
Client DHCP                                                     : 0
Client EAP timeout                                              : 0
Client 8021x failure                                            : 0
Client device idle                                              : 0
Client captive portal security failure                          : 0
Client decryption failure                                       : 0
Client interface disabled                                       : 0
Client user triggered disassociation                            : 0
Client miscellaneous reason                                     : 0
Unknown                                                         : 0
Client peer triggered                                           : 0
Client beacon loss                                              : 0
STA triggered PMK timeout                                     : 0
Excess ARP activity                                           : 0
Excess NDP activity                                           : 0
Unspecified QOS failure                                         : 0
Dpath encode failed                                             : 0
VRF-VLAN mismatch failures                                      : 0
-----------------------------
AP Deletes
-----------------------------
When client is sending disassociation                         : 0
Idle timeout                                                  : 0
```

```
Client ACL mismatch                                          : 0
AP authentication stop                                       : 0
Association expired at AP                                    : 0
4-way handshake failed                                       : 0
DHCP timeout                                                 : 0
Reassociation timeout                                        : 0
SA query timeout                                             : 0
Intra AP roam                                                : 0
Channel switch at AP                                         : 0
Bad AID                                                      : 0
AP requests for client deletion                              : 0
Interface reset                                              : 0
All on slot                                                  : 0
Link to client has changed and uplink can be reaper          : 0
Slot disable                                                 : 0
MIC failure                                                  : 0
VLAN delete                                                  : 0
Channel change                                               : 0
Stop reassociation                                           : 0
Packet maximum retry                                         : 0
Transmission deauthentication                                : 0
Sensor station timeout                                       : 0
Age timeout                                                  : 0
Transmission threshold fail                                  : 0
Uplink receive timeout                                       : 0
Sensor scan next radio                                       : 0
Sensor scan other BSSID                                      : 0
Authentication timeout and web-auth timeout                  : 0
Sending deauthentication packet to client                    : 0
AP IP learn timeout                                          : 0
Flex group change                                            : 0
EAPOL log off                                                : 0
EAP request timeout                                          : 0
4way handshake failure                                       : 0
MIC validation                                               : 0
Wrong replay counter                                         : 0
AP tunnel down                                               : 0
Inter roam                                                   : 0
Unknown client                                               : 0
Reauthentication timeout                                     : 0
Continuous idle timeout                                      : 0
RLDP cleanup                                                 : 0
Intra-switch roam                                            : 0
PEM cleanup                                                  : 0
RLAN Central switch                                          : 0
RLAN data path add failure                                   : 0
RLAN Delete                                                  : 0
RLAN Inactive timeout                                        : 0
RLAN MAB failure                                             : 0
CLSM No memory counter                                       : 0
CLSM BSSID mismatch                                          : 0
CLSM No ACL found                                            : 0
CLSM no parent WGB found                                     : 0
CLSM Key plumb faiure                                        : 0
CLSM Mesh key plumb failure                                  : 0
CLSM data path add fail                                      : 0
CLSM Authentication response reject                          : 0
CLSM Authentication response send failure                    : 0
CLSM Association response send failure                       : 0
CLSM association response failure with status                : 0
CLSM Webauth timer expired                                   : 0
CLSM Dot1x timer expired                                     : 0
CLSM deauthentication and disassociation send failure        : 0
Driver event Class3 received                                 : 0
```

```
Driver event PsPoll when not authenticated                : 0
Driver event ioctl error                                  : 0
Flex FT failure                                           : 0
CLSM driver add failure                                   : 0
Driver client not found                                   : 0
Driver management packet allocation failure               : 0
Driver invalid cipher                                     : 0
Driver invalid association identifier                     : 0
Driver invalid key                                        : 0
Driver firmware set key failure                           : 0
Driver found invalid HT VHT rates                         : 0
Driver found invalid legacy rates                         : 0
Driver found no overlapping legacy rates                  : 0
Driver found maximum VHT streams                          : 0
Driver found association identifer in use                 : 0
Driver found too many association requests                : 0
Driver found cipher attach failure                        : 0
Driver found algorithm mismatch                           : 0
Driver found invalid key length                           : 0
Driver found invalid key index                            : 0
Driver rejected association due to authentication failure  : 0
Driver found client addition to internal records failure   : 0
Driver found client association entry failure             : 0
Driver found client additions to firmware failure         : 0
Driver related internal failure                           : 0
AP limiting maximum client per AP                         : 0
AP limiting maximum client per AP radio per wlan          : 0
AP limiting maximum client per AP radio                   : 0
-------------------
PC Analytics stats:
---------------------------------------
Report Type            Processed Reports
---------------------------------------
 PC_STA_INFO          : 0
 PC_NEIGH_INFO        : 0
 PC_LOW_RSSI          : 0
 PC_TEMP_DISCONN      : 0
 PC_AP_FAILURE        : 0
 PC_UNKNOWN_AP        : 0
---------------------------------------
Report Type            Dropped Reports
---------------------------------------
 PC_STA_INFO          : 0
 PC_NEIGH_INFO        : 0
 PC_LOW_RSSI          : 0
 PC_TEMP_DISCONN      : 0
 PC_AP_FAILURE        : 0
 PC_UNKNOWN_AP        : 0
```

show wireless statistics mobility

To see the wireless mobility manager statistics, use the **show wireless stats mobility** command.

show wireless stats mobility {**dtls** | **messages**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

dtls	View the mobility dtls messages statistics.
messages	View the mobility messages statistics.
chassis-number	Enter the chassis number as either 1 or 2.
active	Active instance of the configuration in Route-processor slot 0.
standby	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the statistics of the wireless mobiliy manager:

```
Device# show wireless stats mobility
```

show wireless stats mesh packet error

To see the packet statistics of all connected mesh APs, use the **show wireless stats mesh packet error** command.

show wireless stats mesh packet error [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

packet	Shows packet statistics information.
error	Shows packet statistics of all connected mesh APs.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the packet error statistics of all connected mesh APs:

```
Device# show wireless stats mesh packet error
```

show wireless stats pmk-propagation

To view the PMK propagation statistics on the Cisco wireless controller, use the **show wireless stats pmk-propagation** command in privileged EXEC mode.

show wireless stats pmk-propagation

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.8.1	This command was introduced.

Examples

The following example shows the PMK propagation statistics on the Cisco Wireless controller:

```
Device# show wireless stats pmk-propagation

Site-Tag       Bulk Sync Success     Bulk Sync Failure     Incremental Sync Failure
-------------------------------------------------------------------------------------
flex-site-tag       97                       0                    0
```

show wireless stats mesh security and queue

To see the mesh queue and security statistics of all connected mesh APs, use the **show wireless stats mesh** command.

show wireless stats mesh {**security** | **queue**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

queue	Shows queue statistics of all connected mesh APs.
security	Shows security statistics of all connected mesh APs.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the security statistics of all connected mesh APs:

```
Device# show wireless stats mesh security
```

show wireless stats client detail

To display detailed wireless client statistics, including client association, authentication, LocalMAC lookup, PMK lookup, anchor-request, and VLAN-override statistics, use the **show wireless stats client detail** command.

show wireless stats client detail

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1	This command was introduced.
Cisco IOS XE 26.2.1	The command output was modified to include LocalMAC client-state lookup, PMK lookup, and anchor-request statistics.

This example shows how to verify the statistics about client including the LocalMAC statistics introduced in Cisco IOS XE 26.2.1:

```
Device# show wireless stats client detail
[…]
Total STA-lookup received                : 0
Total STA-response sent                  : 0
Total STA-response sent allow            : 0
Total STA-response sent deny             : 0
Total STA-response sent excluded         : 0
Total PMKSA-lookup received              : 0
Total PMKSA-response sent                : 0
Total PMKSA not found                    : 0
Total PMKR0-lookup received              : 0
Total PMKR0-response sent                : 0
Total PMKR0 not found                    : 0
Total Anchor-req received                : 0
…]
Total L3 VLAN Override vlan change received          : 1
Total L3 VLAN Override disassociations sent          : 1
Total L3 VLAN Override re-associations received      : 1
Total L3 VLAN Override successful VLAN change        : 1
[…]
L3 VLAN Override connection timeout                  : 0
```

show wireless stats redundancy config database

To view the high availabilty redundancy configuration statistics, use the **show wireless stats redundancy config database** command.

show wireless stats redundancy config database { **mobility** | **nmspd** | **rrm** | **wncd** | **wncmgrd** } *instance-id* **chassis** { *chassis-num* | **active** | **standby** } **R0**

Syntax Description

mobility	Specifes the statistics of Mobilityd configuration database.
nmspd	Specifes the statistics of NMSPD configuration database.
rrm	Specifes the statistics of RRM configuration database.
wncd	Specifes the statistics of WNCD configuration database.
wncmgrd	Specifes the statistics of WNCD configuration database.
instance-id	Instance ID. Valid values range from 0 to 7.
chassis	Specifies the chassis.
chassis-num	Chassis number.
active	Specifies the active instance.
standby	Specifies the standby instance.
R0	Specifies the route processor slot.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the high availabilty redundancy configuration statistics:

```
Device# show wireless stats redundancy config database wncd 0 chassis 1 R0

Wncd Configuration Sync Statistics
 Index   Number of Locks    Duration(sec)   Threshold-count   Max-Duration(nsec)
--------------------------------------------------------------------------------
    1        535               127              1           1112156700
```

show wireless summary

To display the number of access points, radios and wireless clients known to the controller, use the **show wireless summary** command in privileged EXEC mode.

show wireless summary

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless summary** command:

```
Device# show wireless summary

Access Point Summary

               Total    Up    Down
-----------------------------------
802.11a/n          2     2       0
802.11b/g/n        2     2       0
All APs            2     2       0

Client Summary

Current Clients : 1
Excluded Clients: 0
Disabled Clients: 0
```

show wireless tag policy detailed

To display VAP status for 802.11ax and 802.11be WLAN on 6 GHz band, run the **show wireless tag policy detailed***11ax-prof-name-policy-tag***vap-id**command.

show wireless tag policy detailed *11ax-prof-name-policy-tag* **vap-id**

Syntax Description

11ax-prof-name-policy-tag	Specifies the dot11be wireless profile name.
vap-id	Show policy-tag WLAN to VAP-ID details.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to display VAP status for 802.11ax WLAN on 6 GHz band:

```
Device #show wireless tag policy detailed 11ax-prof-name-policy-tag vap-id
WLAN-ID  WLAN profile name                  Policy profile name
     VAP-ID  status    SET-ID  Beacon-Protection status  operational state
------------------------------------------------------------------------------------------
1            open                           default-policy-profile
   2       Enabled   1*      Enabled (128bit cipher)   Enabled
4          wpa3sae                          policy-profile              1
       Enabled   1       Enabled (128bit cipher)   Enabled
5          wpa3owe                          policy-profile              3
       Enabled   1       Disabled                  Enabled
15         mbssid-1                         policy-profile              4
       Enabled   1       Disabled                  Enabled
12         mbssid-8                         default-policy-profile
     6       Enabled   2*      Enabled (256bit cipher)   Enabled
10         mbssid-6                         policy-profile              5
       Enabled   2       Enabled (256bit cipher)   Enabled
7          mbssid-3                         default-policy-profile
     7       Enabled   2       Disabled                  Enabled
9          mbssid-5                         policy-profile              8
       Enabled   2       Disabled                  Enabled
13         mbssid-9                         default-policy-profile
     9       Enabled   3*      Disabled                  Enabled
14         mbssid-10                        policy-profile
12       Enabled   3       Disabled                  Enabled
111        mbssid-a                         policy-profile
10       Enabled   3       Disabled                  Enabled
112        mbssid-b                         default-policy-profile
```

```
     11      Enabled   3       Disabled                  Enabled
17       PSKWLAN                          policy-profile
13      Enabled   0       N/A                       N/A
8        mbssid-4                         default-policy-profile
     14      Enabled   0       N/A                       N/A
6        mixed-mode                       policy-profile
15      Enabled   0       N/A                       N/A

RLAN-ID  Remote-LAN profile name          Policy profile name
    PORT-ID   VAP-ID
-------------------------------------------------------------------------------
16385    rlan_profile                rlan*policy                1
  16
```

The following example shows how to display VAP status for 802.11be WLAN on 6 GHz band:

```
Device #show wireless tag policy detailed 11be-prof-name-policy-tag vap-id
|-------------------------------------------------------------|

                        |                       6GHz VAP information
           |


|-------------------------------------------------------------|

              WLAN     MBBSID
operational
WLAN-ID  WLAN profile name                 Policy profile name
     VAP-ID  status    SET-ID  PHY mode  Beacon-Protection status
state
-------------------------------------------------------------------------------------------------------
4        wpa3sae                           policy-profile              1
      Enabled   1*      802.11ax  Enabled (128bit cipher)   Enabled (11ax
 downgraded)
5        wpa3owe                           policy-profile              2
       Enabled   1       802.11ax  Disabled                  Enabled (11ax
 downgraded)
15       mbssid-1                          policy-profile              3
       Enabled   1       802.11ax  Disabled                  Enabled (11ax
 downgraded)
9        mbssid-5                          policy-profile              4
       Enabled   1       802.11ax  Disabled                  Enabled (11ax
 downgraded)
13       mbssid-9                          default-policy-profile
     5       Enabled   2*      802.11ax  Disabled                 Enabled
 (11ax downgraded)
14       mbssid-10                         policy-profile              6
       Enabled   2       802.11ax  Disabled                  Enabled (11ax
 downgraded)
112      mbssid-b                          default-policy-profile
     7       Enabled   0       802.11be  Enabled (256bit cipher)   Disabled
```

```
 (no MBSSID slot)
17       PSKWLAN                          policy-profile              8
       Enabled   0       N/A       N/A                        N/A
1              open                       default-policy-profile
     9       Enabled   3*      802.11be  Enabled (128bit cipher)   Enabled

8        mbssid-4                         default-policy-profile
     10      Enabled   0       N/A       N/A                         N/A

6        mixed-mode                       policy-profile
11      Enabled   0       N/A       N/A                        N/A

7        mbssid-3                         default-policy-profile
     13      Enabled   4*      802.11be  Enabled (256bit cipher)   Enabled

10       mbssid-6                         policy-profile
14      Enabled   4       802.11be  Enabled (256bit cipher)   Enabled

12       mbssid-8                         default-policy-profile
     15      Enabled   4       802.11be  Enabled (256bit cipher)   Enabled

111      mbssid-a                         policy-profile
16      Enabled   4       802.11be  Enabled (256bit cipher)   Enabled


RLAN-ID  Remote-LAN profile name          Policy profile name
    PORT-ID   VAP-ID
-----------------------------------------------------------------------------------
16385    rlan_profile               rlan*policy                1
  12
```

show wireless tag rf

To displaye the details of wireless RF tag, use the **show wireless tag rf** command.

show wireless tag rf { **summary** | **detailed***rf-tag-name*

Syntax Description

summary	Disaplys the summary of all RF tags.
detailed	Disaplys details of an RF tag.
rf-tag-name	RF tag name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows the sample output of **show wireless tag rf summary** command:

```
Device# show  wireless tag rf summary

Number of RF Tags: 1

RF tag name                     Description
------------------------------------------------------------------------
default-rf-tag                  default RF tag
```

show wireless tag rf detailed

To view the status of wireless tag RF detailed parameters, use the **show wireless tag rf detailed** command.

show wireless tag rf detailed *rf-tag-name*

Syntax Description

Keywords	Description
rf-tag-name	Specifies the name of the RF tag.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Cupertino 17.18.2	This command is introduced.

Examples

This example shows the status of wireless tag RF detailed parameters in the privileged exec mode:

```
Device# show wireless tag rf detailed wat-rf-tag

Tag Name                      : wat-rf-tag
Description                   :
---------------------------------------
6ghz RF Policy                : default-rf-profile-6ghz
5ghz RF Policy                : Global Config
2.4ghz RF Policy              : Global Config
2.4ghz slot 0 Radio Profile   : wat-radio-profile
5ghz slot 0 Radio Profile     : default-radio-profile
5ghz slot 1 Radio Profile     : wat-radio-profile
6ghz slot 1 Radio Profile     : default-radio-profile
5ghz slot 2 Radio Profile     : default-radio-profile
6ghz slot 2 Radio Profile     : wat-radio-profile
6ghz slot 3 Radio Profile     : default-radio-profile
AP Beam State                 : Boresight
URWB Profile                  :
```

show wireless urlfilter details

To view the details of a specified wireless URL filter, use the **show wireless urlfilter details** command.

show wireless urlfilter details *list-name*

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the details of a specified wireless URL filter:

```
Device# show wireless urlfilter details urllist_flex_preauth
List Name..................... : urllist_flex_preauth
Filter ID..................... : : 1
Filter Type................... : PRE-AUTH
Action........................ : PERMIT
Redirect server ipv4...... : 8.8.8.8
Redirect server ipv6...... : 2001:0300:0008:0000:0000:0000:0000:0081
Configured List of URLs
   URL........................ : url1.dns.com
```

show wireless urlfilter summary

To view the summary of all wireless URL filters, use the **show wireless urlfilter summary** command.

show wireless urlfilter summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of all wireless URL filters:

```
Device# show wireless urlfilter summary
Black-list    - DENY
White-list    - PERMIT
Filter-Type   - Specific to Local Mode

URL-List                          ID  Filter-Type  Action   Redirect-ipv4  Redirect-ipv6
-------------------------------------------------------------------------------------------------------
urllist_flex_preauth              1    PRE-AUTH     PERMIT    8.8.8.8
2001:0300:0008:0000:0000:0000:0000:0081
```

show wireless vlan details

To see the VLAN details, use the **show wireless vlan details** command.

show wireless vlan details [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the VLAN details:

```
Device# show wireless vlan details chassis active r0
```

show wireless wgb mac-address

To view all the clients of the wireless workgroup bridge (WGB) using its MAC address, use the **show wireless wgb mac-address** command.

show wireless wgb mac-address *mac-address* **detail**

Syntax Description

mac-address	MAC address of the WGB.
detail	View clients of the wireless WGB.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the clients of the wireless WGB:

```
Device# show wireless wgb mac-address 98-C7-7B-09-EF-ED detail
```

show wireless wgb summary

To see the active workgroup bridges (WGB), use the **show wireless wgb summary** command.

show wireless wgb summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the active workgroup bridges (WGB):

```
Device# show wireless wgb summary
```

show wireless wps mfp ap summary

To verify, if access points support Management Frame Protection (MFP) validation and protection, use the **show wireless wps mfp ap summary** command.

show wireless wps mfp ap summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the access points that support MFP validation and protection:

```
Device# show wireless wps mfp ap summary
AP Name                          Radio MAC               Validation            Protection
-------------------------------------------------------------------------------------------
AP002A.1087.CBF4                 00a2.eefd.bdc0          Enabled               Enabled
AP58AC.78DE.9946                 00a2.eeb8.4ae0          Enabled               Enabled
APb4de.3196.caac                 4c77.6d83.6b90          Enabled               Enabled
```

show wireless wps mfp statistics

To view the Management Frame Protection (MFP) statistics, use the **show wireless wps mfp statistics** command.

show wireless wps mfp statistics

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the Management Frame Protection (MFP) statistics:

```
Device# show wireless wps mfp statistics
BSSID          Radio DetectorAP                        LastSourceAddr Error           Count
     FrameTypes

aabb.ccdd.eeff a     AP3800                            aabb.ccdd.eeff Invalid MIC     10
     Beacon, Probe Response
                                                                     Invalid MIC     20
     Beacon, Probe Response
```

show wireless wps mfp summary

To view the detailed information of Management Frame Protection (MFP), use the **show wireless wps mfp summary** command.

show wireless wps mfp summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the detailed information of Management Frame Protection (MFP):

```
Device# show wireless wps mfp summary
Management Frame Protection
  Global Infrastructure MFP state : Enabled
  AP Impersonation detection      : Disabled
  Key refresh interval            : 15
```

show wireless wps rogue

To see the Rogue AP and Client information, use the **show wireless wps rogue** command.

See Adhoc Rogues (IBSS) information
show wireless wps rogue {**adhoc** | {**detailed***mac-addr*} | **summary**}

See rogue AP information
show wireless wps rogueap {**clients***mac-addr* | **customsummary** | **detailed***mac-addr* | **friendlysummary** | **listmac-address***mac-addr* | **malicious summary** | **summary** | **unclassifiedsummary** | **rldp** {**summary** | **in-progress** | **detailed***rogue-ap-mac-addr*}}

See rogue auto-containment information
show wireless wps rogueauto-contain

See rogue client information
show wireless wps rogueclient {**summary** | **detailed***mac-addr*}

See rogue ignore list
show wireless wps rogueignore-list

See classification rule information
show wireless wps roguerule {**detailed***rule-name* | **summary**}

See statistics about rogue feature
show wireless wps roguestats[**internal**]

Syntax Description

mac-address	MAC address of the client.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the rogue feature statistics:

```
Device# show wireless wps rogue stats
```

show wireless wps rogue ap summary

To display a list of all rogue access points detected by the device, use the **show wireless wps rogue ap summary** command.

show wireless wps rogue ap summary

Command Default None.

Command Modes Privileged EXEC

Command History

Release	Modification
	This command was introduced.

Usage Guidelines None.

This example shows how to display a list of all rogue access points detected by the device:

```
Device# show wireless wps rogue ap summary
Rogue Location Discovery Protocol            : Disabled
Rogue on wire Auto-Contain                   : Disabled
Rogue using our SSID Auto-Contain            : Disabled
Valid client on rogue AP Auto-Contain        : Disabled
Rogue AP timeout                             : 1200
Rogue Detection Report Interval              : 10
Rogue AP minimum RSSI                        : -128
Rogue AP minimum transient time              : 0

Number of rogue APs detected : 624

MAC Address         Classification     # APs    # Clients   Last Heard
-------------------------------------------------------------------------------------
0018.e78d.250a      Unclassified       1        0           Thu Jul 25 05:04:01 2013
0019.0705.d5bc      Unclassified       1        0           Thu Jul 25 05:16:26 2013
0019.0705.d5bd      Unclassified       1        0           Thu Jul 25 05:10:28 2013
0019.0705.d5bf      Unclassified       1        0           Thu Jul 25 05:16:26 2013
```

show wireless wps rogue client detailed

To view the detailed information of a specific rogue client, use the **show wireless wps rogue client detailed** *client-mac* command.

show wireless wps rogue client detailed *client-mac*

Syntax Description

client-mac	MAC address of the rogue client.

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

None.

This example shows how to display the detailed information for a specific rogue client:

```
Device# show wireless wps rogue client detail  0024.d7f1.2558
Rogue BSSID                         : 64d8.146f.379f
Rogue Radio Type                    : 802.11n - 5GHz
State                               : Alert
First Time Rogue was Reported       : Wed Aug  7 12:51:43 2013
Last Time Rogue was Reported        : Wed Aug  7 12:51:43 2013
Reported by
  AP 2
    MAC Address                     : 3cce.7309.0370
    Name                            : AP3502-talwar-ccie
    Radio Type                      : 802.11a
    RSSI                            : -42 dBm
    SNR                             : 47 dB
    Channel                         : 52
    Last reported by this AP        : Wed Aug  7 12:51:43 2013
```

show wireless wps rogue containment summary

To verify the containment summary details for all the AP radios, use the **show wireless wps rogue containment summary** command.

show wireless wps rogue containment summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.17.1	This command was introduced.

Examples

The following examples shows how to verify the containment summary details for all the AP radios:

```
Device# show wireless wps rogue containment summary
Rogue Containment activities for each managed AP

AP: 6XXX.b4XX.2aXX  Slot: 1
  Active Containments   : 3
   Containment Mode     : OFFCHAN_PMF
   Rogue AP MAC         : 68XX.b4XX.2aXX
   Containment Channels : 40
```

show wireless wps rogue ap detailed

To view the detailed information of a rogue access point, use **show wireless wps rogue ap detailed** *mac-address* command.

show wireless wps rogue ap detailed *0008.30a7.7797*

Syntax Description

mac-address The MAC address of the rogue access point.

Note
If a rogue access point uses dot11n on 2.4GHz, the command output displays the **radio type** as **dot11g , dot11n - 2.4 GHz**.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Fuji 16.7.x	This command was introduced.

Example

This example shows how to display the detailed information about a rogue access point:

```
Device# wireless wps rogue ap detailed 0008.30a7.7797
Rogue Event history

Rogue BSSID                          : 0008.30a7.7797
Is Rogue on Wired Network            : No
Classification                       : Unclassified
Manually Contained                   : Yes
State                                : Contained Pending
Containment Level                    : 1
Number of Containing APs             : 0
First Time Rogue was Reported        : 03/08/2017 17:41:55
Last Time Rogue was Reported         : 03/08/2017 21:48:34

Number of clients                    : 0

Reported By
  AP Name : JEWLC-AA
    MAC Address                      : 00d7.8f4e.7240
    Detecting slot ID                : 0
    Radio Type                       : dot11g , dot11n - 2.4 GHz
    SSID                             : psk
    Channel                          : 5
    Channel Width                    : 20 MHz
    RSSI                             : -128 dBm
    SNR                              : 0 dB
    Encryption                       : Enabled
    ShortPreamble                    : Disabled
```

```
WPA Support                          : Not Friendly
Last reported by this AP             : 03/08/2017 21:48:34
```

show wireless wps rogue client summary

To display summary of WPS rogue clients, use the **show wireless wps rogue client summary** command.

show wireless wps rogue client summary

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Example

The following displays the output of the **show wireless wps rogue client summary** command:

```
Device# show wireless wps rogue client summary
Validate rogue clients against AAA  : Disabled
Validate rogue clients against MSE  : Enabled
Number of rogue clients detected : 0
```

show wireless wps rogue stats

To view the statistics about the rogue feature, use the **show wireless wps rogue stats** command.

show wireless wps rogue stats

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.17.1	This command was introduced.

Examples

The following example shows you how to verify the statistics about the rogue feature:

```
Device# show wireless wps rogue stats
Stats
  Alert                          : 256
  Internal                       : 0
  External                       : 0
  Contained                      : 1
  Containment-pending            : 0
  Threat                         : 0
  Pending                        : 0
Rogue Clients
  Total/Max Scale                : 20/16000
  Contained                      : 0
  Containment-pending            : 0
.
.
.
```

show wireless wps summary

To view the detailed information of wps, use the **show wireless wps summary** command.

show wireless wps summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.5	The output of the command was modified to include ARP activity information.

This example shows if the Management Frame Protection (MFP) is enabled or disabled:

```
Device# show wireless wps summary

Client Exclusion Policy
  Excessive 802.11-association failures   : unknown
  Excessive 802.11-authentication failures: unknown
  Excessive 802.1x-authentication         : unknown
  IP-theft                                : unknown
  Excessive Web authentication failure    : unknown
  Failed Qos Policy                       : unknown

Management Frame Protection
  Global Infrastructure MFP state : Enabled
  AP Impersonation detection      : Disabled
  Key refresh interval            : 15
```

This example shows whether rate limiting is enabled for ARP packets:

```
Device# show wireless wps summary

Client Exclusion Policy
  Excessive 802.11-association failures   : Enabled
  Excessive 802.1x-authentication         : Enabled
  Mac and IP-theft                        : Enabled
  Excessive Web authentication failure    : Enabled
  Failed Qos Policy                       : Enabled
  Excessive ARP Activity                  : Enabled (per policy setting)
```

show wlan name client stats

To view the WLAN client statistics, use the **show wlan name client stats** command.

show wlan name *wlan-name* **client stats**

Syntax Description

wlan-name	WLAN name.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the WLAN client statistics:

```
Device# show wlan name wlan1 client stats

Wlan Profile Name: wlan1, Wlan Id: 3
Current client state statistics:
------------------------------------------------------------------------------
  Authenticating         : 0
  Mobility               : 0
  IP Learn               : 0
  Webauth Pending        : 0
  Run                    : 0

Locally Administered MAC Clients  : 0
L3 Access Clients                 : 0

.
.
.
```

show wlan summary sort ascending client-count

To view the WLAN summary sorted ascendingly based on the client count, use the **show wlan summary sort ascending client-count** command.

show wlan summary sort ascending client-count

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the WLAN summary sorted ascendingly based on the client count:

```
Device# show wlan summary sort ascending client-count
--------------------------------------------------------------------------------------
Wlan-name                       ID            Client count           Data Usage
--------------------------------------------------------------------------------------
rlan_test_1                     1               1                     6277
WLAN_CA_WPA2_AES_DOT1X          70              1                     167781
```

show wlan summary sort descending client-count

To view the WLAN summary sorted descendingly based on the client count, use the **show wlan summary sort descending client-count** command.

show wlan summary sort descending client-count

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the WLAN summary sorted descendingly based on the client count:

```
Device# show wlan summary sort descending client-count
-------------------------------------------------------------------------------------
Wlan-name                       ID            Client count           Data Usage
-------------------------------------------------------------------------------------
rlan_test_1                     1               1                     6277
WLAN_CA_WPA2_AES_DOT1X          70              1                     167781
```

show wlan summary sort ascending data-usage

To view the wlan summary sorted ascendingly based on the data usage, use the **show wlan summary sort ascending data-usage** command.

show wlan summary sort ascending data-usage

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.1.1	This command was introduced.

This example shows how to view the wlan summary sorted ascendingly based on the data usage:

```
Device# show wlan summary sort ascending data-usage
-------------------------------------------------------------------------------------
Wlan-name                       ID            Client count           Data Usage
-------------------------------------------------------------------------------------
rlan_test_1                     1               1                      6277
WLAN_CA_WPA2_AES_DOT1X          70              1                      167781
```

show wlan summary sort descending data-usage

To view the WLAN summary sorted descendingly based on the data usage, use the **show wlan summary sort descending data-usage** command.

show wlan summary sort descending data-usage

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the WLAN summary sorted descendingly based on the data usage:

```
Device# show wlan summary sort descending data-usage
-------------------------------------------------------------------------------------
Wlan-name                       ID            Client count           Data Usage
-------------------------------------------------------------------------------------
WLAN_CA_WPA2_AES_DOT1X          70              1                      167781
rlan_test_1                     1               1                      6277
```

show wps summary

To display Wireless Protection System (WPS) summary information, use the **show wps summary** command.

show wps summary

Syntax Description This command has no arguments or keywords.

Command Default None

The following example shows how to display WPS summary information:

```
(Cisco Controller) > show wps summary
Auto-Immune
  Auto-Immune.................................. Disabled
Client Exclusion Policy
  Excessive 802.11-association failures.......... Enabled
  Excessive 802.11-authentication failures....... Enabled
  Excessive 802.1x-authentication................ Enabled
  IP-theft....................................... Enabled
  Excessive Web authentication failure........... Enabled
Trusted AP Policy
  Management Frame Protection.................... Disabled
  Mis-configured AP Action....................... Alarm Only
    Enforced encryption policy................... none
    Enforced preamble policy..................... none
    Enforced radio type policy................... none
    Validate SSID................................ Disabled
  Alert if Trusted AP is missing................. Disabled
  Trusted AP timeout............................. 120
Untrusted AP Policy
  Rogue Location Discovery Protocol.............. Disabled
    RLDP Action.................................. Alarm Only
  Rogue APs
    Rogues AP advertising my SSID................ Alarm Only
    Detect and report Ad-Hoc Networks............ Enabled
  Rogue Clients
    Validate rogue clients against AAA........... Enabled
    Detect trusted clients on rogue APs.......... Alarm Only
  Rogue AP timeout............................... 1300
Signature Policy
  Signature Processing........................... Enabled
...
```

shutdown

To close the RF Profile and disable the network, use the **shutdown** command. To disable shutdown execution, use the **no** form of this command.

shutdown

Syntax Description

shutdown	Shuts down the profile and disables network.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to close a RF Profile and disable the network.

```
Device(config-rf-profile)#shutdown
```