

Cisco Embedded Wireless Controller on Catalyst Access Points Command Reference for Cisco IOS XE 17.14.x

First Published: 2024-04-05

Americas Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
http://www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED “AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2024 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE

Preface xxvii

Document Conventions xxvii

Related Documentation xxix

Communications, services, and additional information xxix

Cisco Bug Search Tool xxix

Documentation feedback xxix

CHAPTER 1

Using the Command-Line Interface 1

Information About Using the Command-Line Interface 2

Command Modes 2

Understanding Abbreviated Commands 4

No and Default Forms of Commands 4

CLI Error Messages 4

Configuration Logging 5

Using the Help System 5

CHAPTER 2

Configuration Commands: a to f 7

aaa accounting identity 13

aaa accounting update periodic interval-in-minutes 15

aaa attribute list 16

aaa authentication dot1x 17

aaa authentication login 18

aaa authorization 19

aaa authorization credential download default 23

aaa authorization credential-download MY-METHOD-LIST group MY-SERVER-GROUP 24

aaa group server ldap 25

aaa group server radius 26
aaa local authentication default authorization 27
aaa new-model 28
aaa server radius dynamic-author 30
aaa session-id 32
aaa-override 34
aaa-policy 35
aaa-realm enable 36
absolute-timer 37
access-list 38
access-list acl-ace-limit 40
accounting-list 41
acl-policy 42
active-query timer 43
address 44
address prefix 46
allow at-least min-number at-most max-number 47
ap 48
ap auth-list 49
ap auth-list ap-cert-policy allow-mic-ap 50
ap auth-list ap-cert-policy allow-mic-ap trustpoint 51
ap auth-list ap-cert-policy mac-address MAC-address | serial-number AP-serial-number policy-type mic 52
ap auth-list ap-policy 53
ap capwap retransmit 54
ap capwap timers 55
ap country 57
ap dot11 24ghz cleanair 58
default ap dot11 24ghz cleanair device 59
ap dot11 24ghz dot11g 61
ap dot11 24ghz rate 62
ap dot11 24ghz rrm channel cleanair-event 64
ap dot11 24ghz rrm channel device 65
ap dot11 24ghz rrm optimized-roam 66

ap dot11 24ghz rx-sop threshold 67
ap dot11 24ghz shutdown 68
ap dot11 5ghz channelswitch quiet 69
ap dot11 5ghz cleanair 70
default ap dot11 5ghz cleanair device 71
ap dot11 5ghz power-constraint 72
ap dot11 5ghz rate 73
ap dot11 5ghz rrm channel cleanair-event 74
ap dot11 5ghz rrm channel device 75
ap dot11 5ghz rrm channel zero-wait-dfs 76
ap dot11 5ghz rx-sop threshold 77
ap dot11 5ghz shutdown 78
ap dot11 5ghz smart-dfs 79
ap dot11 80
ap dot11 beaconperiod 81
ap dot11 cac media-stream 82
ap dot11 cac multimedia 85
ap dot11 cac voice 86
ap dot11 cleanair 89
ap dot11 cleanair device 90
ap dot11 dot11n 91
ap dot11 dtpc 94
ap dot11 edca-parameters 96
ap dot11 load-balancing denial 98
ap dot11 load-balancing window 99
ap dot11 rf-profile 100
ap dot11 rrm 101
ap dot11 rrm channel 104
ap dot11 rrm channel cleanair-event 105
ap dot11 rrm channel dca 106
ap dot11 rrm channel-update mesh 108
ap dot11 rrm channel-update mesh bridge-group 109
ap dot11 rrm coverage 110
ap dot11 rrm group-member 112

ap dot11 rrm group-mode 113
ap dot11 rrm logging 114
ap dot11 rrm monitor 116
ap dot11 rrm ndp-type 117
ap dot11 24ghz rrm tpc 118
ap dot11 rrm txpower 119
ap dot11 rrm txpower 120
ap filter 121
ap fra 122
ap fra 5-6ghz interval 123
ap image predownload 124
ap name antenna band mode 125
ap name ble 126
ap name clear-personal-ssid 127
ap name controller 128
ap name country 129
ap name crash-file 130
ap name dot11 24ghz | 5ghz | 6ghz rrm channel update mesh 131
ap name dot11 24ghz slot 0 SI 132
ap name dot11 24ghz slot antenna 133
ap name dot11 24ghz slot beamforming 134
ap name dot11 24ghz slot channel 135
ap name dot11 24ghz slot cleanair 136
ap name dot11 24ghz slot dot11n antenna 137
ap name dot11 24ghz slot dot11ax bss-color 138
ap name dot11 24ghz slot shutdown 139
ap name dot11 5ghz slot {1 | 2} urwb dfs 140
ap name dot11 5ghz slot {1 | 2} urwb ptmp base 141
ap name dot11 dual-band cleanair 142
ap name dot11 dual-band shutdown 143
ap name dot11 rrm profile 144
ap name image 146
ap name icap subscription client anomaly-detection report-individual enable aggregate 147
ap name icap subscription client anomaly-detection report-individual per-client throttle 148

ap name icap subscription client anomaly-detection report-individual per-type throttle 149
ap name indoor 150
ap name ipsla 151
ap name keepalive 152
ap name lan 153
ap name led 154
ap name led-brightness-level 155
ap name location 156
ap name mesh backhaul rate dot11abg 157
ap name mdsn-ap 158
ap name mesh backhaul rate dot11ac 159
ap name name mesh backhaul rate dot11ax 160
ap name name new-ap-name 161
ap name no 162
ap name mesh backhaul rate 163
ap name mesh backhaul rate dot11n 164
ap name mesh block-child 165
ap name mesh daisy-chaining 166
ap name mesh ethernet mode access 167
ap name mesh ethernet mode trunk 168
ap name mesh linktest 169
ap name mesh parent preferred 170
ap name mesh security psk provisioning delete 171
ap name mesh vlan-trunking native 172
ap name monitor-mode dot11b 173
ap name name 174
ap name priority 175
ap name reset 176
ap name reset-button 177
ap name role 178
ap name slot 179
ap name static-ip 181
ap name static-ip 182
ap name shutdown 183

ap name urwb mode coordinator radio-off 184
ap name usb-module 185
ap name usb-module override 186
ap name vlan-tag 187
ap name write tag-config 188
ap name-regex 189
ap profile 190
ap remote-lan profile-name 191
ap remote-lan shutdown 192
ap remote-lan-policy policy-name 193
ap tag persistency enable 194
ap upgrade staggered 195
ap upgrade staggered iteration timeout 196
ap tag-source-priority 197
ap tag-sources revalidate 198
ap vlan-tag 199
assisted-roaming 200
attribute type 201
avg-packet-size packetsize 202
band-select client 203
band-select cycle 204
band-select expire 205
band-select probe-response 206
banner text 207
bss-transition 208
call-snoop 209
captive-bypass-portal 210
capwap-discovery 211
capwap aggregation 212
capwap backup 213
cco-password (image-download-mode cco) 214
cco-username (image-download-mode cco) 215
cco-version (image-download-mode cco) 216
cco-auto-check (image-download-mode cco) 217

ccx aironet-iesupport 218
cdp 219
central association 220
central authentication 221
central dhcp 222
central-webauth 223
channel zero-wait-dfs 224
chassis redundancy ha-interface shutdown 225
chassis redundancy keep-alive 226
chassis renumber 227
chassis transport 228
class 229
classify 231
class-map 232
clear aaa counters servers radius 234
clear chassis redundancy 235
clear mdns-sd cache 236
clear mdns-sd statistics 237
clear platform condition all 238
clear radius statistics 239
clear wireless wps rogue ap 240
clear wireless wps rogue client 241
clear wireless wps rogue stats 242
client association limit 243
channel foreign 245
client-l2-vnid 246
condition chan-width 247
consent activation-mode merge 248
convergence 249
copy configuration download 250
copy configuration upload 251
core-dump kernel limit 252
core-dump kernel type 253
coverage 254

crypto key generate rsa 255
crypto pki trustpoint 261
crypto pki trust pool import terminal 262
crypto pki trustpool clean 263
cts inline-tagging 264
cts role-based enforcement 265
cts sgt 266
custom-page login device 267
default 268
description 271
destination 272
destination stealthwatch-cloud 273
device-tracking binding vlan 274
dhcp-tlv-caching 275
dnscrypt 276
domain-name (DHCP) 277
dot11 5ghz slot1 radio-profile 278
dot11ax twt-broadcast-support 279
dot11 5ghz reporting-interval 280
dot11 reporting-interval 281
dot1x system-auth-control 282
dot11-tlv-accounting 284
eap profile 285
exclusionlist 286
exec-character-bits 287
exec time-out 288
exporter default-flow-exporter 289
fast-teardown 290
fallback-radio-shut 291
flex 292
flow exporter 293
flow monitor 294
flow record 295
ftp-path 296

ftp-password 297

ftp-server 298

ftp-username 299

CHAPTER 3 Configuration Commands: g to z 301

icap subscription client anomaly-detection report-individual enable aggregate 309

icap subscription client anomaly-detection report-individual per-client throttle 310

icap subscription client anomaly-detection report-individual per-type throttle 311

icap subscription client exclude telemetry-data wlan 312

idle-timeout 313

image-download-mode 314

inactive-timeout 315

install add file tftp 316

install add profile default 317

install activate 319

install activate auto-abort-timer 320

install activate file 321

install auto-abort-timer stop 322

install commit 323

install remove file backup_image 324

install remove profile default 325

install deactivate 326

install rollback 327

interface vlan 328

ip access-group 329

ip access-list extended 330

ip address 331

ip dhcp pool 333

ip dhcp-relay information option server-override 335

ip dhcp-relay source-interface 337

ip domain lookup 338

ip domain-name 340

ip flow-export destination 341

ip helper-address 342

ip http authentication 345
ip http auth-retry 347
ip http active-session-modules 348
ip http client secure-ciphersuite 349
ip http secure-ciphersuite 350
ip http secure-server 352
ip http server 354
ip http session-module-list 356
ip ssh 358
ip ssh version 360
ip tftp blocksize 362
ip verify source 363
ipv4 acl 364
ipv4 dhcp 365
ipv4 flow monitor 366
ipv4 flow monitor output 367
ipv6 flow monitor input 368
ipv6 flow monitor output 369
ipv6 access-list 370
ipv6 acl 372
ipv6-address-type 373
ipv6 address 374
ipv6 dhcp pool 376
ipv6 enable 379
ipv6 mld snooping 381
ipv6 nd managed-config-flag 382
ipv6 nd other-config-flag 383
ipv6 nd ra throttler attach-policy 384
ipv6 nd raguard policy 385
ipv6 traffic-filter 387
key chain 388
key config-key 389
key config-key password-encrypt 390
license air level 391

license smart (global config) 395
license smart (privileged EXEC) 406
line vty 413
load 414
local-auth ap eap-fast 415
local-site 416
location expiry 417
location notify-threshold 418
log-export-mode 419
login authentication 420
login block-for 421
mac-filtering 422
mab request format attribute 423
map-fast-ancestor-find 425
match (access-map configuration) 426
match activated-service-template 428
match any 430
match message-type 431
match non-client-nrt 432
match protocol 433
match service-instance 436
match service-type 437
match user-role 438
match username 439
match (access-map configuration) 440
match (class-map configuration) 442
match wlan user-priority 445
max-bandwidth 446
max-through 447
mdns-sd 448
mdns-sd-interface 449
mdns-sd flex-profile 450
mdns-sd profile 451
method fast 452

mgmtuser username 453
mobility backhaul-check coordinator-down 454
mobility backhaul-check eth-down 455
mobility mpo cos 456
mobility mpo enable 457
mobility mpo path 458
mobility mpo rssi 459
mobility mpo telemetry 460
mobility role 461
mobility scan 462
monitor capture (access list/class map) 463
monitor capture export 465
monitor capture (interface/control plane) 466
monitor capture limit 467
monitor capture match 469
monitor capture start 472
monitor capture stop 473
mop sysid 474
mpls ether-filter ethernet-I 475
mpls ether-filter ethertypes filtering 476
mpls high-availability timeout 477
multicast (URWB) 478
multicast vlan 479
nac 480
nas-id option2 481
network 482
network-key key 483
nmsp cloud-services enable 484
nmsp cloud-services http-proxy 485
nmsp cloud-services server token 486
nmsp cloud-services server url 487
nmsp notification interval 488
nmsp strong-cipher 490
no shutdown (URWB) 491

ntp auth-key 492
option 493
parameter-map type subscriber attribute-to-service 495
pae 496
parameter-map type webauth 497
password encryption aes 498
peer-blocking 499
pmf-deauth 500
policy 501
police 502
police cir 504
policy-map 505
policy-map 507
port 509
priority priority-value 510
public-ip 511
qos video 512
radius server 513
radius-server deadtime 514
radius-server attribute wireless accounting call-station-id 515
radius-server attribute wireless authentication call-station-id 517
range 519
record wireless avc basic 520
redirect 521
redirect portal 522
remote-lan 523
request platform software trace archive last 524
rf tag 525
rogue detection containment pmf-denial 526
rrc-evaluation 527
security 528
security dot1x authentication-list 529
security ft 530
security pmf 532

security static-wep-key 534
security web-auth 535
security wpa akm 536
security wpa akm sae 538
sensor-name 539
service-key 540
service-policy 541
service-policy qos 542
service-template 543
service timestamps 544
session-timeout 546
set 547
sftp-image-path (image-download-mode sftp) 554
sftp-image-server (image-download-mode sftp) 555
sftp-password (image-download-mode sftp) 556
sftp-password (trace-export) 557
sftp-path 558
sftp-server 559
sftp-username (image-download-mode sftp) 560
sftp-username (trace-export) 561
snmp-server enable traps wireless 562
snmp-server subagent cache 563
ssid broadcast persistent 564
statistics ap-system-monitoring alarm-enable 565
statistics ap-system-monitoring alarm-hold-time 566
statistics ap-system-monitoring alarm-retransmit-time 567
statistics ap-system-monitoring cpu-threshold 568
statistics ap-system-monitoring enable 569
statistics ap-system-monitoring mem-threshold 570
statistics ap-system-monitoring sampling-interval 571
statistics ap-system-monitoring stats-interval 572
stealthwatch-cloud-monitor 573
stopbits 574
strong-network-key 575

tag rf 576
tag site 577
tftp-image-path (image-download-mode tftp) 578
tftp-image-server (image-download-mode tftp) 579
tftp-path 580
tftp-server 581
timezone delta 582
udp-timeout 583
umbrella-param-map 584
update-timer 585
url 586
urlfilter list 587
urwb chan-list channel 588
urwb channel 589
urwb crypto policy 590
urwb crypto rotating-key-timeout 591
urwb cwidth 592
urwb-profile 593
urwb ptmp autoscan 594
urwb ptmp cluster-id 595
urwb ptmp rssi-threshold 596
urwb ptmp tower-id 597
urwb role 598
usb-enable 599
username 600
violation 602
wgb broadcast-tagging 603
wgb vlan 604
whitelist acl 605
wired-vlan-range 606
config wlan assisted-roaming 607
wireless aaa policy 608
wireless aaa policy 609
wireless autoqos policy-profile 610

wireless broadcast vlan 611
wireless client 612
wireless client mac-address 614
wireless client vlan-persistent 619
wireless config validate 620
wireless country 622
wireless exclusionlist mac address 623
wireless ipv6 ra wired 624
wireless load-balancing 625
wireless macro-micro steering transition-threshold 626
wireless macro-micro steering probe-suppression 627
wireless management certificate 628
wireless management interface 629
wireless management trustpoint 630
wireless mesh alarm association count 631
wireless mesh alarm high-snr 632
wireless mesh alarm low-snr 633
wireless mesh alarm max-children map 634
wireless mesh alarm max-children rap 635
wireless mesh alarm max-hop 636
wireless mesh alarm parent-change count 637
wireless mesh backhaul bdomain-channels 638
wireless mesh backhaul rrm 639
wireless mesh cac 640
wireless mesh ethernet-bridging allow-bdpu 641
wireless mesh security psk provisioning 642
wireless mesh subset-channel-sync 643
wireless ewc-ap ap ap-type 644
wireless ewc-ap ap capwap 645
wireless ewc-ap ap reload 646
wireless ewc-ap ap shell 647
wireless ewc-ap ap shell username 648
wireless ewc-ap preferred-master 649
wireless ewc-ap factory-reset 650

wireless ewc-ap vrrp vrid 651
wireless profile flex 652
wireless profile image-download default 653
wireless profile mesh 654
wireless profile policy 655
wireless profile transfer 656
wireless profile urwb 657
wireless rfid 658
wireless security dot1x 659
wireless security dot1x radius accounting mac-delimiter 661
wireless security dot1x radius accounting username-delimiter 662
wireless security dot1x radius callStationIdCase 663
wireless security dot1x radius mac-authentication call-station-id 664
wireless security dot1x radius mac-authentication mac-delimiter 665
wireless security web-auth retries 666
wireless tag policy 667
wireless tag site 668
wireless wps ap-authentication threshold 669
wireless wps client-exclusion 670
wireless wps mfp ap-impersonation 672
wireless wps rogue network-assurance enable 673
wireless wps rogue ap aaa 674
wireless wps rogue ap aaa polling-interval 675
wireless wps rogue ap init-timer 676
wireless wps rogue ap mac-address rldp initiate 677
wireless wps rogue ap notify-min-rssi 678
wireless wps rogue ap notify-rssi-deviation 679
wireless wps rogue ap rldp alarm-only 680
wireless wps rogue ap rldp alarm-only monitor-ap-only 681
wireless wps rogue ap rldp auto-contain 682
wireless wps rogue ap rldp retries 683
wireless wps rogue ap rldp schedule 684
wireless wps rogue ap rldp schedule day 685
wireless wps rogue ap timeout 686

wireless wps rogue auto-contain 687
wireless wps rogue client aaa 688
wireless wps rogue client mse 689
wireless wps rogue client client-threshold 690
wireless wps rogue client notify-min-rssi 691
wireless wps rogue client notify-rssi-deviation 692
wireless wps rogue rule 693
wireless wps rogue security-level 695
wireless-default radius server 696
wlan policy 697

CHAPTER 4 **Show Commands** 699

show aaa dead-criteria radius 704
show aaa servers 706
show aaa server brief 708
show access-list 709
show ap auth-list 711
show ap auto-rf 712
show ap config 715
show ap config slots 717
show ap crash-file 718
show ap dot11 719
show ap dot11 725
show ap dot11 24ghz 726
show ap dot11 24ghz SI config 727
show ap dot11 24ghz SI device type 728
show ap dot11 5ghz 729
show ap dot11 24ghz cleanair air-quality 731
show ap dot11 24ghz cleanair air-quality 732
show ap dot11 cleanair config 733
show ap dot11 cleanair summary 735
show ap dot11 dual-band summary 736
show ap environment 737
show ap filters active 738

show ap filters all 739
show ap fra 740
show ap gps location 741
show history channel interface dot11Radio all 742
show ap image details 743
show ap link-encryption 744
show ap urwb status 745
show ap name ntp status 746
show ap ntp status 747
show ap primary list 748
show ap multicast mom (multicast over multicast) 749
show ap name auto-rf 750
show ap name ble detail 753
show ap name cablemodem 754
show ap name config 755
show ap name config slot 757
show ap name config ethernet 758
show ap name dot11 759
show ap name dot11 5ghz slot urwb detail 760
show ap name environment 761
show ap name gps location 762
show ap name mesh backhaul 763
show ap name mesh bhrate 764
show ap name mesh linktest 765
show ap name mesh path 766
show ap name mesh stats 767
show ap name urwb coord-routes 768
show ap name urwb fixed-links 769
show ap name urwb info 770
show ap name urwb mobility-links 771
show ap name urwb network 772
show ap name urwb wireless-stats 773
show ap name wlan 774
show ap name temperature 776

show ap profile 777
show ap rf-profile summary 778
show ap summary 779
show ap tag sources 780
show ap tag summary 781
show ap timezone 782
show ap upgrade 783
show ap upgrade method 785
show arp 786
show arp summary 787
show ap upgrade site 788
show avc client 789
show avc wlan 790
show chassis 791
show checkpoint 792
show cts environment data 799
show cts role-based sgt-map all 801
show cts role-based counters 803
show flow exporter 804
show flow interface 806
show flow monitor 808
show flow record 810
show interfaces 811
show install package 815
show install rollback 816
show install summary 817
show inventory 818
show ip 820
show ip nbar protocol-id 821
show ldap attributes 822
show ldap server 823
show license air entities 824
show license all 826
show license authorization 832

show license data conversion 837
show license eventlog 838
show license history message 839
show license reservation 840
show license rum 841
show license status 846
show license summary 856
show license tech 859
show license udi 874
show license usage 875
show platform software sl-infra 878
show platform software tls client summary 879
show platform software client detail 880
show platform software tls statistics 882
show platform software tls session summary 884
show logging profile wireless end timestamp 885
show logging profile wireless filter 886
show logging profile wireless fru 887
show logging profile wireless internal 888
show logging profile wireless level 889
show logging profile wireless module 890
show logging profile wireless reverse 891
show logging profile wireless start 892
show logging profile wireless switch 893
show logging profile wireless to-file 894
show mdns-sd cache 895
show mdns-sd cache detail 896
show mdns-sd cache upn shared 897
show mdns-sd cache upn detail 899
show mdns-sd flexconnect summary 900
show mdns-sd statistics 901
show mdns-sd summary 902
show monitor capture 903
show nmsp 906

show nmsp cloud-services statistics 907
show nmsp cloud-services summary 908
show nmsp subscription group detail all 909
show nmsp subscription group detail ap-list 910
show nmsp subscription group detail services 911
show nmsp subscription group summary 912
show ntp associations 913
show parameter-map type webauth name 914
show platform conditions 915
show platform software wlavc status cp-exporter 916
show platform hardware slot R0 ha_port interface stats 917
show platform software system all 920
show platform software trace filter-binary 921
show platform software trace level 922
show platform software trace message 925
show platform software trace message license-manager chassis active R0 927
show platform software trace message license-manager 930
show policy-map 933
show rate-limit client 938
show ssh 939
show stealthwatch-cloud connection 940
show stealthwatch-cloud wireless-shim 941
show tech-support wireless 942
show tech-support wireless ap 944
show tech-support wireless client 954
show tech-support wireless radio 958
show tunnel eogre global-configuration 969
show tunnel eogre domain detailed 970
show tunnel eogre domain summary 971
show tunnel eogre gateway summary 972
show tunnel eogre gateway detailed 973
show tunnel eogre manager stats global 974
show tunnel eogre manager stats instance 976
show wireless stats ap history 978

show wireless stat redundancy statistics client-recovery mobilityd 979
show wireless stat redundancy statistics client-recovery sisf 980
show wireless stat redundancy client-recovery wncd 981
show wireless band-select 982
show wireless certification config 983
show wireless client 984
show wireless client mac-address 985
show wireless client mac-address (Call Control) 987
show wireless client mac-address (TCLAS) 988
show wireless client summary 989
show wireless client timers 990
show wireless country 991
show wireless detail 994
show wireless dhcp relay statistics 995
show wireless dot11h 996
show wireless dtls connections 997
show wireless exclusionlist 998
show wireless load-balancing 999
show wireless mesh rrm dca changed 1000
show wireless mesh rrm dca status 1003
show wireless ewc-ap ap summary 1006
show wireless ewc-ap ap config-sync 1007
show wireless ewc-ap ap image predownload status 1008
show wireless ewc-ap country-code 1009
show wireless ewc-ap image-master 1010
show wireless ewc-ap invalid-image-master 1011
show wireless ewc-ap predownload 1012
show wireless ewc-ap redundancy summary 1013
show wireless ewc-ap redundancy peers 1014
show wireless mesh ethernet daisy-chain summary 1015
show wireless mesh ethernet daisy-chain bgn 1016
show wireless pmk-cache 1017
show wireless profile flex 1018
show wireless profile policy detailed 1019

show wireless profile urwb detailed 1020
show wireless rfid 1021
show wireless stats client delete reasons 1022
show wireless stats redundancy config database 1028
show wireless summary 1029
show wireless urlfilter details 1030
show wireless urlfilter summary 1031
show wireless vlan details 1032
show wireless wgb mac-address 1033
show wireless wgb summary 1034
show wireless wps rogue ap summary 1035
show wireless wps rogue client detailed 1036
show wireless wps rogue ap detailed 1037
show wireless wps rogue client summary 1039



Preface

- Document Conventions , on page xxvii
- Related Documentation, on page xxix
- Communications, services, and additional information, on page xxix

Document Conventions

This document uses the following conventions:

Convention	Description
^ or Ctrl	Both the ^ symbol and Ctrl represent the Control (Ctrl) key on a keyboard. For example, the key combination **^D** or **Ctrl-D** means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
bold font	Commands and keywords and user-entered text appear in **bold** font.
Italic font	Document titles, new or emphasized terms, and arguments for which you supply values are in *italic* font.
`Courier` font	Terminal sessions and information the system displays appear in `courier` font.
`Bold Courier` font	**`Bold Courier`** font indicates text that the user must enter.
[x]	Elements in square brackets are optional.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
|	A vertical line, called a pipe, indicates a choice within a set of keywords or arguments.
[x | y]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
{x | y}	Required alternative keywords are grouped in braces and separated by vertical bars.

Convention	Description
[x {y | z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Reader Alert Conventions

This document may use the following conventions for reader alerts:



Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Tip Means *the following information will help you solve a problem.*



Caution Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Timesaver Means *the described action saves time.* You can save time by performing the action described in the paragraph.

Take note of the following general safety warnings:



Warning IMPORTANT SAFETY INSTRUCTIONS

Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Read the installation instructions before using, installing, or connecting the system to the power source. Use the statement number at the beginning of each warning statement to locate its translation in the translated safety warnings for this device.

SAVE THESE INSTRUCTIONS



Related Documentation

Note Before installing or upgrading the deviceCiscoEmbedded Wireless Controller, refer to the release notes.

Communications, services, and additional information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business impact you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit Cisco DevNet.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

Documentation feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.



Using the Command-Line Interface

- Information About Using the Command-Line Interface, on page 2

Information About Using the Command-Line Interface



Note Search options on the GUI and CLI are case sensitive.

Command Modes

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

You can start a CLI session through a console connection, through Telnet, an SSH, or by using the browser.

When you start a session, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the device reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global, interface, and line), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the device reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode .

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session using Telnet, SSH, or console.	`Device>`	Enter **logout** or **quit**.	Use this mode to • Change terminal settings. • Perform basic tests. • Display system information.

Mode	Access Method	Prompt	Exit Method	About This Mode
Privileged EXEC	While in user EXEC mode, enter the **enable** command.	`Device#`	Enter **disable** to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the **configure** command.	`Device(config)#`	To exit to privileged EXEC mode, enter **exit** or **end**, or press **Ctrl-Z**.	Use this mode to configure parameters that apply to the entire device.
VLAN configuration	While in global configuration mode, enter the **vlan** *vlan-id* command.	`Device(config-vlan)#`	To exit to global configuration mode, enter the **exit** command. To return to privileged EXEC mode, press **Ctrl-Z** or enter **end**.	Use this mode to configure VLAN parameters. When VTP mode is transparent, you can create extended-range VLANs (VLAN IDs greater than 1005) and save configurations in the device startup configuration file.
Interface configuration	While in global configuration mode, enter the **interface** command (with a specific interface).	`Device(config-if)#`	To exit to global configuration mode, enter **exit**. To return to privileged EXEC mode, press **Ctrl-Z** or enter **end**.	Use this mode to configure parameters for the Ethernet ports.
Line configuration	While in global configuration mode, specify a line with the **line vty** or **line console** command.	`Device(config-line)#`	To exit to global configuration mode, enter **exit**. To return to privileged EXEC mode, press **Ctrl-Z** or enter **end**.	Use this mode to configure parameters for the terminal line.

Understanding Abbreviated Commands

You need to enter only enough characters for the device to recognize the command as unique.

This example shows how to enter the **show configuration** privileged EXEC command in an abbreviated form:

```
Device# show conf
```

No and Default Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to reenable a disabled feature or to enable a feature that is disabled by default.

Configuration commands can also have a **default** form. The **default** form of a command returns the command setting to its default. Most commands are disabled by default, so the **default** form is the same as the **no** form. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** command enables the command and sets variables to their default values.

CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your device.

Table 2: Common CLI Error Messages

Error Message	Meaning	How to Get Help
`% Ambiguous command: "show con"`	You did not enter enough characters for your device to recognize the command.	Reenter the command followed by a question mark (?) without any space between the command and the question mark. The possible keywords that you can enter with the command appear.
`% Incomplete command.`	You did not enter all of the keywords or values required by this command.	Reenter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
`% Invalid input detected at '^' marker.`	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all of the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Configuration Logging

You can log and view changes to the device configuration. You can use the Configuration Change Logging and Notification feature to track changes on a per-session and per-user basis. The logger tracks each configuration command that is applied, the user who entered the command, the time that the command was entered, and the parser return code for the command. This feature includes a mechanism for asynchronous notification to registered applications whenever the configuration changes. You can choose to have the notifications sent to the syslog.



Note Only CLI or HTTP changes are logged.

Using the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

SUMMARY STEPS

1. **help**
2. *abbreviated-command-entry* **?**
3. *abbreviated-command-entry* <Tab>
4. **?**
5. *command* **?**
6. *command keyword* **?**

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	**help** **Example:** `Device# help`	Obtains a brief description of the help system in any command mode.

Step 2	*abbreviated-command-entry* **?**
	Example:
	`Device# di?`
	`dir disable disconnect`
		Obtains a list of commands that begin with a particular character string.

Step 3	*abbreviated-command-entry* <Tab>
	Example:
	`Device# sh conf<tab>`
	`Device# show configuration`
		Completes a partial command name.

	Command or Action	Purpose
Step 4	**?** **Example:** `Device> ?`	Lists all commands available for a particular command mode.
Step 5	*command* **?** **Example:** `Device> show ?`	Lists the associated keywords for a command.

Step 6	*command keyword* **?**
	Example:
	`Device(config)# wireless management ?`
	`certificate  Configure certificate details`
	`interface    Select an interface to configure`
	`transfer     Active transfer profiles`
	`trustpoint   Select a trustpoint to configure`
		Lists the associated arguments for a keyword.



Configuration Commands: a to f

- aaa accounting identity, on page 13
- aaa accounting update periodic interval-in-minutes , on page 15
- aaa attribute list, on page 16
- aaa authentication dot1x, on page 17
- aaa authentication login, on page 18
- aaa authorization, on page 19
- aaa authorization credential download default, on page 23
- aaa authorization credential-download MY-METHOD-LIST group MY-SERVER-GROUP, on page 24
- aaa group server ldap, on page 25
- aaa group server radius, on page 26
- aaa local authentication default authorization, on page 27
- aaa new-model, on page 28
- aaa server radius dynamic-author, on page 30
- aaa session-id, on page 32
- aaa-override, on page 34
- aaa-policy , on page 35
- aaa-realm enable , on page 36
- absolute-timer, on page 37
- access-list, on page 38
- access-list acl-ace-limit, on page 40
- accounting-list, on page 41
- acl-policy, on page 42
- active-query timer, on page 43
- address, on page 44
- address prefix, on page 46
- allow at-least min-number at-most max-number, on page 47
- ap, on page 48
- ap auth-list, on page 49
- ap auth-list ap-cert-policy allow-mic-ap , on page 50
- ap auth-list ap-cert-policy allow-mic-ap trustpoint, on page 51
- ap auth-list ap-cert-policy mac-address MAC-address | serial-number AP-serial-number policy-type mic, on page 52
- ap auth-list ap-policy, on page 53

- ap capwap retransmit, on page 54
- ap capwap timers, on page 55
- ap country, on page 57
- ap dot11 24ghz cleanair, on page 58
- default ap dot11 24ghz cleanair device, on page 59
- ap dot11 24ghz dot11g, on page 61
- ap dot11 24ghz rate, on page 62
- ap dot11 24ghz rrm channel cleanair-event, on page 64
- ap dot11 24ghz rrm channel device, on page 65
- ap dot11 24ghz rrm optimized-roam, on page 66
- ap dot11 24ghz rx-sop threshold, on page 67
- ap dot11 24ghz shutdown, on page 68
- ap dot11 5ghz channelswitch quiet, on page 69
- ap dot11 5ghz cleanair , on page 70
- default ap dot11 5ghz cleanair device, on page 71
- ap dot11 5ghz power-constraint, on page 72
- ap dot11 5ghz rate, on page 73
- ap dot11 5ghz rrm channel cleanair-event, on page 74
- ap dot11 5ghz rrm channel device, on page 75
- ap dot11 5ghz rrm channel zero-wait-dfs, on page 76
- ap dot11 5ghz rx-sop threshold, on page 77
- ap dot11 5ghz shutdown, on page 78
- ap dot11 5ghz smart-dfs, on page 79
- ap dot11 , on page 80
- ap dot11 beaconperiod, on page 81
- ap dot11 cac media-stream, on page 82
- ap dot11 cac multimedia, on page 85
- ap dot11 cac voice, on page 86
- ap dot11 cleanair, on page 89
- ap dot11 cleanair device, on page 90
- ap dot11 dot11n, on page 91
- ap dot11 dtpc, on page 94
- ap dot11 edca-parameters, on page 96
- ap dot11 load-balancing denial, on page 98
- ap dot11 load-balancing window, on page 99
- ap dot11 rf-profile, on page 100
- ap dot11 rrm, on page 101
- ap dot11 rrm channel, on page 104
- ap dot11 rrm channel cleanair-event, on page 105
- ap dot11 rrm channel dca, on page 106
- ap dot11 rrm channel-update mesh, on page 108
- ap dot11 rrm channel-update mesh bridge-group, on page 109
- ap dot11 rrm coverage, on page 110
- ap dot11 rrm group-member, on page 112
- ap dot11 rrm group-mode, on page 113
- ap dot11 rrm logging, on page 114

- ap dot11 rrm monitor, on page 116
- ap dot11 rrm ndp-type, on page 117
- ap dot11 24ghz rrm tpc, on page 118
- ap dot11 rrm txpower, on page 119
- ap dot11 rrm txpower, on page 120
- ap filter , on page 121
- ap fra, on page 122
- ap fra 5-6ghz interval, on page 123
- ap image predownload, on page 124
- ap name antenna band mode, on page 125
- ap name ble, on page 126
- ap name clear-personal-ssid, on page 127
- ap name controller, on page 128
- ap name country, on page 129
- ap name crash-file, on page 130
- ap name dot11 24ghz | 5ghz | 6ghz rrm channel update mesh, on page 131
- ap name dot11 24ghz slot 0 SI, on page 132
- ap name dot11 24ghz slot antenna , on page 133
- ap name dot11 24ghz slot beamforming , on page 134
- ap name dot11 24ghz slot channel , on page 135
- ap name dot11 24ghz slot cleanair , on page 136
- ap name dot11 24ghz slot dot11n antenna, on page 137
- ap name dot11 24ghz slot dot11ax bss-color, on page 138
- ap name dot11 24ghz slot shutdown, on page 139
- ap name dot11 5ghz slot {1 | 2} urwb dfs , on page 140
- ap name dot11 5ghz slot {1 | 2} urwb ptmp base, on page 141
- ap name dot11 dual-band cleanair, on page 142
- ap name dot11 dual-band shutdown, on page 143
- ap name dot11 rrm profile, on page 144
- ap name image, on page 146
- ap name icap subscription client anomaly-detection report-individual enable aggregate, on page 147
- ap name icap subscription client anomaly-detection report-individual per-client throttle, on page 148
- ap name icap subscription client anomaly-detection report-individual per-type throttle, on page 149
- ap name indoor, on page 150
- ap name ipsla, on page 151
- ap name keepalive, on page 152
- ap name lan, on page 153
- ap name led, on page 154
- ap name led-brightness-level, on page 155
- ap name location, on page 156
- ap name mesh backhaul rate dot11abg, on page 157
- ap name mdsn-ap, on page 158
- ap name mesh backhaul rate dot11ac, on page 159
- ap name name mesh backhaul rate dot11ax , on page 160
- ap name name new-ap-name, on page 161
- ap name no, on page 162

- ap name mesh backhaul rate , on page 163
- ap name mesh backhaul rate dot11n, on page 164
- ap name mesh block-child, on page 165
- ap name mesh daisy-chaining, on page 166
- ap name mesh ethernet mode access, on page 167
- ap name mesh ethernet mode trunk, on page 168
- ap name mesh linktest, on page 169
- ap name mesh parent preferred, on page 170
- ap name mesh security psk provisioning delete, on page 171
- ap name mesh vlan-trunking native, on page 172
- ap name monitor-mode dot11b, on page 173
- ap name name, on page 174
- ap name priority, on page 175
- ap name reset, on page 176
- ap name reset-button, on page 177
- ap name role, on page 178
- ap name slot, on page 179
- ap name static-ip, on page 181
- ap name static-ip, on page 182
- ap name shutdown, on page 183
- ap name urwb mode coordinator radio-off, on page 184
- ap name usb-module, on page 185
- ap name usb-module override, on page 186
- ap name vlan-tag, on page 187
- ap name write tag-config , on page 188
- ap name-regex , on page 189
- ap profile, on page 190
- ap remote-lan profile-name, on page 191
- ap remote-lan shutdown, on page 192
- ap remote-lan-policy policy-name, on page 193
- ap tag persistency enable, on page 194
- ap upgrade staggered, on page 195
- ap upgrade staggered iteration timeout, on page 196
- ap tag-source-priority , on page 197
- ap tag-sources revalidate , on page 198
- ap vlan-tag, on page 199
- assisted-roaming, on page 200
- attribute type, on page 201
- avg-packet-size packetsize , on page 202
- band-select client, on page 203
- band-select cycle, on page 204
- band-select expire, on page 205
- band-select probe-response, on page 206
- banner text, on page 207
- bss-transition, on page 208
- call-snoop, on page 209

- captive-bypass-portal, on page 210
- capwap-discovery, on page 211
- capwap aggregation, on page 212
- capwap backup, on page 213
- cco-password (image-download-mode cco), on page 214
- cco-username (image-download-mode cco), on page 215
- cco-version (image-download-mode cco), on page 216
- cco-auto-check (image-download-mode cco), on page 217
- ccx aironet-iesupport, on page 218
- cdp, on page 219
- central association, on page 220
- central authentication, on page 221
- central dhcp, on page 222
- central-webauth, on page 223
- channel zero-wait-dfs, on page 224
- chassis redundancy ha-interface shutdown, on page 225
- chassis redundancy keep-alive, on page 226
- chassis renumber, on page 227
- chassis transport, on page 228
- class, on page 229
- classify, on page 231
- class-map, on page 232
- clear aaa counters servers radius, on page 234
- clear chassis redundancy, on page 235
- clear mdns-sd cache, on page 236
- clear mdns-sd statistics, on page 237
- clear platform condition all, on page 238
- clear radius statistics, on page 239
- clear wireless wps rogue ap, on page 240
- clear wireless wps rogue client, on page 241
- clear wireless wps rogue stats, on page 242
- client association limit, on page 243
- channel foreign, on page 245
- client-l2-vnid , on page 246
- condition chan-width, on page 247
- consent activation-mode merge, on page 248
- convergence, on page 249
- copy configuration download, on page 250
- copy configuration upload, on page 251
- core-dump kernel limit, on page 252
- core-dump kernel type, on page 253
- coverage, on page 254
- crypto key generate rsa, on page 255
- crypto pki trustpoint, on page 261
- crypto pki trust pool import terminal, on page 262
- crypto pki trustpool clean, on page 263

- cts inline-tagging, on page 264
- cts role-based enforcement, on page 265
- cts sgt, on page 266
- custom-page login device, on page 267
- default, on page 268
- description, on page 271
- destination, on page 272
- destination stealthwatch-cloud, on page 273
- device-tracking binding vlan, on page 274
- dhcp-tlv-caching, on page 275
- dnscrypt, on page 276
- domain-name (DHCP), on page 277
- dot11 5ghz slot1 radio-profile, on page 278
- dot11ax twt-broadcast-support, on page 279
- dot11 5ghz reporting-interval , on page 280
- dot11 reporting-interval, on page 281
- dot1x system-auth-control, on page 282
- dot11-tlv-accounting, on page 284
- eap profile, on page 285
- exclusionlist, on page 286
- exec-character-bits , on page 287
- exec time-out, on page 288
- exporter default-flow-exporter, on page 289
- fast-teardown, on page 290
- fallback-radio-shut, on page 291
- flex , on page 292
- flow exporter, on page 293
- flow monitor, on page 294
- flow record, on page 295
- ftp-path, on page 296
- ftp-password, on page 297
- ftp-server, on page 298
- ftp-username, on page 299

aaa accounting identity

To enable authentication, authorization, and accounting (AAA) for IEEE 802.1x, MAC authentication bypass (MAB), and web authentication sessions, use the **aaa accounting identity** command in global configuration mode. To disable IEEE 802.1x accounting, use the **no** form of this command.

aaa accounting identity {*name* | **default** } **start-stop** {**broadcast group** {*name* | **radius** | **tacacs+**} [**group** {*name* | **radius** | **tacacs+**} **. . .**] | **group** {*name* | **radius** | **tacacs+**} [**group** {*name* | **radius** | **tacacs+**} **. . .**] }
no aaa accounting identity {*name* | **default** }

Syntax Description

name	Name of a server group. This is optional when you enter it after the **broadcast group** and **group** keywords.
default	Uses the accounting methods that follow as the default list for accounting services.
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process. The start accounting record is sent in the background. The requested-user process begins regardless of whether or not the start accounting notice was received by the accounting server.
broadcast	Enables accounting records to be sent to multiple AAA servers and send accounting records to the first server in each group. If the first server is unavailable, the uses the list of backup servers to identify the first server.
group	Specifies the server group to be used for accounting services. These are valid server group names: • *name* — Name of a server group. • **radius** — Lists of all RADIUS hosts. • **tacacs+** — Lists of all TACACS+ hosts. The **group** keyword is optional when you enter it after the **broadcast group** and **group** keywords. You can enter more than optional **group** keyword.
radius	(Optional) Enables RADIUS authorization.
tacacs+	(Optional) Enables TACACS+ accounting.

Command Default

AAA accounting is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

To enable AAA accounting identity, you need to enable policy mode. To enable policy mode, enter the **authentication display new-style** command in privileged EXEC mode.

This example shows how to configure IEEE 802.1x accounting identity:

```
Device# authentication display new-style

Please note that while you can revert to legacy style
configuration at any time unless you have explicitly
entered new-style configuration, the following caveats
should be carefully read and understood.

(1) If you save the config in this mode, it will be written
    to NVRAM in NEW-style config, and if you subsequently
    reload the router without reverting to legacy config and
    saving that, you will no longer be able to revert.

(2) In this and legacy mode, Webauth is not IPv6-capable. It
    will only become IPv6-capable once you have entered new-
    style config manually, or have reloaded with config saved
    in 'authentication display new' mode.

Device# configure terminal
Device(config)# aaa accounting identity default start-stop group radius
```

aaa accounting update periodic interval-in-minutes

To configure accounting update records intervals, use the **aaa accounting update periodic** command.

aaa accounting update periodic *interval-in-minutes* [**jitter maximum** *jitter-max-value*]

Syntax Description

periodic	Send accounting update records at regular intervals.
<1-71582>	Periodic intervals to send accounting update records(in minutes)
jitter	Set jitter parameters for periodic interval
maximum	Set maximum jitter value for periodic interval (in seconds)
<0-2147483>	Maximum jitter value for periodic interval(in seconds). Default is 300 seconds.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure the interval to five minutes at which the accounting records are updated:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# aaa accounting update periodic 5
```

aaa attribute list

To define an authentication, authorization, and accounting (AAA) attribute list locally on a device, use the **aaa attribute list** command in either the global configuration mode or IKEv2 authorization policy configuration mode. To remove the AAA attribute list, use the **no** form of this command.

aaa attribute list *list-name*

Syntax Description

Keywords and Variables	Description
list-name	Name of an attribute list.

Command Default

A local attribute list is not defined.

Command Modes

Global Configuration (config)

IKEv2 authorization policy configuration (config-ikev2-author-policy)

Command History

Release	Modification
Cisco IOS XE 17.12.1	This command was introduced in a release earlier than Cisco IOS XE 17.12.1.

Usage Guidelines

There is no limit to the number of lists that can be defined (except for NVRAM storage limits). Use this command to refer to an AAA attribute list. This list must be defined in global configuration mode. Among the AAA attributes, the list can have the **interface-config** attribute that is used to apply interface configuration mode commands on the virtual access interface associated with the session.

The example shows how to apply the AAA attribute list **attr-list1** to the IKEv2 authorization policy **pol1** to dynamically configure interface settings like MTU and tunnel key.

```
!
aaa attribute list attr-list1
attribute type interface-config "ip mtu 1100"
attribute type interface-config "tunnel key 10"
!
!
crypto ikev2 authorization policy pol1
 aaa attribute list attr-list1
!
```

aaa authentication dot1x

To specify the authentication, authorization, and accounting (AAA) method to use on ports complying with the IEEE 802.1x authentication, use the **aaa authentication dot1x** command in global configuration mode . To disable authentication, use the **no** form of this command.

aaa authentication dot1x {**default**} *method1*
no aaa authentication dot1x {**default**} *method1*

Syntax Description

default	The default method when a user logs in. Use the listed authentication method that follows this argument.
method1	Specifies the server authentication. Enter the **group radius** keywords to use the list of all RADIUS servers for authentication. **Note** Though other keywords are visible in the command-line help strings, only the **default** and **group radius** keywords are supported.

Command Default

No authentication is performed.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **method** argument identifies the method that the authentication algorithm tries in the specified sequence to validate the password provided by the client. The only method that is IEEE 802.1x-compliant is the **group radius** method, in which the client data is validated against a RADIUS authentication server.

If you specify **group radius**, you must configure the RADIUS server by entering the **radius-server host** global configuration command.

Use the **show running-config** privileged EXEC command to display the configured lists of authentication methods.

This example shows how to enable AAA and how to create an IEEE 802.1x-compliant authentication list. This authentication first tries to contact a RADIUS server. If this action returns an error, the user is not allowed access to the network.

```
Device(config)# aaa new-model
Device(config)# aaa authentication dot1x default group radius
```

aaa authentication login

To set authentication, authorization, and accounting (AAA) at login, use the **aaa authentication login** command in global configuration mode.

aaa authentication login *authentication-list-name* {**group** }*group-name*

Syntax Description

authentication-list-name	Character string used to name the list of authentication methods activated when a user logs in.
group	Uses a subset of RADIUS servers for authentication as defined by the server group **group-name**.
group-name	Server group name.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Examples

The following example shows how to set an authentication method list named **local_webauth** to the group type named **local** in local web authentication:

```
Device(config)# aaa authentication login local_webauth local
```

The following example shows how to set an authentication method to RADIUS server group in local web authentication:

```
Device(config)# aaa authentication login webauth_radius group ISE_group
```

aaa authorization

To set the parameters that restrict user access to a network, use the **aaa authorization** command in global configuration mode. To remove the parameters, use the **no** form of this command.

aaa authorization { **auth-proxy** | **cache** | **commands** *level* | **config-commands** | **configuration** | **console** | **credential-download** | **exec** | **multicast** | **network** | **onep** | **policy-if** | **prepaid** | **radius-proxy** | **reverse-access** | **subscriber-service** | **template**} {**default** | *list_name* } [*method1* [*method2* . . .]]

Syntax Description

auth-proxy	Runs authorization for authentication proxy services.
cache	Configures the authentication, authorization, and accounting (AAA) server.
commands	Runs authorization for all commands at the specified privilege level.
level	Specific command level that should be authorized. Valid entries are 0 through 15.
config-commands	Runs authorization to determine whether commands entered in configuration mode are authorized.
configuration	Downloads the configuration from the AAA server.
console	Enables the console authorization for the AAA server.
credential-download	Downloads EAP credential from Local/RADIUS/LDAP.
exec	Enables the console authorization for the AAA server.
multicast	Downloads the multicast configuration from the AAA server.
network	Runs authorization for all network-related service requests, including Serial Line Internet Protocol (SLIP), PPP, PPP Network Control Programs (NCPs), and AppleTalk Remote Access (ARA).
onep	Runs authorization for the ONEP service.
reverse-access	Runs authorization for reverse access connections, such as reverse Telnet.
template	Enables template authorization for the AAA server.
default	Uses the listed authorization methods that follow this keyword as the default list of methods for authorization.
list_name	Character string used to name the list of authorization methods.
method1 [*method2...*]	(Optional) An authorization method or multiple authorization methods to be used for authorization. A method may be any one of the keywords listed in the table below.

Command Default

Authorization is disabled for all actions (equivalent to the method keyword **none**).

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines Use the **aaa authorization** command to enable authorization and to create named methods lists, which define authorization methods that can be used when a user accesses the specified function. Method lists for authorization define the ways in which authorization will be performed and the sequence in which these methods will be performed. A method list is a named list that describes the authorization methods (such as RADIUS or TACACS+) that must be used in sequence. Method lists enable you to designate one or more security protocols to be used for authorization, which ensures a backup system in case the initial method fails. Cisco IOS software uses the first method listed to authorize users for specific network services; if that method fails to respond, the Cisco IOS software selects the next method listed in the method list. This process continues until there is successful communication with a listed authorization method, or until all the defined methods are exhausted.



Note The Cisco IOS software attempts authorization with the next listed method only when there is no response from the previous method. If authorization fails at any point in this cycle--meaning that the security server or the local username database responds by denying the user services--the authorization process stops and no other authorization methods are attempted.

If the **aaa authorization** command for a particular authorization type is issued without a specified named method list, the default method list is automatically applied to all interfaces or lines (where this authorization type applies) except those that have a named method list explicitly defined. (A defined method list overrides the default method list.) If no default method list is defined, then no authorization takes place. The default authorization method list must be used to perform outbound authorization, such as authorizing the download of IP pools from the RADIUS server.

Use the **aaa authorization** command to create a list by entering the values for the *list-name* and the *method* arguments, where *list-name* is any character string used to name this list (excluding all method names) and *method* identifies the list of authorization methods tried in the given sequence.



Note In the table that follows, the **group***group-name*, **group ldap**, **group radius**, and **group tacacs+** methods refer to a set of previously defined RADIUS or TACACS+ servers. Use the **radius server** and **tacacs server** commands to configure the host servers. Use the **aaa group server radius**, **aaa group server ldap**, and **aaa group server tacacs+** commands to create a named group of servers.

This table describes the method keywords.

Table 3: aaa authorization Methods

Keyword	Description
cache *group-name*	Uses a cache server group for authorization.

Keyword	Description
group *group-name*	Uses a subset of RADIUS or TACACS+ servers for accounting as defined by the **server group** *group-name* command.
group ldap	Uses the list of all Lightweight Directory Access Protocol (LDAP) servers for authentication.
group radius	Uses the list of all RADIUS servers for authentication as defined by the **aaa group server radius** command.
grouptacacs+	Uses the list of all TACACS+ servers for authentication as defined by the **aaa group server tacacs+** command.
if-authenticated	Allows the user to access the requested function if the user is authenticated. **Note** The **if-authenticated** method is a terminating method. Therefore, if it is listed as a method, any methods listed after it will never be evaluated.
local	Uses the local database for authorization.
none	Indicates that no authorization is performed.

Cisco IOS software supports the following methods for authorization:

- Cache Server Groups—The router consults its cache server groups to authorize specific rights for users.
- If-Authenticated—The user is allowed to access the requested function provided the user has been authenticated successfully.
- Local—The router or access server consults its local database, as defined by the **username** command, to authorize specific rights for users. Only a limited set of functions can be controlled through the local database.
- None—The network access server does not request authorization information; authorization is not performed over this line or interface.
- RADIUS—The network access server requests authorization information from the RADIUS security server group. RADIUS authorization defines specific rights for users by associating attributes, which are stored in a database on the RADIUS server, with the appropriate user.
- TACACS+—The network access server exchanges authorization information with the TACACS+ security daemon. TACACS+ authorization defines specific rights for users by associating attribute-value (AV) pairs, which are stored in a database on the TACACS+ security server, with the appropriate user.

Method lists are specific to the type of authorization being requested. AAA supports five different types of authorization:

- Commands—Applies to the EXEC mode commands a user issues. Command authorization attempts authorization for all EXEC mode commands, including global configuration commands, associated with a specific privilege level.
- EXEC—Applies to the attributes associated with a user EXEC terminal session.
- Network—Applies to network connections. The network connections can include a PPP, SLIP, or ARA connection.

Note You must configure the **aaa authorization config-commands** command to authorize global configuration commands, including EXEC commands prepended by the **do** command.

- Reverse Access—Applies to reverse Telnet sessions.
- Configuration—Applies to the configuration downloaded from the AAA server.

When you create a named method list, you are defining a particular list of authorization methods for the indicated authorization type.

Once defined, the method lists must be applied to specific lines or interfaces before any of the defined methods are performed.

The authorization command causes a request packet containing a series of AV pairs to be sent to the RADIUS or TACACS daemon as part of the authorization process. The daemon can do one of the following:

- Accept the request as is.
- Make changes to the request.
- Refuse the request and authorization.

For a list of supported RADIUS attributes, see the module RADIUS Attributes. For a list of supported TACACS+ AV pairs, see the module TACACS+ Attribute-Value Pairs.

Note Five commands are associated with privilege level 0: **disable**, **enable**, **exit**, **help**, and **logout**. If you configure AAA authorization for a privilege level greater than 0, these five commands will not be included in the privilege level command set.

The following example shows how to define the network authorization method list named mygroup, which specifies that RADIUS authorization will be used on serial lines using PPP. If the RADIUS server fails to respond, local network authorization will be performed.

```
Device(config)#  aaa authorization network mygroup group radius local
```

aaa authorization credential download default

To set an authorization method list to use local credentials, use the **aaa authorization credential download default** command in global configuration mode.

aaa authorization credential download default *group-name*

Syntax Description

group-name	Server group name.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

The following example shows how to set an authorization method list to use local credentials:

```
Device(config)# aaa authorization credential-download default local
```

aaa authorization credential-download MY-METHOD-LIST group MY-SERVER-GROUP

To configure the authorization method list with the named RADIUS server group, use the **aaa authorization credential-download MY-METHOD-LIST group** *My-server-group* command.

aaa authorization credential-download MY-METHOD-LIST group { *My-server-group* | *ldap* | *radius* | *tacacs+* }

Syntax Description

My-Server-Group	Specifies the server group name.
ldap	Specifies the list of all LDAP hosts.
radius	Specifies the list of all RADIUS hosts.
tacacs+	Specifies the list of all TACACS+ hosts.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	This command was introduced.

Examples

The following example shows how to configure the authorization method list with the named RADIUS server group:

```
Device# configure terminal
Device(config)# aaa authorization credential-download MY-METHOD-LIST group MY-SERVER-GROUP
```

aaa group server ldap

To configure a AAA server group, use the **aaa group server ldap** command.

aaa group server ldap *group-name*

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure a AAA server group:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# aaa new-model
Device(config)# aaa group server ldap name1
Device(config-ldap-sg)# server server1
Device(config-ldap-sg)# exit
```

aaa group server radius

To group different RADIUS server hosts into distinct lists and distinct methods, use the **aaa group server radius** command in global configuration mode.

aaa group server radius *group-name*

Syntax Description

group-name	Character string used to name the group of servers.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

The authentication, authorization, and accounting (AAA) server-group feature introduces a way to group existing server hosts. The feature enables you to select a subset of the configured server hosts and use them for a particular service.

A group server is a list of server hosts of a particular type. Currently supported server host types are RADIUS server hosts. A group server is used in conjunction with a global server host list. The group server lists the IP addresses of the selected server hosts.

The following example shows how to configure an AAA group server named **ISE_Group** that comprises three member servers:

```
Device(config)# aaa group server radius ISE_Group
```

aaa local authentication default authorization

To configure local authentication method list, use the **aaa local authentication default authorization** command.

aaa local authentication default authorization [*method-list-name* | **default**]

Syntax Description

method-list-name	Name of the method list.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure local authentication method list to the default list:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# aaa local authentication default authorization default
```

aaa new-model

To enable the authentication, authorization, and accounting (AAA) access control model, issue the **aaa new-model** command in global configuration mode. To disable the AAA access control model, use the **no** form of this command.

aaa new-model
no aaa new-model

Syntax Description

This command has no arguments or keywords.

Command Default

AAA is not enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

This command enables the AAA access control system.

If the **login local** command is configured for a virtual terminal line (VTY), and the **aaa new-model** command is removed, you must reload the to get the default configuration or the **login** command. If the is not reloaded, the defaults to the **login local** command under the VTY.

Note We do not recommend removing the **aaa new-model** command.

The following example shows this restriction:

```
Device(config)# aaa new-model
Device(config)# line vty 0 15
Device(config-line)# login local
Device(config-line)# exit
Device(config)# no aaa new-model
Device(config)# exit
Device# show running-config | b line vty

line vty 0 4
 login local  !<=== Login local instead of "login"
line vty 5 15
 login local
!
```

Examples

The following example initializes AAA:

```
Device(config)# aaa new-model
Device(config)#
```

Related Commands

Command	Description
aaa accounting	Enables AAA accounting of requested services for billing or security purposes.
aaa authentication arap	Enables an AAA authentication method for ARAP using TACACS+.
aaa authentication enable default	Enables AAA authentication to determine if a user can access the privileged command level.
aaa authentication login	Sets AAA authentication at login.
aaa authentication ppp	Specifies one or more AAA authentication method for use on serial interfaces running PPP.
aaa authorization	Sets parameters that restrict user access to a network.

aaa server radius dynamic-author

To configure a device as an authentication, authorization, and accounting (AAA) server to facilitate interaction with an external policy server, use the **aaa server radius dynamic-author**command in global configuration mode. To remove this configuration, use the **no** form of this command.

aaa server radius dynamic-author
no aaa server radius dynamic-author

Syntax Description

This command has no arguments or keywords.

Command Default

The device will not function as a server when interacting with external policy servers.

Command Modes

Global configuration

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.4	This command was integrated into Cisco IOS Release 12.4.
Cisco IOS XE Release 2.6	This command was integrated into Cisco IOS XE Release 2.6.
12.2(5)SXI	This command was integrated into Cisco IOS Release 12.2(5)SXI.
15.2(2)T	This command was integrated into Cisco IOS Release 15.2(2)T.
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Dynamic authorization allows an external policy server to dynamically send updates to a device. Once the **aaa server radius dynamic-author** command is configured, dynamic authorization local server configuration mode is entered. Once in this mode, the RADIUS application commands can be configured.

Dynamic Authorization for the Intelligent Services Gateway (ISG)

ISG works with external devices, referred to as policy servers, that store per-subscriber and per-service information. ISG supports two models of interaction between the ISG device and external policy servers: initial authorization and dynamic authorization.

The dynamic authorization model allows an external policy server to dynamically send policies to the ISG. These operations can be initiated in-band by subscribers (through service selection) or through the actions of an administrator, or applications can change policies on the basis of an algorithm (for example, change session quality of service (QoS) at a certain time of day). This model is facilitated by the Change of Authorization (CoA) RADIUS extension. CoA introduced peer-to-peer capability to RADIUS, enabling ISG and the external policy server each to act as a RADIUS client and server.

Examples

The following example configures the ISG to act as a AAA server when interacting with the client at IP address 10.12.12.12:

```
aaa server radius dynamic-author
```

```
client 10.12.12.12 key cisco
message-authenticator ignore
```

Related Commands

Command	Description
auth-type (ISG)	Specifies the server authorization type.
client	Specifies a RADIUS client from which a device will accept CoA and disconnect requests.
default	Sets a RADIUS application command to its default.
domain	Specifies username domain options.
ignore	Overrides a behavior to ignore certain paremeters.
port	Specifies a port on which local RADIUS server listens.
server-key	Specifies the encryption key shared with RADIUS clients.

aaa session-id

To specify whether the same session ID will be used for each authentication, authorization, and accounting (AAA) accounting service type within a call or whether a different session ID will be assigned to each accounting service type, use the **aaa session-id** command in global configuration mode. To restore the default behavior after the **unique** keyword is enabled, use the **no** form of this command.

aaa session-id [**common** | **unique**]
no aaa session-id [**unique**]

Syntax Description

common	(Optional) Ensures that all session identification (ID) information that is sent out for a given call will be made identical. The default behavior is **common**.
unique	(Optional) Ensures that only the corresponding service access-requests and accounting-requests will maintain a common session ID. Accounting-requests for each service will have a different session ID.

Command Default

The **common** keyword is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.2(4)B	This command was introduced.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE 16.12.1	This command was integrated in Cisco IOS XE 16.12.1.

Usage Guidelines

The **common** keyword behavior allows the first session ID request of the call to be stored in a common database; all proceeding session ID requests will retrieve the value of the first session ID. Because a common session ID is the default behavior, this functionality is written to the system configuration after the **aaa new-model** command is configured.

Note The router configuration will always have either the **aaa session-id common** or the **aaa session-id unique** command enabled; it is not possible to have neither of the two enabled. Thus, the **no aaa session-id unique** command will revert to the default functionality, but the **no aaa session-id common** command will not have any effect because it is the default functionality.

The **unique** keyword behavior assigns a different session ID for each accounting type (Auth-Proxy, Exec, Network, Command, System, Connection, and Resource) during a call. To specify this behavior, the unique keyword must be specified. The session ID may be included in RADIUS access requests by configuring the **radius-server attribute 44 include-in-access-req**command. The session ID in the access-request will be the same as the session ID in the accounting request for the same service; all other services will provide unique session IDs for the same call.

Examples

The following example shows how to configure unique session IDs:

```
aaa new-model
aaa authentication ppp default group radius
radius-server host 10.100.1.34
radius-server attribute 44 include-in-access-req
aaa session-id unique
```

Related Commands

Command	Description
aaa new model	Enables AAA.
radius-server attribute 44 include-in-access-req	Sends RADIUS attribute 44 (Accounting Session ID) in access request packets before user authentication (including requests for preauthentication).

aaa-override

To enable AAA override, use the **aaa-override** command. To disable AAA override, use the **no** form of this command.

aaa-override

no aaa-override

Syntax Description

This command has no keywords or arguments.

Command Default

AAA is disabled by default.

Command Modes

Wireless policy configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to enable AAA:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy policy-test
Device(config-wireless-policy)# aaa-override
```

aaa-policy

To map a AAA policy in a WLAN policy profile, use the **aaa-policy** command.

aaa-policy *aaa-policy-name*

Syntax Description

aaa-policy-name	Name of the AAA policy.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to map a AAA policy in a WLAN policy profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy policy-name
Device(config-wireless-policy)# aaa-policy aaa-policy-name
```

aaa-realm enable

To enable AAA RADUIS selection by realm, use the **aaa-realm enable** command.

aaa-realm enable

Command Default None

Command Modes config-aaa-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable AAA RADIUS section by realm:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless aaa policy aaa-profile-name
Device (config-aaa-policy)#  aaa-realm enable
```

absolute-timer

To enable an absolute timeout for subscriber sessions, use the **absolute-timer** command in service template configuration mode. To disable the timer, use the **no** form of this command.

absolute-timer *minutes*
no absolute-timer

Syntax Description

minutes	Maximum session duration, in minutes. Range: 1 to 65535. Default: 0, which disables the timer.

Command Default

Disabled (the absolute timeout is 0).

Command Modes

Service template configuration (config-service-template)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

Use the **absolute-timer** command to limit the number of minutes that a subscriber session can remain active. After this timer expires, a session must repeat the process of establishing its connection as if it were a new request.

Examples

The following example shows how to set the absolute timeout to 15 minutes in the service template named SVC_3:

```
service-template SVC_3
 description sample
 access-group ACL_2
 vlan 113
 inactivity-timer 15
 absolute-timer 15
```

Related Commands

Command	Description
event absolute-timeout	Specifies the type of event that triggers actions in a control policy if conditions are met.
inactivity-timer	Enables an inactivity timeout for subscriber sessions.
show service-template	Displays configuration information for service templates.

access-list

To add an access list entry, use the **access-list** command.

access-list {*1-99* *100-199* *1300-1999* *2000-2699*} [*sequence-number*] {**deny** | **permit**} {*hostname-or-ip-addr* [*wildcard-bits* | **log**] | **any** [**log**] | **host** *hostname-or-ip-addr* **log**} | {**remark** [*line*]}

Syntax Description

1-99	Configures IP standard access list.
100-199	Configures IP extended access list.
1300-1999	Configures IP standard access list (expanded range).
2000-2699	Configures IP extended access list (expanded range).
sequence-number	Sequence number of the ACL entry. Valid range is 1 to 2147483647.
deny	Configures packets to be rejected.
permit	Configures packets to be forwarded.
hostname-or-ip-addr	Hostname or the IP address to match.
wildcard-bits	Wildcard bits to match the IP address.
log	Configures log matches against this entry.
any	Any source host.
host	A single host address.
remark	Configures ACL entry comment.
line	The ACL entry comment.

Command Default

None

Command Modes

Global Config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to add an access list entry:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# access-list 1 permit any
```

access-list acl-ace-limit

To set the maximum configurable ace limit for all ACLs, use the **access-list acl-ace-limit** command.

access-list acl-ace-limit *max-ace-limit*

Syntax Description

max-ace-limit	Maximum number of ace limit for all ACLs. Valid range is 1 to 4294967295.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to set the maximum configurable ace limit for all ACLs to 100:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# access-list acl-ace-limit 100
```

accounting-list

To configure RADIUS accounting servers on , use the **accounting-list** command. To disable RADIUS server accounting, use the **no** form of this command.

accounting-list *radius-server-acct*
no accounting-list

Syntax Description

radius-server-acct	Accounting RADIUS server name.

Command Default

RADIUS server accounting is disabled by default.

Command Modes

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to configure RADIUS server accounting on :

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#
Deviceaccounting-list test
Device
```

This example shows how to disable RADIUS server accounting on :

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#
Deviceno accounting-list test
Device
```

acl-policy

To configure an access control list (ACL) policy, use the **acl-policy** command.

acl-policy *acl-policy-name*

Syntax Description

acl-policy-name	Name of the ACL policy.

Command Default

None

Command Modes

config-wireless-flex-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure an ACL policy name:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile flex default-flex-profile
Device(config-wireless-flex-profile)# acl-policy my-acl-policy
```

active-query timer

To configure mDNS global active query, use the **active-query timer** command. To disable the command use the **no** form of this command.

active-query timer *15 - 120*

no active-query timer *15 - 120*

Syntax Description

active-query timer	Configures the mDNS global active query timer.
15 - 120	Specifies the active query periodicity in minutes. The default is 30 minutes.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to configure mDNS global active query:

```
Device(config-mdns-sd)# active-query timer 60
```

address

To specify the IP address of the Rivest, Shamir, and Adelman (RSA) public key of the remote peer that you will manually configure in the keyring, use the **address** command inrsa-pubkey configuration mode. To remove the IP address, use the **no** form of this command.

address *ip-address*
no address *ip-address*

Syntax Description

ip-address	IP address of the remote peer.

Command Default

No default behavior or values

Command Modes

Rsa-pubkey configuration

Command History

Release	Modification
11.3 T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.6	This command was integrated into Cisco IOS XE Release 2.6.
Cisco IOS XE 16.12.1	This command was integrated into Cisco ISO XE 16.12.1

Usage Guidelines

Before you can use this command, you must enter the **rsa-pubkey** command in the crypto keyring mode.

Examples

The following example specifies the RSA public key of an IP Security (IPSec) peer:

```
Router(config)# crypto keyring vpnkeyring
Router(conf-keyring)# rsa-pubkey name host.vpn.com
Router(config-pubkey-key)# address 10.5.5.1
Router(config-pubkey)# key-string
Router(config-pubkey)# 00302017 4A7D385B 1234EF29 335FC973
Router(config-pubkey)# 2DD50A37 C4F4B0FD 9DADE748 429618D5
Router(config-pubkey)# 18242BA3 2EDFBDD3 4296142A DDF7D3D8
Router(config-pubkey)# 08407685 2F2190A0 0B43F1BD 9A8A26DB
Router(config-pubkey)# 07953829 791FCDE9 A98420F0 6A82045B
Router(config-pubkey)# 90288A26 DBC64468 7789F76E EE21
Router(config-pubkey)# quit
Router(config-pubkey-key)# exit
Router(conf-keyring)# exit
```

Related Commands

Command	Description
crypto keyring	Defines a crypto keyring to be used during IKE authentication.
key-string	Specifies the RSA public key of a remote peer.
rsa-pubkey	Defines the RSA manual key to be used for encryption or signatures during IKE authentication.

address prefix

To specify an address prefix for address assignment, use the **address prefix** command in interface configuration mode. To remove the address prefix, use the **no** form of this command.

address prefix ipv6-prefix [**lifetime** {**valid-lifetime preferred-lifetime** | **infinite**}]
no address prefix

Syntax Description

ipv6-prefix	IPv6 address prefix.
lifetime {valid-lifetime preferred-lifetime | infinite}]	(Optional) Specifies a time interval (in seconds) that an IPv6 address prefix remains in the valid state. If the **infinite** keyword is specified, the time interval does not expire.

Command Default

No IPv6 address prefix is assigned.

Command Modes

DHCP pool configuration (config-dhcpv6)

Command History

Release	Modification
12.4(24)T	This command was introduced.

Usage Guidelines

You can use the **address prefix** command to configure one or several address prefixes in an IPv6 DHCP pool configuration. Each time the IPv6 DHCP address pool is used, an address will be allocated from each of the address prefixes associated with the IPv6 DHCP pool.

Examples

The following example shows how to configure a pool called engineering with an IPv6 address prefix:

```
Router(config)# ipv6 dhcp pool engineering
Router(config-dhcpv6)# address prefix 2001:1000::0/64 lifetime infinite
```

Related Commands

Command	Description
ipv6 dhcp pool	Configures a DHCPv6 server configuration information pool and enters DHCPv6 pool configuration mode.

allow at-least min-number at-most max-number

To limit the number of multicast RAs per device per throttle period in an RA throttler policy, use the **allow at-least** *min-number* **at-most** *max-number* command.

allow at-least *min-number* **at-most** {*max-number* | **no-limit**}

Syntax Description

at-least *min-number*	Enter the minimum guaranteed number of multicast RAs per router before throttling can be enforced. Valid range is 0 to 32.
at-most *max-number*	Enter the maximum number of multicast RAs from router by which throttling is enforced. Valid range is 0 to 256.
at-most no-limit	No upper bound at the router level.

Command Default

None

Command Modes

config-nd-ra-throttle

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to limit the number of multicast RAs per device per throttle period in an RA throttler policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ipv6 nd ra-throttler policy ra-throttler-policy-name
Device(config-nd-ra-throttle)# allow at-least 5 at-most 10
```

ap

To configure cisco APs, use the **ap** command.

ap *mac-address*

Syntax Description

mac-address	Ethernet MAC address of the AP.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

none.

Example

The following example shows how to configure a Cisco AP:

```
Device(config)# ap F866.F267.7DFB
```

ap auth-list

To configure the AP authorization list, use the **ap auth-list** command in the global configuration mode. To disable the AP authorization list, use the **no** form of this command.

ap auth-list {**authorize-mac** | **authorize-serialNum** | **method-list** *method-list-name*}

no ap auth-list {**authorize-mac** | **authorize-serialNum** | **method-list** *method-list-name*}

Syntax Description

authorize-mac	Configures the AP authorization policy with MAC.
auhorize-serialNum	Configures the AP authorization policy with the serial number.
method-list	Configures the AP authorization method list.
method-list-name	Indicates the method list name.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to configure the AP authorization policy with serial number:

```
Device(config) #ap auth-list authorize-serialNum
```

ap auth-list ap-cert-policy allow-mic-ap

To enable the AP certificate policy during CAPWAP-DTLS handshake, use the **ap auth-list ap-cert-policy allow-mic-ap** command, in the global configuration mode. To disable the AP certificate policy during CAPWAP-DTLS handshake, use the **no** form of this command.

ap auth-list ap-cert-policy allow-mic-ap

no ap auth-list ap-cert-policy allow-mic-ap

Syntax Description

This command has no arguments or keywords.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to configure AP certificate policy during CAPWAP-DTLS handshake:

```
Device# configure terminal
Device(config)# ap auth-list ap-cert-policy
Device(config)# ap auth-list ap-cert-policy allow-mic-ap
```

ap auth-list ap-cert-policy allow-mic-ap trustpoint

To configure the trustpoint name for the controller certificate chain, use the **ap auth-list ap-cert-policy allow-mic-ap trustpoint** command, in the global configuration mode. To disable the feature, use the **no** form of the command.

ap auth-list ap-cert-policy allow-mic-ap trustpoint

no ap auth-list ap-cert-policy allow-mic-ap trustpoint

Syntax Description

trustpoint-name	Specifies the trustpoint name for the wireless controller certificate chain.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to the trustpoint name for the controller certificate chain:

```
Device# configure terminal
Device(config)# ap auth-list ap-cert-policy
Device(config)# ap auth-list ap-cert-policy allow-mic-ap trustpoint trustpoint-name
```

ap auth-list ap-cert-policy mac-address MAC-address | serial-number AP-serial-number policy-type mic

To configure the AP certificate policy based on the Ethernet MAC address or based on the assembly serial number of the AP, use the **ap auth-list ap-cert-policy** {**mac-address** *H.H.H* | **serial-number** *AP-serial-number*} **policy-type mic** command. Use the **no** form of this command to disable the feature.

ap auth-list ap-cert-policy { **mac-address** *H.H.H* | **serial-number** *AP-serial-number* } **policy-type mic**

no ap auth-list ap-cert-policy { **mac-address** *H.H.H* | **serial-number** *AP-serial-number* } **policy-type mic**

Syntax Description

ap auth-list	Configure the authorization list of the Access Point.
ap-cert-policy	Specifies the AP Certificate Policy during CAPWAP DTLS.
mac-address *MAC-address*	Configures AP cert policy based on Ethernet MAC.
serial-number *AP-serial-number*	Configure AP cert policy based on Serial Number.
policy-type	Configures AP certificate policy type.
mic	Selects MIC AP policy.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to configure the AP certificate policy based on the Ethernet MAC address or based on the assembly serial number of the AP:

```
Device# configure terminal
Device(config)# ap auth-list ap-cert-policy mac-address 10.1.1 policy-type mic

Device(config)# ap auth-list ap-cert-policy serial-number ap-serial-number policy-type mic
```

ap auth-list ap-policy

To configure authorization policy for all Cisco lightweight access points joined to the device, use the **ap auth-list ap-policy** command. To disable authorization policy for all Cisco lightweight access points joined to the device, use the **no** form of this command.

ap auth-list ap-policy {**authorize-ap** | **lsc** | **mic** | **ssc**}
no ap auth-list ap-policy {**authorize-ap** | **lsc** | **mic** | **ssc**}

Syntax Description

authorize-ap	Enables the authorization policy.
lsc	Enables access points with locally significant certificates to connect.
mic	Enables access points with manufacture-installed certificates to connect.
ssc	Enables access points with self signed certificates to connect.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to enable the access point authorization policy:

```
Device(config)# ap auth-list ap-policy authorize-ap
```

This example shows how to enable access points with locally significant certificates to connect:

```
Device(config)# ap auth-list ap-policy lsc
```

This example shows how to enable access points with manufacture-installed certificates to connect:

```
Device(config)# ap auth-list ap-policy mic
```

This example shows how to enable access points with self-signed certificates to connect:

```
Device(config)# ap auth-list ap-policy ssc
```

ap capwap retransmit

To configure Control and Provisioning of Wireless Access Points (CAPWAP) control packet retransmit count and control packet retransmit interval under the AP profile, use the **ap capwap retransmit** command.

ap profile default-ap-profile

ap capwap retransmit {**count** *retransmit-count* | **interval** *retransmit-interval*}

Syntax Description

count *retransmit-count*	Specifies the access point CAPWAP control packet retransmit count. **Note** The count is from 3 to 8 seconds.
interval *retransmit-interval*	Specifies the access point CAPWAP control packet retransmit interval. **Note** The interval is from 2 to 5 seconds.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure the CAPWAP control packet retransmit count for an access point:

```
Device(config)# ap profile default-ap-profile
```

This example shows how to configure the CAPWAP control packet retransmit interval for an access point:

```
Device(config-ap-profile)# capwap retransmit count 3
```

ap capwap timers

To configure advanced timer settings under the AP profile mode, use the **ap capwap timers** command.

ap profile default-ap-profile

ap capwap timers {**discovery-timeout** *seconds* | **fast-heartbeat-timeout local** *seconds* | **heartbeat-timeout** *seconds* | **primary-discovery-timeout** *seconds* | **primed-join-timeout** *seconds*}

Syntax Description

discovery-timeout	Specifies the Cisco lightweight access point discovery timeout. **Note** The Cisco lightweight access point discovery timeout is how long a Cisco device waits for an unresponsive access point to answer before considering that the access point failed to respond.
seconds	Cisco lightweight access point discovery timeout from 1 to 10 seconds. **Note** The default is 10 seconds.
fast-heartbeat-timeout local	Enables the fast heartbeat timer that reduces the amount of time it takes to detect a device failure for local or all access points.
seconds	Small heartbeat interval (from 1 to 10 seconds) that reduces the amount of time it takes to detect a device failure. **Note** The fast heartbeat time-out interval is disabled by default.
heartbeat-timeout	Specifies the Cisco lightweight access point heartbeat timeout. **Note** The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keep-alive signal to the Cisco device. This value should be at least three times larger than the fast heartbeat timer.
seconds	Cisco lightweight access point heartbeat timeout value from 1 to 30 seconds. **Note** The default is 30 seconds.
primary-discovery-timeout	Specifies the access point primary discovery request timer. The timer determines the amount of time taken by an access point to discovery the configured primary, secondary, or tertiary device.
seconds	Access point primary discovery request timer from 30 to 3600 seconds. **Note** The default is 120 seconds.

primed-join-timeout	Specifies the authentication timeout. Determines the time taken by an access point to determine that the primary device has become unresponsive. The access point makes no further attempts to join the device until the connection to the device is restored.
seconds	Authentication response timeout from 120 to 43200 seconds. **Note** The default is 120 seconds.

Command Default

None

Command Modes

AP profile mode (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure an access point discovery timeout with the timeout value of 7:

```
Device(config)# ap profile default-ap-profile

Device(config-ap-profile)# ap capwap timers discovery-timeout 7
```

This example shows how to enable the fast heartbeat interval for all access points:

```
Device(config)# ap profile default-ap-profile

Device(config-ap-profile)# ap capwap timers fast-heartbeat-timeout 6
```

This example shows how to configure an access point heartbeat timeout to 20:

```
Device(config)# ap profile default-ap-profile

Device(config-ap-profile)# ap capwap timers heartbeat-timeout 20
```

This example shows how to configure the access point primary discovery request timer to 1200 seconds:

```
Device(config)# ap profile default-ap-profile

Device(config-ap-profile)# ap capwap timers primary-discovery-timeout 1200
```

This example shows how to configure the authentication timeout to 360 seconds:

```
Device(config)# ap profile default-ap-profile

Device(config-ap-profile)# ap capwap timers primed-join-timeout 360
```

ap country

To configure one or more country codes for a device, use the **ap country** command.

ap country *country-code*

Syntax Description

country-code	Two-letter or three-letter country code or several country codes separated by a comma.

Command Default

US (country code of the United States of America).

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.1	This command has been deprecated. **Note** From Cisco IOS XE Amsterdam 17.3.1 onwards, the command **ap country** is deprecated and renamed as **wireless country** *<1 country code>*, where you can enter country codes for more than 20 countries. Although the existing command **ap country** is still functional, it is recommended that you use the **wireless country** *<1 country code>* command.

Usage Guidelines

The Cisco device must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.

This example shows how to configure country codes on the device to IN (India) and FR (France):

```
Device(config)# ap country IN,FR
```

ap dot11 24ghz cleanair

To enable CleanAir for detecting 2.4-GHz devices, use the **ap dot11 24ghz cleanair** command in global configuration mode. To disable CleanAir for detecting 2.4-GHz devices, use the **no** form of this command.

ap dot11 24ghz cleanair

Syntax Description

This command has no arguments or keywords.

Command Default

Disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must enable this CleanAir command before you configure other CleanAir commands.

This example shows how to enable CleanAir for 2.4-GHz devices:

```
Device(config)# ap dot11 24ghz cleanair
```

default ap dot11 24ghz cleanair device

To configure the default state of report generation for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair device** command in global configuration mode.

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
report	Displays the device alarm report.
si_fhss	Specifies the QCA SI FHSS.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair**command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 24ghz cleanair device video
```

ap dot11 24ghz dot11g

To enable the Cisco wireless LAN solution 802.11g network, use the **ap dot11 24ghz dot11g** command. To disable the Cisco wireless LAN solution 802.11g network, use the **no** form of this command.

ap dot11 24ghz dot11g
no ap dot11 24ghz dot11g

Syntax Description

This command has no keywords and arguments.

Command Default

Enabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Before you enter the **ap dot11 24ghz dot11g** command, disable the 802.11 Cisco radio with the **ap dot11 24ghz shutdown** command.

After you configure the support for the 802.11g network, use the **no ap dot11 24ghz shutdown** command to enable the 802.11 2.4 Ghz radio.

This example shows how to enable the 802.11g network:

```
Device(config)# ap dot11 24ghz dot11g
```

ap dot11 24ghz rate

To configure 802.11b operational rates, use the **ap dot11 24ghz rate** command.

ap dot11 24ghz rate {**RATE_11M** | **RATE_12M** | **RATE_18M** | **RATE_1M** | **RATE_24M** | **RATE_2M** | **RATE_36M** | **RATE_48M** | **RATE_54M** | **RATE_5_5M** | **RATE_6M** | **RATE_9M**} {**disable** | **mandatory** | **supported**}

Syntax Description

RATE_11M	Configures the data to be transmitted at the rate of 11 Mbps
RATE_12M	Configures the data to be transmitted at the rate of 12 Mbps
RATE_18M	Configures the data to be transmitted at the rate of 18 Mbps
RATE_1M	Configures the data to be transmitted at the rate of 1 Mbps
RATE_24M	Configures the data to be transmitted at the rate of 24 Mbps
RATE_2M	Configures the data to be transmitted at the rate of 2 Mbps
RATE_36M	Configures the data to be transmitted at the rate of 36 Mbps
RATE_48M	Configures the data to be transmitted at the rate of 48 Mbps
RATE_54M	Configures the data to be transmitted at the rate of 54 Mbps
RATE_5_5M	Configures the data to be transmitted at the rate of 5.5 Mbps
RATE_6M	Configures the data to be transmitted at the rate of 6 Mbps
RATE_9M	Configures the data to be transmitted at the rate of 9 Mbps
disable	Disables the data rate that you specify. Also defines that the clients specify the data rates used for communication.
mandatory	Defines that the clients support this data rate in order to associate with an AP.
supported	Any associated clients support this data rate can communicate with the AP using this rate. However, the clients are not required to use this rate to associate with the AP.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure 802.11b operational rate to 9 Mbps and make it mandatory:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 24ghz rate RATE_9M mandatory
```

ap dot11 24ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and the sensitivity for 2.4-GHz devices, use the **ap dot11 24ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of this command.

ap dot11 24ghz rrm channel cleanair-event sensitivity {**high** | **low** | **medium**}
no ap dot11 24ghz rrm channel cleanair-event [**sensitivity**{**high** | **low** | **medium**}]

Syntax Description

sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
high	(Optional) Specifies the highest sensitivity to non-Wi–Fi interference as indicated by the air quality (AQ) value.
low	(Optional) Specifies the least sensitivity to non-Wi–Fi interference as indicated by the AQ value.
medium	(Optional) Specifies medium sensitivity to non-Wi–Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the sensitivity is low.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

You must enable EDRRM using the **ap dot11 24ghz rrm channel cleanair-event** command before you configure the sensitivity.

This example shows how to enable EDRRM and set the EDRRM sensitivity to low:

```
Device(config)# ap dot11 24ghz rrm channel cleanair-event
Device(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity low
```

ap dot11 24ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11b channel, use the **ap dot11 24ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

ap dot11 24ghz rrm channel device
no ap dot11 24ghz rrm channel device

Syntax Description

This command has no arguments or keywords.

Command Default

Persistent device avoidance is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the device. Local and bridge mode access points detect interference devices on the serving channels only.

This example shows how to enable persistent device avoidance:

```
Device(config)# ap dot11 24ghz rrm channel device
```

ap dot11 24ghz rrm optimized-roam

To configure optimized roaming for 802.11b network, use the **ap dot11 24ghz rrm optimized-roam** command.

ap dot11 24ghz rrm optimized-roam [**data-rate-threshold** {**11M** | **12M** | **18M** | **1M** | **24M** | **2M** | **36M** | **48M** | **54M** | **5_5M** | **6M** | **9M** | **disable**}]

Syntax Description

data-rate-threshold	Configures the data rate threshold for 802.11b optimized roaming.
11M	Sets the data rate threshold for 802.11b optimized roaming to 11 Mbps
12M	Sets the data rate threshold for 802.11b optimized roaming to of 12 Mbps
18M	Sets the data rate threshold for 802.11b optimized roaming to of 18 Mbps
1M	Sets the data rate threshold for 802.11b optimized roaming to of 1 Mbps
24M	Sets the data rate threshold for 802.11b optimized roaming to of 24 Mbps
2M	Sets the data rate threshold for 802.11b optimized roaming to of 2 Mbps
36M	Sets the data rate threshold for 802.11b optimized roaming to of 36 Mbps
48M	Sets the data rate threshold for 802.11b optimized roaming to of 48 Mbps
54M	Sets the data rate threshold for 802.11b optimized roaming to of 54 Mbps
5_5M	Sets the data rate threshold for 802.11b optimized roaming to of 5.5 Mbps
6M	Sets the data rate threshold for 802.11b optimized roaming to of 6 Mbps
9M	Sets the data rate threshold for 802.11b optimized roaming to of 9 Mbps
disable	Disables the data rate threshold.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure optimized roaming for 802.11b network:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 24ghz rrm optimized-roam
```

ap dot11 24ghz rx-sop threshold

To configure 802.11b radio receiver start-of-packet (RxSOP), use the **ap dot11 24ghz rx-sop threshold** command.

ap dot11 24ghz rx-sop threshold {**auto** | **high** | **low** | **medium** | **custom** *rxsop-value*}

Syntax Description

auto	Reverts RxSOP value to the default value.
high	Sets the RxSOP value to high threshold (–79 dBm).
medium	Sets the RxSOP value to medium threshold (–82 dBm).
low	Sets the RxSOP value to low threshold (–85 dBm).
custom *rxsop-value*	Sets the RxSOP value to custom threshold (–85 dBm to –60 dBm)

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

RxSOP determines the Wi-Fi signal level in dBm at which an access point's radio demodulates and decodes a packet. Higher the level, less sensitive the radio is and smaller the receiver cell size. The table below shows the RxSOP threshold values for high, medium, low, and custom levels for 2.4-GHz band.

Table 4: RxSOP Thresholds for 2.4-GHz Band

High Threshold	Medium Threshold	Low Threshold	Custom Threshold
–79 dBm	–82 dBm	–85 dBm	–85 dBm to –60 dBm

Examples

The following example shows how to configure 802.11b radio receiver start-of-packet (RxSOP) value to auto:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 24ghz rx-sop threshold auto
```

ap dot11 24ghz shutdown

To disable 802.11a network, use the **ap dot11 24ghz shutdown** command.

ap dot11 24ghz shutdown

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to disable the 802.11a network:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 24ghz shutdown
```

ap dot11 5ghz channelswitch quiet

To configure the 802.11h channel switch quiet mode, use the **ap dot11 5ghz channelswitch quiet** command.

ap dot11 5ghz channelswitch quiet

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the 802.11h channel switch quiet mode:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 5ghz channelswitch quiet
```

ap dot11 5ghz cleanair

To enable CleanAir for detecting 5-GHz devices, use the **ap dot11 5ghz cleanair** command in global configuration mode.

ap dot11 5ghz cleanair

Command Default

Disabled.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must enable this CleanAir command before you configure other CleanAir commands.

This example shows how to enable CleanAir for 5-GHz devices:

```
Device(config)# ap dot11 5ghz cleanair
```

default ap dot11 5ghz cleanair device

To configure the default state of the alarm for 5-GHz interference devices, use the **default ap dot11 5ghz cleanair device** command in global configuration mode.

default ap dot11 5ghz cleanair device {**canopy** | **cont-tx** | **dect-like** | **inv** | **jammer** | **nonstd** | **radar** | **report** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile**}

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
report	Enables interference device reports.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other interference devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 5ghz cleanair device video
```

ap dot11 5ghz power-constraint

To configure the 802.11h power constraint value, use the **ap dot11 5ghz power-constraint** command. To remove the 802.11h power constraint value, use the **no** form of this command.

ap dot11 5ghz power-constraint *value*
no ap dot11 5ghz power-constraint

Syntax Description

value	802.11h power constraint value. **Note** The range is from 0 to 30 dBm.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure the 802.11h power constraint to 5 dBm:

```
Device(config)# ap dot11 5ghz power-constraint 5
```

ap dot11 5ghz rate

To configure 802.11a operational rates, use the **ap dot11 5ghz rate** command.

ap dot11 5ghz rate {**RATE_12M** | **RATE_18M** | **RATE_24M** | **RATE_36M** | **RATE_48M** | **RATE_54M** | **RATE_6M** | **RATE_9M**} {**disable** | **mandatory** | **supported**}

Syntax Description

RATE_12M	Configures the data to be transmitted at the rate of 12 Mbps
RATE_18M	Configures the data to be transmitted at the rate of 18 Mbps
RATE_24M	Configures the data to be transmitted at the rate of 24 Mbps
RATE_36M	Configures the data to be transmitted at the rate of 36 Mbps
RATE_48M	Configures the data to be transmitted at the rate of 48 Mbps
RATE_54M	Configures the data to be transmitted at the rate of 54 Mbps
RATE_6M	Configures the data to be transmitted at the rate of 6 Mbps
RATE_9M	Configures the data to be transmitted at the rate of 9 Mbps
disable	Disables the data rate that you specify. Also defines that the clients specify the data rates used for communication.
mandatory	Defines that the clients support this data rate in order to associate with an AP.
supported	Any associated clients support this data rate can communicate with the AP using this rate. However, the clients are not required to use this rate to associate with the AP.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure 802.11a operational rate to 24 Mbps and make it supported:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 5ghz rate RATE_24M supported
```

ap dot11 5ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and configure the sensitivity for 5-GHz devices, use the **ap dot11 5ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of the command.

ap dot11 5ghz rrm channel cleanair-event [**sensitivity** {**high** | **low** | **medium**}]
no ap dot11 5ghz rrm channel cleanair-event [**sensitivity** {**high** | **low** | **medium**}]

Syntax Description

sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
high	(Optional) Specifies the highest sensitivity to non-Wi–Fi interference as indicated by the air quality (AQ) value.
low	(Optional) Specifies the least sensitivity to non-Wi–Fi interference as indicated by the AQ value.
medium	(Optional) Specifies medium sensitivity to non-Wi–Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the EDRRM sensitivity is low.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

You must enable EDRRM using the **ap dot11 5ghz rrm channel cleanair-event** command before you configure the sensitivity.

This example shows how to enable EDRRM and set the EDRRM sensitivity to high:

```
Device(config)# ap dot11 5ghz rrm channel cleanair-event
Device(config)# ap dot11 5ghz rrm channel cleanair-event sensitivity high
```

ap dot11 5ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11a channel, use the **ap dot11 5ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

ap dot11 5ghz rrm channel device
no ap dot11 5ghz rrm channel device

Syntax Description

This command has no arguments or keywords.

Command Default

The CleanAir persistent device state is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the device. Local and bridge mode access points detect interference devices on the serving channels only.

This example shows how to enable persistent device avoidance on 802.11a devices:

```
Device(config)# ap dot11 5ghz rrm channel device
```

ap dot11 5ghz rrm channel zero-wait-dfs

To enable thes Zero Wait Dynamic Frequency Selection feature globally on 5-GHz devices, use the **ap dot11 5ghz rrm channel zero-wait-dfs** command. To disable the feature, use the **no** form of this command.

ap dot11 5ghz rrm channel zero-wait-dfs

no ap dot11 5ghz rrm channel zero-wait-dfs

Syntax Description

This command has no arguments or keywords.

Command Default

The Zero Wait Dynamic Frequency Selection feature is not enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Usage Guidelines

This command is applicable only on 5-GHz devices.

Examples

The following example shows how to enable the Zero Wait Dynamic Frequency Selection feature on 5-GHz devices:

```
Device# configure terminal
Device(config)# ap dot11 5ghz rrm channel zero-wait-dfs
```

ap dot11 5ghz rx-sop threshold

To configure 802.11a radio receiver start-of-packet (RxSOP), use the **ap dot11 5ghz rx-sop threshold** command.

ap dot11 5ghz rx-sop threshold {**auto** | **high** | **low** | **medium** | **custom** *rxsop-value*}

Syntax Description

auto	Reverts RxSOP value to the default value.
high	Sets the RxSOP value to high threshold (–76 dBm).
medium	Sets the RxSOP value to medium threshold (–78 dBm).
low	Sets the RxSOP value to low threshold (–80 dBm).
custom *rxsop-value*	Sets the RxSOP value to custom threshold (–85 dBm to –60 dBm)

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

RxSOP determines the Wi-Fi signal level in dBm at which an access point's radio demodulates and decodes a packet. Higher the level, less sensitive the radio is and smaller the receiver cell size. The table below shows the RxSOP threshold values for high, medium, low, and custom levels for 5-GHz band.

Table 5: RxSOP Thresholds for 5-GHz Band

High Threshold	Medium Threshold	Low Threshold	Custom Threshold
–76 dBm	–78 dBm	–80 dBm	–85 dBm to –60 dBm

Examples

The following example shows how to configure 802.11b radio receiver start-of-packet (RxSOP) value to a custom value of –70 dBm:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 24ghz rx-sop threshold custom -70
```

ap dot11 5ghz shutdown

To disable 802.11a network, use the **ap dot11 5ghz shutdown** command.

ap dot11 5ghz shutdown

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to disable the 802.11a network:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 5ghz shutdown
```

ap dot11 5ghz smart-dfs

To configure to use nonoccupancy time for radar interference channel, use the **ap dot11 5ghz smart-dfs** command.

ap dot11 5ghz smart-dfs

Command Default None

Command Modes config

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure to use nonoccupancy time for radar interference channel:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 5ghz smart-dfs
```

ap dot11

To configure Spectrum Intelligence (SI) on Qualcomm based 2.4 GHz or 5 GHz radios, use the **ap dot11 SI** command.

ap dot11 {**24ghz** | **5ghz** } **SI**

Syntax Description

24ghz	2.4 GHz radio
5ghz	5 GHz radio
SI	Enable Spectrum Intelligence (SI). [no] in the command disasbles SI.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable SI on 5GHz radio:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap dot11 5ghz SI
```

ap dot11 beaconperiod

To change the beacon period globally for 2.4 GHz or 5 GHz bands, use the **ap dot11 beaconperiod** command.

Note Disable the 802.11 network before using this command. See the "Usage Guidelines" section.

ap dot11 {**24ghz** | **5ghz**} **beaconperiod** *time*

Syntax Description

24ghz	Specifies the settings for 2.4 GHz band.
5ghz	Specifies the settings for 5 GHz band.
beaconperiod	Specifies the beacon for a network globally.
time	Beacon interval in time units (TU). One TU is 1024 microseconds. The range is from 20 to 1000.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

In Cisco wireless LAN 802.11 networks, all Cisco lightweight access point wireless LANs broadcast a beacon at regular intervals. This beacon notifies clients that the wireless service is available and allows the clients to synchronize with the lightweight access point.

Before you change the beacon period, make sure that you have disabled the 802.11 network by using the **ap dot11** {**24ghz | 5ghz**} **shutdown** command. After changing the beacon period, enable the 802.11 network by using the **no ap dot11** {**24ghz | 5ghz**} **shutdown** command.

This example shows how to configure the 5 GHZ band for a beacon period of 120 time units:

```
Device(config)# ap dot11 5ghz beaconperiod 120
```

ap dot11 cac media-stream

To configure media stream Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac media-stream** command.

ap dot11 {**24ghz** | **5ghz**} **cac media-stream multicast-direct** {**max-retry-percent** *retryPercent* | **min-client-rate** {**eighteen** | **eleven** | **fiftyFour** | **fivePointFive** | **fortyEight** | **nine** | **oneFifty** | **oneFortyFourPointFour** | **oneThirty** | **oneThirtyFive** | **seventyTwoPointTwo** | **six** | **sixtyFive** | **thirtySix** | **threeHundred** | **twelve** | **twentyFour** | **two** | **twoSeventy**}}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
multicast-direct	Specifies CAC parameters for multicast-direct media streams.
max-retry-percent	Specifies the percentage of maximum retries that are allowed for multicast-direct media streams.
retryPercent	Percentage of maximum retries that are allowed for multicast-direct media streams. **Note** The range is from 0 to 100.
min-client-rate	Specifies the minimum transmission data rate to the client for multicast-direct media streams (rate at which the client must transmit in order to receive multicast-direct unicast streams). If the transmission rate is below this rate, either the video will not start or the client may be classified as a bad client. The bad client video can be demoted for better effort QoS or subject to denial.

min-client-rate	You can choose the following rates: • **eighteen** • **eleven** • **fiftyFour** • **fivePointFive** • **fortyEight** • **nine** • **one** • **oneFifty** • **oneFortyFourPointFour** • **oneThirty** • **oneThirtyFive** • **seventyTwoPointTwo** • **six** • **sixtyFive** • **thirtySix** • **threeHundred** • **twelve** • **twentyFour** • **two** • **twoSeventy**

Command Default

The default value for the maximum retry percent is 80. If it exceeds 80, either the video will not start or the client might be classified as a bad client. The bad client video will be demoted for better effort QoS or is subject to denial.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan** *wlan_name* **shutdown** command.

- Disable the radio network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **cac voice acm** or **ap dot11** {**24ghz | 5ghz**} **cac video acm** commands.

This example shows how to configure the maximum retry percent for multicast-direct media streams as 90 on a 802.11a network:

```
Device(config)# ap dot11 5ghz cac media-stream multicast max-retry-percent 90
```

ap dot11 cac multimedia

To configure multimedia Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac multimedia** command.

ap dot11 {**24ghz** | **5ghz**} **cac multimedia max-bandwidth** *bandwidth*

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
max-bandwidth	Specifies the percentage of maximum bandwidth allocated to Wi-Fi Multimedia (WMM) clients for voice and video applications on the 2.4 GHz or 5 GHz band.
bandwidth	Percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a or 802.11b/g network. Once the client reaches the specified value, the access point rejects new multimedia flows this radio band. The range is from 5 to 85%.

Command Default

The default value is 75%.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan** *wlan_name* **shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **cac voice acm** or **ap dot11** {**24ghz | 5ghz**} **cac video acm** commands.

This example shows how to configure the percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 5 GHz band:

```
Device(config)# ap dot11 5ghz cac multimedia max-bandwidth 5
```

ap dot11 cac voice

To configure Call Admission Control (CAC) parameters for the voice category, use the **ap dot11 cac voice** command.

ap dot11 {**24ghz** | **5ghz**} **cac voice** {**acm** | **load-based** | **max-bandwidth** *value* | **roam-bandwidth** *value* | **sip** [**bandwidth** *bw*] **sample-interval** *value* | **stream-size** *x* **max-streams** *y* | **tspec-inactivity-timeout** {**enable** | **ignore**}}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
acm	Enables bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band. **Note** To disable bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band, use the **no ap dot11** {**24ghz** | **5ghz**} **cac voice acm** command.
load-based	Enable load-based CAC on voice access category. **Note** To disable load-based CAC on voice access category for the 2.4 GHz or 5 GHz band, use the **no ap dot11** {**24ghz** | **5ghz**} **cac voice load-based** command.
max-bandwidth	Sets the percentage of the maximum bandwidth allocated to clients for voice applications on the 2.4 GHz or 5 GHz band.
value	Bandwidth percentage value from 5 to 85%.
roam-bandwidth	Sets the percentage of the CAC maximum allocated bandwidth reserved for roaming voice clients on the 2.4 GHz or 5 GHz band.
value	Bandwidth percentage value from 0 to 85%.
sip	Specifies the CAC codec name and sample interval as parameters and calculates the required bandwidth per call for the 802.11 networks.

bw	Bandwidth in kbps. The following bandwidth values specify parameters for the SIP codecs: • 64kbps—Specifies CAC parameters for the SIP G711 codec. • 8kbps—Specifies CAC parameters for the SIP G729 codec. **Note** The default value is 64 Kbps.
sample-interval	Specifies the packetization interval for SIP codec.
value	Packetization interval in msecs. The sample interval for SIP codec value is 20 seconds.
stream-size	Specifies the number of aggregated voice Wi-Fi Multimedia (WMM) traffic specification (TSPEC) streams at a specified data rate for the 2.4 GHz or 5 GHz band.
x	Stream size. The range of the stream size is from 84000 to 92100.
max-streams	Specifies the maximum number of streams per TSPEC.
y	Number (1 to 5) of voice streams. **Note** The default number of streams is 2 and the mean data rate of a stream is 84 kbps.
tspec-inactivity-timeout	Specifies TSPEC inactivity timeout processing mode. **Note** Use this keyword to process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point. When the inactivity timeout is ignored, a client TSPEC is not deleted even if the access point reports an inactivity timeout for that client.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages. **Note** The default is **ignore** (disabled).

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan** *wlan_name* **shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11** {**24ghz | 5ghz**} **cac voice acm** or **ap dot11** {**24ghz | 5ghz**} **cac video acm** commands.

This example shows how to enable the bandwidth-based CAC:

```
Device(config)# ap dot11 24ghz cac voice acm
```

This example shows how to enable the load-based CAC on the voice access category:

```
Device(config)# ap dot11 24ghz cac voice load-based
```

This example shows how to specify the percentage of the maximum allocated bandwidth for voice applications on the selected radio band:

```
Device(config)# ap dot11 24ghz cac voice max-bandwidth 50
```

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming voice clients on the selected radio band:

```
Device(config)# ap dot11 24ghz cac voice roam-bandwidth 10
```

This example shows how to configure the bandwidth and voice packetization interval for the G729 SIP codec on a 2.4 GHz band:

```
Device(config)# ap dot11 24ghz cac voice sip bandwidth 8 sample-interval 40
```

This example shows how to configure the number of aggregated voice traffic specifications stream with a stream size of 85000 and with a maximum of 5 streams:

```
Device(config)# ap dot11 24ghz cac voice stream-size 85000 max-streams 5
```

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
Device(config)# ap dot11 24ghz cac voice tspec-inactivity-timeout enable
```

ap dot11 cleanair

To configure CleanAir on 802.11 networks, use the **ap dot11 cleanair** command. To disable CleanAir on 802.11 networks, use the **no** form of this command.

ap dot11 {**24ghz** | **5ghz**} **cleanair**
no ap dot11 {**24ghz** | **5ghz**} **cleanair**

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
cleanair	Specifies CleanAir on the 2.4 GHz or 5 GHz band.

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to enable the CleanAir settings on the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz cleanair
```

ap dot11 cleanair device

To configure CleanAir interference device types, use the **ap dot11 cleanair device** command.

ap dot11 24ghz cleanair device [**canopy** | **cont-tx** | **dect-like** | **inv** | **jammer** | **nonstd** | **report** | **si_fhss** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile**]

Syntax Description

canopy	Specifies the Canopy devices.
cont-tx	Specifies the continuous transmitter.
dect-like	Specifies a Digital Enhanced Cordless Communication (DECT)-like phone.
inv	Specifies the devices using spectrally inverted Wi-Fi signals.
jammer	Specifies the jammer.
nonstd	Specifies the devices using nonstandard Wi-Fi channels.
superag	Specifies 802.11 SuperAG devices.
tdd-tx	Specifies the TDD transmitter.
video	Specifies video cameras.
wimax-fixed	Specifies a WiMax fixed device.
wimax-mobile	Specifies a WiMax mobile device.
report	Displays the device alarm report.
si_fhss	Specifies the QCA SI FHSS.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure the device to monitor ZigBee interferences:

```
Device(config)# ap dot11 24ghz cleanair device report
```

ap dot11 dot11n

To configure settings for an 802.11n network, use the **ap dot11 dot11n** command.

ap dot11 {**24ghz** | **5ghz**} **dot11n** {**a-mpdu tx priority** {*priority_value* **all** } | **scheduler timeout rt** *scheduler_value*} | **a-msdu tx priority** {*priority_value* | **all**} | **guard-interval** {**any** | **long**} | **mcs tx** *rate* | **rifs rx**}

Syntax Description

24ghz	Specifies the 2.4-GHz band.
5ghz	Specifies the 5-GHz band.
dot11n	Enables 802.11n support.
a-mpdu tx priority	Specifies the traffic that is associated with the priority level that uses Aggregated MAC Protocol Data Unit (A-MPDU) transmission.
priority_value	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
a-msdu tx priority	Specifies the traffic that is associated with the priority level that uses Aggregated MAC Service Data Unit (A-MSDU) transmission.
priority_value	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
scheduler_value	The 802.11n A-MPDU transmit aggregation scheduler timeout value from 1 to 10000 milliseconds.
guard-interval	Specifies the guard interval.
any	Enables either a short or a long guard interval.
long	Enables only a long guard interval.
mcs tx *rate*	Specifies the modulation and coding scheme (MCS) rates at which data can be transmitted between the access point and the client.
rate	Specifies the modulation and coding scheme data rates. **Note** The range is from 0 to 23.
rifs rx	Specifies the Reduced Interframe Space (RIFS) between data frames.

Command Default By default, priority 0 is enabled.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines Aggregation is the process of grouping packet data frames together rather than transmitting them separately. The two aggregation methods available are:

- A-MPDU—This aggregation is performed in the software.
- A-MSDU—This aggregation is performed in the hardware

Aggregated MAC Protocol Data Unit priority levels assigned per traffic type are as follows:

- 0—Best effort
- 1—Background
- 2—Spare
- 3—Excellent effort
- 4—Controlled load
- 5—Video, less than 100-ms latency and jitter
- 6—Voice, less than 10-ms latency and jitter
- 7—Network control
- all—Configure all of the priority levels at once.

Note Configure the priority levels to match the aggregation method used by the clients.

This example shows how to enable 802.11n support on a 2.4-GHz band:

```
Device(config)# ap dot11 24ghz dot11n
```

This example shows how to configure all the priority levels at once so that the traffic that is associated with the priority level uses A-MSDU transmission:

```
Device(config)# ap dot11 24ghz dot11n a-msdu tx priority all
```

This example shows how to enable only long guard intervals:

```
Device(config)# ap dot11 24ghz dot11n guard-interval long
```

This example shows how to specify MCS rates:

```
Device(config)# ap dot11 24ghz dot11n mcs tx 5
```

This example shows how to enable RIFS:

```
Device(config)# ap dot11 24ghz dot11n rifs rx
```

ap dot11 dtpc

To configure Dynamic Transmit Power Control (DTPC) settings, Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature, and the fragmentation threshold on an 802.11 network, use the **ap dot11 dtpc** command.

ap dot11 {**24ghz** | **5ghz**} {**dtpc** | **exp-bwreq** | **fragmentation** *threshold*}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
dtpc	Specifies Dynamic Transport Power Control (DTPC) settings. **Note** This option is enabled by default.
exp-bwreq	Specifies Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature. **Note** The expedited bandwidth request feature is disabled by default.
fragmentation *threshold*	Specifies the fragmentation threshold. **Note** This option can only used be when the network is disabled using the **ap dot11** {**24ghz	5ghz**} **shutdown** command.
threshold	Threshold. The range is from 256 to 2346 bytes (inclusive).

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

When the CCX version 5 expedited bandwidth request feature is enabled, the device configures all joining access points for this feature.

This example shows how to enable DTPC for the 5 GHz band:

```
Device(config)# ap dot11 5ghz dtpc
```

This example shows how to enable the CCX expedited bandwidth settings:

```
Device(config)# ap dot11 5ghz exp-bwrep
```

This example shows how to configure the fragmentation threshold on the 5 GHz band with the threshold number of 1500 bytes:

```
Device(config)# ap dot11 5ghz fragmentation 1500
```

ap dot11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 2.4 GHz or 5 GHz bands, use the **ap dot11 edca-parameters** command. To disable an EDCA profile on the 2.4 GHz or 5 GHz bands, use the **no** form of this command.

ap dot11 { **24ghz** | **5ghz** } **edca-parameters** { **client-load-based** | **custom-voice** | **optimized-video-voice** | **optimized-voice** | **svp-voice** | **wmm-default** }
no ap dot11 { **24ghz** | **5ghz** } **edca-parameters** { **client-load-based** | **custom-voice** | **fastlane** | **optimized-video-voice** | **optimized-voice** | **svp-voice** | **wmm-default** }

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
edca-parameters	Specifies a specific enhanced distributed channel access (EDCA) profile on the 802.11 networks.
fastlane	Enables Fastlane parameters for 24GHz.
client-load-based	Enables client load-based EDCA configuration for 802.11 radios.
custom-voice	Enables custom voice EDCA parameters.
optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network.
optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than SpectraLink are deployed on your network.
svp-voice	Enables SpectraLink voice priority parameters. Choose this option if SpectraLink phones are deployed on your network to improve the quality of calls.
wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.

Command Default

wmm-default

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.
10.3	The **custom-voice** keyword was removed for Cisco 5700 Series WLC.
Cisco IOS XE Bengaluru 17.5.1	The **client-load-based** keyword was added.

This example shows how to enable SpectraLink voice priority parameters:

```
Device(config)# ap dot11 24ghz edca-parameters svp-voice
```

ap dot11 load-balancing denial

To configure the load balancing denial count, use the **ap dot11 load-balancingdenial**command. To disable load balancing denial count, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **load-balancingdenial** *count*

Syntax Description

count	Load balancing denial count.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to configure the load balancing denial count:

```
Device# configure terminal
Device(config)# ap dot11 5ghz load-balancing denial 10
```

ap dot11 load-balancing window

To configure the number of clients for the aggressive load balancing client window, use the **ap dot11 load-balancingwindow**command. To disable the client count, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **load-balancingwindow** *clients*

Syntax Description

clients	Number of clients. Valid range is from 0 to 20.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to configure the number of clients for the aggressive load balancing client window:

```
Device# configure terminal
Device(config)# ap dot11 5ghz load-balancing window 10
```

ap dot11 rf-profile

To configure an RF-Profile for a selected band, use the **ap dot11 rf-profile** command. To delete an RF-Profile, use the **no** form of this command.

ap dot11 { **24ghz** | **5ghz** } **rf-profile** *profile name*

Syntax Description

24ghz	Displays the 2.4-GHz band
5ghz	Displays the 5-GHz band
profile name	Name of the RF profile

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to configure an RF profile for a selected band.

```
Device#ap dot11 24GHz rf-profile doctest
```

ap dot11 rrm

To configure basic and advanced radio resource management settings for 802.11 devices, use the **ap dot11 rrm** command.

ap dot11 {**24ghz** | **5ghz**} **rrm** {**ccx location-measurement** *sec* | **channel** {**cleanair-event** | **dca** | **device** | **foreign** | **load** | **noise** | **outdoor-ap-dca**} | **coverage** {**data fail-percentage** *pct* | **data packet-count** *count* | **data rssi-threshold** *threshold*} | **exception global** *percentage* | **level global** *number* | **voice** {**fail-percentage** *percentage* | **packet-count** *number* | **rssi-threshold** *threshold*}}

Syntax Description

ccx	Configures Advanced (RRM) 802.11 CCX options.
location-measurement	Specifies 802.11 CCX Client Location Measurements in seconds. The range is between 10 and 32400 seconds.
channel	Configure advanced 802.11-channel assignment parameters.
cleanair-event	Configures cleanair event-driven RRM parameters.
dca	Configures 802.11-dynamic channel assignment algorithm parameters.
device	Configures persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise	Enables non-802.11-noise avoidance in the channel assignment.
outdoor-ap-dca	Configures 802.11 DCA list option for outdoor AP.
coverage	Configures 802.11 coverage Hole-Detection.

data fail-percentage *pct*	Configures 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
data packet-count *count*	Configures 802.11 coverage minimum-failure-count threshold for uplinkdata packets.
data rssi-threshold *threshold*	Configures 802.11 minimum-receive-coverage level for voice packets.
exception global *percentage*	Configures 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global *number*	Configures 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Configures 802.11 coverage Hole-Detection for voice packets.
fail-percentage *percentage*	Configures 802.11 coverage failure rate threshold for uplink voice packets.
packet-count *number*	Configures 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold *threshold*	Configures 802.11 minimum receive coverage level for voice packets.

Command Default

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

This command applies for both 802.11a and 802.11b bands. But the appropriate commands must be chosen for configuring the parameter.

This example shows how to configure various RRM settings.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm ?
```

```
ccx             Configure Advanced(RRM) 802.11a CCX options
channel         Configure advanced 802.11a channel assignment parameters
coverage        802.11a Coverage Hole Detection
group-member    Configure members in 802.11a static RF group
group-mode      802.11a RF group selection mode
logging         802.11a event logging
monitor         802.11a statistics monitoring
ndp-type        Neighbor discovery type Protected/Transparent
profile         802.11a performance profile
tpc-threshold   Configures the Tx Power Control Threshold used by RRM for auto
                power assignment
txpower         Configures the 802.11a Tx Power Level
```

ap dot11 rrm channel

To enable radio resource management channel for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm channel** command. To disable the radio resource mangement for 2.4 GHz and 5 GHz devices, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **rrm channel** {**cleanair-event** | **dca** | **device** | **foreign** | **load** | **noise**}
no ap dot11 {**24ghz** | **5ghz**} **rrm channel** {**cleanair-event** | **dca** | **device** | **foreign** | **load** | **noise**}

Syntax Description

cleanair-event	Specifies the cleanair event-driven RRM parameters
dca	Specifies the 802.11 dynamic channel assignment algorithm parameters
device	Specifies the persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise	Enables non-802.11-noise avoidance in the channel assignment.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows all the parameters available for **Channel**.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 24ghz rrm channel ?
  cleanair-event  Configure cleanair event-driven RRM parameters
  dca             Config 802.11b dynamic channel assignment algorithm
                  parameters
  device          Configure persistent non-WiFi device avoidance in the 802.11b
                  channel assignment
  foreign         Configure foreign AP 802.11b interference avoidance in the
                  channel assignment
  load            Configure Cisco AP 802.11b load avoidance in the channel
                  assignment
  noise           Configure 802.11b noise avoidance in the channel assignment
```

ap dot11 rrm channel cleanair-event

To configure CleanAir event-driven Radio Resource Management (RRM) parameters for all 802.11 Cisco lightweight access points, use the **ap dot11 rrm channel cleanair-event** command. When this parameter is configured, CleanAir access points can change their channel when a source of interference degrades the operations, even if the RRM interval has not expired yet.

ap dot11 {**24ghz** | **5ghz**} **rrm channel** {**cleanair-event sensitivity** *value*}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
sensitivity	Sets the sensitivity for CleanAir event-driven RRM.
value	Sensitivity value. You can specify any one of the following three optional sensitivity values: • **low**—Specifies low sensitivity. • **medium**—Specifies medium sensitivity. • **high**—Specifies high sensitivity.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to set the high sensitivity for CleanAir event-driven RRM:

```
Device(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity high
```

ap dot11 rrm channel dca

To configure Dynamic Channel Assignment (DCA) algorithm parameters on 802.11 networks, use the **ap dot11 rrm channel dca** command.

ap dot11 {**24ghz** | **5ghz**} **rrm channel dca** {**add** *value <1-14>* | **anchor-time** *value* | **global** {**auto** | **once**} | **interval** *value* | **min-metric** *value* | **remove** *value <1-14>* | **sensitivity** {**high** | **low** | **medium**}}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
add	Adds the 802.11b DCA channels to RRM allowed channel list
anchor-time	Specifies the anchor time for DCA.
value	Hour of time between 0 and 23. These values represent the hour from 12:00 a.m. to 11:00 p.m.
global	Specifies the global DCA mode for the access points in the 802.11 networks.
auto	Enables auto-RF.
once	Enables one-time auto-RF.
interval	Specifies how often the DCA is allowed to run.
value	Interval between the times when DCA is allowed to run. Valid values are 0, 1, 2, 3, 4, 6, 8, 12, or 24 hours. 0 is 10 minutes (600 seconds). Default value is 0 (10 minutes).
min-metric	Specifies the DCA minimum RSSI energy metric.
value	Minimum RSSI energy metric value from –100 to –60.
remove	Removes the 802.11b DCA channels from RRM allowed channel list.
sensitivity	Specifies how sensitive the DCA algorithm is to environmental changes (for example, signal, load, noise, and interference) when determining whether or not to change channels.
high	Specifies that the DCA algorithm is not particularly sensitive to environmental changes. See the “Usage Guidelines” section for more information.
low	Specifies that the DCA algorithm is moderately sensitive to environmental changes. See the “Usage Guidelines” section for more information.
medium	Specifies that the DCA algorithm is highly sensitive to environmental changes. See the “Usage Guidelines” section for more information.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The DCA sensitivity thresholds vary by radio band as shown in the table below.

To aid in troubleshooting, the output of this command shows an error code for any failed calls. The table below explains the possible error codes for failed calls.

Table 6: DCA Sensitivity Threshold

Sensitivity	2.4 Ghz DCA Sensitivity Threshold	5 Ghz DCA Sensitivity Threshold
High	5 dB	5 dB
Medium	15 dB	20 dB
Low	30 dB	35 dB

This example shows how to configure the device to start running DCA at 5 pm for the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca anchor-time 17
```

This example shows how to set the DCA algorithm to run every 10 minutes for the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca interval 0
```

This example shows how to configure the value of DCA algorithm's sensitivity to low on the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca sensitivity low
```

ap dot11 rrm channel-update mesh

To initiate update of the 802.11a, 802.11b, and 802.11 6GHz channel selection for every mesh Cisco AP, use the **ap dot11** {**24ghz** | **5ghz** | **6ghz**} **rrm channel-update mesh**

AP

ap dot11 { **24ghz** | **5ghz** | **6ghz** } **rrm channel-update mesh**

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

The example shows how to initiate update of the 802.11a, 802.11b, and 802.11 6GHz channel selection for every mesh Cisco AP:

```
Device# ap dot11 5ghz rrm channel-update mesh
```

ap dot11 rrm channel-update mesh bridge-group

To initiate the update of the 802.11, 802.11a, or 802.11b channel selection for mesh AP in the bridge group, use the **ap dot11** {**24ghz** | **5ghz** | **6ghz**} **channel-update mesh bridge-group**

ap dot11 { **24ghz** | **5ghz** | **6ghz** } **rrm channel-update mesh channel-update mesh bridge-group** *bridge-group-name*

Syntax Description

bridge-group-name	Specifies the name of the bridge group.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to initiate the update of the 802.11, 802.11a, or 802.11b channel selection for mesh AP in the bridge group:

```
Device# ap dot11 5ghz rrm channel-update mesh bridge-group cisco-bridge-group
```

ap dot11 rrm coverage

To enable 802.11 coverage hole detection, use the **ap dot11 rrm coverage** command.

ap dot11 {**24ghz** | **5ghz**} **rrm coverage** [**data** {**fail-percentage** *percentage* | **packet-count** *count* | **rssi-threshold** *threshold*} | **exceptional global** *value* | **level global** *value* | **voice** {**fail-percentage** *percentage* | **packet-count** *packet-count* | **rssi-threshold** *threshold*}]

Syntax Description

data	Specifies 802.11 coverage hole-detection data packets.
fail-percentage *percentage*	Specifies 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
packet-count *count*	Specifies 802.11 coverage minimum-failure-count threshold for uplink data packets.
rssi-threshold *threshold*	Specifies 802.11 minimum-receive-coverage level for voice packets.
exceptional global *value*	Specifies 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global *value*	Specifies 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Specifies 802.11 coverage Hole-Detection for voice packets.
fail-percentage *percentage*	Specifies 802.11 coverage failure rate threshold for uplink voice packets.
packet-count *packet-count*	Specifies 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold *threshold*	Specifies 802.11 minimum receive coverage level for voice packets.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

If you enable coverage hole-detection, the device automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 {24ghz | 5ghz} rrm coverage packet-count** and **ap dot11 {24ghz | 5ghz} rrm coverage fail-percentage** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The device uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the

ap dot11 {24ghz | 5ghz} rrm coverage level-global and **ap dot11 {24ghz | 5ghz} rrm coverage exceptional-global** commands over a 90-second period. The device determines whether the coverage hole can be corrected and, if appropriate, mitigate the coverage hole by increasing the transmit power level for that specific access point.

This example shows how to set the RSSI-threshold for data in 5-GHz band.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm coverage data rssi-threshold -80
```

ap dot11 rrm group-member

To configure members in an 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove members from 802.11 RF group, use the **no** form of this command.

ap dot11 {**24ghz** | **5ghz**} **rrm group-member** *controller-name controller-ip*
no ap dot11 {**24ghz** | **5ghz**} **rrm group-member** *controller-name controller-ip*

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
controller-name	Name of the device to be added.
controller-ip	IP address of the device to be added.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to add a device in the 5 GHz band RF group:

```
Device(config)# ap dot11 5ghz rrm group-member cisco-controller 192.0.2.54
```

ap dot11 rrm group-mode

To set the 802.11 automatic RF group selection mode on, use the **ap dot11 rrm group-mode** command. To set the 802.11 automatic RF group selection mode off, use the **no** form of this command.

ap dot11 { **5ghz** | **24ghz** } **rrm group-mode** { **auto** | **leader** | **off** }
no ap dot11 {**5ghz** | **24ghz**} **rrm group-mode**

Syntax Description

5ghz	Specifies the 2.4-GHz band.
24ghz	Specifies the 5-GHz band.
auto	Sets the 802.11 RF group selection to automatic update mode.
leader	Sets the 802.11 RF group selection to static mode, and sets this device as the group leader.
off	Sets the 802.11 RF group selection to off.

Command Default

auto

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to turn the auto RF group selection mode on the 5 GHz band:

```
Device(config)# ap dot11 5ghz rrm group-mode auto
```

ap dot11 rrm logging

To configure report log settings on supported 802.11 networks, use the **ap dot11 rrm logging** command.

ap dot11 {**24ghz** | **5ghz**} **rrm logging** {**channel** | **coverage** | **foreign** | **load** | **noise** | **performance** | **txpower**}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
channel	Turns the channel change logging mode on or off. The default mode is off (Disabled).
coverage	Turns the coverage profile logging mode on or off. The default mode is off (Disabled).
foreign	Turns the foreign interference profile logging mode on or off. The default mode is off (Disabled).
load	Turns the load profile logging mode on or off. The default mode is off (Disabled).
noise	Turns the noise profile logging mode on or off. The default mode is off (Disabled).
performance	Turns the performance profile logging mode on or off. The default mode is off (Disabled).
txpower	Turns the transit power change logging mode on or off. The default mode is off (Disabled).

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to turn the 5 GHz logging channel selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging channel
```

This example shows how to turn the 5 GHz coverage profile violation logging selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging coverage
```

This example shows how to turn the 5 GHz foreign interference profile violation logging selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging foreign
```

This example shows how to turn the 5 GHz load profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging load
```

This example shows how to turn the 5 GHz noise profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging noise
```

This example shows how to turn the 5 GHz performance profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging performance
```

This example shows how to turn the 5 GHz transmit power change mode on:

```
Device(config)# ap dot11 5ghz rrm logging txpower
```

ap dot11 rrm monitor

To Configure monitor settings on the 802.11 networks, use the **ap dot11 rrm monitor** command.

ap dot11 {**24ghz** | **5ghz**} **rrm monitor** {**channel-list** | {**all** | **country** | **dca**} | **coverage** | **load** | **noise** | **signal**} *seconds*

Syntax Description

24ghz	Specifies the 802.11b parameters.
5ghz	Specifies the 802.11a parameters.
channel-list all	Monitors the noise, interference, and rogue monitoring channel list for all channels.
channel-list country	Monitors the noise, interference, and rogue monitoring channel list for the channels used in the configured country code.
channel-list dca	Monitors the noise, interference, and rogue monitoring channel list for the channels used by automatic channel assignment.
coverage	Specifies the coverage measurement interval.
load	Specifies the load measurement interval.
noise	Specifies the noise measurement interval.
signal	Specifies the signal measurement interval.
rssi-normalization	Configure RRM Neighbor Discovery RSSI Normalization.
seconds	Measurement interval time from 60 to 3600 seconds.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to monitor the channels used in the configured country:

```
Device(config)# ap dot11 24ghz rrm monitor channel-list country
```

This example shows how to set the coverage measurement interval to 60 seconds:

```
Device(config)# ap dot11 24ghz rrm monitor coverage 60
```

ap dot11 rrm ndp-type

To configure the 802.11 access point radio resource management neighbor discovery protocol type, use the **ap dot11 rrm ndp-type** command.

ap dot11 { **24ghz** | **5ghz** } **rrm ndp-type** { **protected** | **transparent** }

Syntax Description

24ghz	Specifies the 2.4-GHz band.
5ghz	Specifies the 5-GHz band.
6ghz	Specifies the 6-GHz band.
protected	Specifies the Tx RRM protected (encrypted) neighbor discovery protocol.
transparent	Specifies the Tx RRM transparent (not encrypted) neighbor discovery protocol.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.
Cisco IOS XE Cupertino 17.7.1	This command was modified with the introduction of the 6-GHz band.

Usage Guidelines

Before you configure the 802.11 access point RRM neighbor discovery protocol type, ensure that you have disabled the network by entering the **ap dot11** {**24ghz | 5ghz** } **shutdown** command.

This example shows how to enable the 802.11a access point RRM neighbor discovery protocol type as protected:

```
Device(config)# ap dot11 5ghz rrm ndp-type protected
```

ap dot11 24ghz rrm tpc

To configure the tx-power control threshold used by RRM for auto power assignment, use the **ap dot11 rrm tpc** command. To disable, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **rrm tpc{threshold** | **tpcv1-chan-aware**}

Syntax Description

tpc threshold	Configures the Tx-Power Control threshold used by RRM..
tpcv1-chan-aware	Configures the Tx-Power Control to be channel aware.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to configure the tx-power control threshold used by RRM for auto power assignment.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 24ghz rrm tpc
```

ap dot11 rrm txpower

To configure the 802.11 tx-power level, use the **ap dot11 rrm txpower** command. To disable the 802.11 tx-power level, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **rrm txpower** {*powerLevel <1-5>* | **auto** | **max** *powerLevel* | **min** *powerLevel* | **once***power-level*}

Syntax Description

powerLevel	Configures the transmit power level.
auto	Enables auto-RF.
max *powerLevel*	Configures maximum auto-RF tx power. The range is between -10 to -30.
min *powerLevel*	Configures minimum auto-RF tx power. The range is between -10 to -30.
once	Enables one-time auto-RF.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to enables auto-RF once.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm txpower once
```

ap dot11 rrm txpower

To configure the 802.11 tx-power level, use the **ap dot11 rrm txpower** command. To disable the 802.11 tx-power level, use the **no** form of the command.

ap dot11 {**24ghz** | **5ghz**} **rrm txpower** {*powerLevel* <*1-5*> | **auto** | **max** *powerLevel* | **min** *powerLevel* | **once***power-level*}

Syntax Description

powerLevel	Configures the transmit power level.
auto	Enables auto-RF.
max *powerLevel*	Configures maximum auto-RF tx power. The range is between -10 to -30.
min *powerLevel*	Configures minimum auto-RF tx power. The range is between -10 to -30.
once	Enables one-time auto-RF.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to enables auto-RF once.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm txpower once
```

ap filter

To configure the AP filter and set the priority, use the **ap filter** command.

ap filter { { **name** *filter-name* } **type** { **tag** } | { **priority** *priority-number* | **filter-name** *filter-name* } }

Syntax Description

Parameter	Description
priority	Set the priority for a named filter.
priority-number	The valid AP filter priority range is 0 to 1023.
filter-name	Enter the name for the ap filter.
type	Type of filter.
tag	Filter to assign AP Tags. Tag filter may be persistent based on tag persistence on the global configuration.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to create a ap filter and set the priority to this filter:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap filter name test-filter
Device(config)# ap filter name test-filter type priming
Device(config)# ap filter priority 12 filter-name test-filter
```

ap fra

To configure flexible radio assignment (FRA) and its parameters, use the **ap fra** command.

ap fra[**interval** *no-of-hours* | **sensitivity** {**high** | **low** | **medium** } | **sensor-threshold** {**balanced** | **client-preferred** | **client-priority** | **sensor-preferred** | **sensor-priority** } | **service-priority** {**coverage** | **service-assurance**}]

Syntax Description

interval *no-of-hours*	Enter the number of hours for the FRA interval. Valid range is 1 to 24 hours.
sensitivity {**high** | **low** | **medium**}	Configures the FRA coverage overlap sensitivity as high, low, or medium.
sensor-threshold {**balanced** | **client-preferred** | **client-priority** | **sensor-preferred** | **sensor-priority**}	Configures FRA sensor threshold to one of the available options.
service-priority {**coverage** | **service-assurance**}	Configures FRA service priority to Coverage or Service Assurance.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Ensure that the RF group leader for 802.11b/g and 802.11a bands are same across RF domain and make sure that the RF group leader has FRA enabled.

Examples

The following example show how to configure the FRA interval to 8 hours:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap fra interval 8
```

ap fra 5-6ghz interval

To configure the Flexible Radio Assignment (FRA) 5/6-GHz interval in hours, use the **ap fra 5-6ghz interval** command.

ap fra 5-6ghz interval *number-of-hours*

Syntax Description

number-of-hours	Specifies the FRA 5/6-GHz interval in hours. The value range is between 1 to 24 hours.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to configure the Flexible Radio Assignment (FRA) 5/6-GHz interval in hours:

```
Device(config)# ap fra 5-6ghz interval 12
```

ap image predownload

To instruct all APs to start image predownload, use the **ap image predownload** command.

ap image predownload {**abort** | **site-tag** *site-tag-name* **start**}

Syntax Description

abort	Instructs all the APs to abort image predownload.
site-tag	Initiates image predownload parameters.
site-tag-name	Specifies the site-tag name.
start	Starts image predownload.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how the APs are instructed to start image predownload:

```
Device#ap image download site-tag site-tag-name start
```

ap name antenna band mode

To configure the antenna mode, use the **ap name***ap- name* **antenna-band-mode{ single | dual }** command.

ap name*ap-name* **antenna-band-mode** {**single** | **dual**}

Syntax Description

ap- name	Name of the Cisco lightweight access point.
antenna-band-mode	Instructs the access point to enable the band mode of antenna.

Command Default

None

Example

This example shows how to configure the antenna band mode of access point.

```
Deviceap name <ap-name> antenna-band-mode single
```

ap name ble

To enable the able ltx state on the AP, use the **ap name** *ap name* **ble** command.

ap name *ap_name* **antena-band-mode {admin | ibeacon | interval | no-advertisement | sync | vibeacon}**

Syntax Description

ap name	AP Name
admin	Enables the ble ltx admin state.
ibeacon	Enables the BLE LTX iBeacon configuration.
interval	Enables the BLE LTX scan configuration interval.
no-advertisement	Enables the BLE LTX No Advertisement.
Sync	Enables the BLE LTX synchronize.
vibeacon	Enables the BLE LTX viBeacon configuration.

Command Default

Disabled

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to enable ble on the AP:

```
Device# ap name test ble
```

ap name clear-personal-ssid

To clear the personal SSID from a Cisco OfficeExtend Access Point (OEAP), use the **ap name clear-personal-ssid** command.

ap name *ap-name* **clear-personal-ssid**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to clear the personal SSID from a Cisco OEAP:

```
Device# ap name my-oeap clear-personal-ssid
```

ap name controller

To configure the controller on the AP, use the **ap name** *ap name* **controller** command.

ap name *ap_name* **controller {primary | secondary | tertiary}** *name {A.B.C.D | X:X:X::XX}*

Syntax Description

ap name	AP Name
controller	Configures the controller.
primary	Configures the primary controller.
secondary	Configures the secondary controller.
tertiary	Configures the tertiary controller.
name	Specifies the name of the primary controller, secondary controller, or tertiary controller.
A.B.C.D	Specifies theIPv4 address of the primary controller, secondary controller, or tertiary controller.
X:X:X::XX	Specifies theIPv6 address of the primary controller, secondary controller, or tertiary controller.

Command Default

Disabled

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to configure the controller on the AP:

```
Device# ap name cisco-ap controller primary cisco-primary-controller 10.1.1.1
```

ap name country

To configure the country of operation for a Cisco lightweight access point, use the **ap name country** command.

ap name *ap-name* **country** *country-code*

Syntax Description

ap-name	Name of the Cisco lightweight access point.
country-code	Two-letter or three-letter country code.

Command Default

None

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

Cisco devices must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains. Also, access point regulatory domains are defined during the access point manufacturing process. You can change the access point country code if the new country code matches a country that is valid within the access point regulatory domain. If you try to enter a country that is not valid to the access point regulatory domain, the command fails.

This example shows how to configure the Cisco lightweight access point's country code to DE:

```
Device# ap name AP2 country JP
```

ap name crash-file

To manage crash data and radio core files for the Cisco access point, use the **ap name crash-file** command.

ap name *ap-name* **crash-file** {**get-crash-data** | **get-radio-core-dump** {**slot 0** | **slot 1**}}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
get-crash-data	Collects the latest crash data for a Cisco lightweight access point.
get-radio-core-dump	Gets a Cisco lightweight access point's radio core dump
slot	Slot ID for Cisco access point.
0	Specifies Slot 0.
1	Specifies Slot 1.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to collect the latest crash data for access point AP3:

```
Device# ap name AP3 crash-file get-crash-data
```

This example shows how to collect the radio core dump for access point AP02 and slot 0:

```
Device# ap name AP02 crash-file get-radio-core-dump slot 0
```

ap name dot11 24ghz | 5ghz | 6ghz rrm channel update mesh

To trigger the RRM DCA for a specific AP, use the **ap name** *cisco-ap-name* **dot11** {**24ghz** | **5ghz** | **6ghz**} **rrm channel update mesh**

ap name *cisco-ap-name* **dot11** { **24ghz** | **5ghz** | **6ghz** } **rrm channel update mesh**

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to trigger the RRM DCA for a specific AP:

```
Device# ap name Cisco-ap-name dot11 5ghz rrm channel update mesh
```

ap name dot11 24ghz slot 0 SI

To enable Spectrum Intelligence (SI) for the dedicated 2.4-GHz radio hosted on slot 0 for a specific access point, use the **ap name dot11 24ghz slot 0 SI** command.

ap name *ap-name* **dot11** { **24ghz** | **5ghz** | **dual-band** | **rx-dual-band** } **slot** *slot ID* **SI**

Syntax Description

ap_name	Name of the Cisco Access Point.
slot 0	Enables Spectrum Intelligence (SI) for the dedicated 2.4-GHz radio hosted on slot 0 for a specific access point. Here, 0 refers to the Slot ID.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure Spectrum Intelligence of an AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 SI
```

ap name dot11 24ghz slot antenna

To configure the 802.11b antenna hosted on slot 0, use the **ap name dot11 24ghz slot antenna** command.

ap name *ap-name***dot1124ghzslot 0antenna** { **ext-ant-gain** *antenna-gain-value* | **selection** [**internal** | **external** }

Syntax Description

ap-name	Name of the AP.
24ghz	Configures 802.11b parameters.
slot	Sets the slot ID for the Cisco Access Point.
antenna	Configures the 802.11b Antenna.
ext-ant-gain	Configures the 802.11b External Antenna Gain. The value range is 0 - 4294967295. Enter External Antenna Gain value in multiple of .5 dBi units (i.e. An integer value 4 means 4 x 0.5 = 2 dBi of gain)
selection	Configure the 802.11b Antenna selection (internal/external)

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to configure the channel width of an AP.

```
Device# ap name ax1 dot11 24ghz slot 0 antenna selection external
```

ap name dot11 24ghz slot beamforming

To configures beamforming for the 2.4-GHz radio hosted on slot 0 for a specific access point, use the **ap name dot11 24ghz slot beamforming** command.

ap name *ap-name***dot1124ghzslot 0beamforming**

Syntax Description

beamforming	Enable 802.11b tx beamforming - 5 GHz

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to configure beamforming of an AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 beamforming
```

ap name dot11 24ghz slot channel

To configure advanced 802.11 channel assignment parameters for Cisco AP, use the **ap name dot11 24ghz slot channel** command.

ap name *ap-name* **dot11 24ghz slot 0 channel** { *channel_number* | **auto** }

Syntax Description

channel_number	Advanced 802.11 channel assignment parameters for Cisco AP. Enter a channel number from 1 - 14.
auto	Enables auto RF.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to configure the channel of an AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 channel auto
```

ap name dot11 24ghz slot cleanair

To enable CleanAir for 802.11b radio hosted on slot 0 for a specific access point, use the **ap name dot11 24ghz slot cleanair** command.

ap name *ap-name* **dot11 24ghz slot 0 cleanair**

Syntax Description

cleanair	Enables 802.11b cleanair management

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure the cleanair of an AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 cleanair
```

ap name dot11 24ghz slot dot11n antenna

To configure 802.11n antenna for 2.4-GHz radio hosted on slot 0 for a specific access point, use the **ap name dot11 24ghz slot dot11n antenna** command.

ap name *ap-name* **dot11 24ghz slot 0 dot11n antenna** { **A** | **B** | **C** | **D** }

Syntax Description

dot11n	Configures 802.11n antenna for 2.4-GHz radio hosted on slot 0 for a specific access point.
antenna	Configures the 802.11n - 2.4 GHz antenna selection from antenna ports A, B, C, and D.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure the channel width of an AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 dot11n antenna A
```

ap name dot11 24ghz slot dot11ax bss-color

To set the BSS color on the 2.4 GHz, 5 GHz, or dual-band radio, for a specific access point, use the **ap name dot11 24ghz slot dot11ax bss-color** command.

ap name *ap-name* **dot11 24ghz slot 0 dot11ax bss-color** *<1-63>*

Syntax Description

bss-color	Configures 802.11ax-2.4GHz BSS color

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to disable 802.11b radio on Cisco AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 dot11ax bss-color 3
```

ap name dot11 24ghz slot shutdown

To disable 802.11b radio hosted on slot 0 for a specific access point, use the **ap name dot11 24ghz slot shutdown** command.

ap name *ap-name* **dot11 24ghz slot 0 shutdown**

Syntax Description

shutdown	Disables 802.11b radio on Cisco AP

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to disable 802.11b radio on Cisco AP.

```
Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 shutdown
```

ap name dot11 5ghz slot {1 | 2} urwb dfs

To configure the URWB DFS role on a 5 GHz radio interface, use the **ap name** *ap-name* **dot11 5ghz slot** {**1** | **2**}**urwb dfs** {**auto** | **primary** | **secondary**}

ap name *ap-name* **dot11 5ghz slot** { **1** | **2** } **urwb dfs** { **auto** | **primary** | **secondary** }

Syntax Description

ap-name	Specifies the name of the Cisco AP.
auto	Specifies the URWB DFS role as auto on this radio interface.
primary	Specifies URWB DFS role as primary on this radio interface.
secondary	Specifies URWB DFS role as secondary on this radio interface.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB DFS role on a 5 GHz radio interface:

```
Device# ap name ap-name 5ghz slot 1 urwb dfs auto
```

ap name dot11 5ghz slot {1 | 2} urwb ptmp base

To enable URWB PTMP base on a 5 GHz radio interface, use the **ap name** *ap-name* **dot11 5ghz slot** {**1** | **2**}**urwb ptmp base**

ap name *ap-name* **dot11 5ghz slot** { **1** | **2** } **urwb ptmp base**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to enable URWB PTMP base on a 5 GHz radio interface:

```
Device# ap name ap-name 5ghz slot 1 urwb ptmp base
```

ap name dot11 dual-band cleanair

To configure CleanAir for a dual band radio, use the **ap name dot11 dual-band cleanair** command.

ap name *ap-name* **dot11 dual-band cleanair**
ap name *ap-name* **no dot11 dual-band cleanair**

Syntax Description

ap-name	Name of the Cisco AP.
cleanair	Specifies the CleanAir feature.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to enable CleanAir for a dual band radio of the access point AP01:

```
Device# ap name AP01 dot11 dual-band cleanair
```

ap name dot11 dual-band shutdown

To disable dual band radio on a Cisco AP, use the **ap name dot11 dual-band shutdown** command.

ap name *ap-name* **dot11 dual-band shutdown**
ap name *ap-name* **no dot11 dual-band shutdown**

Syntax Description

ap-name	Name of the Cisco AP.
shutdown	Disables the dual band radio on the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to disable dual band radio on the Cisco access point AP01:

```
Device# ap name AP01 dot11 dual-band shutdown
```

ap name dot11 rrm profile

To configure Radio Resource Management (RRM) performance profile settings for a Cisco lightweight access point, use the **ap name dot11 rrm profile** command.

ap name *ap-name* **dot11** {**24ghz** | **5ghz**} **rrm profile** {**clients** *value* | **customize** | **foreign** *value* | **noise** *value* | **throughput** *value* | **utilization** *value*}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
clients	Sets the access point client threshold.
value	Access point client threshold from 1 to 75 clients. **Note** The default client threshold is 12.
customize	Turns on performance profile customization for an access point. **Note** Performance profile customization is off by default.
foreign	Sets the foreign 802.11 transmitter interference threshold.
value	Foreign 802.11 transmitter interference threshold from 0 to 100 percent. **Note** The default is 10 percent.
noise	Sets the 802.11 foreign noise threshold.
value	802.11 foreign noise threshold between –127 and 0 dBm. **Note** The default is —70 dBm.
throughput	Sets the data-rate throughput threshold.
value	802.11 throughput threshold from 1000 to 10000000 bytes per second. **Note** The default is 1,000,000 bytes per second.
utilization	Sets the RF utilization threshold. **Note** The operating system generates a trap when this threshold is exceeded.

value	802.11 RF utilization threshold from 0 to 100 percent. **Note** The default is 80 percent.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to set the AP1 clients threshold to 75 clients:

```
Device# ap name AP1 dot11 24ghz rrm profile clients 75
```

This example shows how to turn performance profile customization on for 802.11a Cisco lightweight access point AP1:

```
Device# ap name AP1 dot11 5ghz rrm profile customize
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
Device# ap name AP1 dot11 5ghz rrm profile foreign 0
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
Device# ap name AP1 dot11 5ghz rrm profile noise 0
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
Device# ap name AP1 dot11 5ghz rrm profile throughput 10000000
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
Device# ap name AP1 dot11 5ghz rrm profile utilization 100
```

ap name image

To configure an image on a specific access point, use the **ap name image** command.

ap name *ap-name* **image** {**predownload** | **swap**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
predownload	Instructs the access point to start the image predownload.
swap	Instructs the access point to swap the image.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to predownload an image to an access point:

```
Device# ap name AP2 image predownload
```

This example shows how to swap an access point's primary and secondary images:

```
Device# ap name AP2 image swap
```

ap name icap subscription client anomaly-detection report-individual enable aggregate

To configure anomaly detection for client subscriptions and to enable individual report aggregation, use the **ap name icap subscription client anomaly-detection report-individual enable aggregate** command.

ap name *ap name* **icap subscription client anomaly-detection report-individual enable aggregate**

Syntax Description

ap name	Name of the Cisco access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to configure anomaly detection for client subscriptions and to enable individual report aggregation:

```
Device# ap name cisco-AP icap subscription client anomaly-detection report-individual enable
 aggregate
```

ap name icap subscription client anomaly-detection report-individual per-client throttle

To configure individual reports per client every five minutes on an AP, use the **ap name icap subscription client anomaly-detection report-individual per-client throttle** command.

ap name *ap name* **icap subscription client anomaly-detection report-individual per-client throttle** *throttle-value*

Syntax Description

ap name	Name of the Cisco access point.
throttle-value	Number of event reports per client. Valid value ranges from 0 to 50. If the value is 0, there is no throttle.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following examples shows how to configure individual reports per client every five minutes on an AP:

```
Device# ap name cisco-AP icap subscription client anomaly-detection report-individual
per-client throttle 10
```

ap name icap subscription client anomaly-detection report-individual per-type throttle

To configure individual reports per type on an AP, use the **ap name icap subscription client anomaly-detection report-individual per-type throttle** command.

ap name *ap name* **icap subscription client anomaly-detection report-individual per-type throttle** *throttle*

Syntax Description

ap name	Name of the Cisco access point.
throttle-value	Number of event reports per client. Valid values range from 0 to 100. If the value is 0, there is no throttle.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to configure individual reports per type on an AP:

```
Device# ap name cisco-AP icap subscription client anomaly-detection report-individual
per-type throttle 50
```

ap name indoor

To enable the access point in the indoor mode, use the **ap name** *ap name* **indoor** command.

ap name *ap_name* **indoor**

Syntax Description

ap name	AP Name
indoor	Enables the access point in the indoor mode.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to enable the access point in the indoor mode:

```
Device# ap name test indoor
```

ap name ipsla

To configure ipsla on the AP, use the **ap name** *ap name* **ipsla** command.

ap name *ap_name* **ipsla**

Syntax Description

ap name	AP Name
ipsla	Enables the ipsla on the access point.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to configure ipsla on the access point:

```
Device# ap name test ipsla
```

ap name keepalive

To enable the keepalive option on the AP, use the **ap name** *ap name* **keepalive** command.

ap name *ap_name* **keepalive**

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.03.1	This command was introduced.

Examples

The following example shows how to enable the keepalive option on the AP:

```
Device# ap name test keepalive
```

ap name lan

To configure LAN port configurations for APs, use the **ap name lan** command. To remove LAN port configurations for APs, use the**ap name no lan** command.

ap name *ap-name* **[no]lan port-id** *port-id* {**shutdown** | **vlan-access**}

Syntax Description

no	Removes LAN port configurations.
port-id	Configures the port.
port-id	The ID of the port. The range is 1-4
shotdown	Disables the Port.
vlan-access	Enables VLAN access to Port.

Command Default

None

Command Modes

Privileged EXEC(#)

This example shows how to enable VLAN access to port:

```
Device# ap name AP1 lan port-id 1 vlan-access
```

ap name led

To enable the LED state for an access point, use the **ap name led** command. To disable the LED state for an access point, use the **no** form of this command.

ap name *ap-name* **led**
no ap name *ap-name* [**led**] **led**

Syntax Description

ap-name	Name of the Cisco lightweight access point.
led	Enables the access point's LED state.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to enable the LED state for an access point:

```
Device# ap name AP2 led
```

This example shows how to disable the LED state for an access point:

```
Device# ap name AP2 no led
```

ap name led-brightness-level

To configure the LED brightness level on the AP, use the **ap name** *ap name* **led-brightness-level** command.

ap name *ap_name* **led-brightness-level {1–8}**

Syntax Description

ap name	AP Name
led brightness level	Configures the led brightness level. **Note** Valid led brightness level is from 1 to 8.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows the LED brightness level on the access point:

```
Device# ap name cisco-ap led-brightness-level2
```

ap name location

To modify the descriptive location of a Cisco lightweight access point, use the **ap name location** command.

ap name *ap-name* **location** *location*

Syntax Description

ap-name	Name of the Cisco lightweight access point.
location	Location name of the access point (enclosed by double quotation marks).

Command Default

None

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

This example shows how to configure the descriptive location for access point AP1:

```
Device# ap name AP1 location Building1
```

ap name mesh backhaul rate dot11abg

To set the mesh backhaul dot11abg rate, use the **ap name** *ap-name* **mesh backhaul rate dot11abg** command.

ap name *ap-name* **mesh backhaul rate dot11abg** { **RATE_11M** | **RATE_12M** | **RATE_18M** | **RATE_1M** | **RATE_24M** | **RATE_2M** | **RATE_36M** | **RATE_48M** | **RATE_54M** | **RATE_5DOT5M** | **RATE_6M** | **RATE_9M** }

Syntax Description

RATE_11M | **RATE_12M** | **RATE_18M** | **RATE_1M** | **RATE_24M** | **RATE_2M** | **RATE_36M** | **RATE_48M** | **RATE_54M** | **RATE_5DOT5M** | **RATE_6M** | **RATE_9M**	Sets the mesh backhaul rates.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the AP mesh backhaul dot11abg rate:

```
Device# ap name cisco-ap mesh backhaul rate dot11abg RATE_11M
```

ap name mdsn-ap

To configure mdsn-ap on the AP, use the **ap name** *ap name* **mdsn-ap** command.

ap name *ap_name* **mdsn-ap {disable | enable | vlan}** *add delete*

Syntax Description

ap name	AP Name
disable	Disables the mDNS access point.
enable	Enables the mDNS access point.
vlan	Adds or deletes the VLAN from mDNS access point.
add	Adds vlan to mDNS AP.
add	Deletes vlan from the mDNS AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to enable mdns on the AP:

```
Device# Device# ap name test mdns enable
```

ap name mesh backhaul rate dot11ac

To set the mesh backhaul dot11ac rate, use the **ap name** *ap-name* **mesh backhaul rate dot11ac** command.

ap name *ap-name* **mesh backhaul rate dot11ac mcs** *0-9* **ss** *1-4*

Syntax Description

mcs *0-9*	Sets the mesh backhaul 11ac MCS rate.
0-9	Indicates the mesh backhaul rate 11ac mcs index .
ss	Sets the mesh backhaul 11ac spatial stream.
1-4	Indicates the mesh backhaul 11ac spatial stream value.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the AP mesh backhaul dot11ac rate:

```
Device# ap name cisco-ap mesh backhaul rate dot11ac mcs 5 ss 3
```

ap name name mesh backhaul rate dot11ax

To set the mesh backhaul dot11ax rate, use the **ap name** *ap-name* **mesh backhaul rate dot11ax** command.

ap name *ap-name* **mesh backhaul rate dot11ax mcs** *0-11* **ss** *1-8*

Syntax Description

mcs	Sets the mesh backhaul 11ax MCS rate.
0-11	Indicates the mesh backhaul 11ax MCS index.
ss	Sets the mesh backhaul 11ax spatial stream.
1-8	Indicates the mesh backhaul 11ax spatial stream value. Range 1-4 indicates the range for 2.4-Ghz, and range 1 - 8 indicates the range for 5-Ghz backhaul.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the AP mesh backhaul dot11ax rate:

```
Device# ap name cisco-ap mesh backhaul rate dot11ax mcs 6 ss 5
```

ap name name new-ap-name

To configure the new Cisco AP name, use the **ap name** *ap name* **name** *new-ap-name* command.

ap name *ap_name* **name** *new-ap-name*

Syntax Description

ap name	AP Name
name	Specifies the new Cisco AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to configure the new Cisco AP:

```
Device# ap name test name test2
```

ap name no

To negate a command or set its defaults on the AP, use the **no** command.

ap name *ap_name* **no**

Syntax Description

ap name	AP Name
no	Negate a command or set its defaults.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

The following example shows how to negate a command or set its defaults on the AP:

```
Device# ap name test no
```

ap name mesh backhaul rate

To configure the AP mesh backhaul rate, use the **ap name** *ap-name* **mesh backhaul rate** command.

ap name *ap-name* **mesh backhaul rate** { **auto** | **dot11abg** | **dot11ac** | **dot11ax** | **dot11n** }

Syntax Description

auto	Configures the mesh backhaul rate as auto.
dot11abg	Configures the mesh backhaul dot11abg rate.
dot11ac	Configures the mesh backhaul dot11ac rate.
dot11ax	Configures the mesh backhaul dot11ax rate.
dot11n	Configures the mesh backhaul dot11n rate.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the AP mesh backhaul rate as auto:

```
Device# ap name cisco-ap mesh backhaul rate auto
```

ap name mesh backhaul rate dot11n

To set the mesh backhaul dot11n rate, use the **ap name** *ap-name* **mesh backhaul rate dot11n** command.

ap name *ap-name* **mesh backhaul rate dot11n mcs** *0-31*

Syntax Description

mcs *0-31*	Sets the mesh backhaul 11n MCS rate.
0-31	Indicates the mesh backhaul rate dot11n mcs index.s

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the AP mesh backhaul dot11n rate:

```
Device# ap name cisco-ap mesh backhaul rate dot11n mcs 20
```

ap name mesh block-child

To set mesh block-child state for a mesh AP, use the **ap name mesh block-child** command.

ap name *ap-name* **mesh block-child**

Syntax Description

ap-name	Name of the mesh AP.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh block-child state for a mesh AP:

```
Device# ap name mymeshap mesh block-child
```

ap name mesh daisy-chaining

To configure daisy-chain mode for a mesh AP, use the **ap name** *ap-name* **mesh daisy-chaining** command.

ap name *ap-name* **mesh daisy-chaining** [**strict-rap**]

Syntax Description

ap-name	Name of the mesh AP.
strict-rap	Configures to allow only the Ethernet interface as mesh uplink.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure daisy-chaining mode for a mesh AP:

```
Device# ap name mymeshap mesh daisy-chaining
```

ap name mesh ethernet mode access

To configure the mode of Ethernet interface as access for a mesh AP, use the **ap name** *ap-name* **mesh ethernet** *port-no* **mode access** command.

ap name *ap-name* **mesh ethernet** *port-no* **mode access** *vlan-id*

Syntax Description

ap-name	Name of the mesh AP.
port-no	Port number of the AP. Valid options are 1, 2, 3, and 4.
vlan-id	VLAN ID. Valid range is from 0 to 4095.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mode of Ethernet interface as access for a mesh AP:

```
Device# ap name mymeshap mesh ethernet 0 mode access 10
```

ap name mesh ethernet mode trunk

To configure the mode of Ethernet interface as trunk for a mesh AP, use the **ap name** *ap-name* **mesh ethernet** *port-no* **mode trunk** command.

ap name *ap-name* **mesh ethernet** *port-no* **mode trunk vlan** {**allowed** | **native**}*vlan-id*

Syntax Description

ap-name	Name of the mesh AP.
port-no	Port number of the AP. Valid options are 1, 2, 3, and 4.
allowed	Configures allowed VLANs for the trunk port.
native	Configures native VLAN for the trunk port.
vlan-id	VLAN ID. Valid range for allowed VLANs is from 0 to 4095. Valid range for native VLANs is 1 to 4095.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mode of Ethernet interface as trunk for a mesh AP and also configure allowed VLANs for the trunk port:

```
Device# ap name mymeshap mesh ethernet 0 mode trunk vlan allowed 10
```

ap name mesh linktest

To perform a link test with a mesh AP, use the **ap name** *ap-name***mesh linktest** command.

ap name *ap-name* **mesh linktest** *dest-ap-mac data-rate pkts-per-sec pkt-size test-duration*

Syntax Description

ap-name	Name of the mesh AP.
dest-ap-mac	MAC address of the destination mesh AP.
data-rate	Data rate in Mbps (1, 2, 5.5, 6, 9, 11, 12, 24, 36, 48, 53, m0-m15)
pkts-per-sec	Packets to be sent per second. Valid range is from 1 to 25000.
pkt-size	Packet size. Valid range is from 1 to 1500.
test-duration	Test duration. Valid range is from 10 to 300 seconds.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a link test for a mesh AP:

```
Device# ap name mymeshap mesh linktest 00c0.00a0.03fa.0000.0000.0000
 9 100 10 180
```

ap name mesh parent preferred

To configure preferred parent for a mesh AP, use the **ap name mesh parent preferred** command.

ap name *ap-name* **mesh parent preferred** *mac-address*

Syntax Description

ap-name	Name of the mesh AP.
mac-address	Radio MAC address of the parent AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to preferred parent for a mesh AP:

```
Device # ap name mymeshap mesh parent preferred dc:5f:be:f5:fd:84
```

ap name mesh security psk provisioning delete

To delete PSK-provisioned key from a mesh AP, use the **ap name mesh security psk provisioning delete** command.

ap name *ap-name* **mesh security psk provisioning delete**

Syntax Description

ap-name	Name of the mesh AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to delete PSK-provisioned key from a mesh AP:

```
Device# ap name mymeshap mesh security psk provisioning delete
```

ap name mesh vlan-trunking native

To configure native VLAN for mesh AP, use the **ap name mesh vlan-trunking native** command.

ap name *name-of-rap* **vlan-trunking native** *vlan-id*

Syntax Description

name-of-rap	Name of the root access point.
vlan-id	VLAN ID.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to configure native VLAN for mesh AP:

```
Device # ap name mesh vlan-trunking native 12
```

ap name monitor-mode dot11b

To configures 802.11b scanning channels for a monitor-mode access point, use the **ap name monitor-mode dot11b** command.

ap name *ap-name* **monitor-mode dot11b fast-channel** *channel1* [*channel2*] [*channel3*] [*channel4*]

Syntax Description

ap-name	Name of the access point.
fast-channel	Specifies the 2.4 GHz band scanning channel (or channels) for a monitor-mode access point.
channel1	Scanning channel1.
channel2	(Optional) Scanning channel2.
channel3	(Optional) Scanning channel3.
channel4	(Optional) Scanning channel4.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to configure an access point in tracking optimized mode to listen to channels 1, 6, and 11:

```
Device# ap name AP01 monitor-mode dot11b fast-channel 1 6 11
```

ap name name

To modify the name of a Cisco lightweight access point, use the **ap name name** command.

ap name *ap-name* **name** *new-name*

Syntax Description

ap-name	Current Cisco lightweight access point name.
new-name	Desired Cisco lightweight access point name.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to modify the name of access point AP1 to AP2:

```
Device# ap name AP1 name AP2
```

ap name priority

To configure the priority of an access point, use the **ap name priority** command.

ap name *ap-name* **priority** *priority-value*

Syntax Description

priority-value	Priority value for the AP. Valid range is 1 to 4.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure the priority for an access point:

```
Device# ap name my-ap priority 1
```

ap name reset

To reset a specific Cisco lightweight access point, use the **ap name reset** command.

ap name *ap-name* **reset**

Syntax Description

ap-name	Name of the Cisco lightweight access point.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to reset a Cisco lightweight access point named AP2:

```
Device# ap name AP2 reset
```

ap name reset-button

To configure the Reset button for an access point, use the **ap name reset-button** command.

ap name *ap-name* **reset-button**

Syntax Description

ap-name	Name of the Cisco lightweight access point.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to enable the Reset button for access point AP03:

```
Device# ap name AP03 reset-button
```

ap name role

To configure the role of operation for an AP, use the **ap name role** command.

ap name *ap-name* **role** {**mesh-ap** | **root-ap**}

Syntax Description

ap-name	Name of the AP.
mesh-ap	Configures mesh AP role for the AP.
root-ap	Configures root AP role for the AP.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure the role of operation as mesh AP for an AP:

```
Device# ap name mymeshap role mesh-ap
```

ap name slot

To configure various slot parameters, use the **ap name slot** command. To disable a slot on a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **slot** *slot-number* {**channel** {**global** | **number** *channel-number* | **width** *channel-width*} | **rtsthreshold** *value* | **shutdown** | **txpower** {**global***channel-level*}}
ap name *ap-name* **no slot** {**0** | **1** | **2** | **3**} **shutdown**

Syntax Description

ap-name	Name of the Cisco access point.
slot-number	Slot downlink radio to which the channel is assigned. You can specify the following slot numbers: • **0**—Enables slot number 0 on a Cisco lightweight access point. • **1**—Enables slot number 1 on a Cisco lightweight access point. • **2**—Enables slot number 2 on a Cisco lightweight access point. • **3**—Enables slot number 3 on a Cisco lightweight access point.
channel	Specifies the channel for the slot.
global	Specifies channel global properties for the slot.
number	Specifies the channel number for the slot.
channel-number	Channel number from 1 to 169.
width	Specifies the channel width for the slot.
channel-width	Channel width from 20 to 40.
rtsthreshold	Specifies the RTS/CTS threshold for an access point.
value	RTS/CTS threshold value from 0 to 65535.
shutdown	Shuts down the slot.
txpower	Specifies Tx power for the slot.
global	Specifies auto-RF for the slot.
channel-level	Transmit power level for the slot from 1 to 7.

Command Default

None

Command History

Release	Modification
	This command was introduced.

This example shows how to enable slot 3 for the access point abc:

```
Device# ap name abc slot 3
```

This example shows how to configure RTS for the access point abc:

```
Device# ap name abc slot 3 rtsthreshold 54
```

ap name static-ip

ap name *Cisco-ap-name***static-ipip-address** { **A.B.C.Dnetmask***netmask* | **X:X:X:X::Xprefix***prefix-length* } **gateway***gateway*

Syntax Description

ap name	Name of the Cisco access point.
static-ip	Sets the Cisco AP static IP address configuration.
ip-address	Adds the Cisco AP static IP address.
A.B.C.D	Indicates the IPv4 address.
X:X:X:X::X	Indicates the IPv6 address.
netmask*netmask*	Specifies the Cisco AP static-IP netmask.
prefix*prefix-length*	Specifies the Cisco AP static-IP prefix length.
gateway*gateway*	Specifies the Cisco AP static-IP gateway.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

The following example shows how to enable or disable static-ip for an access point:

```
Device#ap name cisco-ap-name static-ip ip-address 9.9.9.2 netmask 255.0.0.0 gateway 9.9.9.2
```

ap name static-ip

To configure lightweight access point static IP settings, use the **ap name static-ip** command. To disable the Cisco lightweight access point static IP address, use the **no** form of this command.

ap name *ap-name* **static-ip** {**domain** *domain-name* | **ip-address** *ip-address* **netmask** *netmask* **gateway** *gateway* | **nameserver** *ip-address*}
ap name *ap-name* **no static-ip**

Syntax Description

ap-name	Name of the access point.
domain	Specifies the Cisco access point domain name.
domain-name	Domain to which a specific access point belongs.
ip-address	Specifies the Cisco access point static IP address.
ip-address	Cisco access point static IP address.
netmask	Specifies the Cisco access point static IP netmask.
netmask	Cisco access point static IP netmask.
gateway	Specifies the Cisco access point gateway.
gateway	IP address of the Cisco access point gateway.
nameserver	Specifies a DNS server so that a specific access point can discover the device using DNS resolution.
ip-address	IP address of the DNS server.

Command Default

None

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

An access point cannot discover the device using Domain Name System (DNS) resolution if a static IP address is configured for the access point unless you specify a DNS server and the domain to which the access point belongs.

This example shows how to configure an access point static IP address:

```
Device# ap name AP2 static-ip ip-address 192.0.2.54 netmask 255.255.255.0 gateway 192.0.2.1
```

ap name shutdown

To disable a Cisco lightweight access point, use the **ap name shutdown** command. To enable a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **shutdown**
ap name *ap-name* **no shutdown**

Syntax Description

ap-name	Name of the Cisco lightweight access point.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example how to disable a specific Cisco lightweight access point:

```
Device# ap name AP2 shutdown
```

ap name urwb mode coordinator radio-off

To configure an AP as a URWB coordinator and to configure the radio-off mode, use the **ap name** *ap-name* **urwb mode coordinator radio-off** {**fixed** | **mobility**}

ap name *ap-name* **urwb mode coordinator radio-off** { **fixed** | **mobility** }

Syntax Description

ap-name	Specifies the name of the Cisco AP.
fixed	Configures the coordinator radio-off fixed mode.
mobility	Configures the coordinator radio-off fixed mode.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure an AP as a URWB coordinator and to configure the radio-off mode:

```
Device# ap name ap-name urwb mode coordinator radio-off fixed
```

ap name usb-module

To enable the USB port on the access point (AP), use the **ap name** *ap-name* **usb-module**. To disable the feature, use the **no** form of this command.

ap name *ap-name* **usb-module**

no ap name *ap-name* **usb-module**

Syntax Description

usb-module	Enables the USB port on the AP.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows you how to enable the USB port on the AP:

```
Device# ap name ap-name usb-module
```

ap name usb-module override

To enable access point (AP) USB override, use the **ap name** *ap-name* **usb-module override** command. To disable the feature, use the **no** form of this command.

ap name *ap-name* **usb-module override**

no ap name *ap-name* **usb-module override**

Syntax Description

usb-module override	Overrides USB status of the AP profile and considers the local AP configuration. You can configure the USB status for an AP only if you enable USB override for it.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows you how to override USB status of the AP:

```
Device# ap name ap-name usb-module override
```

ap name vlan-tag

To configure VLAN tagging for a nonbridge AP, use the **ap name vlan-tag** command.

ap name *ap-name* **vlan-tag** *vlan-id*

Syntax Description

ap-name	Access point name.
vlan-id	VLAN identifier.

Command Default

VLAN tagging is not enabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure VLAN tagging for a nonbridge AP:

```
Device# ap name AP1 vlan-tag 12
```

ap name write tag-config

To write the existing configuration to an AP, use the **ap name write tag-config** command in privileged EXEC mode

ap name *ap-name***write tag-config**

Syntax Description

ap-name	Name of the access point.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Usage Guidelines

Use this command to write the existing configuration to an AP.

Example

This example shows how to write the existing configuration to an AP:

```
Device# ap name AP40CE.2485.D594 write tag-config
```

ap name-regex

To configure filter based on AP name regular expression to match with, use the **ap name-regex** command.

ap name-regex *regular-expression*

Syntax Description

regular-expression	Enter the filter string.

Command Default

None

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure filter based on AP name regular expression match with:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap filter name filter--name
Device(config-ap-filter)# ap name-regex regular-expression-string
```

ap profile

To configure access point profile, use the **ap profile** command.

ap profile *profile-name*

Syntax Description

profile-name	Enter the name of the AP profile.

Command Default

By default, the AP profile name is default-ap-profile.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure AP profile name:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap profile my-ap-profile
```

ap remote-lan profile-name

To configure remote LAN profile, use the **ap remote-lan profile-name** command.

ap remote-lan profile-name *remote-lan-profile-name rlan-id*

Syntax Description

remote-lan-profile-name	Is the remote LAN profile name. Range is from 1 to 32 alphanumeric characters.
rlan-id	Is the remote LAN identifier. Range is from 1 to 128. **Note** You can create a maximum of 128 RLANs. You cannot use the *rlan-id* of an existing RLAN while creating another RLAN. Both RLAN and WLAN profile cannot have the same names. Similarly, RLAN and WLAN policy profile cannot have the same names.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to configure remote LAN profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap remote-lan profile-name rlan_profile_name 3
```

ap remote-lan shutdown

To enable or disable all RLANs, use the **ap remote-lan shutdown** command.

ap remote-lan shutdown

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

This example shows how to enable or disable all RLANs:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# [no] ap remote-lan shutdown
Device(config)# end
```

ap remote-lan-policy policy-name

To configure RLAN policy profile, use the **ap remote-lan-policy policy-name** command.

ap remote-lan-policy policy-name *profile-name*

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

This example shows how to configure RLAN policy profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap remote-lan-policy policy-name rlan_policy_prof_name
```

ap tag persistency enable

To configure AP tag persistency settings, use the **ap tag persistency enable** command, in the global configuration mode. To disable the AP tag persistency settings, use the **no** form of this command.

ap tag persistency enable

no ap tag persistency enable

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to enable tag persistency for an AP:

```
Device(config)# ap tag persistency enable
```

ap upgrade staggered

To configure staggered AP upgrade parameters, use the **ap upgrade staggered** command

ap upgrade staggered { **1** | **2** | **5** | **15** | **25** | **client-deauth** | **client-steering** | **iteration** | **one-shot** | **serial** }

Syntax Description

Keywords and Variables	Description
1	1% of APs per iteration
5	5% of APs per iteration
15	15% of APs per iteration
25	25% of APs per iteration
client-deauth	Enable or disable client de-authentication
client-steering	Enable or disable client steering
iteration	Configure iteration accounting parameters
one-shot	Upgrade all APs in a single iteration
serial	Serialize AP upgrade, one AP per iteration.

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	The **serial** and **1** keywords were introduced.

ap upgrade staggered iteration timeout

To configure the maximum time allowed per iteration during an access point (AP) upgrade, use the **ap upgrade staggered iteration timeout** command.

ap upgrade staggered iteration timeout *timeout-duration*

Syntax Description

timeout-duration	Time allowed per iteration, in minutes. Valid values range from 9 to 60.

Command Default

Iteration timeout is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Usage Guidelines

If an AP upgrade iteration is not completed during the specified duration, the error action that is set using the **ap upgrade staggered iteration error** command is taken.

Examples

The following example shows how to configure the maximum time allowed per iteration:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap upgrade staggered iteration timeout 40
```

ap tag-source-priority

To configure ap tag source priority, use the **ap tag-source-priority** command.

ap tag-source-priority *source-priority* **source** { **filter** | **ap** }

Syntax Description

source-priority	Enter the ap tag source priority. Valid range is 2 to 3.
source	Specifiy the source for which priority is been set.
filter	AP filter as tag source.
ap	AP as tag source.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to set AP as a tag source:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap tag-source-priority priority-value source ap
```

ap tag-sources revalidate

To revalidate the access point tag sources, use the **ap tag-sources revalidate** command.

ap tag-sources revalidate

Syntax Description

tag-sources	Tag Sources.
revalidate	Revalidate access point tag sources.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to revalidate the access point tag sources:

```
Device# ap tag-sources revalidate
```

ap vlan-tag

To configure VLAN tagging for all nonbridge APs, use the **ap vlan-tag** command.

ap vlan-tag *vlan-id*

Syntax Description

vlan-id	VLAN identifier.

Command Default

VLAN tagging is not enabled for nonbridge APs.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure VLAN tagging for all non-bridge APs:

```
Device# ap vlan-tag 1000
```

assisted-roaming

To configure assisted roaming using 802.11k on a WLAN, use the **assisted-roaming** command. To disable assisted roaming, use the **no** form of this command.

assisted-roaming {**dual-list** | **neighbor-list** | **prediction**}

no assisted-roaming {**dual-list** | **neighbor-list** | **prediction**}

Syntax Description

dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
neighbor-list	Configures an 802.11k neighbor list for a WLAN.
prediction	Configures assisted roaming optimization prediction for a WLAN.

Command Default

Neighbor list and dual band support are enabled by default. The default is the band that the client is currently associated with.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

When you enable the assisted roaming prediction list, a warning appears and load balancing is disabled for the WLAN if load balancing is already enabled on the WLAN. To make changes to the WLAN, the WLAN must be in disabled state.

Example

The following example shows how to configure a 802.11k neighbor list on a WLAN:

```
Device(config-wlan)#assisted-roaming neighbor-list
```

The following example shows the warning message when load balancing is enabled on a WLAN. Load balancing must be disabled if it is already enabled when configuring assisted roaming:

```
Device(config)#wlan test-prediction 2 test-prediction
Device(config-wlan)#client vlan 43
Device(config-wlan)#no security wpa
Device(config-wlan)#load-balance
Device(config-wlan)#assisted-roaming prediction
WARNING: Enabling neighbor list prediction optimization may slow association and impact
VOICE client perform.
Are you sure you want to continue? (y/n)[y]: y
% Request aborted - Must first disable Load Balancing before enabling Assisted Roaming
Prediction Optimization on this WLAN.
```

attribute type

To define an attribute type that is to be added to an attribute list locally on a device, use the **attribute type** command in global configuration mode. To remove the attribute type from the list, use the **no** form of this command.

attribute type *name value* { [**service** *service*] | [**protocol** *protocol*] | [*tag*] }

Syntax Description

Keywords and Variables	Description
name	The Cisco IOS authentication, authorization, and accounting (AAA) internal name of the IETF RADIUS attribute to be added to the attribute list. For a list of supported attributes, use the CLI help option (?) on your platform.
value	A string, binary, or IPv4 address value. This is the RADIUS attribute that is being defined in Cisco IOS AAA format. A string added to the attribute value must be inside quotation marks. For example, if the value is interface-config and the string is “ip unnumbered FastEthernet0,” you would write interface-config “ip unnumbered FastEthernet0”.
service *service*	(Optional) Specifies the Access method, which is typically PPP.
protocol *protocol*	(Optional) Specifies the type of protocol, which can be ATM, IP, or virtual private Dial-up network (VPDN).
tag	(Optional) A means of grouping attributes that refer to the same VPDN tunnel.

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE 17.12.1	This command was introduced in a release earlier than Cisco IOS XE 17.12.1.

Usage Guidelines

Attributes are added to the attribute list each time a new attribute type is defined. Attributes are not validated at configuration. The AAA subsystem recognizes the expected attribute format defined by the services in a definition file. However, it cannot validate the attribute information itself. This validation is done by a service when it first uses the attribute. This validation is applicable to both RADIUS and TACACS+ AAA servers. Thus, if you are not familiar with configuring a AAA server, test your attribute list on a test device with the service that will be using the list before configuring and using it in a production environment.

avg-packet-size packetsize

To configure the wireless media-stream's average packet size, use the **avg-packet-size** command.

avg-packet-size *packetsize-value*

Syntax Description

packetsize-value	Average Packet Size. Valid range is 100 to 1500.

Command Default

None

Command Modes

media-stream

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to configure wireless media-stream's average packet size:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group doc-grp 224.0.0.0 224.0.0.223
Device(config-media-stream)# avg-packet-size500
```

band-select client

To configure the client threshold minimum dB for the selected band, use the **band-select client** command. To reset the client threshold minimum dB for the selected band, use the **no** form of this command.

band-select client { **mid-rssi** | **rssi** } *dBm value*

Syntax Description

mid-rssi	Minimum dBm of a client RSSI start to respond to probe
rssi	Minimum dBm of a client RSSI to respond to probe
dBm value	Minimum dBm of a client RSSI to respond to probe. Valid range is between –90 and –20 dBm.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

This command is enabled only for 2.4-GHz band.

This example shows how to set the client threshold to minimum dB for a selected band.

```
Device(config-rf-profile)#band-select client rssi -50
```

band-select cycle

To configure the band cycle parameters, use the **band-select cycle** command. To reset the threshold value, use the **no** form of this command.

band-select cycle { **count** | **threshold** } *value*

Syntax Description

count	Sets the Band Select probe cycle count.
value	Maximum number of cycles not responding. The range is between 1 and 10.
threshold	Sets the time threshold for a new scanning cycle.
value	Set the threshold value in milliseconds. The valid is between 1and 1000.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to configure the probe cycle count in an RF profile for a selected band.

```
Device(config-rf-profile)#band-select cycle count 5
```

band-select expire

To configure the expiry time for the RF profile for the selected band, use the **band-select expire** command. To reset the value, use the **no** form of this command.

band-select expire { **dual-band** | **suppression** } *value*
no band-select expire { **dual-band** | **suppression** }

Syntax Description

dual-band	Configures the RF Profile Band Select Expire Dual Band.
value	Setting the time to expire for pruning previously known dual-band clients. The range is between 10 and 300.
suppression	Configures the RF Profile Band Select Expire Suppression.
value	Setting the time to expire for pruning previously known 802.11b/g clients. The range is between 10 and 200.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to configure the time to expire for a dual-band of an RF profile in a selected band.

```
Device(config-rf-profile)#band-select expire dual-band 15
```

band-select probe-response

To configure the probe responses to the clients for a selected band, use the **band-select probe-response** command. To disable the probe-response, use the **no** form of this command.

band-select probe-response

Syntax Description

probe-response	Probe responses to clients.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to enable probe response to the clients.

```
Device(config-rf-profile)#band-select probe-response
```

banner text

To configure the message in a banner, use the **banner text** command. Use the **no** form of this command to remove the message.

banner text *text*

no banner text

Syntax Description

text	Text message to be displayed.

Command Default

None

Command Modes

Parameter map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a message in a banner:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type webauth global
Device(config-params-parameter-map)# banner text #Hêllö#
```

bss-transition

To configure BSS transition per WLAN, use the **bss-transition** command.

bss-transition [**disassociation-imminent**]

Syntax Description

disassociation-imminent	BSS transition disassociation Imminent per WLAN.

Command Default

None

Command Modes

config-wlan

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to configure BSS transition per WLAN:

```
Device(config-wlan)# bss-transition
```

call-snoop

call-snoop

no call-snoop

Syntax Description

This command has no keywords or arguments.

Command Default

VoIP snooping is disabled by default.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. The WLAN on which call snooping is configured must be configured with Platinum QoS. You must disable quality of service before using this command.

Example

This example shows how to enable VoIP on a WLAN:

```
Device# configure terminal
Device(config)# wireless profile policy policy-name
Device(config-wireless-policy)#service-policy input platinum-up
Device(config-wireless-policy)#service-policy output platinum
Device(config-wireless-policy)#call-snoop
Device(config-wireless-policy)#no shutdown
Device(config-wireless-policy)#end
```

captive-bypass-portal

To configure captive bypassing, use the **captive-bypass-portal** command.

captive-bypass-portal

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

This example shows how to configure captive bypassing for WLAN in LWA and CWA:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type webauth WLAN1_MAP
Device(config)# captive-bypass-portal
Device(config)# wlan WLAN1_NAME 4 WLAN1_NAME
Device(config-wlan)# security web-auth
Device(config-wlan)# security web-auth parameter-map WLAN1_MAP
Device(config-wlan)# end
```

capwap-discovery

To set CAPWAP discovery response method as to whether a capwap-discovery response contains the public or private IP of the controller, use the **capwap-discovery** command.

capwap-discovery { **private** | **public** }

Syntax Description

private	Includes private IP in CAPWAP discovery response.
public	Includes public IP in CAPWAP discovery response.

Command Default

None

Command Modes

Management Interface Configuration(config-mgmt-interface)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Example

The following example shows how to configure a CAPWAP discovery response method:

```
Device# configure terminal
Device(config)# wireless management interface Vlan1
Device(config-mgmt-interface)# capwap-discovery public
```

capwap aggregation

To enable CAPWAP message aggregation in the controller, use the **capwap aggregation** command. To disable the functionality, use the **no** form of this command.

capwap aggregation

no capwap aggregation

Syntax Description

This command has no keywords and arguments.

Command Default

The CAPWAP Message Aggregation feature is disabled by default.

Command Modes

config-ap-profile

Command History

Release	Modification
Cisco IOS XE 17.14.1	This command was introduced.

Usage Guidelines

The CAPWAP Message Aggregation feature aggregates the CAPWAP control messages to be sent to APs. When APs are busy processing packets, the messages to be sent to the APs are stored in the controller. When you enable the feature, if the last message type in the queue and the current message type are the same, the CAPWAP messages are aggregated and capped at Maximum Transmission Unit (MTU). This improves the performance of the system.

Examples

This example shows how to enable CAPWAP message aggregation in the controller:

```
Device# configure terminal
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# capwap aggregation
Device(config-ap-profile)# end
```

capwap backup

To configure a primary or secondary backup device for all access points that are joined to a specific device, use the **capwap backup** command.

capwap backup {**primary** *primary-controller-name primary-controller-ip-address* | **secondary** *secondary-controller-name secondary-controller-ip-address*}

Syntax Description

primary	Specifies the primary backup device.
primary-controller-name	Primary backup device name.
primary-controller-ip-address	Primary backup device IP address.
secondary	Specifies the secondary backup device.
secondary-controller-name	Secondary backup device name.
secondary-controller-ip-address	Secondary backup device IP address.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

This example shows how to configure a primary backup device for all access points that are joined to a specific device:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# capwap backup primary controller1 192.0.2.51
```

This example shows how to configure a secondary backup device for all access points that are joined to a specific device:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# capwap backup secondary controller1 192.0.2.52
```

cco-password (image-download-mode cco)

To configure the CCO server password for image dowload, use the **cco-password** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`cco-password {0| 8}`<*Enter password*> <*Re-enter password*>

`no cco-password {0 | 8}`<*Enter password*> <*Re-enter password*>

Syntax Description

0	Specifies that an unencrypted password will follow.
8	Specifies that an AES encrypted password will follow.
password	Specifies the CCO server password.
re-enter password	Indicates that the user must re-enter the CCO server password.

Command Default

None

Command Modes

Wireless image download profile CCO configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode cco
Device(config-wireless-image-download-profile-cco)# cco-password 0 xxxxxxxx
```

cco-username (image-download-mode cco)

To configure the CCO username for image download, use the **cco-username**command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`cco-username` *Username*

`no cco-username` *Username*

Syntax Description

username	Specifies the CCO username.

Command Default

None

Command Modes

Wireless image download profile CCO configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode cco
Device(config-wireless-image-download-profile-cco)# cco-username cco-server-username
```

cco-version (image-download-mode cco)

To configure and download the latest or the suggested version of the software image from CCO, use the **cco-version** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
cco-version {latest| suggested}

no cco-version {latest| suggested}
```

Syntax Description

latest	Configures and downloads the **latest** version of software image from CCO.
suggested	Configures and downloads the **suggested** version of software image from CCO. By default **suggested** version is selected.

Command Default

None

Command Modes

Wireless image download profile CCO configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode cco
Device(config-wireless-image-download-profile-cco)# cco-version suggested
```

cco-auto-check (image-download-mode cco)

To enable automatic check of the new software version on CCO, use the **cco-auto-check** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
cco-auto-check

no  cco-auto-check
```

Syntax Description

cco-auto-check	Enables the automatic check of the new software version at CCO every 30 days. This is applicable to Image Upgrade or Predownload only. By default the command is enabled.

Command Default

None

Command Modes

Wireless image download profile CCO configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode cco
Device(config-wireless-image-download-profile-cco)# cco-auto-check
```

ccx aironet-iesupport

To configure the support of Aironet IE CCX option, use the following command:

ccx aironet-iesupport

Syntax Description

ccx	Configures the Cisco Client Extension options.
aironet-iesupport	Sets the support of Aironet IE on WLAN.

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to configure Aironet IE support:

```
Device(config-wlan)#ccx aironet-iesupport
```

cdp

To enable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point under the AP profile, use the **cdp** command. To disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **no** form of this command.

```
ap profile default-ap-profile

cdp
no  cdp
```

Command Default

Disabled on all access points.

Command Modes

AP profile mode (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **no cdp** command disables CDP on all access points that are joined to the device and all access points that join in the future. CDP remains disabled on both current and future access points even after the device or access point reboots. To enable CDP, enter the **cdp** command.

Note CDP over Ethernet/radio interfaces is available only when CDP is enabled.

This example shows how to enable CDP on all access points:

```
Device(config)# ap profile default-ap-profile


Device(config-ap-profile)# cdp
```

central association

To enable central association for locally switched clients, use the **central association** command.

central association

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to enable enable central association for locally switched clients:

```
Device(config-wireless-policy)# central association
```

central authentication

To enable or disable central authentication, use the **central authentication** command.

central authentication

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to enable central authentication:

```
Device(config-wireless-policy)# central authentication
```

central dhcp

To enable central dhcp for locally switched clients, use the **central dhcp** command.

central dhcp

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to enable central dhcp for locally switched clients:

```
Device(config-wireless-policy)# central dhcp
```

central-webauth

To configure central-webauth for an ACL, use the **central-webauth** command.

central-webauth

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to configure central-webauth for an ACL:

```
Device(config-wireless-policy)# central-webauth
```

channel zero-wait-dfs

To enable the Zero Wait Dynamic Frequency Selection feature on the 802.11a radio frequency (RF) profile of 5-GHz devices, use the **channel zero-wait-dfs** command. To disable Zero Wait DFS feature, use the **no** form of this command.

channel zero-wait-dfs

no channel zero-wait-dfs

Syntax Description

This command has no arguments or keywords.

Command Default

The Zero Wait Dynamic Frequency Selection feature is not enabled.

Command Modes

RF profile configuration (config-rf-profile)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Usage Guidelines

This command is applicable only on 5-GHz devices.

Examples

The following example shows how to enable the Zero Wait Dynamic Frequency Selection feature for the 802.11a RF profile of 5-GHz devices:

```
Device# configure terminal
Device(config)# ap dot11 5ghz rf-profile test-dfs
Device(config-rf-profile)# channel zero-wait-dfs
```

chassis redundancy ha-interface shutdown

To configure [no] shutdown of ha_port interface to support RMA, use the **chassis redundancy ha-interface shutdown** command.

Syntax Description

Device# chassis redundancy ha-interface shutdown	Redundancy interface shutdown.

Command Default:

[no] chassis redundancy ha-interface shutdown

Command Modes

This is an exec CLI

Command History

Release	Modification
Cisco IOS XE 17.12	This command was introduced in the release Cisco IOS XE 17.12.

Examples

The following example shows how to configure [no] shutdown of ha_port interface to support RMA:

```
Device# chassis redundancy ha-interface shutdown
```

chassis redundancy keep-alive

To configure peer keep-alive retries and time interval before claiming peer is down, use the **chassis redundancy keep-alive** command.

chassis redundancy keep-alive { **retries** *retries* | **timer** *timer* }

Syntax Description

retries	Chassis peer keep-alive retries before claiming peer is down. Valid values range from 5 to 10, enter 5 for default.
timer	Chassis peer keep-alive time interval in multiple of 100 ms. Valid values range from 1 to 10, enter 1 for default.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure peer keep-alive retries and time interval:

```
Device# chassis redundancy keep-alive retries 6
Device# chassis redundancy keep-alive timer 6
```

chassis renumber

To renumber the local chassis id assignment, use the **chassis renumber** command.

chassis *chassis-num* **renumber** *renumber-id*

Syntax Description

chassis-num	Chassis number.
renumber-id	Local chassis id.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to renumber the local chassis id assignment:

```
Device# chassis 1 renumber 1
```

chassis transport

To enable or disable chassis transport, use the **chassis transport** command.

chassis *chassis-num* **transport** {**enable** | **disable**}

Syntax Description

chassis-num	Chassis number.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable chassis transport:

```
Device# chassis 1 transport enable
```

class

To define a traffic classification match criteria for the specified class-map name, use the **class** command in policy-map configuration mode. Use the **no** form of this command to delete an existing class map.

class {*class-map-name* | **class-default**}
no class {*class-map-name* | **class-default**}

Syntax Description

class-map-name	The class map name.
class-default	Refers to a system default class that matches unclassified packets.

Command Default

No policy map class-maps are defined.

Command Modes

Policy-map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Before using the **class** command, you must use the **policy-map** global configuration command to identify the policy map and enter policy-map configuration mode. After specifying a policy map, you can configure a policy for new classes or modify a policy for any existing classes in that policy map. You attach the policy map to a port by using the **service-policy** interface configuration command.

After entering the **class** command, you enter the policy-map class configuration mode. These configuration commands are available:

- **exit**—Exits the policy-map class configuration mode and returns to policy-map configuration mode.
- **no**—Returns a command to its default setting.
- **police**—Defines a policer or aggregate policer for the classified traffic. The policer specifies the bandwidth limitations and the action to take when the limits are exceeded. For more information about this command, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com.
- **set**—Specifies a value to be assigned to the classified traffic. For more information, see set, on page 547

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

The **class** command performs the same function as the **class-map** global configuration command. Use the **class** command when a new classification, which is not shared with any other ports, is needed. Use the **class-map** command when the map is shared among many ports.

You can configure a default class by using the **class class-default** policy-map configuration command. Unclassified traffic (traffic that does not meet the match criteria specified in the traffic classes) is treated as default traffic.

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress direction, it matches all the incoming traffic defined in class1, sets the IP Differentiated Services Code Point (DSCP) to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic exceeding the profile is marked down to a DSCP value gotten from the policed-DSCP map and then sent.

```
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# police 1000000 20000 conform-action
Device(config-pmap-c)# police 1000000 20000 exceed-action
Device(config-pmap-c)# exit
```

This example shows how to configure a default traffic class to a policy map. It also shows how the default traffic class is automatically placed at the end of policy-map pm3 even though **class-default** was configured first:

```
Device# configure terminal
Device(config)# class-map cm-3
Device(config-cmap)# match ip dscp 30
Device(config-cmap)# exit

Device(config)# class-map cm-4
Device(config-cmap)# match ip dscp 40
Device(config-cmap)# exit

Device(config)# policy-map pm3
Device(config-pmap)# class class-default
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# exit

Device(config-pmap)# class cm-3
Device(config-pmap-c)# set dscp 4
Device(config-pmap-c)# exit

Device(config-pmap)# class cm-4
Device(config-pmap-c)# set precedence 5
Device(config-pmap-c)# exit
Device(config-pmap)# exit

Device# show policy-map pm3
Policy Map pm3
  Class cm-3
    set dscp 4
  Class cm-4
    set precedence 5
  Class class-default
    set dscp af11
```

classify

To classify a rule for rogue devices, use the **classify** command.

classify {**friendly** | **malicious** | **delete**}

Syntax Description

friendly	Classifies devices matching this rule as friendly.
malicious	Classifies devices matching this rule as malicious.
delete	Devices matching this rule are ignored.

Command Default

None

Command Modes

config-rule

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to classify rogue devices as friendly:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless wps rogue rule my-rogue-rule priority 3
Device(config-rule)# classify friendly
```

class-map

To create a class map to be used for matching packets to the class whose name you specify and to enter class-map configuration mode, use the **class-map** command in global configuration mode. Use the **no** form of this command to delete an existing class map and to return to global or policy map configuration mode.

class-map [**match-any***type*][**match-all***type*] *class-map-name*
no class-map [**match-any***type*][**match-all***type*] *class-map-name*

Syntax Description

match-any	(Optional) Performs a logical-OR of the matching statements under this class map. One or more criteria must be matched.
match-all	(Optional) Performs a logical-AND all matching statements under this classmap.
type	(Optional) Configures the CPL class map.
class-map-name	The class map name.

Command Default

No class maps are defined.

Command Modes

Global configuration

Policy map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use this command to specify the name of the class for which you want to create or modify class-map match criteria and to enter class-map configuration mode.

The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally named service policy applied on a per-port basis.

After you are in quality of service (QoS) class-map configuration mode, these configuration commands are available:

- **description**—Describes the class map (up to 200 characters). The **show class-map** privileged EXEC command displays the description and the name of the class map.
- **exit**—Exits from QoS class-map configuration mode.
- **match**—Configures classification criteria.
- **no**—Removes a match statement from a class map.

If you enter the **match-any** keyword, you can only use it to specify an extended named access control list (ACL) with the **match access-group** class-map configuration command.

To define packet classification on a physical-port basis, only one **match** command per class map is supported.

The ACL can have multiple access control entries (ACEs).

Examples

This example shows how to configure the class map called class1 with one match criterion, which is an access list called 103:

```
Device(config)# access-list 103 permit ip any any dscp 10
Device(config)# class-map class1
Device(config-cmap)# match access-group 103
Device(config-cmap)# exit
```

This example shows how to delete the class map class1:

```
Device(config)# no class-map class1
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

clear aaa counters servers radius

To clear all AAA server radius or specific server radius, use the **clear aaa counters servers radius** {*server-id* | **all**}

clear aaa counters servers radius { *server-id* | **all** }

Syntax Description

server-id	Specifies the server IDs of the AAA servers that are displayed by the **show** command.
all	Specifies all the AAA server IDs.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to clear all AAA server radius:

```
Device# clear aaa counters servers radius all
```

clear chassis redundancy

To clear high-availability (HA) configuration, use the **clear chassis redundancy** command.

clear chassis redundancy

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to clear HA configuration:

```
Device# clear chassis redundancy
```

clear mdns-sd cache

To clear mDNS cache details, use the **clear mdns-sd cache** command.

clear mdns-sd cache { **ap-mac** *mac-address (H.H.H)* | **client-mac** *client-mac-address (H.H.H)* | **detail** | **glan-id** *<1 - 5>* | **location-group** *<0 - 4096>* | **mdns-ap** *mdns-ap mac address (H.H.H)* | **rlan-id** *<1 - 128>* | **udn** { *<1 - 4294967295>* | **shared** } | **wired** | **wlan-id** *<0 - 4096>* }

Syntax Description

ap-mac*mac-address (H.H.H)*	Clears the AP Ethernet MAC address.
client-mac*client-mac-address (H.H.H)*	Clears the client MAC address.
detail	Clears the cache details.
glan-id *<1 - 5>*	Clears the GLAN ID. The value range is from 1 to 5.
location-group *<0 - 4096>*	Clears the location group. The value range is from 0 to 4096.
mdns-ap *mdns-ap mac address (H.H.H)*	Clears cached services from mDNS AP.
rlan-id *<1 - 128>*	Clears the RLAN ID. The value range is from 1 - 128.
udn *<1 - 4294967295>*	Clears the UDN ID. The value range is from 1 to 4294967295.
shared	Clears the UDN shared services.
wired	Clears the mDNS services from wired clients.
wlan-id *<0 - 4096>*	Clears the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to clear the mDNS cache details:

```
Device# clear mdns-sd cache
```

clear mdns-sd statistics

To clear mDNS statistics, use the **clear mdns-sd statistics** command.

clear mdns-sd statistics { **debug** | **glan-id** *<1 - 5>* | **rlan-id** *<1 - 128>* **wired** | **wlan-id** *<1 - 4096>* }

Syntax Description

debug	Clears the mDNS debug statistics.
glan-id*<1 - 5>*	Clears the GLAN ID. The value range is from 1 to 5.
rlan-id*<1 - 128>*	Clears the RLAN ID. The value range is from 1 to 128.
wired	Clears the mDNS wired statistics.
wlan-id*<1 - 4096>*	Clears the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to clear the mDNS statistics:

```
Device# clear mdns-sd statistics
```

clear platform condition all

To clear all conditional debug and packet-trace configuration and data, use the **clear platform condition all** command.

clear platform condition all

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to clear all conditional debug and packet-trace configuration and data:

```
Device# clear platform condition all
```

clear radius statistics

To clear the radius server information statistics, use the **clear radius statistics** command.

clear radius statistics

Syntax Description

There are no arguments for this command.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to clear the radius server information statistics:

```
Device# clear radius statistics
```

clear wireless wps rogue ap

To clear all rogue APs or rogue APs with specific MAC addresses, use the **clear wireless wps rogue ap** command.

clear wireless wps rogue ap { **all** | **mac-address** <*MAC Address*> }

Syntax Description

all	Clears all the rogue APs.
mac-address <*MAC Address*>	Clears the rogue APs with specific MAC addresses.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to clear all rogue APs or rogue APs with specific MAC addresses:

```
Device# clear wireless wps rogue ap all
Device# clear wireless wps rogue ap mac-address 10.10.1
```

clear wireless wps rogue client

To clear all rogue clients or client with specific MAC addresses, use the **clear wireless wps rogue client** command.

clear wireless wps rogue client { **all** | **mac-address** <*MAC Address*> }

Syntax Description

all	Clears all the rogue clients.
mac-address <*MAC Address*>	Clears the rogue clients with specific MAC addresses.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to clear all rogue clients or rogue clients with specific MAC addresses:

```
Device# clear wireless wps rogue client all
Device# clear wireless wps rogue client mac-address 10.10.1
```

clear wireless wps rogue stats

To clear rogue statistics, use the **clear wireless wps rogue stats** command.

clear wireless wps rogue stats

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to clear rogue statistics:

```
Device# clear wireless wps rogue stats
```

client association limit

To configure the maximum number of client connections on a WLAN, use the **client association limit** command. To disable clients association limit on the WLAN, use the **no** form of this command.

client association limit {*association-limit*}
no client association limit {*association-limit*}

Syntax Description

association-limit	Number of client connections to be accepted. The range is from 0 to . A value of zero (0) indicates no set limit.

Command Default

The maximum number of client connections is set to 0 (no limit).

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to configure a client association limit on a WLAN and configure the client limit to 200:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# client association limit 200
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to disable a client association limit on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# no client association limit
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to configure a client association limit per radio on a WLAN and configure the client limit to 200:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client association limit radio 200
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to configure a client association limit per AP on a WLAN and configure the client limit to 300::

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client association limit ap 300
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

channel foreign

To configure the RF Profile DCA foreign AP contribution, use the **channel foreign** command. To disable the DCA Foreign AP Contribution, use the **no** form of this command.

channel foreign

Syntax Description

foreign	Configures the RF Profile DCA foreign AP contribution.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to configure the RF profile DCA foreign AP contribution.

```
Device(config-rf-profile)#channel foreign
```

client-l2-vnid

To configure the client l2-vnid on a wireless fabric profile, use the **client-l2-vnid** command.

client-l2-vnid *vnid*

Syntax Description

vnid	Configures client l2-vnid. Valid range is 0 to 16777215.

Command Default

None

Command Modes

config-wireless-fabric

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the client l2-vnid value on a wireless fabirc profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile fabric fabric-profile-name
Device(config-wireless-fabric)# client-l2-vnid 10
```

condition chan-width

To configure channel width and band for rogue detection, use the **condition chan-width** command. To remove channel width and band from rogue detection, use the **no** form of this command.

condition chan-width { **160MHz** | **20MHz** | **40MHz** | **80MHz** } **band** { **2.4GHz** | **5GHz** | **6GHz** }

no condition chan-width

Syntax Description

160MHz	Specifies channel width as 160 MHz.
20MHz	Specifies channel width as 20 MHz.
40MHz	Specifies channel width as 40 MHz.
80MHz	Specifies channel width as 80 MHz.
band	Specifies the radio band.
2.4GHz	Specifies the radio band as 2.4 GHz.
5GHz	Specifies the radio band as 5 GHz.
6GHz	Specifies the radio band as 6 GHz.

Command Default

Channel width is not configured.

Command Modes

Rule configuration (config-rule)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Usage Guidelines

If the classification is **Friendly**, the value configured is the minimum channel width.

If the classification is **Custom**, **Malicious**, or **Delete**, the value configured is the maximum channel width.

Examples

The following example shows how to configure channel width value and band for rogue-detection classification:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless wps rogue rule 1 priority 1
Device(config-rule)#condition chan-width 20MHz band 5gHz
```

consent activation-mode merge

To enable the policy activation mode and merge it with the policy applied for 802.1X or MAC Authentication Bypass (MAB), thereby enabling a client to access the network, use the **consent activation-mode merge** command in the parameter map configuration mode. To disable this feature, use the **no** form of this command.

consent activation-mode merge

no consent activation-mode merge

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Parameter map configuration mode

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to enable the policy activation mode and merge it with the policy applied for 802.1X or MAC Authentication Bypass (MAB), thereby enabling a client to access the network:

```
Device# configure terminal
Device(config)# parameter-map type webauth parameter-map-name
Device(config-params-parameter-map)# consent activation-mode merge
```

convergence

To configure mesh convergence method, use the **convergence** command.

convergence { **fast** | **noise-tolerant-fast** | **standard** | **very-fast** }

Syntax Description

fast	Configures fast convergence method.
noise-tolerant-fast	Configures noise-tolerant fast convergence method method to handle unstable RF environment.
standard	Configures standard convergence method.
very-fast	Configures very fast convergence method.

Command Default

Standard

Command Modes

config-wireless-mesh-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the fast convergence method for a mesh AP profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile mesh mesh-profile
Device(config-wireless-mesh-profile)# convergence fast
```

copy configuration download

To download a workgroup bridge (WGB) configuration file from the SFTP or TFTP server, use the **copy configuration download** command.

copy configuration download { **sftp:** | **tftp:** } *ip-address* [*directory*] [*file-name*]

Syntax Description

sftp:	Selects SFTP server.
tftp:	Selects TFTP server.
ip-address	IP address of the SFTP or TFTP server that you want to use.
directory	(Optional) Directory name to use in the SFTP or TFTP server.
file-name	(Optional) WGB configuration file name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.8.1	This command was introduced.

Usage Guidelines

You can enter this command on the AP console only if the AP is in the WGB mode.

Examples

The following example shows how to select a WGB configuration file from the SFTP server:

```
Device# copy configuration download sftp: 10.10.10.1 C:sample.txt
```

copy configuration upload

To create a workgroup bridge (WGB) configuration file and upload it to the SFTP or TFTP server, use the **copy configuration upload** command.

copy configuration upload { **sftp:** | **tftp:** } *ip-address* [*directory*] [*file-name*]

Syntax Description

sftp:	Selects SFTP server.
tftp:	Selects TFTP server.
ip-address	IP address of the SFTP or TFTP server that you want to use.
directory	(Optional) Directory name to use in the SFTP or TFTP server.
file-name	(Optional) WGB configuration file name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.8.1	This command was introduced.

Usage Guidelines

You can enter this command on the AP console only if the AP is in the WGB mode.

Examples

The following example shows how to create a WGB configuration file and upload it to the SFTP server:

```
Device# copy configuration upload sftp: 10.10.10.1 C:sample.txt
```

core-dump kernel limit

To limit the number of kernel core dumps collected on an AP, use the **core-dump kernel limit** command. To disable this feature, use the **no** form of this command.

core-dump kernel limit *limit*

no core-dump kernel limit

Syntax Description

limit	The maximum number of kernel core dumps to be collected on an AP. Valid range is from 0 to 5. The default value is 0.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Usage Guidelines

Every connected AP reboots after enabling or disabling the **core-dump kernel limit** command.

Examples

The following example shows how to limit the number of kernel core dumps collected on an AP:

```
Device(config)# ap profile default-ap profile
Device(config-ap-profile)# core-dump kernel limit 3
```

core-dump kernel type

To configure the type of kernel core dump to be collected on the AP, use the **core-dump kernel type** command. To disable kernel core dump collection, use the **disable** option of this command.

core-dump kernel type { **disable** | **full-dump** | **mini-dump** }

Syntax Description

disable	Disables kernel core dump collection
full-dump	Enables full kernel core dump mode
mini-dump	Enables mini kernel core dump mode

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE 17.14.1	This command was introduced.

Usage Guidelines

Changing the kernel core dump type from disabled to full-dump or mini-dump or vice versa will cause the APs to reboot.

Examples

The following example shows how to configure the type of kernel core dump to be collected on the AP.

```
Device# configure terminal
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# core-dump kernel type mini-dump
```

coverage

To configure the voice and data coverage, use the **coverage** command. To reset the minimum RSSI value use the **no** form of this command.

coverage {**data** | **voice**} **rssi threshold** *value*

Syntax Description

data	Configure Coverage Hole Detection for data packets.
voice	Configure Coverage Hole Detection for voice packets.
value	Minimum RSSI value for the packets received by the access point. The valid rage is between –90 and –60 dBm.

Command Default

None

Command Modes

config-rf-profile

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to configure the coverage hole detection for data packets.

```
Device(config-rf-profile)#coverage data rssi threshold –85
```

crypto key generate rsa

To generate Rivest, Shamir, and Adelman (RSA) key pairs, use the **crypto key generate rsa** commandinglobal configuration mode.

crypto key generate rsa [**general-keys** | **usage-keys** | **signature** | **encryption**] [**label** *key-label*] [**exportable**] [**modulus** *modulus-size*] [**storage** *devicename* **:**] [**redundancy**] [**on** *devicename* **:**]

Syntax Description

general-keys	(Optional) Specifies that a general-purpose key pair will be generated, which is the default.
usage-keys	(Optional) Specifies that two RSA special-usage key pairs, one encryption pair and one signature pair, will be generated.
signature	(Optional) Specifies that the RSA public key generated will be a signature special usage key.
encryption	(Optional) Specifies that the RSA public key generated will be an encryption special usage key.
label *key-label*	(Optional) Specifies the name that is used for an RSA key pair when they are being exported. If a key label is not specified, the fully qualified domain name (FQDN) of the router is used.
exportable	(Optional) Specifies that the RSA key pair can be exported to another Cisco device, such as a router.
modulus *modulus-size*	(Optional) Specifies the IP size of the key modulus. By default, the modulus of a certification authority (CA) key is 1024 bits. The recommended modulus for a CA key is 2048 bits. The range of a CA key modulus is from 350 to 4096 bits. **Note** Effective with Cisco IOS XE Release 2.4 and Cisco IOS Release 15.1(1)T, the maximum key size was expanded to 4096 bits for private key operations. The maximum for private key operations prior to these releases was 2048 bits.
storage *devicename* **:**	(Optional) Specifies the key storage location. The name of the storage device is followed by a colon (:).
redundancy	(Optional) Specifies that the key should be synchronized to the standby CA.
on *devicename* **:**	(Optional) Specifies that the RSA key pair will be created on the specified device, including a Universal Serial Bus (USB) token, local disk, or NVRAM. The name of the device is followed by a colon (:). Keys created on a USB token must be 2048 bits or less.

Command Default

RSA key pairs do not exist.

Command Modes

Global configuration (config)

From Cisco IOS XE Release 17.11.1a, the command mode is Privileged EXEC (#)

Command History

Release	Modification
11.3	This command was introduced.
12.2(8)T	The *key-label* argumentwas added.
12.2(15)T	The **exportable** keyword was added.
12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
12.4(4)T	The **storage** keyword and *devicename* **:** argument were added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4(11)T	The **storage** keyword and *devicename* **:** argument were implemented on the Cisco 7200VXR NPE-G2 platform. The **signature**, **encryption** and **on** keywords and *devicename* **:** argument were added.
12.4(24)T	Support for IPv6 Secure Neighbor Discovery (SeND) was added.
XE 2.4	The maximum RSA key size was expanded from 2048 to 4096 bits for private key operations.
15.0(1)M	This command was modified. The **redundancy** keyword was introduced.
15.1(1)T	This command was modified. The range value for the **modulus** keyword value is extended from 360 to 2048 bits to 360 to 4096 bits.
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.
Cisco IOS XE Release 17.11.1a	The default command mode for this command has changed from Global configuration (config) to Privileged EXEC (#).

Usage Guidelines

Note Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Use this command to generate RSA key pairs for your Cisco device (such as a router).

RSA keys are generated in pairs--one public RSA key and one private RSA key.

If your router already has RSA keys when you issue this command, you will be warned and prompted to replace the existing keys with new keys.

Note Before issuing this command, ensure that your router has a hostname and IP domain name configured (with the **hostname** and **ip domain-name** commands). You will be unable to complete the **crypto key generate rsa** command without a hostname and IP domain name. (This situation is not true when you generate only a named key pair.)

Note Secure Shell (SSH) may generate an additional RSA key pair if you generate a key pair on a router having no RSA keys. The additional key pair is used only by SSH and will have a name such as {*router_FQDN* }.server. For example, if a router name is "router1.cisco.com," the key name is "router1.cisco.com.server."

This command is not saved in the router configuration; however, the RSA keys generated by this command are saved in the private configuration in NVRAM (which is never displayed to the user or backed up to another device) the next time the configuration is written to NVRAM.

Note If the configuration is not saved to NVRAM, the generated keys are lost on the next reload of the router.

There are two mutually exclusive types of RSA key pairs: special-usage keys and general-purpose keys. When you generate RSA key pairs, you will be prompted to select either special-usage keys or general-purpose keys.

Special-Usage Keys

If you generate special-usage keys, two pairs of RSA keys will be generated. One pair will be used with any Internet Key Exchange (IKE) policy that specifies RSA signatures as the authentication method, and the other pair will be used with any IKE policy that specifies RSA encrypted keys as the authentication method.

A CA is used only with IKE policies specifying RSA signatures, not with IKE policies specifying RSA-encrypted nonces. (However, you could specify more than one IKE policy and have RSA signatures specified in one policy and RSA-encrypted nonces in another policy.)

If you plan to have both types of RSA authentication methods in your IKE policies, you may prefer to generate special-usage keys. With special-usage keys, each key is not unnecessarily exposed. (Without special-usage keys, one key is used for both authentication methods, increasing the exposure of that key.)

General-Purpose Keys

If you generate general-purpose keys, only one pair of RSA keys will be generated. This pair will be used with IKE policies specifying either RSA signatures or RSA encrypted keys. Therefore, a general-purpose key pair might get used more frequently than a special-usage key pair.

Named Key Pairs

If you generate a named key pair using the *key-label*argument, you must also specify the **usage-keys** keyword or the **general-keys** keyword. Named key pairs allow you to have multiple RSA key pairs, enabling the Cisco IOS software to maintain a different key pair for each identity certificate.

Modulus Length

When you generate RSA keys, you will be prompted to enter a modulus length. The longer the modulus, the stronger the security. However a longer modules takes longer to generate (see the table below for sample times) and takes longer to use.

Table 7: Sample Times by Modulus Length to Generate RSA Keys

Router	360 bits	512 bits	1024 bits	2048 bits (maximum)
Cisco 2500	11 seconds	20 seconds	4 minutes, 38 seconds	More than 1 hour
Cisco 4700	Less than 1 second	1 second	4 seconds	50 seconds

Cisco IOS software does not support a modulus greater than 4096 bits. A length of less than 512 bits is normally not recommended. In certain situations, the shorter modulus may not function properly with IKE, so we recommend using a minimum modulus of 2048 bits.

Note As of Cisco IOS Release 12.4(11)T, peer *public* RSA key modulus values up to 4096 bits are automatically supported. The largest private RSA key modulus is 4096 bits. Therefore, the largest RSA private key a router may generate or import is 4096 bits. However, RFC 2409 restricts the private key size to 2048 bits or less for RSA encryption. The recommended modulus for a CA is 2048 bits; the recommended modulus for a client is 2048 bits.

Additional limitations may apply when RSA keys are generated by cryptographic hardware. For example, when RSA keys are generated by the Cisco VPN Services Port Adapter (VSPA), the RSA key modulus must be a minimum of 384 bits and must be a multiple of 64.

Specifying a Storage Location for RSA Keys

When you issue the **crypto key generate rsa** command with the **storage** *devicename* **:** keyword and argument, the RSA keys will be stored on the specified device. This location will supersede any **crypto key storage** command settings.

Specifying a Device for RSA Key Generation

As of Cisco IOS Release 12.4(11)T and later releases, you may specify the device where RSA keys are generated. Devices supported include NVRAM, local disks, and USB tokens. If your router has a USB token configured and available, the USB token can be used as cryptographic device in addition to a storage device. Using a USB token as a cryptographic device allows RSA operations such as key generation, signing, and authentication of credentials to be performed on the token. The private key never leaves the USB token and is not exportable. The public key is exportable.

RSA keys may be generated on a configured and available USB token, by the use of the **on** *devicename* **:** keyword and argument. Keys that reside on a USB token are saved to persistent token storage when they are generated. The number of keys that can be generated on a USB token is limited by the space available. If you attempt to generate keys on a USB token and it is full you will receive the following message:

```
% Error in generating keys:no available resources
```

Key deletion will remove the keys stored on the token from persistent storage immediately. (Keys that do not reside on a token are saved to or deleted from nontoken storage locations when the **copy**or similar command is issued.)

For information on configuring a USB token, see " Storing PKI Credentials " chapter in the Cisco IOS Security Configuration Guide, Release 12.4T. For information on using on-token RSA credentials, see the " Configuring and Managing a Cisco IOS Certificate Server for PKI Deployment " chapter in the Cisco IOS Security Configuration Guide , Release 12.4T.

Specifying RSA Key Redundancy Generation on a Device

You can specify redundancy for existing keys only if they are exportable.

Examples

The following example generates a general-usage 1024-bit RSA key pair on a USB token with the label “ms2” with crypto engine debugging messages shown:

```
Router(config)# crypto key generate rsa label ms2 modulus 2048 on usbtoken0:
The name for the keys will be: ms2
% The key modulus size is 2048 bits
% Generating 1024 bit RSA keys, keys will be on-token, non-exportable...
Jan 7 02:41:40.895: crypto_engine: Generate public/private keypair [OK]
Jan 7 02:44:09.623: crypto_engine: Create signature
Jan 7 02:44:10.467: crypto_engine: Verify signature
Jan 7 02:44:10.467: CryptoEngine0: CRYPTO_ISA_RSA_CREATE_PUBKEY(hw)(ipsec)
Jan 7 02:44:10.467: CryptoEngine0: CRYPTO_ISA_RSA_PUB_DECRYPT(hw)(ipsec)
```

Now, the on-token keys labeled “ms2” may be used for enrollment.

The following example generates special-usage RSA keys:

```
Router(config)# crypto key generate rsa usage-keys
The name for the keys will be: myrouter.example.com
Choose the size of the key modulus in the range of 360 to 2048 for your Signature Keys.
Choosing a key modulus greater than 512 may take a few minutes.
How many bits in the modulus[512]? <return>
Generating RSA keys.... [OK].
Choose the size of the key modulus in the range of 360 to 2048 for your Encryption Keys.
Choosing a key modulus greater than 512 may take a few minutes.
How many bits in the modulus[512]? <return>
Generating RSA keys.... [OK].
```

The following example generates general-purpose RSA keys:



Note You cannot generate both special-usage and general-purpose keys; you can generate only one or the other.

```
Router(config)# crypto key generate rsa general-keys
The name for the keys will be: myrouter.example.com
Choose the size of the key modulus in the range of 360 to 2048 for your General Purpose
Keys. Choosing a key modulus greater than 512 may take a few minutes.
How many bits in the modulus[512]? <return>
Generating RSA keys.... [OK].
```

The following example generates the general-purpose RSA key pair “exampleCAkeys”:

```
crypto key generate rsa general-keys label exampleCAkeys
crypto ca trustpoint exampleCAkeys
 enroll url
http://exampleCAkeys/certsrv/mscep/mscep.dll
 rsakeypair exampleCAkeys 1024 1024
```

The following example specifies the RSA key storage location of “usbtoken0:” for “tokenkey1”:

crypto key generate rsa general-keys label tokenkey1 storage usbtoken0:

The following example specifies the **redundancy** keyword:

```
Router(config)# crypto key generate rsa label MYKEYS redundancy
The name for the keys will be: MYKEYS
Choose the size of the key modulus in the range of 360 to 2048 for your
General Purpose Keys. Choosing a key modulus greater than 512 may take
a few minutes.
How many bits in the modulus [512]:
% Generating 512 bit RSA keys, keys will be non-exportable with redundancy...[OK]
```

Related Commands

Command	Description
copy	Copies any file from a source to a destination, use the copy command in privileged EXEC mode.
crypto key storage	Sets the default storage location for RSA key pairs.
debug crypto engine	Displays debug messages about crypto engines.
hostname	Specifies or modifies the hostname for the network server.
ip domain-name	Defines a default domain name to complete unqualified hostnames (names without a dotted-decimal domain name).
show crypto key mypubkey rsa	Displays the RSA public keys of your router.
show crypto pki certificates	Displays information about your PKI certificate, certification authority, and any registration authority certificates.

crypto pki trustpoint

To create a new TrustPoint dedicated for a single CA certificate, use the **crypto pki trustpoint** command.

crypto pki trustpoint

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

This example shows how to create a new TrustPoint dedicated for a single CA certificate:

```
Device# configure terminal
Device(config)# crypto pki trustpoint <tp_name>
Device(ca-trustpoint)# enrollment terminal
Device(ca-trustpoint)# exit
Device(config)# crypto pki authenticate <tp_name>
<<< PASTE CA-CERT in PEM format followed by quit >>>
```

crypto pki trust pool import terminal

To import the root certificate by pasting the CA certificate from the **digicert.com**, use the **crypto pki trust pool import terminal** command.

crypto pki trust pool import terminal

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

This example shows how to import the root certificate by pasting the CA certificate from the **digicert.com**:

```
Device# configure terminal
Device(config)# crypto pki trust pool import terminal
Device(config)# end
```

crypto pki trustpool clean

To erase the downloaded CA certificate bundles, use the **crypto pki trustpool clean** command.

crypto pki trustpool clean

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Usage Guidelines

This example shows how to erase the downloaded CA certificate bundles:

```
Device# configure terminal
Device(config)# crypto pki trustpool clean
Device(config)# end
```

cts inline-tagging

To configure Cisco TrustSec (CTS) inline tagging, use the **cts inline-tagging** command.

cts inline-tagging

Syntax Description

This command has no keywords or arguments.

Command Default

Inline tagging is not configured.

Command Modes

wireless policy configuration (config-wireless-policy)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure CTS inline tagging.

```
Device(config-wireless-policy)# cts inline-tagging
```

cts role-based enforcement

To configure Cisco TrustSec (CTS) SGACL enforcement, use the **cts role-based enforcement** command.

cts role-based enforcement

Syntax Description

This command has no keywords or arguments.

Command Default

SGACL is not enforced.

Command Modes

wireless policy configuration (config-wireless-policy)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure CTS SGACL enforcement.

```
Device(config-wireless-policy)# cts role-based enforcement
```

cts sgt

To set the Cisco TrustSec (CTS) default security group tag (SGT), use the **cts sgt** command.

cts sgt *sgt-value*

Syntax Description

sgt-value	Security group tag value.

Command Default

SGT tag is not set.

Command Modes

wireless policy configuration (config-wireless-policy)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to set the default SGT.

```
Device(config-wireless-policy)# cts sgt 100
```

custom-page login device

To configure a customized login page, use the **custom-page login device** command.

custom-page login device *html-filename*

Syntax Description

html-filename	Enter the HTML filename of the login page.

Command Default

None

Command Modes

config-params-parameter-map

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a customized login page:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type webauth parameter-map-name
Device(config-params-parameter-map)# custom-page login device bootflash:login.html
```

default

To set the parameters to their default values, use the **default** command.

default {**aaa-override** | **accounting-list** | **band-select** | **broadcast-ssid** | **call-snoop** | **ccx** | **channel-scan** | **parameters** | **chd** | **client** | **datalink** | **diag-channel** | **dtim** | **exclusionlist** | **ip** | **ipv6** | **load-balance** | **local-auth** | **mac-filtering** | **media-stream** | **mfp** | **mobility** | **nac** | **passive-client** | **peer-blocking** | **radio** | **roamed-voice-client** | **security** | **service-policy** | **session-timeout** | **shutdown** | **sip-cac** | **static-ip** | **uapsd** | **wgb** | **wmm**}

Syntax Description

aaa-override	Sets the AAA override parameter to its default value.
accounting-list	Sets the accounting parameter and its attributes to their default values.
band-select	Sets the band selection parameter to its default values.
broadcast-ssid	Sets the broadcast Service Set Identifier (SSID) parameter to its default value.
call-snoop	Sets the call snoop parameter to its default value.
ccx	Sets the Cisco client extension (Cisco Aironet IE) parameters and attributes to their default values.
channel-scan	Sets the channel scan parameters and attributes to their default values.
chd	Sets the coverage hold detection parameter to its default value.
client	Sets the client parameters and attributes to their default values.
datalink	Sets the datalink parameters and attributes to their default values.
diag-channel	Sets the diagnostic channel parameters and attributes to their default values.
dtim	Sets the Delivery Traffic Indicator Message (DTIM) parameter to its default value.
exclusionlist	Sets the client exclusion timeout parameter to its default value.
ip	Sets the IP parameters to their default values.
ipv6	Sets the IPv6 parameters and attributes to their default values.
load-balance	Sets the load-balancing parameter to its default value.
local-auth	Sets the Extensible Authentication Protocol (EAP) profile parameters and attributes to their default values.
mac-filtering	Sets the MAC filtering parameters and attributes to their default values.
media-stream	Sets the media stream parameters and attributes to their default values.

mfp	Sets the Management Frame Protection (MPF) parameters and attributes to their default values.
mobility	Sets the mobility parameters and attributes to their default values.
nac	Sets the RADIUS Network Admission Control (NAC) parameter to its default value.
passive-client	Sets the passive client parameter to its default value.
peer-blocking	Sets the peer to peer blocking parameters and attributes to their default values.
radio	Sets the radio policy parameters and attributes to their default values.
roamed-voice-client	Sets the roamed voice client parameters and attributes to their default values.
security	Sets the security policy parameters and attributes to their default values.
service-policy	Sets the WLAN quality of service (QoS) policy parameters and attributes to their default values.
session-timeout	Sets the client session timeout parameter to its default value.
shutdown	Sets the shutdown parameter to its default value.
sip-cac	Sets the Session Initiation Protocol (SIP) Call Admission Control (CAC) parameters and attributes to their default values.
static-ip	Sets the static IP client tunneling parameters and their attributes to their default values.
uapsd	Sets the Wi-Fi Multimedia (WMM) Unscheduled Automatic Power Save Delivery (UAPSD) parameters and attributes to their default values.
wgb	Sets the Workgroup Bridges (WGB) parameter to its default value.
wmm	Sets the WMM parameters and attributes to their default values.

Command Default

None.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to set the Cisco Client Extension parameter to its default value:

```
Device(config-wlan)# default ccx aironet-iesupport
```

description

To configure a description for a flow monitor, flow exporter, or flow record, use the **description** command in the appropriate configuration mode. To remove a description, use the **no** form of this command.

description *description*
no description *description*

Syntax Description

description	Text string that describes the flow monitor, flow exporter, or flow record.

Command Default

The default description for a flow sampler, flow monitor, flow exporter, or flow record is "User defined."

Command Modes

The following command modes are supported:

Flow exporter configuration

Flow monitor configuration

Flow record configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

To return this command to its default setting, use the **no description** or **default description** command in the appropriate configuration mode.

The following example configures a description for a flow monitor:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# description Monitors traffic to 172.16.0.1 255.255.0.0
```

destination

To configure an export destination for a flow exporter, use the **destination** command in flow exporter configuration mode. To remove an export destination for a flow exporter, use the **no** form of this command.

destination {*hostnameip-address*}
no destination {*hostnameip-address*}

Syntax Description

hostname	Hostname of the device to which you want to send the NetFlow information.
ip-address	IPv4 address of the workstation to which you want to send the NetFlow information.

Command Default

An export destination is not configured.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Each flow exporter can have only one destination address or hostname.

When you configure a hostname instead of the IP address for the device, the hostname is resolved immediately and the IPv4 address is stored in the running configuration. If the hostname-to-IP-address mapping that was used for the original Domain Name System (DNS) name resolution changes dynamically on the DNS server, the device does not detect this, and the exported data continues to be sent to the original IP address, resulting in a loss of data.

To return this command to its default setting, use the **no destination** or **default destination** command in flow exporter configuration mode.

The following example shows how to configure the networking device to export the cache entry to a destination system:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# destination 10.0.0.4
```

destination stealthwatch-cloud

To configure the export destination as Cisco Stealthwatch Cloud, use the **destination stealthwatch-cloud** command. To disable the command, use the **no** form of this command.

destination stealthwatch-cloud

no destination stealthwatch-cloud

Syntax Description

destination	Configures the export destination.
stealthwatch-cloud	Configures export to Cisco Stealthwatch Cloud.

Command Default

None

Command Modes

Flow Exporter Configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the export destination as Cisco Stealthwatch Cloud:

```
Device(config-flow-exporter)# destination stealthwatch-cloud
```

device-tracking binding vlan

To configure IPv4 or IPv6 static entry, use the **device-tracking binding vlan** command.

device-tracking binding vlan *vlan-id* {*ipv4-addr ipv6-addr* }**interface gigabitEthernet** *ge-intf-num hardware-or-mac-address*

Syntax Description

vlan-id	VLAN ID. Valid range is 1 to 4096.
ipv4-addr	IPv4 address of the device.
interface gigabitEthernet	GigabitEthernet IEEE 802.3z.
ge-intf-num	GigabitEthernet interface number. Valid range is 1 to 32.
hardware-or-mac-address	The 48-bit hardware address or the MAC address of the device.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure IPv4 static entry:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# device-tracking binding vlan 20 20.20.20.5 interface gigabitEthernet 1
0000.1111.2222
```

dhcp-tlv-caching

To configure DHCP TLV caching on a WLAN, use the **dhcp-tlv-caching** command.

dhcp-tlv-caching

Command Default None

Command Modes config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure DHCP TLV caching on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy rr-xyz-policy-1
Device(config-wireless-policy)# dhcp-tlv-caching
Device(config-wireless-policy)# radius-profiling
Device(config-wireless-policy)# end
```

dnscrypt

To enable or disable DNScrypt, use the **dnscrypt** command.

dnscrypt

Command Default

None

Command Modes

config-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

By default, the DNScrypt option is enabled.

This example shows how to enable or disable DNScrypt:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type umbrella global
Device(config-profile)# token 57CC80106C087FB1B2A7BAB4F2F4373C00247166
Device(config-profile)# local-domain dns_wl
Device(config-profile)# no dnscrypt
Device(config-profile)# end
```

domain-name (DHCP)

To specify the domain n ame for a Dynamic Host Configuration Protocol (DHCP) client, use the **domain-name** command in DHCP pool configuration mode. To remove the domain name, use the no form of this command.

domain-name *domain*
no domain-name

Syntax Description

domain	Specifies the domain name string of the client.

Command Default

No default behavior or values.

Command Modes

DHCP pool configuration

Command History

Release	Modification
12.0(1)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example specifies cisco.com as the domain name of the client:

```
domain-name cisco.com
```

Related Commands

Command	Description
dns-server	Specifies the DNS IP servers available to a DHCP client.
ip dhcp pool	Configures a DHCP address pool on a Cisco IOS DHCP server and enters DHCP pool configuration mode.

dot11 5ghz slot1 radio-profile

To configure 802.11a radio profile for slot 1, use the **dot11 5ghz slot1 radio-profile** *radio-profile-name*

dot11 5ghz slot1 radio-profile *radio-profile-name*

Syntax Description

radio-profile-name	Specifies the name of the radio profile.

Command Default

None

Command Modes

Wireless RF tag configuration (config-wireless-rf-tag)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure 802.11a radio profile for slot 1:

```
Device# configure terminal
Device(config)# wireless tag rf rf-tag-name
Device(config-wireless-rf-tag)# dot11 5GHz slot1 radio-profile radio-name
```

dot11ax twt-broadcast-support

To configure TWT broadcast support on WLAN, use the **dot11ax twt-broadcast-support** command. To disable the feature, use the **no** command of the command.

dot11ax twt-broadcast-support

[no] dot11ax twt-broadcast-support

Syntax Description

dot11ax twt-broadcast-support	Configures the TWT broadcast support on WLAN

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to configure target wakeup time on WLAN:

```
Device(config-wlan)# dot11ax twt-broadcast-support
```

dot11 5ghz reporting-interval

To configure the client report interval sent from AP for clients on 802.11a radio, use the **dot11 5ghz reporting-interval** command.

dot11 5ghz reporting-interval *reporting-interval*

Syntax Description

reporting-interval	Interval at which client report needs to be sent in seconds.

Command Default

None

Command Modes

config-ap-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to set the client report interval in seconds:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap profile profile-name
Device(config-ap-profile)# dot11 5ghz reporting-interval 8
```

dot11 reporting-interval

To set the volume metering interval, use the **dot11 reporting-interval** command.

dot11 { **24ghz** | **5ghz** } *reporting-interval*

Syntax Description

reporting-interval	Interval to send client accounting statistics.

Command Default

Interval is configured at the default level of 90 seconds.

Command Modes

config-ap-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Though the CLI allows you to configure range from 5 to 90 seconds, we recommend that you use 60 to 90 seconds range for Volume Metering.

This CLI can also be used to configure the interval when smart roam is enabled, which has a range of 5 to 90 seconds.

Though you can set two different values for volume metering and smart roam, only one value takes effect based on the order of execution. So, we recommend that you use the same reporting interval for both.

Example

The following example shows how to configure volume metering:

```
Device(config-ap-profile)# dot11 24ghz 60
```

dot1x system-auth-control

To globally enable 802.1X SystemAuthControl (port-based authentication), use the **dot1x system-auth-control**command in global configuration mode. To disable SystemAuthControl, use the **no** form of this command.

dot1x system-auth-control
no dot1x system-auth-control

Syntax Description

This command has no arguments or keywords.

Command Default

System authentication is disabled by default. If this command is disabled, all ports behave as if they are force authorized.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.3(2)XA	This command was introduced.
12.2(14)SX	This command was implemented on the Supervisor Engine 720.
12.3(4)T	This command was integrated into Cisco IOS Release 12.3(4)T.
12.2(17d)SXB	Support for this command on the Supervisor Engine 2 was extended to 12.2(17d)SXB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines

The IEEE 802.1x standard defines a client-server-based access control and authentication protocol that restricts unauthorized devices from connecting to a LAN through publicly accessible ports. 802.1x controls network access by creating two distinct virtual access points at each port. One access point is an uncontrolled port; the other is a controlled port. All traffic through the single port is available to both access points. 802.1x authenticates each user device that is connected to a switch port and assigns the port to a VLAN before making available any services that are offered by the switch or the LAN. Until the device is authenticated, 802.1x access control allows only Extensible Authentication Protocol (EAP) over LAN (EAPOL) traffic through the port to which the device is connected. After authentication is successful, normal traffic can pass through the port.

The **no** form of the command removes any 802.1X-related configurations.

You must enable Authentication, Authorization, and Accounting (AAA) and specify the authentication method list before enabling 802.1X. A method list describes the sequence and authentication methods to be queried to authenticate a user.

Examples

The following example shows how to enable SystemAuthControl:

```
Router(config)# dot1x system-auth-control
```

Related Commands

Command	Description
aaa authentication dot1x	Specifies one or more AAA methods for use on interfaces running IEEE 802.1X.
aaa new-model	Enables the AAA access-control model.
debug dot1x	Displays 802.1X debugging information.
description	Specifies a description for an 802.1X profile.
device	Statically authorizes or rejects individual devices.
dot1x initialize	Initializes 802.1X state machines on all 802.1X-enabled interfaces.
dot1x max-req	Sets the maximum number of times that a router or Ethernet switch network module can send an EAP request/identity frame to a client (assuming that a response is not received) before restarting the authentication process.
dot1x port-control	Enables manual control of the authorized state of a controlled port.
dot1x re-authenticate	Manually initiates a reauthentication of the specified 802.1X-enabled ports.
dot1x reauthentication	Globally enables periodic reauthentication of the client PCs on the 802.1X interface.
dot1x timeout	Sets retry timeouts.
identity profile	Creates an identity profile and enters identity profile configuration mode.
show dot1x	Displays details and statistics for an identity profile.
template	Specifies a virtual template from which commands may be cloned.

dot11-tlv-accounting

To configure client 802.11 type, length, value (TLV) accounting, use the **dot11-tlv-accounting** command. To disable client 802.11 TLV accounting, use the **no** form of this command.

dot11-tlv-accounting

Syntax Description

This command has no keywords or arguments.

Command Default

Client 802.11 TLV accounting is not configured.

Command Modes

Wireless policy configuration (config-wireless-policy)#

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example shows how to configure client 802.11 TLV accounting:

```
Device# configure terminal
Device(config)# wireless profile policy default-policy-profile
Device(config-wireless-policy)# dot11-tlv-accounting
```

eap profile

To configure an EAP profile, use the **eap profile** command.

eap profile *profile-name*

Syntax Description

profile-name	Name of the EAP profile. Maximum number of allowed characters is 63.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure an EAP profile name:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# eap profile eap-profile-name
```

exclusionlist

To configure an exclusion list, use the **exclusionlist** command. To disable an exclusion list, use the **no** form of this command.

exclusionlist [**timeout** *seconds*]
no exclusionlist [**timeout**]

Syntax Description

timeout *seconds*	(Optional) Specifies an exclusion list timeout in seconds. The range is from 0 to 2147483647. A value of zero (0) specifies no timeout.

Command Default

The exclusion list is set to 60 seconds.

Command Modes

Wireless policy configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to configure a client exclusion list:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy default-policy-profile
Device(config-wireless-policy)# exclusionlist timeout 5
```

exec-character-bits

To configure the character widths of EXEC and configuration command characters, use the **exec-character-bits** command in line configuration mode. To restore the default value, use the **no** form of this command.

exec-character-bits { *7* | *8* }

no exec-character-bits

Syntax Description

7	Sets the 7-bit character set. This is the default.
8	Sets the full 8-bit character set for use of international and graphical characters in banner messages, prompts, and so on.

Command Default

7-bit ASCII character set.

Command Modes

Line configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Setting the EXEC character width to 8 allows you to use special graphical and international characters in banners, prompts, and so on. However, setting the EXEC character width to 8 bits can cause failures. For example, if a user on a terminal that is sending parity enters the **help** command, an "unrecognized command" message appears because the system is reading all 8 bits, and the eighth bit is not needed for the **help** command.

Examples

The following example shows how to configure the character widths of EXEC and configuration command characters :

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# line console 0
Device(config-line)# exec-character-bit 8
```

exec time-out

To set the interval that the EXEC command interpreter waits until user input is detected, use the **exec-timeout** command in line configuration mode. To remove the timeout duration, use the **no** form of this command.

exec time-out *minutes* [*seconds*]

exec time-out

Syntax Description

minutes	Integer that specifies the number of minutes. The default is 10 minutes.
seconds	(Optional) Additional time intervals, in seconds.

Command Default

10 minutes

Command Modes

Line configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

If no input is detected during the interval, the EXEC facility resumes the current connection. If no connections exist, the EXEC facility returns the terminal to the idle state and disconnects the incoming session.

To specify no timeout, enter the **exec-timeout 0 0** command.

Examples

The following example sets a time interval of 2 minutes, 30 seconds:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# line console 0
Device(config-line)# exec-timeout 12 0
```

exporter default-flow-exporter

To add an exporter to use to export records, use the **exporter default-flow-exporter** command. Use the **no** form of this command to disable the feature.

exporter default-flow-exporter

[no] exporter default-flow-exporter

Syntax Description

There are no arguments to this command.

Command Default

None

Command Modes

Flow monitor configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to add an exporter to use to export records:

```
Device(config-flow-monitor)#exporter default-flow-exporter
```

fast-teardown

To enable fast teardown for a mesh access point (AP) profile and configure the feature's parameters, use the **fast-teardown** command.



Note Fast Teardown for Mesh APs is not supported on Cisco Industrial Wireless (IW) 3702 Access Points.

fast-teardown {enabled | interval *duration* **latency-exceeded-threshold | latency-threshold | uplink-recovery-interval** *duration* **| retries** *retry limit*

Syntax Description

enabled	Enables the fast teardown feature.
interval	(optional) Configures the retry interval, in seconds. The valid values range between 1 and 10 seconds.
latency-exceeded-threshold	(optional) Specifies the latency interval in which at least one ping must succeed in less than threshold time. The valid values range between 1 and 30 seconds.
latency-threshold	(optional) Speficies the latency threshold. The valid values range between 1 and 500 milliseconds.
uplink-recovery-interval	(Optional) Specifies the time during which root acccess point uplink has to be stable to accept child connections. The valid values range between 1 and 3600 seconds.
retries	(optional) Specifies the maximum retries until the gateway is considered unreachable. The range is from 0 to 10.

Command Default

None

Command Modes

Fast Teardown configuration

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to enable the fast teardown feature for a mesh AP profile and configure its parameters:

```
Device# configure terminal
Device(config)# wireless mesh profile mesh-profile-name
Device(config-wireless-mesh-profile)# fast-teardown
Device(config-wireless-mesh-profile-fast-teardown)# interval 1
```

fallback-radio-shut

To configure shutdown of the radio interface, use the **fallback-radio-shut** command.

fallback-radio-shut

Command Default None

Command Modes config-wireless-flex-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure shutdown of the radio interface:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile flex flex-profile-name
Device(config-wireless-flex-profile)# fallback-radio-shut
```

flex

To configure flex related parameters, use the **flex** command.

flex {**nat-pat** | **split-mac-acl** *split-mac-acl-name* | **vlan-central-switching** }

Syntax Description

nat-pat	Enables NAT-PAT.
split-mac-acl	Configures split-mac-acl name.
split-mac-acl-name	Name of split MAC ACL.
vlan-central-switching	VLAN based central switching.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure flex related VLAN central-switching:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy profile-name
Device(config-wireless-policy)# flex vlan-central-switching
```

flow exporter

To create a flow exporter, or to modify an existing flow exporter, and enter flow exporter configuration mode, use the **flow exporter** command in global configuration mode. To remove a flow exporter, use the **no** form of this command.

flow exporter *exporter-name*
no flow exporter *exporter-name*

Syntax Description

exporter-name	Name of the flow exporter that is being created or modified.

Command Default

flow exporters are not present in the configuration.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Flow exporters export the data in the flow monitor cache to a remote system, such as a server running NetFlow collector, for analysis and storage. Flow exporters are created as separate entities in the configuration. Flow exporters are assigned to flow monitors to provide data export capability for the flow monitors. You can create several flow exporters and assign them to one or more flow monitors to provide several export destinations. You can create one flow exporter and apply it to several flow monitors.

Examples

The following example creates a flow exporter named FLOW-EXPORTER-1 and enters flow exporter configuration mode:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)#
```

flow monitor

To create a flow monitor, or to modify an existing flow monitor, and enter flow monitor configuration mode, use the **flow monitor** command in global configuration mode. To remove a flow monitor, use the **no** form of this command.

flow monitor *monitor-name*
no flow monitor *monitor-name*

Syntax Description

monitor-name	Name of the flow monitor that is being created or modified.

Command Default

flow monitors are not present in the configuration.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Flow monitors are the component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a flow record and a cache. You add the record to the flow monitor after you create the flow monitor. The flow monitor cache is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and nonkey fields in the flow monitor's record and stored in the flow monitor cache.

Examples

The following example creates a flow monitor named FLOW-MONITOR-1 and enters flow monitor configuration mode:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)#
```

flow record

To create a flow record, or to modify an existing flow record, and enter flow record configuration mode, use the **flow record** command in global configuration mode. To remove a record, use the **no** form of this command.

flow record *record-name*
no flow record *record-name*

Syntax Description

record-name	Name of the flow record that is being created or modified.

Command Default

A flow record is not configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

A flow record defines the keys that uses to identify packets in the flow, as well as other fields of interest that gathers for the flow. You can define a flow record with any combination of keys and fields of interest. The supports a rich set of keys. A flow record also defines the types of counters gathered per flow. You can configure 64-bit packet or byte counters.

Examples

The following example creates a flow record named FLOW-RECORD-1, and enters flow record configuration mode:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)#
```

ftp-path

To configure the path at the FTP server for trace log export, use the **ftp-path** command. Use the **no** form of the command to negate the command or to set the command to its default.

`ftp-path`*ftp-path*

`no ftp-path`*ftp-path*

Syntax Description

ftp-path	Specifies the path at the FTP server.

Command Default

None

Command Modes

Wireless trace export profile FTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode ftp
Device(config-wireless-trace-export-profile-ftp)# ftp-path
ip-address/download/object/stream/images/ap-images
```

ftp-password

To configure the FTP server password for trace export, use the **ftp-password** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`ftp-password}<Enter password> <Re-enter password>`

`no ftp-password<Enter password> <Re-enter password>`

Syntax Description

password	Specifies the FTP server password.
re-enter password	Indicates that the user must re-enter the FTP server password.

Command Default

None

Command Modes

Wireless trace export profile FTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode ftp
Device(config-wireless-trace-export-profile-ftp)# ftp-password xxxxxxxx xxxxxxxx
```

ftp-server

To configure the FTP server address for trace export, use the **ftp-server** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
ftp-server {A.B.C.D | X:X:X:X::X}

no ftp-server {A.B.C.D | X:X:X:X::X}
```

Syntax Description

A.B.C.D	Specifies the FTP IPv4 server address.
X:X:X:X::X	Specifies the FTP IPv6 server address.

Command Default

None

Command Modes

Wireless trace export profile FTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode ftp
Device(config-wireless-trace-export-profile-ftp)# ftp-server 10.1.1.1
```

ftp-username

To configure the FTP server username for trace export, use the **ftp-username**command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`ftp-username` *Username*

`no ftp-username` *Username*

Syntax Description

username	Specifies the FTP server username.

Command Default

None

Command Modes

Wireless trace export profile FTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode ftp
Device(config-wireless-trace-export-profile-ftp)# ftp-username ftp-server-username
```



Configuration Commands: g to z

- icap subscription client anomaly-detection report-individual enable aggregate, on page 309
- icap subscription client anomaly-detection report-individual per-client throttle, on page 310
- icap subscription client anomaly-detection report-individual per-type throttle, on page 311
- icap subscription client exclude telemetry-data wlan, on page 312
- idle-timeout , on page 313
- image-download-mode , on page 314
- inactive-timeout, on page 315
- install add file tftp, on page 316
- install add profile default, on page 317
- install activate, on page 319
- install activate auto-abort-timer, on page 320
- install activate file, on page 321
- install auto-abort-timer stop, on page 322
- install commit, on page 323
- install remove file backup_image, on page 324
- install remove profile default , on page 325
- install deactivate , on page 326
- install rollback, on page 327
- interface vlan, on page 328
- ip access-group, on page 329
- ip access-list extended , on page 330
- ip address, on page 331
- ip dhcp pool, on page 333
- ip dhcp-relay information option server-override, on page 335
- ip dhcp-relay source-interface, on page 337
- ip domain lookup, on page 338
- ip domain-name , on page 340
- ip flow-export destination, on page 341
- ip helper-address, on page 342
- ip http authentication, on page 345
- ip http auth-retry, on page 347
- ip http active-session-modules, on page 348
- ip http client secure-ciphersuite, on page 349

- ip http secure-ciphersuite, on page 350
- ip http secure-server, on page 352
- ip http server, on page 354
- ip http session-module-list, on page 356
- ip ssh, on page 358
- ip ssh version, on page 360
- ip tftp blocksize, on page 362
- ip verify source, on page 363
- ipv4 acl, on page 364
- ipv4 dhcp , on page 365
- ipv4 flow monitor , on page 366
- ipv4 flow monitor output, on page 367
- ipv6 flow monitor input, on page 368
- ipv6 flow monitor output, on page 369
- ipv6 access-list, on page 370
- ipv6 acl, on page 372
- ipv6-address-type, on page 373
- ipv6 address, on page 374
- ipv6 dhcp pool, on page 376
- ipv6 enable, on page 379
- ipv6 mld snooping, on page 381
- ipv6 nd managed-config-flag , on page 382
- ipv6 nd other-config-flag , on page 383
- ipv6 nd ra throttler attach-policy , on page 384
- ipv6 nd raguard policy, on page 385
- ipv6 traffic-filter , on page 387
- key chain, on page 388
- key config-key, on page 389
- **key config-key password-encrypt**, on page 390
- license air level, on page 391
- license smart (global config), on page 395
- license smart (privileged EXEC), on page 406
- line vty , on page 413
- load, on page 414
- local-auth ap eap-fast , on page 415
- local-site , on page 416
- location expiry , on page 417
- location notify-threshold, on page 418
- log-export-mode , on page 419
- login authentication , on page 420
- login block-for, on page 421
- mac-filtering , on page 422
- mab request format attribute, on page 423
- map-fast-ancestor-find, on page 425
- match (access-map configuration), on page 426
- match activated-service-template, on page 428

- match any , on page 430
- match message-type, on page 431
- match non-client-nrt, on page 432
- match protocol, on page 433
- match service-instance, on page 436
- match service-type, on page 437
- match user-role , on page 438
- match username, on page 439
- match (access-map configuration), on page 440
- match (class-map configuration), on page 442
- match wlan user-priority, on page 445
- max-bandwidth , on page 446
- max-through, on page 447
- mdns-sd, on page 448
- mdns-sd-interface, on page 449
- mdns-sd flex-profile, on page 450
- mdns-sd profile, on page 451
- method fast , on page 452
- mgmtuser username , on page 453
- mobility backhaul-check coordinator-down, on page 454
- mobility backhaul-check eth-down , on page 455
- mobility mpo cos, on page 456
- mobility mpo enable, on page 457
- mobility mpo path, on page 458
- mobility mpo rssi , on page 459
- mobility mpo telemetry, on page 460
- mobility role, on page 461
- mobility scan , on page 462
- monitor capture (access list/class map), on page 463
- monitor capture export, on page 465
- monitor capture (interface/control plane), on page 466
- monitor capture limit, on page 467
- monitor capture match, on page 469
- monitor capture start, on page 472
- monitor capture stop, on page 473
- mop sysid, on page 474
- mpls ether-filter ethernet-I, on page 475
- mpls ether-filter ethertypes filtering, on page 476
- mpls high-availability timeout, on page 477
- multicast (URWB), on page 478
- multicast vlan, on page 479
- nac, on page 480
- nas-id option2 , on page 481
- network , on page 482
- network-key key, on page 483
- nmsp cloud-services enable , on page 484

- nmsp cloud-services http-proxy , on page 485
- nmsp cloud-services server token , on page 486
- nmsp cloud-services server url, on page 487
- nmsp notification interval, on page 488
- nmsp strong-cipher, on page 490
- no shutdown (URWB), on page 491
- ntp auth-key, on page 492
- option, on page 493
- parameter-map type subscriber attribute-to-service , on page 495
- pae, on page 496
- parameter-map type webauth , on page 497
- password encryption aes, on page 498
- peer-blocking, on page 499
- pmf-deauth, on page 500
- policy, on page 501
- police, on page 502
- police cir, on page 504
- policy-map, on page 505
- policy-map, on page 507
- port, on page 509
- priority priority-value, on page 510
- public-ip, on page 511
- qos video, on page 512
- radius server, on page 513
- radius-server deadtime, on page 514
- radius-server attribute wireless accounting call-station-id, on page 515
- radius-server attribute wireless authentication call-station-id, on page 517
- range, on page 519
- record wireless avc basic, on page 520
- redirect , on page 521
- redirect portal , on page 522
- remote-lan, on page 523
- request platform software trace archive last , on page 524
- rf tag, on page 525
- rogue detection containment pmf-denial, on page 526
- rrc-evaluation, on page 527
- security , on page 528
- security dot1x authentication-list, on page 529
- security ft, on page 530
- security pmf, on page 532
- security static-wep-key , on page 534
- security web-auth, on page 535
- security wpa akm, on page 536
- security wpa akm sae, on page 538
- sensor-name, on page 539
- service-key, on page 540

- service-policy, on page 541
- service-policy qos , on page 542
- service-template, on page 543
- service timestamps, on page 544
- session-timeout, on page 546
- set, on page 547
- sftp-image-path (image-download-mode sftp), on page 554
- sftp-image-server (image-download-mode sftp), on page 555
- sftp-password (image-download-mode sftp), on page 556
- sftp-password (trace-export), on page 557
- sftp-path, on page 558
- sftp-server, on page 559
- sftp-username (image-download-mode sftp), on page 560
- sftp-username (trace-export), on page 561
- snmp-server enable traps wireless, on page 562
- snmp-server subagent cache, on page 563
- ssid broadcast persistent, on page 564
- statistics ap-system-monitoring alarm-enable, on page 565
- statistics ap-system-monitoring alarm-hold-time, on page 566
- statistics ap-system-monitoring alarm-retransmit-time, on page 567
- statistics ap-system-monitoring cpu-threshold, on page 568
- statistics ap-system-monitoring enable, on page 569
- statistics ap-system-monitoring mem-threshold, on page 570
- statistics ap-system-monitoring sampling-interval, on page 571
- statistics ap-system-monitoring stats-interval, on page 572
- stealthwatch-cloud-monitor, on page 573
- stopbits, on page 574
- strong-network-key, on page 575
- tag rf, on page 576
- tag site, on page 577
- tftp-image-path (image-download-mode tftp), on page 578
- tftp-image-server (image-download-mode tftp), on page 579
- tftp-path, on page 580
- tftp-server, on page 581
- timezone delta , on page 582
- udp-timeout, on page 583
- umbrella-param-map, on page 584
- update-timer, on page 585
- url, on page 586
- urlfilter list, on page 587
- urwb chan-list channel, on page 588
- urwb channel, on page 589
- urwb crypto policy, on page 590
- urwb crypto rotating-key-timeout, on page 591
- urwb cwidth , on page 592
- urwb-profile, on page 593

- urwb ptmp autoscan, on page 594
- urwb ptmp cluster-id, on page 595
- urwb ptmp rssi-threshold, on page 596
- urwb ptmp tower-id, on page 597
- urwb role, on page 598
- usb-enable, on page 599
- username, on page 600
- violation, on page 602
- wgb broadcast-tagging, on page 603
- wgb vlan, on page 604
- whitelist acl, on page 605
- wired-vlan-range, on page 606
- config wlan assisted-roaming, on page 607
- wireless aaa policy, on page 608
- wireless aaa policy, on page 609
- wireless autoqos policy-profile , on page 610
- wireless broadcast vlan, on page 611
- wireless client, on page 612
- wireless client mac-address, on page 614
- wireless client vlan-persistent, on page 619
- wireless config validate , on page 620
- wireless country, on page 622
- wireless exclusionlist mac address, on page 623
- wireless ipv6 ra wired, on page 624
- wireless load-balancing, on page 625
- wireless macro-micro steering transition-threshold , on page 626
- wireless macro-micro steering probe-suppression, on page 627
- wireless management certificate, on page 628
- wireless management interface, on page 629
- wireless management trustpoint, on page 630
- wireless mesh alarm association count , on page 631
- wireless mesh alarm high-snr , on page 632
- wireless mesh alarm low-snr , on page 633
- wireless mesh alarm max-children map , on page 634
- wireless mesh alarm max-children rap , on page 635
- wireless mesh alarm max-hop , on page 636
- wireless mesh alarm parent-change count , on page 637
- wireless mesh backhaul bdomain-channels , on page 638
- wireless mesh backhaul rrm , on page 639
- wireless mesh cac , on page 640
- wireless mesh ethernet-bridging allow-bdpu , on page 641
- wireless mesh security psk provisioning , on page 642
- wireless mesh subset-channel-sync , on page 643
- wireless ewc-ap ap ap-type, on page 644
- wireless ewc-ap ap capwap, on page 645
- wireless ewc-ap ap reload, on page 646

- wireless ewc-ap ap shell , on page 647
- wireless ewc-ap ap shell username, on page 648
- wireless ewc-ap preferred-master, on page 649
- wireless ewc-ap factory-reset, on page 650
- wireless ewc-ap vrrp vrid, on page 651
- wireless profile flex, on page 652
- wireless profile image-download default, on page 653
- wireless profile mesh, on page 654
- wireless profile policy, on page 655
- wireless profile transfer, on page 656
- wireless profile urwb, on page 657
- wireless rfid, on page 658
- wireless security dot1x, on page 659
- wireless security dot1x radius accounting mac-delimiter, on page 661
- wireless security dot1x radius accounting username-delimiter, on page 662
- wireless security dot1x radius callStationIdCase, on page 663
- wireless security dot1x radius mac-authentication call-station-id, on page 664
- wireless security dot1x radius mac-authentication mac-delimiter, on page 665
- wireless security web-auth retries, on page 666
- wireless tag policy, on page 667
- wireless tag site, on page 668
- wireless wps ap-authentication threshold, on page 669
- wireless wps client-exclusion, on page 670
- wireless wps mfp ap-impersonation, on page 672
- wireless wps rogue network-assurance enable, on page 673
- wireless wps rogue ap aaa , on page 674
- wireless wps rogue ap aaa polling-interval, on page 675
- wireless wps rogue ap init-timer, on page 676
- wireless wps rogue ap mac-address rldp initiate , on page 677
- wireless wps rogue ap notify-min-rssi, on page 678
- wireless wps rogue ap notify-rssi-deviation, on page 679
- wireless wps rogue ap rldp alarm-only, on page 680
- wireless wps rogue ap rldp alarm-only monitor-ap-only, on page 681
- wireless wps rogue ap rldp auto-contain, on page 682
- wireless wps rogue ap rldp retries, on page 683
- wireless wps rogue ap rldp schedule, on page 684
- wireless wps rogue ap rldp schedule day, on page 685
- wireless wps rogue ap timeout, on page 686
- wireless wps rogue auto-contain , on page 687
- wireless wps rogue client aaa, on page 688
- wireless wps rogue client mse, on page 689
- wireless wps rogue client client-threshold , on page 690
- wireless wps rogue client notify-min-rssi, on page 691
- wireless wps rogue client notify-rssi-deviation, on page 692
- wireless wps rogue rule, on page 693
- wireless wps rogue security-level, on page 695

- wireless-default radius server, on page 696
- wlan policy , on page 697

icap subscription client anomaly-detection report-individual enable aggregate

To configure anomaly detection for client subscriptions and to enable individual report aggregation, use the **icap subscription client anomaly-detection report-individual enable aggregate** command.

icap subscription client anomaly-detection report-individual enable aggregate

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.12.1	This command was introduced.

Examples

The following example shows how to configure anomaly detection for client subscriptions and to enable individual report aggregation:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# icap subscription client anomaly-detection report-individual
enable aggregate
```

icap subscription client anomaly-detection report-individual per-client throttle

To configure individual reports per client every five minutes on an AP, use the **icap subscription client anomaly-detection report-individual per-client throttle** command.

icap subscription client anomaly-detection report-individual per-client throttle *throttle value*

Syntax Description

throttle value	Number of event reports per client. Valid value ranges from 0 to 50.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.12.1	This command was introduced.

Examples

The following example shows how to configure individual reports per client every five minutes on an AP:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# icap subscription client anomaly-detection report-individual
per-client throttle 10
```

icap subscription client anomaly-detection report-individual per-type throttle

To configure individual reports per type every five minutes on an AP, use the **icap subscription client anomaly-detection report-individual per-type throttle** command.

icap subscription client anomaly-detection report-individual per-type throttle *throttle value*

Syntax Description

throttle value	Number of event reports per client. Valid value ranges from 0 to 100.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.12.1	This command was introduced.

Examples

The following example shows how to configure individual reports per type every five minutes on an AP:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# icap subscription client anomaly-detection report-individual
per-type throttle 80
```

icap subscription client exclude telemetry-data wlan

To enable iCAP filtering in an AP, use the **icap subscription client exclude telemetry-data wlan** command.

icap subscription client exclude telemetry-data wlan *wlan-profile-name*

Syntax Description

wlan-profile-name	Specifies the name of the WLAN profile.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

This example shows how to enable iCAP filtering in an AP:

```
Device# configure terminal
Device(config)# ap profile xyz-ap-profile
Device(config-ap-profile)# description "xyz ap profile"
Device(config-ap-profile)# icap subscription client exclude telemetry-data wlan wlan-name
```

idle-timeout

To configure the idle-timeout value in seconds for a wireless profile policy, use the **idle-timeout** command.

idle-timeout *value*

Syntax Description

value	Sets the idle-timeout value. Valid range is 15 to 100000 seconds.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to set the idle-timeout in a wireless profile policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy policy-profile-name
Device(config-wireless-policy)# idle-timeout 100
```

image-download-mode

To configure image download using the HTTP, SFTP, TFTP, or CCO modes, use the **image-download-mode** command.

image-download-mode { **http** | **sftp** | **tftp** | **cco** }

Syntax Description

http	Configures image download using the HTTP mode.
sftp	Configures image download using the SFTP mode.
tftp	Configures image download using the TFTP mode.
cco	Configures image download using the CCO mode.

Command Default

None

Command Modes

Wireless image download profile configuration mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.
Cisco IOS XE Amsterdam 17.1.1s	The **image-download-mode cco**was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode http
```

inactive-timeout

To enable in-active timer, use the **inactive-timeout** command.

inactive-timeout *timeout-in-seconds*

Syntax Description

timeout-in-seconds	Specifies the inactive flow timeout value. The range is from 1 to 604800.

Command Default

None

Command Modes

ET-Analytics configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to enable in-active timer in the ET-Analytics configuration mode:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# et-analytics
Device(config-et-analytics)# inactive-timeout 15
Device(config-et-analytics)# end
```

install add file tftp

To install a package file to the system, use the **install add file tftp** command.

install add file tftp: *tftp file path*

Syntax Description

install add file tftp:	The **install add** command copies the file from the external server to the backup_image directory on the embedded wireless controller.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to install a package file to the system:

```
Device#install add file tftp://<server-ip>/<path>/<smu-filename>
```

install add profile default

To download the embedded wireless controller image from the external server, use the **install add profile default** command.

install add profile *profile_name***activatecommitprompt-level none**

Syntax Description

add	Installs a package file to the system.
profile	Selects a profile.
profile_name	Adds a profile name with a maximum of 15 characters. Specify **default** to trigger the default behaviour.
activate	Activates the installed profile.
commit	Commits the changes to the loadpath.
prompt-level	Sets the prompt-level to none.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Usage Guidelines

Ensure that you have the *image-download-profile* configured on embedded wireless controller. Extract the contents of the image bundle (.zip archive) to an external TFTP or HTTP(S) server. The .zip archive contains the controller image and various compatible AP images (`apXgY`).

Example

The following example shows how to download the embedded wireless controller image:

```
Device#install add profile default

install_add: START Thu Jan 24 20:08:01 UTC 2019
Jan 24 20:08:03.389: %INSTALL-5-INSTALL_START_INFO: R0/0: install_engine: Started install
add
Jan 24 20:08:03.389 %INSTALL-5-INSTALL_START_INFO: R0/0: install_engine: Started install
add
install_add: Default profile addition successful
SUCCESS: install_add Thu Jan 24 20:08:03 UTC 2019
Jan 24 20:08:04.358: %INSTALL-5-INSTALL_COMPLETED_INFO: R0/0: install_engine: Completed
install add
Jan 24 20:08:04.358 %INSTALL-5-INSTALL_COMPLETED_INFO: R0/0: install_engine: Completed
install add
WLC#
*Jan 24 20:08:03.350: %INSTALL-5-INSTALL_START_INFO: Chassis 1 R0/0: install_engine: Started
 install add
```

```
*Jan 24 20:08:04.335: %INSTALL-5-INSTALL_COMPLETED_INFO: Chassis 1 R0/0: install_engine:
Completed install add
```



Note The log `Completed install add` means that the command is successful and the download will start soon.

The following example verifies the the image download status:

```
Device#sh wireless ewc-ap predownload status
```

install activate

To activate an installed package, use the **install activate** command.

install activate {**auto-abort-timer** | **file** | **profile** | **prompt-level**}

Syntax Description

auto-abort-timer	Sets the cancel timer. The time range is between 30 and 1200 minutes.
file	Specifies the package to be activated.
profile	Specifies the profile to be activated.
prompt-level	Sets the prompt level.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to activate the installed package:

```
Device# install activate profile default
install_activate: START Thu Nov 24 20:14:53 UTC 2019

System configuration has been modified.
Press Yes(y) to save the configuration and proceed.
Press No(n) for proceeding without saving the configuration.
Press Quit(q) to exit, you may save configuration and re-enter the command. [y/n/q] y
Building configuration...
[OK]Modified configuration has been saved
Jan 24 20:15:02.745: %INSTALL-5-INSTALL_START_INFO: R0/0: install_engine: Started install
activate
Jan 24 20:15:02.745 %INSTALL-5-INSTALL_START_INFO: R0/0: install_engine: Started install
activate
install_activate: Activating PACKAGE
```

install activate auto-abort-timer

To set the abort timer, use the **install activate auto-abort-timer** command.

install activate auto-abort-timer *<30-1200>* **prompt-level none**

Syntax Description

auto-abort-timer	Sets the cancel timer. The time range is between 30 and 1200 minutes.
<30-1200>	Specifies the cancel timer time in minutes.
prompt-level	Specifies the prompt level.
none	Specifies no prompting.

Command Default

None

Command Modes

Privileged EXEC (#)

Task ID

Task ID	Operation
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to activate the cancel timer:

```
Device#install activate auto-abort-timer 30 prompt-level none
```

install activate file

To activate an installed package, use the **install activate file** command.

install activate file *file-name*

Syntax Description

file-name	Specifies the package name. Options are: bootflash:, flash:, and webui:.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to use an auto cancel timer while activating an install package on a standby location:

```
Device# install activate file vwlc_apsp_16.11.1.0_74.bin
```

install auto-abort-timer stop

To stop the auto abort timer, use the **install auto-abort-timer stop** command.

install auto-abort-timer stop

Syntax Description

auto-abort-timer stop	Stops the auto-abort-timer

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to stop the auto abort timer:

```
Device#install auto-abort-timer stop
```

install commit

To commit the changes to the loadpath, use the **install commit** command.

install commit

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to commit the changes to the loadpath:

```
Device# install commit
```

install remove file backup_image

To remove installed packages, use the **install remove file backup_image** command.

install remove file backup_image *filename*

Syntax Description

filename	Specifes the file that needs to be removed.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how a file is removed from the package:

```
Device#install remove file backup_image: file_name
```

install remove profile default

To specify an install package that is to be removed, use the **install remove profile default** command.

install remove profile default

Syntax Description

remove	Removes the install package.
profile	Specifies the profile to be removed.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to remove a default profile:

```
Device# install remove profile default
```

install deactivate

To specify an install package that is to be deactivated, use the **install deactivate file** command.

install deactivate file *file-name*

Syntax Description

file-name	Specifies the package name. Options are: bootflash:, flash:, and webui:.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to deactivate an install package:

```
Device# install deactivate file vwlc_apsp_16.11.1.0_74.bin
```

install rollback

To roll back to a particular installation point, use the **install rollback** command.

install rollback to {**base** | **committed** | **id** *id* | **label** *label*} [**prompt-level none**]

Syntax Description

base	Rolls back to the base image.
prompt-level none	Sets the prompt level as none.
committed	Rolls back to the last committed installation point.
id	Rolls back to a specific install point ID.
label	Rolls back to a specific install point label.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

The following example shows how to specify the ID of the install point to roll back to:

```
Device# install rollback to id 1
```

interface vlan

To create or access a dynamic switch virtual interface (SVI) and to enter interface configuration mode, use the **interface vlan** command in global configuration mode. To delete an SVI, use the **no** form of this command.

interface vlan *vlan-id*
no interface vlan *vlan-id*

Syntax Description

vlan-id	VLAN number. The range is 1 to 4094.

Command Default

The default VLAN interface is VLAN 1.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

SVIs are created the first time you enter the **interface vlan** *vlan-id* command for a particular VLAN. The *vlan-id* corresponds to the VLAN-tag associated with data frames on an IEEE 802.1Q encapsulated trunk or the VLAN ID configured for an access port.

Note When you create an SVI, it does not become active until it is associated with a physical port.

If you delete an SVI using the **no interface vlan** *vlan-id* command, it is no longer visible in the output from the **show interfaces** privileged EXEC command.

Note You cannot delete the VLAN 1 interface.

You can reinstate a deleted SVI by entering the **interface vlan** *vlan-id* command for the deleted interface. The interface comes back up, but the previous configuration is gone.

The interrelationship between the number of SVIs configured on a and the number of other features being configured might have an impact on CPU utilization due to hardware limitations. You can use the **sdm prefer** global configuration command to reallocate system hardware resources based on templates and feature tables.

You can verify your setting by entering the **show interfaces** and **show interfaces vlan** *vlan-id* privileged EXEC commands.

This example shows how to create a new SVI with VLAN ID 23 and enter interface configuration mode:

```
Device(config)# interface vlan 23
Device(config-if)#
```

ip access-group

To configure WLAN access control group (ACL), use the **ip access-group** command. To remove a WLAN ACL group, use the **no** form of the command.

ip access-group [**web**] *acl-name*
no ip access-group [**web**]

Syntax Description

web	(Optional) Configures the IPv4 web ACL.
acl-name	Specify the preauth ACL used for the WLAN with the security type value as webauth.

Command Default

None

Command Modes

WLAN configuration

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure a WLAN ACL:

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#wlan wlan1
Device(config-wlan)#ip access-group test-acl
```

This example shows how to configure an IPv4 WLAN web ACL:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# ip access-group web test
Device(config-wlan)#
```

ip access-list extended

To configure extended access list, use the **ip access-list extended** command.

ip access-list extended {**<100-199>** | **<2000-2699>** *access-list-name*}

Syntax Description

<100-199>	Extended IP access-list number.
<2000-2699>	Extended IP access-list number (expanded range).

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure extended access list:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ip access-list extended access-list-name
```

ip address

To set a primary or secondary IP address for an interface, use the **ip address** command in interface configuration mode. To remove an IP address or disable IP processing, use the noform of this command.

ip address *ip-address mask* [**secondary** [**vrf** *vrf-name*]]
no ip address *ip-address mask* [**secondary** [**vrf** *vrf-name*]]

Syntax Description

ip-address	IP address.
mask	Mask for the associated IP subnet.
secondary	(Optional) Specifies that the configured address is a secondary IP address. If this keyword is omitted, the configured address is the primary IP address. **Note** If the secondary address is used for a VRF table configuration with the **vrf** keyword, the **vrf** keyword must be specified also.
vrf	(Optional) Name of the VRF table. The *vrf-name* argument specifies the VRF name of the ingress interface.

Command Default

No IP address is defined for the interface.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

An interface can have one primary IP address and multiple secondary IP addresses. Packets generated by the Cisco IOS software always use the primary IP address. Therefore, all devices and access servers on a segment should share the same primary network number.

Hosts can determine subnet masks using the Internet Control Message Protocol (ICMP) mask request message. Devices respond to this request with an ICMP mask reply message.

You can disable IP processing on a particular interface by removing its IP address with the **no ip address** command. If the software detects another host using one of its IP addresses, it will print an error message on the console.

The optional **secondary** keyword allows you to specify an unlimited number of secondary addresses. Secondary addresses are treated like primary addresses, except the system never generates datagrams other than routing updates with secondary source addresses. IP broadcasts and Address Resolution Protocol (ARP) requests are handled properly, as are interface routes in the IP routing table.

Secondary IP addresses can be used in a variety of situations. The following are the most common applications:

- There may not be enough host addresses for a particular network segment. For example, your subnetting allows up to 254 hosts per logical subnet, but on one physical subnet you need 300 host addresses. Using

secondary IP addresses on the devices or access servers allows you to have two logical subnets using one physical subnet.

- Many older networks were built using Level 2 bridges. The judicious use of secondary addresses can aid in the transition to a subnetted, device-based network. Devices on an older, bridged segment can be easily made aware that many subnets are on that segment.
- Two subnets of a single network might otherwise be separated by another network. This situation is not permitted when subnets are in use. In these instances, the first network is *extended*, or layered on top of the second network using secondary addresses.



Note

- If any device on a network segment uses a secondary address, all other devices on that same segment must also use a secondary address from the same network or subnet. Inconsistent use of secondary addresses on a network segment can very quickly cause routing loops.
- When you are routing using the Open Shortest Path First (OSPF) algorithm, ensure that all secondary addresses of an interface fall into the same OSPF area as the primary addresses.
- If you configure a secondary IP address, you must disable sending ICMP redirect messages by entering the **no ip redirects** command, to avoid high CPU utilization.

Examples

In the following example, 192.108.1.27 is the primary address and 192.31.7.17 is the secondary address for GigabitEthernet interface 1/0/1:

```
Device# enable
Device# configure terminal
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# ip address 192.108.1.27 255.255.255.0
Device(config-if)# ip address 192.31.7.17 255.255.255.0 secondary
```

Related Commands

Command	Description
match ip route-source	Specifies a source IP address to match to required route maps that have been set up based on VRF connected routes.
route-map	Defines the conditions for redistributing routes from one routing protocol into another, or to enable policy routing.
set vrf	Enables VPN VRF selection within a route map for policy-based routing VRF selection.
show ip arp	Displays the ARP cache, in which SLIP addresses appear as permanent ARP table entries.
show ip interface	Displays the usability status of interfaces configured for IP.
show route-map	Displays static and dynamic route maps.

ip dhcp pool

To configure a Dynamic Host Configuration Protocol (DHCP) address pool on a DHCP server and enter DHCP pool configuration mode, use the **ip dhcp pool** command in global configuration mode. To remove the address pool, use the no form of this command.

ip dhcp pool *name*
no ip dhcp pool *name*



Note When configuring the **ip dhcp pool** command, note that it can be affected by the **ip dhcp database** command if an incorrect URL is provided. The console may hang due to multiple attempts by the DHCP service to reach the URL before it returns a failure. This is expected behavior. To prevent this issue, ensure that the correct URL, including the file name, is provided when using the **ip dhcp database** command, especially when it includes ftp/tftp.

Syntax Description

name	Name of the pool. Can either be a symbolic string (such as engineering) or an integer (such as 0).

Command Default

DHCP address pools are not configured.

Command Modes

Global configuration

Command History

Release	Modification
12.0(1)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

During execution of this command, the configuration mode changes to DHCP pool configuration mode, which is identified by the (config-dhcp)# prompt. In this mode, the administrator can configure pool parameters, like the IP subnet number and default router list.

Examples

The following example configures pool1 as the DHCP address pool:

```
ip dhcp pool pool1
```

Related Commands

Command	Description
host	Specifies the IP address and network mask for a manual binding to a DHCP client.
ip dhcp excluded-address	Specifies IP addresses that a Cisco IOS DHCP server should not assign to DHCP clients.

Command	Description
network (DHCP)	Configures the subnet number and mask for a DHCP address pool on a Cisco IOS DHCP server.

ip dhcp-relay information option server-override

To enable the system to globally insert the server ID override and link selection suboptions into the DHCP relay agent information option in forwarded BOOTREQUEST messages to a Dynamic Host Configuration Protocol (DHCP) server, use the **ip dhcp-relay information option server-override** command in global configuration mode. To disable inserting the server ID override and link selection suboptions into the DHCP relay agent information option, use the **no** form of this command.

ip dhcp-relay information option server-override
no ip dhcp-relay information option server-override

Syntax Description

This command has no arguments or keywords.

Command Default

The server ID override and link selection suboptions are not inserted into the DHCP relay agent information option.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Aggregation Services Routers.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
15.1(1)SY	This command was integrated into Cisco IOS Release 15.1(1)SY.

Usage Guidelines

The **ip dhcp-relay information option server-override** command adds the following suboptions into the relay agent information option when DHCP broadcasts are forwarded by the relay agent from clients to a DHCP server:

- Server ID override suboption
- Link selection suboption

When this command is configured, the gateway address (giaddr) will be set to the IP address of the outgoing interface, which is the interface that is reachable by the DHCP server.

If the **ip dhcp relay information option server-id-override** command is configured on an interface, it overrides the global configuration on that interface only.

Examples

In the following example, the DHCP relay will insert the server ID override and link selection suboptions into the relay information option of the DHCP packet. The loopback interface IP address is configured to be the source IP address for the relayed messages.

```
Device(config)# ip dhcp-relay information option server-override
Device(config)# ip dhcp-relay source-interface loopback 0
Device(config)# interface Loopback 0
Device(config-if)# ip address 10.2.2.1 255.255.255.0
```

Related Commands

Command	Description
ip dhcp relay information option server-id-override	Enables the system to insert the server ID override and link selection suboptions on a specific interface into the DHCP relay agent information option in forwarded BOOTREQUEST messages to a DHCP server.

ip dhcp-relay source-interface

To globally configure the source interface for the relay agent to use as the source IP address for relayed messages, use the **ip dhcp-relay source-interface** command in global configuration mode. To remove the source interface configuration, use the **no** form of this command.

ip dhcp-relay source-interface *type number*
no ip dhcp-relay source-interface *type number*

Syntax Description

type	Interface type. For more information, use the question mark (?) online help function.
number	Interface or subinterface number. For more information about the numbering system for your networking device, use the question mark (?) online help function.

Command Default

The source interface is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Aggregation Services Routers.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
15.1(1)SY	This command was integrated into Cisco IOS Release 15.1(1)SY.

Usage Guidelines

The **ip dhcp-relay source-interface** command allows the network administrator to specify a stable, hardware-independent IP address (such as a loopback interface) for the relay agent to use as a source IP address for relayed messages.

If the **ip dhcp-relay source-interface** global configuration command is configured and the **ip dhcp relay source-interface** command is also configured, the **ip dhcp relay source-interface** command takes precedence over the global configuration command. However, the global configuration is applied to interfaces without the interface configuration.

Examples

In the following example, the loopback interface IP address is configured to be the source IP address for the relayed messages:

```
Device(config)# ip dhcp-relay source-interface loopback 0
Device(config)# interface loopback 0
Device(config-if)# ip address 10.2.2.1 255.255.255.0
```

Related Commands

Command	Description
ip dhcp relay source-interface	Configures the source interface for the relay agent to use as the source IP address for relayed messages.

ip domain lookup

To enable IP Domain Name System (DNS)-based hostname-to-address translation, use the **ip domain lookup** command in global configuration mode. To disable DNS-based hostname-to-address translation, use the **no** form of this command.

ip domain lookup [**nsap** | **recursive** | **source-interface** *interface-type-number* | **vrf** *vrf-name* { **source-interface** *interface-type-number* }]

Syntax Description

nsap	(Optional) Enables IP DNS queries for Connectionless Network Service (CLNS) and Network Service Access Point (NSAP) addresses.
recursive	(Optional) Enables IP DNS recursive lookup.
source-interface *interface-type-number*	(Optional) Specifies the source interface for the DNS resolver. Enter an interface type and number.
vrf *vrf-name*	(Optional) Defines a Virtual Routing and Forwarding (VRF) table. For vrf-name, enter a name for the VRF table.

Command Default

IP DNS-based hostname-to-address translation is enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Fuji 16.9.2	This command was introduced.
Cisco IOS XE Dublin 17.12.1	An issue relating to the configuration of the **ip domain lookup source-interface** *interface-type-number* command on Layer 3 physical interfaces was resolved. Starting from this release, even if configured on a Layer 3 physical interface, the command is retained across reloads and in case the port mode is changed.

Usage Guidelines

If this command is enabled on a device and you execute the **show tcp brief** command, the output may be displayed very slowly.

When both IP and ISO CLNS are enabled on a device, the **ip domain lookup nsap** command allows you to discover a CLNS address without having to specify a full CLNS address, given a hostname.

This command is useful for the **ping** (ISO CLNS) command, and for CLNS Telnet connections.

If you configure the **ip domain lookup source-interface** *interface-type-number* command on a Layer 3 physical interface, note the following: If the port mode is changed or in case of a device reload, the command is automatically removed from running configuration (Refer to the output of the **show running-configuration** privileged EXEC command when this happens). Removal of the command causes DNS queries that use the specified source interface, to be dropped. The only available workaround is to reconfigure the command. Starting with Cisco IOS XE Dublin 17.12.1, this issue is resolved.

Examples

The following example shows how to configure IP DNS-based hostname-to-address translation:

```
Device# configure terminal
Device(config)# ip domain lookup
Device(config)# end
```

The following example shows how to configure a source interface for the DNS domain lookup:

```
Device# configure terminal
Device(config)# ip domain lookup source-interface gigabitethernet1/0/2
Device(config)# end
```

ip domain-name

To configure the host domain on the device, use the **ip domain-name** command.

ip domain-name *domain-name* [**vrf** *vrf-name*]

Syntax Description

domain-name	Default domain name.
vrf-name	Specifies the virtual routing and forwarding (VRF) to use to resolve the domain name.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a host domain in a device:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ip domain-name domain-name
```

ip flow-export destination

To configure ETA flow export destination, use the **ip flow-export destination** command.

ip flow-export destination *ip_address port_number*

Syntax Description

port_number	Port number. The range is from 1 to 65535.

Command Default

None

Command Modes

ET-Analytics configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure ETA flow export destination in the ET-Analytics configuration mode:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# et-analytics
Device(config-et-analytics)# ip flow-export
destination 120.0.0.1 2055
Device(config-et-analytics)# end
```

ip helper-address

To enable forwarding of User Datagram Protocol (UDP) broadcasts, including Bootstrap Protocol (BOOTP), received on an interface, use the **ip helper-address** command in interface configuration mode. To disable forwarding of broadcast packets to specific addresses, use the**no** form of this command.

ip helper-address[**vrf** *name* | **global**] *address* {[**redundancy** *vrg-name*]}
no ip helper-address [**vrf** *name* | **global**] *address* {[**redundancy** *vrg-name*]}

Syntax Description

vrf *name*	(Optional) Enables the VPN routing and forwarding (VRF) instance and the VRF name.
global	(Optional) Configures a global routing table.
address	Destination broadcast or host address to be used when forwarding UDP broadcasts. There can be more than one helper address per interface.
redundancy *vrg-name*	(Optional) Defines the Virtual Router Group (VRG) name.

Command Default

UDP broadcasts are not forwarded.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
10.0	This command was introduced.
12.2(4)B	This command was modified. The **vrf** *name* keyword and argument pair and the **global** keyword were added.
12.2(15)T	This command was modified. The **redundancy** *vrg-name* keyword and argument pair was added.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **ip forward-protocol** command along with the **ip helper-address** command allows you to control broadcast packets and protocols that are forwarded.

One common application that requires helper addresses is DHCP, which is defined in RFC 1531. To enable BOOTP or DHCP broadcast forwarding for a set of clients, configure a helper address on the router interface connected to the client. The helper address must specify the address of the BOOTP or DHCP server. If you have multiple servers, configure one helper address for each server.

The following conditions must be met for a UDP or IP packet to be able to use the **ip helper-address** command:

- The MAC address of the received frame must be all-ones broadcast address (ffff.ffff.ffff).

- The IP destination address must be one of the following: all-ones broadcast (255.255.255.255), subnet broadcast for the receiving interface, or major-net broadcast for the receiving interface if the **no ip classless** command is also configured.
- The IP time-to-live (TTL) value must be at least 2.
- The IP protocol must be UDP (17).
- The UDP destination port must be for TFTP, Domain Name System (DNS), Time, NetBIOS, ND, BOOTP or DHCP packet, or a UDP port specified by the **ip forward-protocol udp** command in global configuration mode.

If the DHCP server resides in a VPN or global space that is different from the interface VPN, then the **vrf** *name* or the **global** option allows you to specify the name of the VRF or global space in which the DHCP server resides.

The **ip helper-addressvrf***name address* option uses the address associated with the VRF name regardless of the VRF of the incoming interface. If the **ip helper-addressvrf***name address* command is configured and later the VRF is deleted from the configuration, then all IP helper addresses associated with that VRF name will be removed from the interface configuration.

If the **ip helper-address** *address* command is already configured on an interface with no VRF name configured, and later the interface is configured with the **ip helper-address vrf** *name address* command, then the previously configured **ip helper-address** *address* command is considered to be global.



Note The **ip helper-address**command does not work on an X.25 interface on a destination router because the router cannot determine if the packet was intended as a physical broadcast.

The **service dhcp** command must be configured on the router to enable IP helper statements to work with DHCP. If the command is not configured, the DHCP packets will not be relayed through the IP helper statements. The **service dhcp** command is configured by default.

Examples

The following example shows how to define an address that acts as a helper address:

```
Router(config)# interface ethernet 1
Router(config-if)# ip helper-address 10.24.43.2
```

The following example shows how to define an address that acts as a helper address and is associated with a VRF named host1:

```
Router(config)# interface ethernet 1/0
Router(config-if)# ip helper-address vrf host1 10.25.44.2
```

The following example shows how to define an address that acts as a helper address and is associated with a VRG named group1:

```
Router(config)# interface ethernet 1/0
Router(config-if)# ip helper-address 10.25.45.2 redundancy group1
```

Related Commands

Command	Description
ip forward-protocol	Specifies which protocols and ports the router forwards when forwarding broadcast packets.
service dhcp	Enables the DHCP server and relay agent features on the router.

ip http authentication

To specify a particular authentication method for HTTP server users, use the **ip http authentication** command in global configuration mode. To disable a configured authentication method, use the **no** form of this command

ip http authentication { **aaa** { **command-authorization** *level list-name* | **exec-authorization** *list-name* | **login-authentication** *list-name* } | **enable** | **local** }

no ip http authentication { **aaa** { **command-authorization** *level list-name* | **exec-authorization** *list-name* | **login-authentication** *list-name* } | **enable** | **local** }

Syntax Description

aaa	Indicates that the authentication method used for the authentication, authorization, and accounting (AAA) login service should be used for authentication. The AAA login authentication method is specified by the **aaa authentication login default** command, unless otherwise specified by the **login-authentication** *listname* keyword and argument.
command-authorization	Sets the authorization method list for commands at the specified privilege level.
level	Indicates a privilege value from 0 through 15. By default, there are the following three command privilege levels on the router: **1.** 0--Includes the **disable** , **enable** , **exit** , **help** , and **logout** commands. **2.** 1--Includes all user-level commands at the device prompt (>). **3.** 15--Includes all enable-level commands at the device prompt (>).
list-name	Sets the name of the method list.
exec-authorization	Sets the method list for EXEC authorization, which applies authorization for starting an EXEC session.
login-authentication	Sets the method list for login authentication, which enables AAA authentication for logins.
enable	Indicates that the "enable" password should be used for authentication. (This is the default method.)
local	ndicates that the login user name, password and privilege level access combination specified in the local system configuration (by the **username** global configuration command) should be used for authentication and authorization.

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The **ip http authentication** command specifies the authentication method to be used for login when a client connects to the HTTP server. Use of the **aaa** option is recommended. The **enable**, **local**, and **tacacs** methods should be specified using the **aaa authentication login** command.

The “enable” password method is the default HTTP server authentication method. If the enable password is used as the HTTP server login authentication method, the client connects to the HTTP server with a default privilege level of 15.

Examples

The following example shows how to specify that AAA should be used for authentication for HTTP server users. The AAA login method is configured as the “local” username/password authentication method. This example also shows how to specify using the local username database for login authentication and EXEC authorization of HTTP sessions:

```
Device(config)# ip http authentication aaa authentication login LOCALDB local
Device(config)# aaa authorization exec LOCALDB local
Device(config)# ip http authentication aaa login-authentication LOCALDB
Device(config)# ip http authentication aaa exec-authorization LOCALDB
```

ip http auth-retry

To configure the maximum number of authentication retry attempts within a specific time-window, use the **ip http auth-retry** command.

ip http auth-retry *retry_number* **time-window** *time-in-minutes*

Syntax Description

retry_number	Specifies the maximum number of authentication retry attempts.
time-window	Retry time window in minutes.
time-in-minutes	The time window period in minutes during which the maximum number of authentication retries specified can be attempted.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the maximum number of authentication retry attempts as 5 in a time-window of 2 minutes:

```
Device# ip http auth-retry 5 time-window 2
```

ip http active-session-modules

To selectively enable HTTP applications that will service incoming HTTP requests from remote clients, use the **ip http active-session-modules** command. Use the **no** form of this command to return to the default, for which all HTTP services will be enabled.

ip http active-session-modules { *list-name* | **all** | **none** }

no ip http active-session-modules { *list-name* | **all** | **none** }

Syntax Description

list-name	Enables only those HTTP services configured in the list identified by the **ip http session-module-list** command to serve HTTP requests. All other HTTP or HTTPS applications on the controller will be disabled.
all	Enables all HTTP applications to service incoming HTTP requests from remote clients.
none	Disables all HTTP services.

Command Default

If no arguments or keywords are specified, all HTTP services are enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Use the **ip http active-session-modules** command to selectively enable HTTP applications, for servicing incoming HTTP requests from remote clients. With this command, a selected list of applications can be enabled. All the applications can be enabled or none of the applications can be enabled, in other words, all disabled. Use the **ip http session-module-list** command to define a list of HTTP or secure HTTP (HTTPS) application names to be enabled. If an HTTP request is made for a service that is disabled, a 404 error message is displayed in the remote client browser.

Examples

The following example shows how to configure a different set of services to be available for HTTP and HTTPS requests. In this example, all HTTP applications are enabled for providing services to remote clients, but for HTTPS services, only the HTTPS applications defined in list1 (Simple Certificate Enrollment Protocol [SCEP] and HOME_PAGE) are enabled:

```
Device# ip http session-module-list list1 SCEP,HOME_PAGE
ip http active-session-modules all
ip http server
ip http secure-server
ip http secure-active-session-modules list1
```

ip http client secure-ciphersuite

To specify the CipherSuite that should be used for encryption over the secure HTTP connection from the client to a remote server, use the **ip http client secure-ciphersuite** command in global configuration mode. To remove a previously configured CipherSuite specification for the client, use the **no** form of this command.

ip http client secure-ciphersuite [**3des-ede-cbc-sha**] [**rc4-128-sha**] [**rc4-128-md5**] [**des-cbc-sha**]
no ip http client secure-ciphersuite

Syntax Description

3des-ede-cbc-sha	SSL_RSA_WITH_3DES_EDE_CBC_SHA--Rivest, Shamir, and Adleman (RSA) key exchange with 3DES and DES-EDE3-CBC for message encryption and Secure Hash Algorithm (SHA) for message digest.
rc4-128-sha	SSL_RSA_WITH_RC4_128_SHA--RSA key exchange (RSA Public Key Cryptography) with RC4 128-bit encryption for message encryption and SHA for message digest.
rc4-128-md5	SSL_RSA_WITH_RC4_128_MD5--RSA key exchange (RSA Public Key Cryptography) with RC4 128-bit encryption for message encryption and Message Digest 5 (MD5) for message digest.
des-cbc-sha	SSL_RSA_WITH_DES_CBC_SHA--RSA key exchange with DES-CBC for message encryption and SHA for message digest.

Command Default

The client and server negotiate the best CipherSuite that they both support from the list of available CipherSuites.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE

Usage Guidelines

This command allows you to restrict the list of CipherSuites (encryption algorithms) that the client offers when connecting to a secure HTTP server. For example, you may want to allow only the most secure CipherSuites to be used.

Unless you have a reason to specify the CipherSuites that should be used, or you are unfamiliar with the details of these CipherSuites, you should leave this command unconfigured and let the server and client negotiate the CipherSuite that they both support (this is the default). The **no** form of this command returns the list of available CipherSuites to the default (that is, all CipherSuites supported on your device are available for negotiation).

Examples

The following example shows how to configure the HTTPS client to use only the SSL_RSA_WITH_3DES_EDE_CBC_SHA CipherSuite:

```
Router(config)# ip http client secure-ciphersuite 3des-ede-cbc-sha
```

ip http secure-ciphersuite

To specify the CipherSuites that should be used by the secure HTTP server when negotiating a connection with a remote client, use the **ip http secure-ciphersuite** command in global configuration mode. To return the configuration to the default set of CipherSuites, use the **no** form of this command.

ip http secure-ciphersuite [**3des-ede-cbc-sha**] [**rc4-128-sha**] [**rc4-128-md5**] [**des-cbc-sha**]
no ip http secure-ciphersuite

Syntax Description

3des-ede-cbc-sha	SSL_RSA_WITH_3DES_EDE_CBC_SHA--Rivest, Shamir, and Adleman (RSA) key exchange with 3DES and DES-EDE3-CBC for message encryption and Secure Hash Algorithm (SHA) for message digest.
rc4-128-sha	SSL_RSA_WITH_RC4_128_SHA --RSA key exchange (RSA Public Key Cryptography) with RC4 128-bit encryption for message encryption and SHA for message digest.
rc4-128-md5	SSL_RSA_WITH_RC4_128_MD5 --RSA key exchange (RSA Public Key Cryptography) with RC4 128-bit encryption for message encryption and Message Digest 5 (MD5) for message digest.
des-cbc-sha	SSL_RSA_WITH_DES_CBC_SHA--RSA key exchange with DES-CBC for message encryption and SHA for message digest.

Command Default

The HTTPS server negotiates the best CipherSuite using the list received from the connecting client.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE

Usage Guidelines

This command is used to restrict the list of CipherSuites (encryption algorithms) that should be used for encryption over the HTTPS connection. For example, you may want to allow only the most secure CipherSuites to be used.

Unless you have a reason to specify the CipherSuites that should be used, or you are unfamiliar with the details of these CipherSuites, you should leave this command unconfigured and let the server and client negotiate the CipherSuite that they both support (this is the default).

The supported CipherSuites vary by Cisco IOS software image. For example, “IP Sec56” (“k8”) images support only the SSL_RSA_WITH_DES_CBC_SHA CipherSuite in Cisco IOS Release 12.2(15)T.

In terms of router processing load (speed), the following list ranks the CipherSuites from fastest to slowest (slightly more processing time is required for the more secure and more complex CipherSuites):

1. SSL_RSA_WITH_DES_CBC_SHA
2. SSL_RSA_WITH_RC4_128_MD5
3. SSL_RSA_WITH_RC4_128_SHA

4. SSL_RSA_WITH_3DES_EDE_CBC_SHA

Additional information about these CipherSuites can be found online from sources that document the Secure Sockets Layer (SSL) 3.0 protocol.

Examples

The following exampleshows how to restrictsthe CipherSuites offered to a connecting secure web client:

```
Router(config)# ip http secure-ciphersuite rc4-128-sha rc4-128-md5
```

ip http secure-server

To enable a secure HTTP (HTTPS) server, enter the **ip http secure-server** command in global configuration mode. To disable the HTTPS server, use the **no** form of this command..

ip http secure-server
no ip http secure-server

Syntax Description

This command has no arguments or keywords.

Command Default

The HTTPS server is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The HTTPS server uses the Secure Sockets Layer (SSL) version 3.0 protocol.

Caution When enabling an HTTPS server, you should always disable the standard HTTP server to prevent unsecured connections to the same services. Disable the standard HTTP server using the **no ip http server** command in global configuration mode (this step is precautionary; typically, the HTTP server is disabled by default).

If a certificate authority (CA) is used for certification, you should declare the CA trustpoint on the routing device before enabling the HTTPS server.

To close HTTP/TCP port 8090, you must disable both the HTTP and HTTPS servers. Enter the **no http server** and the **no http secure-server** commands, respectively.

Examples

In the following example the HTTPS server is enabled, and the (previously configured) CA trustpoint CA-trust-local is specified:

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#ip http secure-server
Device(config)#ip http secure-trustpoint CA-trust-local
Device(config)#end

Device#show ip http server secure status
HTTP secure server status: Enabled
HTTP secure server port: 443
HTTP secure server ciphersuite: 3des-ede-cbc-sha des-cbc-sha rc4-128-md5 rc4-12a
HTTP secure server client authentication: Disabled
HTTP secure server trustpoint: CA-trust-local
```

Related Commands

Command	Description
ip http secure-trustpoint	Specifies the CA trustpoint that should be used for obtaining signed certificates for the HTTPS server.
ip http server	Enables the HTTP server on an IP or IPv6 system, including the Cisco web browser user interface.
show ip http server secure status	Displays the configuration status of the HTTPS server.

ip http server

To enable the HTTP server on your IP or IPv6 system, including the Cisco web browser user interface, enter the **ip http server** command in global configuration mode. To disable the HTTP server, use the **no** form of this command..

ip http server
no ip http server

Syntax Description

This command has no arguments or keywords.

Command Default

The HTTP server uses the standard port 80 by default.

HTTP/TCP port 8090 is open by default.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The command enables both IPv4 and IPv6 access to the HTTP server. However, an access list configured with the **ip http access-class** command is applied only to IPv4 traffic. IPv6 traffic filtering is not supported.



Caution The standard HTTP server and the secure HTTP (HTTPS) server can run on a system at the same time. If you enable the HTTPS server using the **ip http secure-server** command, disable the standard HTTP server using the **no ip http server** command to ensure that secure data cannot be accessed through the standard HTTP connection.

To close HTTP/TCP port 8090, you must disable both the HTTP and HTTPS servers. Enter the **no http server** and the **no http secure-server** commands, respectively.

Examples

The following example shows how to enable the HTTP server on both IPv4 and IPv6 systems.

After enabling the HTTP server, you can set the base path by specifying the location of the HTML files to be served. HTML files used by the HTTP web server typically reside in system flash memory. Remote URLs can be specified using this command, but use of remote path names (for example, where HTML files are located on a remote TFTP server) is not recommended.

```
Device(config)#ip http server
Device(config)#ip http path flash:
```

Related Commands

Command	Description
ip http access-class	Specifies the access list that should be used to restrict access to the HTTP server.
ip http path	Specifies the base path used to locate files for use by the HTTP server.

Command	Description
ip http secure-server	Enables the HTTPS server.

ip http session-module-list

To define a list of HTTP or secure HTTP application names, use the **ip http session-module-list** command in global configuration mode. To remove the defined list, use the **no** form of this command.

ip http session-module-list *listname prefix1* [*prefix2,...prefixn*]

no ip http session-module-list *listname prefix1* [*prefix2,...prefixn*]

Syntax Description

listname	Name of the list.
prefix 1	Associated HTTP or HTTPS application names. Prefix strings represent the names of applications, for example, SCEP, WEB_EXEC or HOME_PAGE.
prefix2,...prefixn	(Optional) Additional associated HTTP or HTTPS application names. Each application is separated by a comma.

Command Default

No list of HTTP or HTTPS application names is defined.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Use this command to define a list of HTTP or HTTPS application names. The defined list can then be used by the **ip http active-session-modules** or **ip http secure-active-session-modules** commands to selectively enable HTTP or HTTPS applications, respectively, for servicing incoming HTTP and HTTPS requests from remote clients.

When defining a list of HTTP or HTTPS application names, use the following guidelines:

- A maximum of four lists can be defined on a controller. Attempts to define more than four lists will fail and an error message will be displayed stating the limit restrictions.
- An existing list can be removed using the **no ip http session-module-list** command.
- You cannot reconfigure an existing list. Instead of reconfiguring an existing list, remove the existing list and create a new list with the same name.
- There is no limit to how many application names can be in the list. However, the maximum number of sessions that can be registered with the Cisco IOS HTTP or HTTPS server is 32.

Examples

The following example shows how to configure a different set of services to be available for HTTP and HTTPS requests. In this example, all HTTP applications are enabled for providing services to remote clients, but for HTTPS services, only the HTTPS applications defined in list1 (Simple Certificate Enrollment Protocol [SCEP] and HOME_PAGE) are enabled:

```
Device# ip http session-module-list list1 SCEP,HOME_PAGE
Device# ip http active-session-modules all
```

```
Device# ip http server
Device# ip http secure-server
Device# ip http secure-active-session-modules list1
```

ip ssh

To configure Secure Shell (SSH) control parameters on your router, use the **ip ssh** command in global configuration mode. To restore the default value, use the **no** form of this command.

ip ssh [**timeout** *seconds* | **authentication-retries** *integer*]
no ip ssh [**timeout** *seconds* | **authentication-retries** *integer*]

Syntax Description

timeout	(Optional) The time interval that the router waits for the SSH client to respond. This setting applies to the SSH negotiation phase. Once the EXEC session starts, the standard timeouts configured for the vty apply. By default, there are 5 vtys defined (0-4), therefore 5 terminal sessions are possible. After the SSH executes a shell, the vty timeout starts. The vty timeout defaults to 10 minutes.
seconds	(Optional) The number of seconds until timeout disconnects, with a maximum of 120 seconds. The default is 120 seconds.
authentication- retries	(Optional) The number of attempts after which the interface is reset.
integer	(Optional) The number of retries, with a maximum of 5 authentication retries. The default is 3.

Command Default

SSH control parameters are set to default router values.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(1)T	This command was integrated into Cisco IOS Release 12.1(1) T.
12.2(17a)SX	This command was integrated into Cisco IOS Release 12.2(17a)SX.
12.2(33)SRA	This command was integrated into Cisco IOS release 12.(33)SRA.
Cisco IOS XE Release 2.4	This command was implemented on the Cisco ASR 1000 series routers.

Usage Guidelines

Before you configure SSH on your router, you must enable the SSH server using the **crypto key generate rsa**command.

Examples

The following examples configure SSH control parameters on your router:

```
ip ssh timeout 120
ip ssh authentication-retries 3
```

ip ssh version

To specify the version of Secure Shell (SSH) to be run on a router, use the **ip ssh version**command in global configuration mode. To disable the version of SSH that was configured and to return to compatibility mode, use the **no** form of this command.

ip ssh version [**1** | **2**]
no ip ssh version [**1** | **2**]

Syntax Description

1	(Optional) Router runs only SSH Version 1.
2	(Optional) Router runs only SSH Version 2.

Command Default

If this command is not configured, SSH operates in compatibility mode, that is, Version 1 and Version 2 are both supported.

Command Modes

Global configuration

Command History

Release	Modification
12.3(4)T	This command was introduced.
12.3(2)XE	This command was integrated into Cisco IOS Release 12.3(2)XE.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.3(7)JA	This command was integrated into Cisco IOS Release 12.3(7)JA.
12.0(32)SY	This command was integrated into Cisco IOS Release 12.0(32)SY.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

Usage Guidelines

You can use this command with the **2** keyword to ensure that your router will not inadvertently establish a weaker SSH Version 1 connection.

Examples

The following example shows that only SSH Version 1 support is configured:

```
Router (config)# ip ssh version 1
```

The following example shows that only SSH Version 2 is configured:

```
Router (config)# ip ssh version 2
```

The following example shows that SSH Versions 1 and 2 are configured:

```
Router (config)# no ip ssh version
```

Related Commands

Command	Description
debug ip ssh	Displays debug messages for SSH.
disconnect ssh	Terminates a SSH connection on your router.
ip ssh	Configures SSH control parameters on your router.
ip ssh rsa keypair-name	Specifies which RSA key pair to use for a SSH connection.
show ip ssh	Displays the SSH connections of your router.

ip tftp blocksize

To specify TFTP client blocksize, use the **ip tftp blocksize** command.

ip tftp blocksize *blocksize-value*

Syntax Description

blocksize-value	Blocksize value. Valid range is from 512-8192 Kbps.

Command Default

TFTP client blocksize is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Use this command to change the default blocksize to decrease the image download time.

Example

The following example shows how to specify TFTP client blocksize:

```
Device(config)# ip tftp blocksize 512
```

ip verify source

To enable IP source guard on an interface, use the **ip verify source** command in interface configuration mode. To disable IP source guard, use the **no** form of this command.

ip verify source
no ip verify source

Command Default

IP source guard is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

To enable IP source guard with source IP address filtering, use the **ip verify source** interface configuration command.

Examples

This example shows how to enable IP source guard with source IP address filtering on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip verify source
```

You can verify your settings by entering the **show ip verify source** privileged EXEC command.

ipv4 acl

To create ACL configuration for wireless IPv4, use the **ipv4 acl** command.

configuration.

ipv4 acl *ipv4-acl-name*

Syntax Description

ipv4 acl	Creates ACL configuration for wireless IPv4.
ipv4-acl-name	Specifies the IPv4 ACL name.

Command Default

None

Command Modes

Wireless policy confirguration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to create an ACL configuration for wireless IPv4:

```
Device(config-wireless-policy)#ipv4 acl ipv4-acl-name
```

ipv4 dhcp

To configure the DHCP parameters for a WLAN, use the **ipv4 dhcp** command.

ipv4 dhcp {**opt82** | {**ascii** | **rid** | **format** | {**ap_ethmac** | **ap_location** | **apmac** | **apname** | **policy_tag** | **ssid** | **vlan_id** }} | **required** | **server** *dhcp-ip-addr*}

Syntax Description

opt82	Sets DHCP option 82 for wireless clients on this WLAN
required	Specifies whether DHCP address assignment is required
server	Configures the WLAN's IPv4 DHCP Server
ascii	Supports ASCII for DHCP option 82
rid	Supports adding Cisco 2 byte RID for DHCP option 82
format	Sets RemoteID format
ap_ethmac	Enables DHCP AP Ethernet MAC address
ap_location	Enables AP location
apmac	Enables AP MAC address
apname	Enables AP name
site_tag (Policy tag)	Enables Site tag
ssid	Enables SSID
vlan_id	Enables VLAN ID
dhcp-ip-addr	Enter the override DHCP server's IP Address.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure DHCP address assignment as a requirement:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy demo-profile-name
Device(config-wireless-policy)# ipv4 dhcp required
```

ipv4 flow monitor

To configure the IPv4 traffic ingress flow monitor for a WLAN profile policy, use the **ipv4 flow monitor input** command.

ipv4 flow monitor *monitor-name* **input**

Syntax Description

monitor-name	Flow monitor name.
input	Enables flow monitor on ingress traffic.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the IPv4 traffic ingress flow monitor for a WLAN profile policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy policy-profile-name
Device(config-wireless-policy)# ipv4 flow monitor flow-monitor-name input
```

ipv4 flow monitor output

To configure the IPv4 traffic egress flow monitor for a WLAN profile policy, use the **ipv4 flow monitor output** command.

ipv4 flow monitor *monitor-name* **output**

Syntax Description

monitor-name	Flow monitor name.
output	Enables flow monitor on egress traffic.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.2.1.

Examples

The following example shows how to configure the IPv4 traffic egress flow monitor for a WLAN profile policy:

```
Device(config-wireless-policy)#ipv4 flow monitor flow-monitor-name output
```

ipv6 flow monitor input

To configure the IPv6 traffic ingress flow monitor for a WLAN profile policy, use the **ipv6 flow monitor input** command.

ipv6 flow monitor *monitor-name* **input**

Syntax Description

monitor-name	Flow monitor name.
input	Enables flow monitor on ingress traffic.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.2.1.

Examples

The following example shows how to configure the IPv6 traffic ingress flow monitor for a WLAN profile policy:

```
Device(config-wireless-policy)#ipv6 flow monitor flow-monitor-name input
```

ipv6 flow monitor output

To configure the IPv6 traffic egress flow monitor for a WLAN profile policy, use the **ipv6 flow monitor output** command.

ipv6 flow monitor *monitor-name* **output**

Syntax Description

monitor-name	Flow monitor name.
output	Enables flow monitor on egress traffic.

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.2.1.

Examples

The following example shows how to configure the IPv6 traffic egress flow monitor for a WLAN profile policy:

```
Device(config-wireless-policy)#ipv6 flow monitor flow-monitor-name output
```

ipv6 access-list

To define an IPv6 access list and to place the device in IPv6 access list configuration mode, use the **ipv6 access-list** command in global configuration mode. To remove the access list, use the **no** form of this command.

ipv6 access-list *access-list-name* | **match-local-traffic** | **log-update threshold** *threshold-in-msgs* | **role-based** *list-name*
noipv6 access-list *access-list-name* | **client** *permit-control-packets* | **log-update** *threshold* | **role-based** *list-name*

Syntax Description

ipv6 *access-list-name*	Creates a named IPv6 ACL (up to 64 characters in length) and enters IPv6 ACL configuration mode. *access-list-name* - Name of the IPv6 access list. Names cannot contain a space or quotation mark, or begin with a numeric.
match-local-traffic	Enables matching for locally-generated traffic.
log-update threshold *threshold-in-msgs*	Determines how syslog messages are generated after the initial packet match. *threshold-in-msgs*- Number of packets generated.
role-based *list-name*	Creates a role-based IPv6 ACL.

Command Default

No IPv6 access list is defined.

Command Modes

Global configuration

Command History

Release	Modification

Usage Guidelines

IPv6 ACLs are defined by using the **ipv6 access-list**command in global configuration mode and their permit and deny conditions are set by using the **deny** and **permit**commands in IPv6 access list configuration mode. Configuring the **ipv6 access-list**command places the device in IPv6 access list configuration mode--the device prompt changes to Device(config-ipv6-acl)#. From IPv6 access list configuration mode, permit and deny conditions can be set for the defined IPv6 ACL.

Note IPv6 ACLs are defined by a unique name (IPv6 does not support numbered ACLs). An IPv4 ACL and an IPv6 ACL cannot share the same name.

IPv6 is automatically configured as the protocol type in **permit any any** and **deny any any** statements that are translated from global configuration mode to IPv6 access list configuration mode.

Every IPv6 ACL has implicit **permit icmp any any nd-na**, **permit icmp any any nd-ns**, and **deny ipv6 any any** statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.) An IPv6 ACL must contain at least one entry for the implicit **deny ipv6 any any** statement to take effect. The IPv6 neighbor discovery process makes use of the IPv6 network layer service; therefore, by default,

IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, makes use of a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

Use the **ipv6 traffic-filter** interface configuration command with the *access-list-name* argument to apply an IPv6 ACL to an IPv6 interface. Use the **ipv6 access-class** line configuration command with the *access-list-name* argument to apply an IPv6 ACL to incoming and outgoing IPv6 virtual terminal connections to and from the device.

An IPv6 ACL applied to an interface with the **ipv6 traffic-filter** command filters traffic that is forwarded, not originated, by the device.

Examples

The example configures the IPv6 ACL list named list1 and places the device in IPv6 access list configuration mode.

```
Device(config)# ipv6 access-list list1
Device(config-ipv6-acl)#
```

The following example configures the IPv6 ACL named list2 and applies the ACL to outbound traffic on Ethernet interface 0. Specifically, the first ACL entry keeps all packets from the network FEC0:0:0:2::/64 (packets that have the site-local prefix FEC0:0:0:2 as the first 64 bits of their source IPv6 address) from exiting out of Ethernet interface 0. The second entry in the ACL permits all other traffic to exit out of Ethernet interface 0. The second entry is necessary because an implicit deny all condition is at the end of each IPv6 ACL.

```
Device(config)# ipv6 access-list list2 deny FEC0:0:0:2::/64 any
Device(config)# ipv6 access-list list2 permit any any
Device(config)# interface ethernet 0
Device(config-if)# ipv6 traffic-filter list2 out
```

ipv6 acl

To create ACL configuration for wireless IPv6, use the **ipv6 acl** command.

configuration.

ipv6 acl *ipv6-acl-name*

Syntax Description

ipv6 acl	Creates ACL configuration for wireless IPv6.
ipv6-acl-name	Specifies the IPv6 ACL name.

Command Default

None

Command Modes

Wireless policy confirguration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to create an ACL configuration for wireless IPv6:

```
Device(config-wireless-policy)#ipv6 acl ipv6-acl-name
```

ipv6-address-type

To configure the 802.11u IPv6 address type, use the **ipv6-address-type** command. To remove the address type, use the **no** form of the command.

ipv6-address-type {**available** | **not-available** | **not-known**}

Syntax Description

available	Sets IPv6 address type as available.
not-available	Sets IPv6 address type as not available.
not-known	Sets IPv6 address type availability as not known.

Command Default

None

Command Modes

Wireless ANQP Server Configuration (config-wireless-anqp-server)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to configure a 802.11u IPv6 address type:

```
Device(config)# wireless hotspot anqp-server my-server
Device(config-wireless-anqp-server)# ipv4-address-type available
```

ipv6 address

To configure an IPv6 address based on an IPv6 general prefix and enable IPv6 processing on an interface, use the **ipv6 address**command in interface configuration mode. To remove the address from the interface, use the **no** form of this command.

ipv6 address {*ipv6-prefix/prefix-length* | *prefix-name sub-bits/prefix-length*}
no ipv6 address {*ipv6-address/prefix-length* | *prefix-name sub-bits/prefix-length*}

Syntax Description

ipv6-address	The IPv6 address to be used.
/ *prefix-length*	The length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.
prefix-name	A general prefix, which specifies the leading bits of the network to be configured on the interface.
sub-bits	The subprefix bits and host bits of the address to be concatenated with the prefixes provided by the general prefix specified with the *prefix-name* argument. The *sub-bits*argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.

Command Default

No IPv6 addresses are defined for any interface.

Command Modes

Interface configuration

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(25)SG	This command was integrated into Cisco IOS Release 12.2(25)SG.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE Release 2.1	This command was integrated into Cisco ASR 1000 Series devices.
15.2(4)S	This command was integrated into Cisco IOS Release 15.2(4)S.
15.2(2)SNG	This command was implemented on the Cisco ASR 901 Series Aggregation Services devices.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

The **ipv6 address** command allows multiple IPv6 addresses to be configured on an interface in various different ways, with varying options. The most common way is to specify the IPv6 address with the prefix length.

Addresses may also be defined using the general prefix mechanism, which separates the aggregated IPv6 prefix bits from the subprefix and host bits. In this case, the leading bits of the address are defined in a general prefix, which is globally configured or learned (for example, through use of Dynamic Host Configuration Protocol-Prefix Delegation (DHCP-PD)), and then applied using the *prefix-name* argument. The subprefix bits and host bits are defined using the *sub-bits* argument.

Using the **no ipv6 address autoconfig** command without arguments removes all IPv6 addresses from an interface.

IPv6 link-local addresses must be configured and IPv6 processing must be enabled on an interface by using the **ipv6 address link-local** command.

Examples

The following example shows how to enable IPv6 processing on the interface and configure an address based on the general prefix called my-prefix and the directly specified bits:

```
Device(config-if) ipv6 address my-prefix 0:0:0:7272::72/64
```

Assuming the general prefix named my-prefix has the value of 2001:DB8:2222::/48, then the interface would be configured with the global address 2001:DB8:2222:7272::72/64.

Related Commands

Command	Description
ipv6 address anycast	Configures an IPv6 anycast address and enables IPv6 processing on an interface.
ipv6 address eui-64	Configures an IPv6 address and enables IPv6 processing on an interface using an EUI-64 interface ID in the low-order 64 bits of the address.
ipv6 address link-local	Configures an IPv6 link-local address for an interface and enables IPv6 processing on the interface.
ipv6 unnumbered	Enables IPv6 processing on an interface without assigning an explicit IPv6 address to the interface.
no ipv6 address autoconfig	Removes all IPv6 addresses from an interface.
show ipv6 interface	Displays the usability status of interfaces configured for IPv6.

ipv6 dhcp pool

To configure a Dynamic Host Configuration Protocol (DHCP) for IPv6 server configuration information pool and enter DHCP for IPv6 pool configuration mode, use the **ipv6 dhcp pool** command in global configuration mode. To delete a DHCP for IPv6 pool, use the **no** form of this command.

ipv6 dhcp pool *poolname*
no ipv6 dhcp pool *poolname*

Syntax Description

poolname	User-defined name for the local prefix pool. The pool name can be a symbolic string (such as "Engineering") or an integer (such as 0).

Command Default

DHCP for IPv6 pools are not configured.

Command Modes

Global configuration

Command History

Release	Modification
12.3(4)T	This command was introduced.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.4(24)T	This command was integrated into Cisco IOS Release 12.4(24)T.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)XNE.

Usage Guidelines

Use the **ipv6 dhcp pool**command to create a DHCP for IPv6 server configuration information pool. When the **ipv6 dhcp pool** command is enabled, the configuration mode changes to DHCP for IPv6 pool configuration mode. In this mode, the administrator can configure pool parameters, such as prefixes to be delegated and Domain Name System (DNS) servers, using the following commands:

- **address prefix** *IPv6-prefix* [**lifetime** {*valid-lifetime preferred-lifetime* | **infinite**}]sets an address prefix for address assignment. This address must be in hexadecimal, using 16-bit values between colons.
- **link-address** *IPv6-prefix* sets a link-address IPv6 prefix. When an address on the incoming interface or a link-address in the packet matches the specified IPv6-prefix, the server uses the configuration information pool. This address must be in hexadecimal, using 16-bit values between colons.
- **vendor-specific** *vendor-id* enables DHCPv6 vendor-specific configuration mode. Specify a vendor identification number. This number is the vendor IANA Private Enterprise Number. The range is 1 to 4294967295. The following configuration command is available:
  - **suboption** *number* sets vendor-specific suboption number. The range is 1 to 65535. You can enter an IPv6 address, ASCII text, or a hex string as defined by the suboption parameters.

Note The **hex** value used under the **suboption** keyword allows users to enter only hex digits (0-f). Entering an invalid **hex** value does not delete the previous configuration.

Once the DHCP for IPv6 configuration information pool has been created, use the **ipv6 dhcp server** command to associate the pool with a server on an interface. If you do not configure an information pool, you need to use the **ipv6 dhcp server interface** configuration command to enable the DHCPv6 server function on an interface.

When you associate a DHCPv6 pool with an interface, only that pool services requests on the associated interface. The pool also services other interfaces. If you do not associate a DHCPv6 pool with an interface, it can service requests on any interface.

Not using any IPv6 address prefix means that the pool returns only configured options.

The **link-address** command allows matching a link-address without necessarily allocating an address. You can match the pool from multiple relays by using multiple link-address configuration commands inside a pool.

Since a longest match is performed on either the address pool information or the link information, you can configure one pool to allocate addresses and another pool on a subprefix that returns only configured options.

Examples

The following example specifies a DHCP for IPv6 configuration information pool named cisco1 and places the router in DHCP for IPv6 pool configuration mode:

```
Router(config)# ipv6 dhcp pool cisco1
Router(config-dhcpv6)#
```

The following example shows how to configure an IPv6 address prefix for the IPv6 configuration pool cisco1:

```
Router(config-dhcpv6)# address prefix 2001:1000::0/64
Router(config-dhcpv6)# end
```

The following example shows how to configure a pool named engineering with three link-address prefixes and an IPv6 address prefix:

```
Router# configure terminal
Router(config)# ipv6 dhcp pool engineering
Router(config-dhcpv6)# link-address 2001:1001::0/64
Router(config-dhcpv6)# link-address 2001:1002::0/64
Router(config-dhcpv6)# link-address 2001:2000::0/48
Router(config-dhcpv6)# address prefix 2001:1003::0/64
Router(config-dhcpv6)# end
```

The following example shows how to configure a pool named 350 with vendor-specific options:

```
Router# configure terminal
Router(config)# ipv6 dhcp pool 350
Router(config-dhcpv6)# vendor-specific 9
Router(config-dhcpv6-vs)# suboption 1 address 1000:235D::1
Router(config-dhcpv6-vs)# suboption 2 ascii "IP-Phone"
Router(config-dhcpv6-vs)# end
```

Related Commands

Command	Description
ipv6 dhcp server	Enables DHCP for IPv6 service on an interface.
show ipv6 dhcp pool	Displays DHCP for IPv6 configuration pool information.

ipv6 enable

To enable IPv6 processing on an interface that has not been configured with an explicit IPv6 address, use the **ipv6 enable**command in interface configuration mode. To disable IPv6 processing on an interface that has not been configured with an explicit IPv6 address, use the **no** form of this command.

ipv6 enable
no ipv6 enable

Syntax Description

This command has no arguments or keywords.

Command Default

IPv6 is disabled.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(25)SG	This command was integrated into Cisco IOS Release 12.2(25)SG.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
15.2(2)SNG	This command was implemented on the Cisco ASR 901 Series Aggregation Services devices.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

Usage Guidelines

The **ipv6 enable**command automatically configures an IPv6 link-local unicast address on the interface while also enabling the interface for IPv6 processing. The no **ipv6 enable**command does not disable IPv6 processing on an interface that is configured with an explicit IPv6 address.

Examples

The following example enables IPv6 processing on Ethernet interface 0/0:

```
Device(config)# interface ethernet 0/0
Device(config-if)# ipv6 enable
```

Related Commands

Command	Description
ipv6 address link-local	Configures an IPv6 link-local address for an interface and enables IPv6 processing on the interface.
ipv6 address eui-64	Configures an IPv6 address and enables IPv6 processing on an interface using an EUI-64 interface ID in the low-order 64 bits of the address.
ipv6 unnumbered	Enables IPv6 processing on an interface without assigning an explicit IPv6 address to the interface.
show ipv6 interface	Displays the usability status of interfaces configured for IPv6.

ipv6 mld snooping

To enable Multicast Listener Discovery version 2 (MLDv2) protocol snooping globally, use the **ipv6 mld snooping** command in global configuration mode. To disable the MLDv2 snooping globally, use the **no** form of this command.

ipv6 mld snooping
no ipv6 mld snooping

Syntax Description

This command has no arguments or keywords.

Command Default

This command is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.2(18)SXE	This command was introduced on the Supervisor Engine 720.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
15.4(2)S	This command was implemented on the Cisco ASR 901 Series Aggregation Services Router.

Usage Guidelines

MLDv2 snooping is supported on the Supervisor Engine 720 with all versions of the Policy Feature Card 3 (PFC3).

To use MLDv2 snooping, configure a Layer 3 interface in the subnet for IPv6 multicast routing or enable the MLDv2 snooping querier in the subnet.

Examples

This example shows how to enable MLDv2 snooping globally:

```
Router(config)# ipv6 mld snooping
```

Related Commands

Command	Description
show ipv6 mld snooping	Displays MLDv2 snooping information.

ipv6 nd managed-config-flag

To set the managed address configuration flag in IPv6 router advertisements, use the **ipv6 nd managed-config-flag** command in an appropriate configuration mode. To clear the flag from IPv6 router advertisements, use the **no** form of this command.

ipv6 nd managed-config-flag
no ipv6 nd managed-config-flag

Syntax Description

This command has no keywords or arguments.

Command Default

The managed address configuration flag is not set in IPv6 router advertisements.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Setting the managed address configuration flag in IPv6 router advertisements indicates to attached hosts whether they should use stateful autoconfiguration to obtain addresses. If the flag is set, the attached hosts should use stateful autoconfiguration to obtain addresses. If the flag is not set, the attached hosts should not use stateful autoconfiguration to obtain addresses.

Hosts may use stateful and stateless address autoconfiguration simultaneously.

Examples

This example shows how to configure the managed address configuration flag in IPv6 router advertisements:

```
Device(config)# interface
Device(config-if)# ipv6 nd managed-config-flag
```

ipv6 nd other-config-flag

To set the other stateful configuration flag in IPv6 router advertisements, use the **ipv6 nd other-config-flag** command in an appropriate configuration mode. To clear the flag from IPv6 router advertisements, use the **no** form of this command.

ipv6 nd other-config-flag

Syntax Description

This command has no keywords or arguments.

Command Default

The other stateful configuration flag is not set in IPv6 router advertisements.

Command Modes

Interface configuration

Dynamic template configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The setting of the other stateful configuration flag in IPv6 router advertisements indicates to attached hosts how they can obtain autoconfiguration information other than addresses. If the flag is set, the attached hosts should use stateful autoconfiguration to obtain the other (nonaddress) information.

Note If the managed address configuration flag is set using the **ipv6 nd managed-config-flag** command, then an attached host can use stateful autoconfiguration to obtain the other (nonaddress) information regardless of the setting of the other stateful configuration flag.

Examples

This example (not applicable for BNG) configures the “other stateful configuration” flag in IPv6 router advertisements:

```
Device(config)# interface
Device(config-if)# ipv6 nd other-config-flag
```

ipv6 nd ra throttler attach-policy

To configure a IPv6 policy for feature RA throttler, use the **ipv6 nd ra-throttler attach-policy** command.

ipv6 nd ra-throttler attach-policy *policy-name*

Syntax Description

ipv6	IPv6 root chain.
ra-throttler	Configure RA throttler on the VLAN.
attach-policy	Apply a policy for feature RA throttler.
policy-name	Policy name for feature RA throttler

Command Default

None

Command Modes

config-vlan

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure configure a IPv6 policy for feature RA throttler:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# vlan configuration vlan-id
Device(config-vlan-config)# ipv6 nd ra-throttler attach-policy
```

ipv6 nd raguard policy

To define the router advertisement (RA) guard policy name and enter RA guard policy configuration mode, use the **ipv6 nd raguard policy** command in global configuration mode.

ipv6 nd raguardpolicy *policy-name*

Syntax Description

policy-name	IPv6 RA guard policy name.

Command Default

An RA guard policy is not configured.

Command Modes

Global configuration (config)#

Command History

Release	Modification
12.2(50)SY	This command was introduced.
15.2(4)S	This command was integrated into Cisco IOS Release 15.2(4)S.
15.0(2)SE	This command was integrated into Cisco IOS Release 15.0(2)SE.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Use the **ipv6 nd raguard policy** command to configure RA guard globally on a router. Once the device is in ND inspection policy configuration mode, you can use any of the following commands:

- **device-role**
- **drop-unsecure**
- **limit address-count**
- **sec-level minimum**
- **trusted-port**
- **validate source-mac**

After IPv6 RA guard is configured globally, you can use the **ipv6 nd raguard attach-policy** command to enable IPv6 RA guard on a specific interface.

Examples

The following example shows how to define the RA guard policy name as policy1 and place the device in policy configuration mode:

```
Device(config)# ipv6 nd raguard policy policy1
Device(config-ra-guard)#
```

Related Commands

Table 8:

Command	Description
device-role	Specifies the role of the device attached to the port.
drop-unsecure	Drops messages with no or invalid options or an invalid signature.
ipv6 nd raguard attach-policy	Applies the IPv6 RA guard feature on a specified interface.
limit address-count	Limits the number of IPv6 addresses allowed to be used on the port.
sec-level minimum	Specifies the minimum security level parameter value when CGA options are used.
trusted-port	Configures a port to become a trusted port.
validate source-mac	Checks the source MAC address against the link layer address.

ipv6 traffic-filter

This command enables IPv6 traffic filter.

To enable the filtering of IPv6 traffic on an interface, use the **ipv6 traffic-filter** command. To disable the filtering of IPv6 traffic on an interface, use the **no** form of the command.

Use the **ipv6 traffic-filter** interface configuration command on the switch stack or on a standalone switch to filter IPv6 traffic on an interface. The type and direction of traffic that you can filter depends on the feature set running on the switch stack. Use the **no** form of this command to disable the filtering of IPv6 traffic on an interface.

ipv6 traffic-filter [**web**] *acl-name*
no ipv6 traffic-filter [**web**]

Syntax Description

web	(Optional) Specifies an IPv6 access name for the WLAN Web ACL.
acl-name	Specifies an IPv6 access name.

Command Default

Filtering of IPv6 traffic on an interface is not configured.

Command Modes

wlan

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

To configure the dual IPv4 and IPv6 template, enter the **sdm prefer dual-ipv4-and-ipv6 {default | vlan}** global configuration command and reload the switch.

You can use the **ipv6 traffic-filter** command on physical interfaces (Layer 2 or Layer 3 ports), Layer 3 port channels, or switch virtual interfaces (SVIs).

You can apply an ACL to outbound or inbound traffic on Layer 3 interfaces (port ACLs), or to inbound traffic on Layer 2 interfaces (router ACLs).

If **any** port ACL (IPv4, IPv6, or MAC) is applied to an interface, that port ACL is used to filter packets, and any router ACLs attached to the SVI of the port VLAN are ignored.

This example shows how to filter IPv6 traffic on an interface:

```
Device(config-wlan)# ipv6 traffic-filter TestDocTrafficFilter
```

key chain

To create or modify a keychain, use the **key chain** command. To disable this feature, use the **no** form of this command.

key chain*key-chain name* { **macsec** | **tcp** }
no key chain*key-chain name* { **macsec** | **tcp** }

Syntax Description

key-chain name	Specifies the name of the key chain.
macsec	Specifies a MacSEC key chain.
tcp	Specifies the tcp key chain.

Command Default

No default.

Command Modes

Global configuration mode.

Examples

The following example shows how to specify a key chain to identify authentication on a key-chain:

```
Device(config)# key chain key-chain-name macsec
```

Related Commands

Command	Description
key config-key	Sets a private configuration key for general use.
show key chain	Displays authentication key information.

key config-key

To set a private configuration key for private use, use the **key config-key** command. To disable this feature, use the **no** form of this command.

key config-key { **1 LINE** | **newpass** *config-key* | **password-encrypt LINE** }
no key config-key { **1 LINE** | **newpass** *config-key* | **password-encrypt LINE** }

Syntax Description

1	Sets a private configuration key for private use.
newpass	Specifies a new password without space or tabs.
config-key	Specifies the config key, with a minimum of 8 characters, and not beginning with the IOS special characters - !, #, and ;.
password-encrypt	Sets a private configuration key for password encryption.

Command Default

None

Command Modes

Global configuration mode.

Examples

The following example shows how to specify a config-key:

```
Device(config)# key config-key password-encrypt config-key
```

key config-key password-encrypt

To set a private configuration key for password encryption, use the **key config-key password-encrypt** command. To disable this feature, use the **no** form of this command.

key config-key password-encrypt <*config-key*>

Syntax Description

config-key	Enter a value with minimum 8 characters. **Note** The value must not begin with the following special characters: !, #, and ;

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.6.1	This command was introduced.

Examples

The following example shows how to set a username and password for AP management:

```
Device# enable
Device# configure terminal
Device(config)# key config-key password-encryption 12345678
Device(config-ap-profile)# password encryption aes
Device(config-ap-profile)# end
```

license air level

To configure AIR licenses on a wireless controller, enter the **license air level** command in global configuration mode. To revert to the default setting, use the **no** form of this command.

license air level { **air-network-advantage** [**addon air-dna-advantage**] | **air-network-essentials** [**addon air-dna-essentials**] }

no license air level

Syntax Description

air-network-advantage	Configures the AIR Network Advantage license level.
addon air-dna-advantage	(Optional) Configures the add-on AIR DNA Advantage license level. This add-on option is available with the AIR Network Advantage license.
air-network-essentials	Configures the AIR Network Essentials license level.
addon air-dna-essentials	(Optional) Configures the add-on AIR DNA Essentials license level. This add-on option is available with the AIR Network Essential license.

Command Default

For all Cisco Catalyst 9800 Wireless controllers the default license is AIR DNA Advantage.

For EWC-APs:

- Prior to Cisco IOS XE Bengaluru 17.4.1, the default license is AIR DNA Essentials.
- Starting with Cisco IOS XE Bengaluru 17.4.1, the default license is AIR Network Essentials

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available and applicable with the introduction of Smart Licensing Using Policy.
Cisco IOS XE Bengaluru 17.4.1	Only for EWC-APs, the default license was changed from AIR DNA Essentials to AIR Network Essentials.

Usage Guidelines

In the Smart Licensing Using Policy environment, you can use the **license air level** command to change the license level being used on the product instance, or to additionally configure an add-on license on the product instance. The change is effective after a reload.

The licenses that can be configured are:

- AIR Network Essential
- AIR Network Advantage
- AIR DNA Essential

- AIR DNA Advantage

You can configure AIR DNA Essential or AIR DNA Advantage license level and on term expiry, you can move to the Network Advantage or Network Essentials license level, if you do not want to renew the DNA license.

Every connecting AP requires a Cisco DNA Center License to leverage the unique value properties of the controller.

Specifics for EWC-APs

Starting with Cisco IOS XE Bengaluru 17.4.1, *only for EWC-APs*, you can opt-out of purchasing an AIR DNA license. The option to opt-out of AIR DNA licenses is available only through the Cisco Commerce portal. When you opt-out, Smart Licensing Using Policy functionality is disabled.

For a new product instance, this means:

Condition	Required Action	Outcome or Result
You opt-out of AIR DNA licenses	None.	Use only AIR Network Essentials. Smart Licensing Using Policy functionality is disabled on the product instance and for your Smart Account and Virtual Account in CSSM. License usage is not recorded, and no reporting requirements apply.
You purchase AIR DNA licenses	Enter the **license air level** command in global configuration mode and configure the corresponding AIR DNA license. Reload to use the corresponding license. Implement one of the supported topologies and fulfill reporting requirements. For information about implementing a topology, For information about implementing a topology, see the Supported Topologies section in the software configuration guide of the required release.	Use the purchased AIR DNA and AIR Network license. Smart Licensing Using Policy functionality is enabled on the product instance and for your Smart Account and Virtual Account in CSSM.

For an existing product instance, this means:

Condition	Required Action	Outcome or Result
You are using an AIR DNA license	None.	No change. You are already in the Smart Licensing Using Policy environment.

Condition	Required Action	Outcome or Result
You do not want to renew the DNA license on term expiry	On term expiry, enter the **license air level** command in global configuration mode and configure AIR Network Essentials or AIR Network Advantage. Reload to use the corresponding license.	If you had AIR DNA Essentials, you now use AIR Network Essentials. If you had AIR DNA Advantage, you now use AIR Network Advantage. Smart Licensing Using Policy functionality is disabled on the product instance and for your Smart Account and Virtual Account in CSSM. License usage is not recorded, and no reporting requirements apply.

Examples

The following example show how to configure the AIR DNA Essential license level:

```
Device# configure terminal
Device(config)# license air level network-essentials addon air-dna-essentials
```

The following example shows how the AIR DNA Advantage license level is configured to begin with and then changed to AIR DNA Essentials:

Current configuration as AIR DNA Advantage:

```
Device# show version
Cisco IOS XE Software, Version 17.03.02
Cisco IOS Software [Amsterdam], C9800-CL Software (C9800-CL-K9_IOSXE), Version 17.3.2,
RELEASE SOFTWARE
<output truncated>
AIR License Level: AIR DNA Advantage
Next reload AIR license Level: AIR DNA Advantage

Smart Licensing Status: Registration Not Applicable/Not Applicable
<output truncated>
```

Configuration of AIR DNA Essentials :

```
Device# configure terminal
Device(config)# license air level air-network-essentials addon air-dna-essentials

Device# exit
Device# show version
Cisco IOS XE Software, Version 17.03.02
Cisco IOS Software [Amsterdam], C9800-CL Software (C9800-CL-K9_IOSXE), Version 17.3.2,
RELEASE SOFTWARE
<output truncated>
AIR License Level: AIR DNA Advantage
Next reload AIR license Level: AIR DNA Essentials
Smart Licensing Status: Registration Not Applicable/Not Applicable
<output truncated>

Device# write memory
Device# reload
```

After reload:

```
Device# show version
Cisco IOS XE Software, Version 17.03.02
```

```
Cisco IOS Software [Amsterdam], C9800-CL Software (C9800-CL-K9_IOSXE), Version 17.3.2,
RELEASE SOFTWARE
<output truncated>
AIR License Level: AIR DNA Essentials
Next reload AIR license Level: AIR DNA Essentials

Smart Licensing Status: Registration Not Applicable/Not Applicable
<output truncated>
```

license smart (global config)

To configure licensing-related settings such as the mode of transport and the URL that the product instance uses to communicate with Cisco Smart Software Manager (CSSM), or Cisco Smart Licensing Utility (CSLU), or Smart Software Manager On-Prem (SSM On-Prem), to configure the usage reporting interval, to configure the information that must be exluded or included in a license usage report (RUM report), enter the **license smart** command in global configuration mode. Use the **no** form of the command to revert to default values.

license smart { **custom_id** *ID* | **enable** | **privacy** { **all** | **hostname** | **version** } | **proxy** { **address** *address_hostname* | **port** *port* } | **reservation** | **server-identity-check** | **transport** { **automatic** | **callhome** | **cslu** | **off** | **smart** } | **url** { *url* | **cslu** *cslu_or_on-prem_url* | **default** | **smart** *smart_url* | **utility** *secondary_url* } | **usage** { **customer-tags** { **tag1** | **tag2** | **tag3** | **tag4** } *tag_value* | **interval** *interval_in_days* } | **utility** [**customer_info** { **city** *city* | **country** *country* | **postalcode** *postalcode* | **state** *state* | **street** *street* }] }

no license smart { **custom_id** | **enable** | **privacy** { **all** | **hostname** | **version** } | **proxy** { **address** *address_hostname* | **port** *port* } | **reservation** | **server-identity-check** | **transport** | **url** { *url* | **cslu** *cslu_or_on-prem_url* | **default** | **smart** *smart_url* | **utility** *secondary_url* } | **usage** { **customer-tags** { **tag1** | **tag2** | **tag3** | **tag4** } *tag_value* | **interval** *interval_in_days* } | **utility** [**customer_info** { **city** *city* | **country** *country* | **postalcode** *postalcode* | **state** *state* | **street** *street* }] }

Syntax Description

custom_id *ID*	Although available on the CLI, this option is not supported.
enable	Although visible on the CLI, configuring this keyword has no effect. Smart licensing is always enabled.

privacy { **all** | **hostname** | **version** }	Sets a privacy flag to prevent the sending of the specified data privacy related information. When the flag is disabled, the corresponding information is sent in a message or offline file created by the product instance. Depending on the topology this is sent to one or more components, including CSSM, CSLU, and SSM On-Prem. *All data privacy settings are disabled by default*. You must configure the option you want to exclude from all communication: • **all**: All data privacy related information is excluded from any communication. The **no** form of the command causes all data privacy related information to be sent in a message or offline file. **Note** The Product ID (PID) and serial number are *included in the RUM report* regardless of whether data privacy is enabled or not. • **hostname**: Excludes hostname information from any communication. When hostname privacy is enabled, the *UDI* of the product instance is displayed on the applicable user interfaces (CSSM, CSLU, and SSM On-Prem). The **no** form of the command causes hostname information to be sent in a message or offline file. The hostname is displayed on the applicable user interfaces (CSSM, CSLU, and SSM On-Prem). • **version**: Excludes the Cisco IOS-XE software version running on the product instance and the Smart Agent version from any communication. The **no** form of the command causes version information to be sent in a message or offline file.

proxy { **address** *address_hostname* | **port** *port* }	Configures a proxy for license usage synchronization with CSLU or CSSM. This means that you can use this option to configure a proxy only if the transport mode is **license smart transport smart** (CSSM), or **license smart transport cslu** (CSLU). However, you cannot configure a proxy for license usage synchronization in an SSM On-Prem deployment, which also uses **license smart transport cslu** as the transport mode. Configure the following options: • **address** *address_hostname*: Configures the proxy address. For *address_hostname*, enter the enter the IP address or hostname of the proxy. • **port***port*: Configures the proxy port. For *port*, enter the proxy port number.
reservation	Enables or disables a license reservation feature. **Note** Although available on the CLI, this option is not applicable because license *reservation* is not applicable in the Smart Licensing Using Policy environment.
server-identity-check	Enables or disables the HTTP secure server identity check.
transport { **automatic** | **callhome** | **cslu** | **off** | **smart** }	Configures the mode of transport the product instance uses to communicate with CSSM. Choose from the following options: • **automatic**: Sets the transport mode **cslu**. **Note** The **automatic** keyword is not supported on Cisco Catalyst Wireless Controllers. • **callhome**: Enables Call Home as the transport mode. • **cslu**: Enables CSLU as the transport mode. This is the default transport mode. The same keyword applies to both CSLU *and* SSM On-Prem, but the URLs are different. See **cslu***cslu_or_on-prem_url* in the following row. • **off**: Disables all communication from the product instance. • **smart**: Enables Smart transport.

url { *url* | **cslu** *cslu_url* | **default** | **smart** *smart_url* | **utility** *secondary_url* }

Sets URL that is used for the configured transport mode. Choose from the following options:

- *url*: If you have configured the transport mode as **callhome**, configure this option. Enter the CSSM URL exactly as follows:

  `https://ptesdc.cloudapps.cisco.com/its/service/oddce/`

  The **no license smart url** *url* command reverts to the default URL.

- **cslu** *cslu_or_on-prem_url*: If you have configured the transport mode as **cslu**, configure this option, with the URL for CSLU or SSM On-Prem, as applicable:

  - If you are using CSLU, enter the URL as follows:

    `http://<cslu_ip_or_host>:8182/cslu/v1/pi`

    For `<cslu_ip_or_host>`, enter the hostname or the IP address of the windows host where you have installed CSLU. 8182 is the port number and it is the only port number that CSLU uses.

    The **no license smart url cslu** *cslu_or_on-prem_url* command reverts to `http://cslu-local:8182/cslu/v1/pi`

  - If you are using SSM On-Prem, enter the URL as follows:

    `http://<ip>/cslu/v1/pi/<tenant ID>`

    For <ip>, enter the hostname or the IP address of the server where you have installed SSM On-Prem. The <tenantID> must be the default local virtual account ID.

    Tip
    You can retrieve the entire URL from SSM On-Prem. In the software configuration guide (17.3.x and later), see Smart Licensing Using Policy > Task Library for Smart Licensing Using Policy > Retrieving the Transport URL (SSM On-Prem UI).

    The **no license smart url cslu** *cslu_or_on-prem_url* command reverts to `http://cslu-local:8182/cslu/v1/pi`

- **default**: Depends on the configured transport mode. Only the **smart** and **cslu** transport modes are supported with this option.

  If the transport mode is set to **cslu**, and you configure **license smart url default**, the CSLU URL is configured automatically

(`https://cslu-local:8182/cslu/v1/pi`).

If the transport mode is set to **smart**, and you configure **license smart url default**, the Smart URL is configured automatically (`https://smartreceiver.cisco.com/licservice/license`).

- **smart** *smart_url*: If you have configured the transport type as **smart**, configure this option. Enter the URL exactly as follows:

  `https://smartreceiver.cisco.com/licservice/license`

  When you configure this option, the system automatically creates a duplicate of the URL in **license smart url** *url*. You can ignore the duplicate entry, no further action is required.

  The **no license smart url smart***smart_url* command reverts to the default URL.

- **utility** *smart_url*: Although available on the CLI, this option is not supported.

usage { **customer-tags** { **tag1** | **tag2** | **tag3** | **tag4** } *tag_value* | **interval** *interval_in_days* }	Configures usage reporting settings. You can set the following options: • **customer-tags** { **tag1** | **tag2** | **tag3** | **tag4** } *tag_value*: Defines strings for inclusion in data models, for telemetry. Up to 4 strings (or tags) may be defined. For *tag_value*, enter the string value for each tag that you define. • **interval** *interval_in_days*: Sets the reporting interval in days. By default the RUM report is sent every 30 days. The valid value range is 1 to 3650. If you set the value to zero, RUM reports are not sent, regardless of what the applied policy specifies - this applies to topologies where CSLU or CSSM may be on the receiving end. If you set a value that is greater than zero and the transport type is set to **off**, then, between the *interval_in_days* and the policy value for `Ongoing reporting frequency(days):`, the lower of the two values is applied. For example, if *interval_in_days* is set to 100, and the value in the in the policy says `Ongoing reporting frequency (days):90`, RUM reports are sent every 90 days. If you do not set an interval, and the default is effective, the reporting interval is determined entirely by the policy value. For example, if the default value is effective and only unenforced licenses are in use, if the policy states that reporting is not required, then RUM reports are not sent.
utility [**customer_info** { **city** *city* | **country** *country* | **postalcode** *postalcode* | **state** *state* | **street** *street* }]	Although visible on the CLI, this option is not supported.

Command Default

Cisco IOS XE Amsterdam 17.3.1 or earlier: Smart Licensing is enabled by default.

Cisco IOS XE Amsterdam 17.3.2a and later: Smart Licensing Using Policy is enabled by default.

Command Modes

Global config (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	The following keywords and variables were introduced with Smart Licensing Using Policy: • Under the **url**keyword, these options were introduced: { **cslu** *cslu_url* | **smart** *smart_url* } • Under the **transport** keyword, these options were introduced: { **cslu** | **off** } Further, the default transport type was changed from **callhome**, to **cslu**. • **usage** { **customer-tags** { **tag1** | **tag2** | **tag3** | **tag4** } *tag_value* | **interval** *interval_in_days* } The following keywords and variables under the **license smart** command are deprecated and no longer available on the CLI: **enable**and **conversion automatic**.
Cisco IOS XE Amsterdam 17.3.3	SSM On-Prem support was introduced. For product instance-initiated communication in an SSM On-Prem deployment, the existing [**no**]**license smart url cslu***cslu_or_on-prem_url* command supports the configuration of a URL for SSM On-Prem as well. But the required URL format for SSM On-Prem is: `http://<ip>/cslu/v1/pi/<tenant ID>`. The corresponding transport mode that must be configured is also an existing command (**license smart transport cslu**).
Cisco IOS XE Cupertino 17.9.1	• A new mechanism to send all data privacy related information was introduced. This information is no longer included in a RUM report. If data privacy is disabled (**no license smart privacy** {**all** | **hostname** | **version**} global configuration command), data privacy related information is sent in a separate sync message or offline file. • Support for sending hostname information was introduced. If the privacy setting for the hostname is disabled (**no license smart privacy hostname** global configuration command), hostname information is sent from the product instance, in a separate sync message, or offline file. Depending on the topology you have implemented, the hostname information is received by CSSM, CSLU, or SSM On-Prem. It is also displayed on the corresponding user interface.

Usage Guidelines

Data Privacy Settings

When you disable a privacy setting, the topology you have implemented determines the recipient and how the information reaches its destination:

- The recipient of the information may be one or more of the following: CSSM, CSLU, and SSM On-Prem. The privacy setting has no effect on a controller (Cisco DNA Center).

In case of the **hostname** keyword, after the hostname information is received by CSSM, CSLU, or SSM On-Prem, it is also displayed on the corresponding UIs – as applicable. If you then *enable* privacy the corresponding UIs revert to displaying the UDI of the product instance.

- How the information is sent.
  - In case of a topology where the product instance initiates communication, the product instance initiates the sending of this information in a message, to CSSM, or CSLU, or SSM On-Prem.

    The product instance sends the hostname sent every time one of the following events occur: the product instance boots up, the hostname changes, there is a switchover in a High Availability set-up.
  - In case of a topology where CSLU or SSM On-Prem initiate communication, the corresponding component initiates the retrieval of privacy information from the product instance.

    The hostname is retrieved at the frequency you configure in CSLU or SSM On-Prem, to retrieve information.
  - In case of a topology where the product instance is in an air-gapped network, privacy information is included in the offline file that is generated when you enter the **license smart save usage** privileged EXEC command.

Note For all topologies, data privacy related information is *not* included in the RUM report.

Data privacy related information it is not stored by the product instance *prior* to sending or saving. This ensures that if and when information is sent, it is consistent with the data privacy setting at the time of sending or saving.

Communication failures and reporting

The reporting interval that you configure (**license smart usage interval** *interval_in_days* command), determines the date and time at which the product instance sends out the RUM report. If the scheduled interval coincides with a communication failure, the product instance attempts to send out the RUM report for up to four hours after the scheduled time has expired. If it is still unable to send out the report (because the communication failure persists), the system resets the interval to 15 minutes. Once the communication failure is resolved, the system reverts the reporting interval to the value that you last configured.

The system message you may see in case of a communicatin failure is %SMART_LIC-3-COMM_FAILED. For information about resolving this error and restoring the reporting interval value, in the software configuration guide of the required release (17.3.x onwards), see *System Configuration* > *Smart Licensing Using Policy* > *Troubleshooting Smart Licensing Using Policy*.

Proxy server acceptance

When configuring the **license smart proxy** {**address** *address_hostname* | **port***port*} command, note the change in the criteria for the acceptance of proxy servers, starting with Cisco IOS XE Bengaluru 17.6.1: only the status code of the proxy server response is verified by the system and not the reason phrase. The RFC format is `status-line = HTTP-version SP status-code SP reason-phrase CRLF`, where the status code is a three-digit numeric code. For more information about the status line, see section 3.1.2 of RFC 7230.

Examples

- Examples for Data Privacy, on page 404

• Examples for Transport Type and URL, on page 404
• Examples for Usage Reporting Options, on page 405

Examples for Data Privacy

The following examples show how to configure data privacy related information using **license smart privacy** command in global configuration mode. The accompanying **show license status** output displays configured information.



Note The output of the **show** command only tells you if a particular option is enabled or disabled.

Here, no data privacy related information information is sent:

```
Device#configure terminal
Device(config)#license smart privacy all
Device(config)#exit
Device#show license status
<output truncated>
Data Privacy:
 Sending Hostname: no
   Callhome hostname privacy: ENABLED
   Smart Licensing hostname privacy: ENABLED
 Version privacy: ENABLED

Transport:
 Type: Callhome
<output truncated>
```

Examples for Transport Type and URL

The following examples show how to configure some of the transport types using the **license smart transport** and the **license smart url** commands in global configuration mode. The accompanying **show license all** output displays configured information.

Transport **cslu**:

```
Device#configure terminal
Device(config)#license smart transport cslu
Device(config)#license smart url default
Device(config)#exit
Device#show license all
<output truncated>
Transport:
 Type: cslu
 Cslu address: http://192.168.0.1:8182/cslu/v1/pi
 Proxy:
   Not Configured
<output truncated>
```

Transport **smart**:

```
Device#configure terminal
Device(config)#license smart transport smart
Device(config)#license smart url smart https://smartreceiver.cisco.com/licservice/license
```

```
Device(config)#exit
Device#show license all
<output truncated>
Transport:
 Type: Smart
 URL: https://smartreceiver-stage.cisco.com/licservice/license
 Proxy:
   Not Configured
<output truncated>
```

Examples for Usage Reporting Options

The following examples show how to configure some of the usage reporting settings using the **license smart usage** command in global configuration mode. The accompanying **show running-config** output displays configured information.

Configuring the **customer-tag** option:

```
Device# configure terminal
Device(config)# license smart usage customer-tags tag1 SA/VA:01
Device(config)# exit
Device#show running-config | include tag1
license smart usage customer-tags tag1 SA/VA:01
```

Configuring a narrower reporting interval than the currently applied policy:

```
Device#show license status
<output truncated>
Usage Reporting:
Last ACK received: Sep 22 13:49:38 2020 PST
Next ACK deadline: Dec 21 12:02:21 2020 PST
 Reporting push interval: 30 days
Next ACK push check: Sep 22 12:20:34 2020 PST
 Next report push: Oct 22 12:05:43 2020 PST
Last report push: Sep 22 12:05:43 2020 PST
Last report file write: <none>
<output truncated>

Device#configure terminal
Device(config)#license smart usage interval 20
Device(config)#exit
Device#show license status
<output truncated>

Usage Reporting:
Last ACK received: Sep 22 13:49:38 2020 PST
 Next ACK deadline: Nov 22 12:02:21 2020 PST
Reporting push interval: 20 days
Next ACK push check: Sep 22 12:20:34 2020 PST
 Next report push: Oct 12 12:05:43 2020 PST
Last report push: Sep 22 12:05:43 2020 PST
Last report file write: <none>
<output truncated>
```

license smart (privileged EXEC)

To configure licensing functions such as requesting or returning authorization codes, saving Resource Utilization Measurement reports (RUM reports), importing a file on to a product instance, establishing trust with Cisco Smart Software Manager (CSSM), synchronizing the product instance with CSSM, or Cisco Smart License Utility (CSLU), or Smart Software Manager On-Prem (SSM On-Prem), and removing licensing information from the product instance, enter the **license smart** command in privileged EXEC mode with the corresponding keyword or argument.

license smart { **authorization** { **request** { **add** | **replace** | **save** *filepath_filename* } *feature_name* { **all** | **local** } | **return** { **all** | **local** } { **offline** [*filepath_filename*] | **online** } } | **clear eventlog** | **export return** { **all** | **local** } *feature_name* | **factory reset** | **import** *filepath_filename* | **save** { **trust-request** *filepath_filename* | **usage** { **all** | **days** *days* | **rum-id** *rum-ID* | **unreported** } { **file** *filepath_filename* } } | **sync** { **all** | **local** } | **trust idtoken** *id_token_value* { **local** | **all** } [**force**] }

Syntax Description

smart	Provides options for Smart Licensing.
authorization	Provides the option to request for, or return, authorization codes. Authorization codes are required *only* if you use licenses with enforcement type: export-controlled or enfored.
request	Requests an authorization code from CSSM, CSLU (CSLU in-turn fetches it from CSSM), or SSM On-Prem and installs it on the product instance.
add	Adds the requested license to the existing authorization code. The new authorization code will contain all the licenses of the existing authorization code and the requested license.
replace	Replaces the existing authorization code. The new authorization code will contain only the requested license. All licenses in the current authorization code are returned. When you enter this option, the product instance verifies if licenses that correspond to the authorization codes that will be removed, are in-use. If licenses are being used, an error message tells you to first disable the corresponding features.
save*filepath_filename*	Saves the authorization code request to a file. For *filepath_filename*, specify the absolute path to the file, including the filename.
feature_name	Name of the license for which you are requesting an authorization code.
all	Performs the action for all product instances in a High Availability configuration.
local	Performs the action for the *active* product instance. This is the default option.
return	Returns an authorization code back to the license pool in CSSM.

offline *filepath_filename*	Means the product instance is not connected to CSSM. The authorization code is returned offline. This option requires you to print the return code to a file. Optionally, you can also specify a path to save the file. The file format can be any readable format, such as `.txt` If you choose the offline option, you must complete the additional step of copying the return code from the CLI or the saved file and entering it in CSSM.
online	Means that the product instance is in a connected mode. The authorization code is returned to CSLU or CSSM directly.
clear eventlog	Clears all event log files from the product instance.
export return	Returns the authorization key for an export-controlled license.
factory reset	Clears all saved licensing information from the product instance.
import *filepath_filename*	Imports a file on to the product instance. The file may be that of an authorization code, a trust code, or, or a policy. For *filepath_filename*, specify the location, including the filename.
save	Provides options to save RUM reports or trust code requests.
trust-request *filepath_filename*	Saves the trust code request for the active product instance in the specified location. For *filepath_filename*, specify the absolute path to the file, including the filename.
usage { **all** | **days** *days* | **rum-id** *rum-ID* | **unreported** } { **file** *file_path* }	Saves RUM reports (license usage information) in the specified location. You must specify one of these options: • **all**: Saves all RUM reports. • **days** *days*: Saves RUM report for the last *n* number of days (excluding the current day). Enter a number. The valid range is 0 to 4294967295. For example, if you enter 3, RUM reports of the last three days are saved. • **rum-Id** *rum-ID*: Saves a specified RUM ID. The valid value range is 0 to 18446744073709551615. • **unreported**: Saves all unreported RUM reports. **file** *filepath_filename*: Saves the specified usage information to a file. Specify the absolute path to the file, including the filename.

sync { **all** | **local** }	Synchronizes with CSSM or CSLU, or SSM On-Prem, to send and receive any pending data. This includes uploading pending RUM reports, downloading the ACK response, any pending authorization codes, trust codes, and policies for the product instance. Specify the product instance by entering one of these options: • **all**: Performs synchronization for all the product instances in a High Availability set-up. If you choose this option, the product instance also sends the list of all the UDIs in the synchronization request. • **local**: Performs synchronization only for the active product instance sending the request, that is, its own UDI. This is the default option.
trust idtoken *id_token_value*	Establishes a trusted connection with CSSM. To use this option, you must first generate a token in the CSSM portal. Provide the generated token value for *id_token_value*.
force	Submits a trust code request even if a trust code already exists on the product instance. A trust code is node-locked to the UDI of a product instance. If the UDI is already registered, CSSM does not allow a new registration for the same UDI. Entering the **force** keyword overrides this behavior.

Command Default

Cisco IOS XE Amsterdam 17.3.1 or earlier: Smart Licensing is enabled by default.

Cisco IOS XE Amsterdam 17.3.2a and later: Smart Licensing Using Policy is enabled by default.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	The following keywords and variables were introduced with Smart Licensing Using Policy: • **authorization** { **request** { **add** | **replace** } *feature_name* { **all** | **local** } | **return** { **all** | **local** } { **offline** [*path*] | **online** } } • **import** *file_path* • **save** { **trust-request** *filepath_filename* | **usage** { **all** | **days** *days* | **rum-id** *rum-ID* | **unreported** } { **file** *file_path* } } • **sync** { **all** | **local** } • **trust idtoken** *id_token_value* { **local** | **all** } [**force**] The following keywords and variables under the **license smart** command are deprecated and no longer available on the CLI: • **register idtoken** *token_id* [**force**] • **renew id** { **ID** | **auth** } • **debug** { **error** | **debug** | **trace** | **all** } • **reservation** { **cancel** [**all** | **local**] | **install** [**file**] *key* | **request** { **all** | **local** | **universal** } | **return** [**all** | **authorization** { *auth_code* | **file** *filename* } | **Local**] *key* } • **mfg reservation** { **request** | **install** | **install file** | **cancel** } • **conversion** { **start** | **stop** }
Cisco IOS XE Amsterdam 17.3.3	Support for SSM On-Prem was introduced. You can perform licensing-related tasks such as saving Resource Utilization Measurement reports (RUM reports), importing a file on to a product instance, synchronizing the product instance, returning authorization codes, and removing licensing information from the product instance in an SSM On-Prem deployment.
Cisco IOS XE Cupertino 17.7.1	The following enhancements were introduced in this release: • The **save** *filepath_filename* keyword and variable was added to the **license smart authorization request** string. Although visible on the CLI, the new keywords are not applicable, because there are no export-controlled or enforced licenses on any of the Cisco Catalyst Wireless Controllers. • The existing **license smart save usage** command was enhanced to include a trust code request in applicable topologies.

Usage Guidelines

Overwriting a Trust Code

Use case for the **force** option when configuring the **license smart trust idtoken** command: You use same token for all the product instances that are part of one Virtual Account. If the product instance has moved

from one account to another (for instance, because it was added to a High Availability set-up, which is part of another Virtual Account), then there may be an existing trust code you have to overwrite.

Removing Licensing Information

Entering the **licence smart factory reset** command removes all licensing information (except the licenses in-use) from the product instance, including any authorization codes, RUM reports etc. Therefore, we recommend the use of this command only if the product instance is being returned (Return Material Authrization, or RMA), or being decommissioned permanently. We also recommend that you send a RUM report to CSSM, before you remove licensing information from the product instance - this is to ensure that CSSM has up-to-date usage information.

Authorization Codes and License Reservations:

Options relating to authorization codes and license reservations:

- Since there are no export-controlled or enforced licenses on any of the Cisco Catalyst Wireless Controllers, and the notion of reserved licenses is not applicable in the Smart Licensing Using Policy environment, the following commands are not applicable:
  - { { **license smart authorization request** { **add** | **replace** | **save** *path* } *feature_name* { **all** | **local** } *request_count* } }
  - **license smart export return**
- The following option is applicable and required for any SLR authorization codes you may want to return:

  license smart authorization return { **all** | **local** } { **offline** [*path*] | **online** }

Examples

- Example for Saving Licensing Usage Information, on page 410
- Example for Installing a Trust Code, on page 411
- Example for Returning an SLR Authorization Code, on page 411

Example for Saving Licensing Usage Information

The following example shows how you can save license usage information on the product instance. You can use this option to fulfil reporting requirements in an air-gapped network. In the example, the file is first save to flash memory and then copied to a TFTP location:

```
 Device> enable
Device# license smart save usage unreported file flash:RUM-unrep.txt
Device# dir
Directory of bootflash:/

33      -rw-             5994   Nov 2 2020 03:58:04 +05:00  RUM-unrep.txt

Device# copy flash:RUM-unrep.txt tftp://192.168.0.1//auto/tftp-user/user01/
Address or name of remote host [192.168.0.1]?
Destination filename [//auto/tftp-user/user01/RUM-unrep.txt]?
!!
15128 bytes copied in 0.161 secs (93963 bytes/sec)
```

After you save RUM reports to a file, you must upload it to CSSM (from a workstation that has connectivity to the internet, and Cisco).

Example for Installing a Trust Code

The following example shows how to install a trust code even if one is already installed on the product instance. This requires connectivity to CSSM. The accompanying **show license status** output shows sample output after successful installation:

Before you can install a trust code, you must generate a token and download the corresponding file from CSSM.

Use the **show license status** command (`Trust Code Installed:`) to verify results.

```
Device> enable
Device# license smart trust idtoken
NGMwMjk5mYtNZaxMS00NzMZmtgWm local force

Device# show license status
<output truncated>
Trust Code Installed:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
    INSTALLED on Nov 02 05:19:05 2020 IST
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
    INSTALLED on Nov 02 05:19:05 2020 IST
<output truncated>
```

Example for Returning an SLR Authorization Code

The following example shows how to remove and return an SLR authorization code. Here the code is returned offline (no connectivity to CSSM). The accompanying **show license all** output shows sample output after successful return:

```
Device> enable
Device# show license all
<output truncated>
License Authorizations
======================
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
      Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      Last Confirmation code: ad4382fe
<output truncated>

Device# license smart authorization return local offlline
Enter this return code in Cisco Smart Software Manager portal:
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS
    Return code: CqaUPW-WSPYiq-ZNU2ci-SnWydS-hBCXHP-MuyPqy-PJ1GiG-tPTGQj-S2h
UDI: PID:C9800-CL-K9,SN:9XECPSUU4XN
    Return code: CNLwxR-eWiAEJ-XaTEQg-j4rrYW-dSRz9j-37VpcP-imjuLD-mNeA4k-TXA

Device# show license all
<output truncated>
License Authorizations
======================
Overall status:
```

```
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: NOT INSTALLED
      Last return code: CqaUPW-WSPYiq-ZNU2ci-SnWydS-hBCXHP-MuyPqy-PJ1GiG-tPTGQj-S2h
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: NOT INSTALLED
      Last return code: CNLwxR-eWiAEJ-XaTEQg-j4rrYW-dSRz9j-37VpcP-imjuLD-mNeA4k-TXA
<output truncated>
```

If you choose the **offline** option, you must complete the additional step of copying the return code from the CLI or the saved file and entering it in CSSM.

line vty

To identify a specific line for configuration and begin the command in line configuration mode in a virtual terminal for remote console access, use the **line vty** command.

line vty *line_number*

Syntax Description

line_number	First line number. Valid values range from 0 to 530.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to identify a specific line for configuration in a virtual terminal:

```
Device# line vty 10
```

load

To configure site tag-based load balancing, use the **load** command.

load *load*

Syntax Description

load	Specifies the estimate of the relative load reserved for the site. Values range between 0 to 1000. The default value 0 means no load recommendation for the site.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

This example shows how to configure site tag-based load balancing:

```
Device# configure terminal
Device(config)# wireless tag site area1
Device(config-site-tag)# load 200
Device(config-site-tag)# end
```

local-auth ap eap-fast

To configure Flex policy local authentication using EAP Fast method, use the **local-auth ap eap-fast** command.

local-auth ap eap-fast *profile-name*

Syntax Description

profile-name	Enter eap-fast profile name.

Command Default

None

Command Modes

config-wireless-flex-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure EAP Fast method authentication on a Flex policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile flex profile-name
Device(config-wireless-flex-profile)# local-auth ap eap-fast eap-fast-profile-name
```

local-site

To configure the site as local site, use the **local-site** command.

local-site

Syntax Description

local-site	Configure this site as local site.

Command Default

None

Command Modes

config-site-tag

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to set the current site as local site:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless tag site tag-name
Device(config-site-tag)# local-site
```

location expiry

To configure the location expiry duration, use the **location expiry** command in global configuration mode.

location expiry {**calibrating-client** | **client** | **tags** } *timeout-duration*

Syntax Description

calibrating-client	Timeout value for calibrating clients.
client	Timeout value for clients.
tags	Timeout value for RFID tags.
timeout-duration	Timeout duration, in seconds.

Command Default

Timeout value is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure the location expiry duration:

```
Device(config)# location expiry tags 50
```

location notify-threshold

To configure the NMSP notification threshold for RSSI measurements, use the **location notify-threshold** command in global configuration mode. To remove the NMSP notification threshold for RSSI measurements, use the **no** form of this command.

location notify-threshold {**client** | **rogue-aps** | **tags** } *db*
no location notify-threshold {**client** | **rogue-aps** | **tags** }

Syntax Description

client	Specifies the NMSP notification threshold (in dB) for clients and rogue clients. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
rogue-aps	Specifies the NMSP notification threshold (in dB) for rogue access points. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
tags	Specifies the NMSP notification threshold (in dB) for RFID tags. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
db	The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure the NMSP notification threshold to 10 dB for clients. A notification NMSP message is sent to MSE as soon as the client RSSI changes by 10 dB:

```
Device# configure terminal
Device(config)# location notify-threshold client 10
Device(config)# end
```

log-export-mode

To configure the log export using FTP, STP and TFTP, use the **log-export-mode** command. Use the **no** command to negate the command or to set the command to its default.

log-export-mode { **ftp** | **stp** | **tftp** }

no log-export-mode { **ftp** | **stp** | **tftp** }

Syntax Description

ftp	Configures the log export using FTP.
stp	Configures the log export using STP.
tftp	Configures the log export using TFTP.

Command Default

None

Command Modes

Wireless trace export profile configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace-export-name
Device(config-wireless-trace-export-profile)# log-export-mode tftp
```

login authentication

To configure login authentication parameters, use the **login authentication** command.

login authentication *word* **default**

Syntax Description

word	Authentication list with a name.
default	Uses the default authentication list.

Command Default

None

Command Modes

Line configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure login authentication :

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# line console 0
Device(config-line)# login authentication NO_LOGIN
```

login block-for

To configure the login security on the Cisco controller and to set the duration for which the controller has to block further login attempts after a specified number of consecutive failed login attempts within a certain time frame, use the **login block-for** command.

login block-for *duration* **attempts** *attempts* **within** *time-frame*

Syntax Description

duration	Specifies the duration in seconds for which the device will block login attempts
attempts	Number of consecutive failed login attempts
attempts	Specifies the maximum number of failed attempts
within	Time frame within which the specified number of consecutive failed login attempts must occur to trigger the blocking
time-frame	Specifies the time period in seconds

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the login security on the controller to set the duration of 60 seconds for which the controller has to block further login attempts after 3 unsuccessful login attempts within a period of 10 seconds.:

```
Device# login block-for 60 attempts 3 within 10
```

mac-filtering

To enable MAC filtering on a WLAN, use the **mac-filtering** command.

mac-filtering [*mac-authorization-list*]

Syntax Description

mac-authorization-list	Name of the Authorization list.

Command Default

None

Command Modes

config-wlan

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable MAC filtering on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan-name wlan-index SSID-name
Device(config-wlan)# mac-filtering
```

mab request format attribute

To configure the delimiter while configuring MAC filtering on a WLAN, use the **mab request format attribute** command in global configuration mode. To disable the delimiter while configuring MAC filtering on a WLAN, use the **no** form of this command.

mab request format attribute { **1 groupsize** *size* **separator** *separator* [**lowercase** | **uppercase**] | **2** { **0** | **7** | **LINE** } **LINE** *password* | **32 vlan access-vlan** }

no mab request format attribute { **1 groupsize** *size* **separator** *separator* [**lowercase** | **uppercase**] | **2** { **0** | **7** | **LINE** } **LINE** *password* | **32 vlan access-vlan** }

Syntax Description

1	Specifies the username format used for MAB requests.
groupsize *size*	Specifies the number of hex digits per group. The valid values range from 1 to 12.
separator *separator*	Specifies how to separate groups. The separators are hyphen (-), colon (:), and full stop (.) For more information about the groupsize and separator, refer to the Overview of the Configurable MAB Username and Password.
lowercase	Specifies the username in lowercase format.
uppercase	Specifies the username in uppercase format.
2	Specifies the global password used for all the MAB requests.
0	Specifies the unencrypted password.
7	Specifies the hidden password.
LINE	Specifies the encrypted or unencrypted password.
password	LINE password.
32	Specifies the NAS-Identifier attribute.
vlan	Specifies a VLAN.
access-vlan	Specifies the configured access VLAN.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example:

The following example shows how to configure the delimiter while configuring MAC filtering:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# mab request format attribute 1 groupsize 4 separator -
```

map-fast-ancestor-find

To configure the MAP fast ancestor find mode in wireless mesh profile, use the **map-fast-ancestor-find** command.

map-fast-ancestor-find

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Wireless mesh profile configuration (config-wireless-mesh-profile)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Example

The following example shows how to configure MAP fast ancestor find mode for a mesh AP profile:

```
Device # configure terminal
Device (config)# wireless profile mesh mesh-profile
Device (config-wireless-mesh-profile)# map-fast-ancestor-find
```

match (access-map configuration)

To set the VLAN map to match packets against one or more access lists, use the **match** command in access-map configuration mode on the switch stack or on a standalone switch. To remove the match parameters, use the **no** form of this command.

match { **ip address** { *name number* } [*name number*] [*name number*] . . . | **ipv6 address** { *name number* } [*name number*] [*name number*] . . . | **mac address** { *name* } [*name*] [*name*] . . . }
no match { **ip address** { *name number* } [*name number*] [*name number*] . . . | **ipv6 address** { *name number* } [*name number*] [*name number*] . . . | **mac address** { *name* } [*name*] [*name*] . . . }

Syntax Description

ip address	Sets the access map to match packets against an IP address access list.
ipv6 address	Sets the access map to match packets against an IPv6 address access list.
mac address	Sets the access map to match packets against a MAC address access list.
name	Name of the access list to match packets against.
number	Number of the access list to match packets against. This option is not valid for MAC access lists.

Command Default

The default action is to have no match parameters applied to a VLAN map.

Command Modes

Access-map configuration

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

You enter access-map configuration mode by using the **vlan access-map** global configuration command.

You must enter one access list name or number; others are optional. You can match packets against one or more access lists. Matching any of the lists counts as a match of the entry.

In access-map configuration mode, use the **match** command to define the match conditions for a VLAN map applied to a VLAN. Use the **action** command to set the action that occurs when the packet matches the conditions.

Packets are matched only against access lists of the same protocol type; IP packets are matched against IP access lists, IPv6 packets are matched against IPv6 access lists, and all other packets are matched against MAC access lists.

IP, IPv6, and MAC addresses can be specified for the same map entry.

This example shows how to define and apply a VLAN access map vmap4 to VLANs 5 and 6 that will cause the interface to drop an IP packet if the packet matches the conditions defined in access list al2:

```
Device(config)# vlan access-map vmap4
Device(config-access-map)# match ip address al2
Device(config-access-map)# action drop
Device(config-access-map)# exit
Device(config)# vlan filter vmap4 vlan-list 5-6
```

You can verify your settings by entering the **show vlan access-map** privileged EXEC command.

match activated-service-template

To create a condition that evaluates true based on the service template activated on a session, use the **match activated-service-template** command in control class-map filter configuration mode. To create a condition that evaluates true if the service template activated on a session does not match the specified template, use the **no-match activated-service-template** command in control class-map filter configuration mode. To remove the condition, use the **no** form of this command.

match activated-service-template *template-name*
no-match activated-service-template *template-name*
no {**match** | **no-match**} **activated-service-template** *template-name*

Syntax Description

template-name	Name of a configured service template as defined by the **service-template** command.

Command Default

The control class does not contain a condition based on the service template.

Command Modes

Control class-map filter configuration (config-filter-control-classmap)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

The **match activated-service-template** command configures a match condition in a control class based on the service template applied to a session. A control class can contain multiple conditions, each of which will evaluate as either true or false. The control class defines whether all, any, or none of the conditions must evaluate true for the actions of the control policy to be executed.

The **no-match** form of this command specifies a value that results in an unsuccessful match. All other values of the specified match criterion result in a successful match. For example, if you configure the **no-match activated-service-template SVC_1** command, all template values except SVC_1 are accepted as a successful match.

The **class** command associates a control class with a control policy.

Examples

The following example shows how to configure a control class that evaluates true if the service template named VLAN_1 is activated on the session:

```
class-map type control subscriber match-all CLASS_1
 match activated-service-template VLAN_1
```

Related Commands

Command	Description
activate (policy-map action)	Activates a control policy or service template on a subscriber session.
class	Associates a control class with one or more actions in a control policy.
match service-template	Creates a condition that evaluates true based on an event's service template.

Command	Description
service-template	Defines a template that contains a set of service policy attributes to apply to subscriber sessions.

match any

To perform a match on any protocol that passes through the device, use the **match any** command.

match any

Command Default None

Command Modes config-cmap

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to match any packet passing through the device:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# class-map cmap-name
Device(config-cmap)# match any
```

match message-type

To set a message type to match a service list, use the **match message-type** command.

match message-type {**announcement** | **any** | **query**}

Syntax Description

announcement	Allows only service advertisements or announcements for the Device.
any	Allows any match type.
query	Allows only a query from the client for a certain Device in the network.

Command Default

None

Command Modes

Service list configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Multiple service maps of the same name with different sequence numbers can be created, and the evaluation of the filters will be ordered on the sequence number. Service lists are an ordered sequence of individual statements, with each one having a permit or deny result. The evaluation of a service list consists of a list scan in a predetermined order, and an evaluation of the criteria of each statement that matches. A list scan is stopped once the first statement match is found and a permit/deny action associated with the statement match is performed. The default action after scanning through the entire list is to deny.

Note It is not possible to use the **match** command if you have used the **service-list mdns-sd** *service-list-name* **query** command. The **match** command can be used only for the **permit** or **deny** option.

Example

The following example shows how to set the announcement message type to be matched:

```
Device(config-mdns-sd-sl)# match message-type announcement
```

match non-client-nrt

To match non-client NRT (non-real-time), use the **match non-client-nrt** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

match non-client-nrt
no match non-client-nrt

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Class-map

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

This example show how you can configure non-client NRT:

```
Device(config)# class-map test_1000
Device(config-cmap)# match non-client-nrt
```

match protocol

To configure the match criterion for a class map on the basis of a specified protocol, use the **match protocol** command in class-map configuration or policy inline configuration mode. To remove the protocol-based match criterion from the class map, use the **no** form of this command. For more information about the **match protocol** command, refer to the *Cisco IOS Quality of Service Solutions Command Reference*.

match protocol {*protocol-name* | **attribute category** *category-name* | **attribute sub-category** *sub-category-name* | **attribute application-group** *application-group-name*}

Syntax Description

protocol-name	Name of the protocol (for example, bgp) used as a matching criterion.
category-name	Name of the application category used as a matching criterion.
sub-category-name	Name of the application subcategory used as a matching criterion.
application-group-name	Name of the application group as a matching criterion. When the application name is specified, the application is configured as the match criterion instead of the application group.

Command Default

No match criterion is configured.

Command Modes

Class-map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to create class maps with apply match protocol filters for application name, category, and sub category:

```
Device# configure terminal
Device(config)# class-map cat-browsing
Device(config-cmap)# match protocol attribute category browsing
Device(config-cmap)#end

Device# configure terminal
Device(config)# class-map cat-fileshare
Device(config-cmap)# match protocol attribute category file-sharing
Device(config-cmap)#end

Device# configure terminal
Device(config)# class-map match-any subcat-terminal
Device(config-cmap)# match protocol attribute sub-category terminal
Device(config-cmap)#end

Device# configure terminal
Device(config)# class-map match-any webex-meeting
Device(config-cmap)# match protocol webex-meeting
Device(config-cmap)#end
```

This example shows how to create policy maps and define existing class maps for upstream QoS:

```
Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class cat-browsing
Device(config-pmap-c)# police 150000
Device(config-pmap-c)# set dscp 12
Device(config-pmap-c)#end


Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class cat-fileshare
Device(config-pmap-c)# police 1000000
Device(config-pmap-c)# set dscp 20
Device(config-pmap-c)#end


Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class subcat-terminal
Device(config-pmap-c)# police 120000
Device(config-pmap-c)# set dscp 15
Device(config-pmap-c)#end

Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class webex-meeting
Device(config-pmap-c)# police 50000000
Device(config-pmap-c)# set dscp 21
Device(config-pmap-c)#end
```

This example shows how to create policy maps and define existing class maps for downstream QoS:

```
Device# configure terminal
Device(config)# policy-map test-avc-down
Device(config-pmap)# class cat-browsing
Device(config-pmap-c)# police 200000
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)#end


Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class cat-fileshare
Device(config-pmap-c)# police 300000
Device(config-pmap-c)# set wlan user-priority 2
Device(config-pmap-c)# set dscp 20
Device(config-pmap-c)#end


Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class subcat-terminal
Device(config-pmap-c)# police 100000
Device(config-pmap-c)# set dscp 25
Device(config-pmap-c)#end

Device# configure terminal
Device(config)# policy-map test-avc-up
Device(config-pmap)# class webex-meeting
Device(config-pmap-c)# police 60000000
```

```
Device(config-pmap-c)# set dscp 41
Device(config-pmap-c)#end
```

This example shows how to apply defined QoS policy on a WLAN:

```
Device# configure terminal
Device(config)#wlan  alpha
Device(config-wlan)#shut
Device(config-wlan)#end
Device(config-wlan)#service-policy client input test-avc-up
Device(config-wlan)#service-policy client output test-avc-down
Device(config-wlan)#no shut
Device(config-wlan)#end
```

match service-instance

To set a service instance to match a service list, use the **match service-instance** command.

match service-instance *line*

Syntax Description

line	Regular expression to match the service instance in packets.

Command Default

None

Command Modes

Service list configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

It is not possible to use the **match** command if you have used the **service-list mdns-sd** *service-list-name* **query** command. The **match** command can be used only for the **permit** or **deny** option.

Example

The following example shows how to set the service instance to match:

```
Device(config-mdns-sd-sl)# match service-instance servInst 1
```

match service-type

To set the value of the mDNS service type string to match, use the **match service-type** command.

match service-type *line*

Syntax Description

line	Regular expression to match the service type in packets.

Command Default

None

Command Modes

Service list configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

It is not possible to use the **match** command if you have used the **service-list mdns-sd** *service-list-name* **query** command. The **match** command can be used only for the **permit** or **deny** option.

Example

The following example shows how to set the value of the mDNS service type string to match:

```
Device(config-mdns-sd-sl)# match service-type _ipp._tcp
```

match user-role

To configure the class-map attribute filter criteria, use the **match user-role** command.

match user-role *user-role*

Command Default None

Command Modes config-filter-control-classmap

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a class-map attribute filter criteria:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# class-map type control subscriber match-any map-name
Device(config-filter-control-classmap)# match user-role user-role
```

match username

To create a condition that evaluates true based on an event's username, use the **match username** command in control class-map filter configuration mode. To create a condition that evaluates true if an event's username does not match the specified username, use the **no-match username** command in control class-map filter configuration mode. To remove the condition, use the **no** form of this command.

match username *username*
no-match username *username*
no {**match** | **no-match**} **username** *username*

Syntax Description

username	Username.

Command Default

The control class does not contain a condition based on the event's username.

Command Modes

Control class-map filter configuration (config-filter-control-classmap)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

The **match username** command configures a match condition in a control class based on the username. A control class can contain multiple conditions, each of which will evaluate as either true or false. The control class defines whether all, any, or none of the conditions must evaluate true to execute the actions of the control policy.

The **no-match** form of this command specifies a value that results in an unsuccessful match. All other values of the specified match criterion result in a successful match. For example, if you configure the **no-match username josmithe** command, the control class accepts any username value except josmithe as a successful match.

The **class** command associates a control class with a control policy.

Examples

The following example shows how to configure a control class that evaluates true if the username is josmithe:

```
class-map type control subscriber match-all CLASS_1
 match username josmithe
```

Related Commands

Command	Description
class	Associates a control class with one or more actions in a control policy.
policy-map type control subscriber	Defines a control policy for subscriber sessions

match (access-map configuration)

To set the VLAN map to match packets against one or more access lists, use the **match** command in access-map configuration mode. Use the **no** form of this command to remove the match parameters.

{**match ip address** {*namenumber*} [*namenumber*] [*namenumber*]**. . .** | **mac address** *name* [*name*] [*name*]**. . .**}
{**no match ip address** {*namenumber*} [*namenumber*] [*namenumber*]**. . .** | **mac address** *name* [*name*] [*name*]**. . .**}

Syntax Description

ip address	Set the access map to match packets against an IP address access list.
mac address	Set the access map to match packets against a MAC address access list.
name	Name of the access list to match packets against.
number	Number of the access list to match packets against. This option is not valid for MAC access lists.

Command Default

The default action is to have no match parameters applied to a VLAN map.

Command Modes

Access-map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You enter access-map configuration mode by using the **vlan access-map** global configuration command.

You must enter one access list name or number; others are optional. You can match packets against one or more access lists. Matching any of the lists counts as a match of the entry.

In access-map configuration mode, use the **match** command to define the match conditions for a VLAN map applied to a VLAN. Use the **action** command to set the action that occurs when the packet matches the conditions.

Packets are matched only against access lists of the same protocol type; IP packets are matched against IP access lists, and all other packets are matched against MAC access lists.

Both IP and MAC addresses can be specified for the same map entry.

Examples

This example shows how to define and apply a VLAN access map *vmap4* to VLANs 5 and 6 that will cause the interface to drop an IP packet if the packet matches the conditions defined in access list *al2*.

```
Device(config)# vlan access-map vmap4
Device(config-access-map)# match ip address al2
Device(config-access-map)# action drop
Device(config-access-map)# exit
```

```
Device(config)# vlan filter vmap4 vlan-list 5-6
```

You can verify your settings by entering the **show vlan access-map** privileged EXEC command.

match (class-map configuration)

To define the match criteria to classify traffic, use the **match** command in class-map configuration mode. Use the **no** form of this command to remove the match criteria.

Cisco IOS XE Everest 16.5.x and Earlier Releases

match {**access-group** {**name***acl-name acl-index*} | **class-map** *class-map-name* | **cos** *cos-value* | **dscp** *dscp-value* | [**ip**] **dscp** *dscp-list* | [**ip**] **precedence** *ip-precedence-list* | **precedence** *precedence-value1...value4* | **qos-group** *qos-group-value* | **vlan** *vlan-id*}
no match {**access-group** {**name***acl-name acl-index*} | **class-map** *class-map-name* | **cos** *cos-value* | **dscp** *dscp-value* | [**ip**] **dscp** *dscp-list* | [**ip**] **precedence** *ip-precedence-list* | **precedence** *precedence-value1...value4* | **qos-group** *qos-group-value* | **vlan** *vlan-id*}

Cisco IOS XE Everest 16.6.x and Later Releases

match {**access-group** {**name** *acl-name acl-index*} | **cos** *cos-value* | **dscp** *dscp-value* | [**ip**] **dscp** *dscp-list* | [**ip**] **precedence** *ip-precedence-list* | **mpls** *experimental-value* | **non-client-nrt** | **precedence** *precedence-value1...value4* | **protocol** *protocol-name* | **qos-group** *qos-group-value* | **vlan** *vlan-id* | **wlan** *wlan-id*}
no match {**access-group** {**name** *acl-name acl-index*} | **cos** *cos-value* | **dscp** *dscp-value* | [**ip**] **dscp** *dscp-list* | [**ip**] **precedence** *ip-precedence-list* | **mpls** *experimental-value* | **non-client-nrt** | **precedence** *precedence-value1...value4* | **protocol** *protocol-name* | **qos-group** *qos-group-value* | **vlan** *vlan-id* | **wlan** *wlan-id*}

Syntax Description

access-group	Specifies an access group.
name *acl-name*	Specifies the name of an IP standard or extended access control list (ACL) or MAC ACL.
acl-index	Specifies the number of an IP standard or extended access control list (ACL) or MAC ACL. For an IP standard ACL, the ACL index range is 1 to 99 and 1300 to 1999. For an IP extended ACL, the ACL index range is 100 to 199 and 2000 to 2699.
class-map *class-map-name*	Uses a traffic class as a classification policy and specifies a traffic class name to use as the match criterion.
cos *cos-value*	Matches a packet on the basis of a Layer 2 class of service (CoS)/Inter-Switch Link (ISL) marking. The cos-value is from 0 to 7. You can specify up to four CoS values in one **match cos** statement, separated by a space.
dscp *dscp-value*	Specifies the parameters for each DSCP value. You can specify a value in the range 0 to 63 specifying the differentiated services code point value.

ip dscp *dscp-list*	Specifies a list of up to eight IP Differentiated Services Code Point (DSCP) values to match against incoming packets. Separate each value with a space. The range is 0 to 63. You also can enter a mnemonic name for a commonly used value.
ip precedence *ip-precedence-list*	Specifies a list of up to eight IP-precedence values to match against incoming packets. Separate each value with a space. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
precedence *precedence-value1...value4*	Assigns an IP precedence value to the classified traffic. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
qos-group *qos-group-value*	Identifies a specific QoS group value as a match criterion. The range is 0 to 31.
vlan *vlan-id*	Identifies a specific VLAN as a match criterion. The range is 1 to 4094.
mpls *experimental-value*	Specifies Multi Protocol Label Switching specific values.
non-client-nrt	Matches a non-client NRT (non-real-time).
protocol *protocol-name*	Specifies the type of protocol.
wlan *wlan-id*	Identifies 802.11 specific values.

Command Default

No match criteria are defined.

Command Modes

Class-map configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introc

Usage Guidelines

The **match** command is used to specify which fields in the incoming packets are examined to classify the packets. Only the IP access group or the MAC access group matching to the Ether Type/Len are supported.

If you enter the **class-map match-any***class-map-name* global configuration command, you can enter the following **match** commands:

- **match access-group name** *acl-name*



Note The ACL must be an extended named ACL.

- **match ip dscp** *dscp-list*
- **match ip precedence** *ip-precedence-list*

The **match access-group** *acl-index* command is not supported.

To define packet classification on a physical-port basis, only one **match** command per class map is supported. In this situation, the **match-any** keyword is equivalent.

For the **match ip dscp** *dscp-list* or the **match ip precedence** *ip-precedence-list* command, you can enter a mnemonic name for a commonly used value. For example, you can enter the **match ip dscp af11** command, which is the same as entering the **match ip dscp 10** command. You can enter the **match ip precedence critical** command, which is the same as entering the **match ip precedence 5** command. For a list of supported mnemonics, enter the **match ip dscp ?** or the **match ip precedence ?** command to see the command-line help strings.

Use the **input-interface** *interface-id-list* keyword when you are configuring an interface-level class map in a hierarchical policy map. For the *interface-id-list*, you can specify up to six entries.

Examples

This example shows how to create a class map called class2, which matches all the incoming traffic with DSCP values of 10, 11, and 12:

```
Device(config)# class-map class2
Device(config-cmap)# match ip dscp 10 11 12
Device(config-cmap)# exit
```

This example shows how to create a class map called class3, which matches all the incoming traffic with IP-precedence values of 5, 6, and 7:

```
Device(config)# class-map class3
Device(config-cmap)# match ip precedence 5 6 7
Device(config-cmap)# exit
```

This example shows how to delete the IP-precedence match criteria and to classify traffic using acl1:

```
Device(config)# class-map class2
Device(config-cmap)# match ip precedence 5 6 7
Device(config-cmap)# no match ip precedence
Device(config-cmap)# match access-group acl1
Device(config-cmap)# exit
```

This example shows how to specify a list of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Device(config)# class-map match-any class4
Device(config-cmap)# match cos 4
Device(config-cmap)# exit
```

This example shows how to specify a range of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Device(config)# class-map match-any class4
Device(config-cmap)# match cos 4
Device(config-cmap)# exit
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

match wlan user-priority

To match 802.11 specific values, use the **match wlan user-priority** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

match wlan user-priority *wlan-value* [*wlan-value*] [*wlan-value*] [*wlan-value*]
no match wlan user-priority *wlan-value* [*wlan-value*] [*wlan-value*] [*wlan-value*]

Syntax Description

wlan-value	The 802.11-specific values. Enter the user priority 802.11 TID user priority (0-7). (Optional) Enter up to three user priority values separated by white-spaces.

Command Default

None

Command Modes

Class-map configuration (config-cmap)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

This example show how you can configure user-priority values:

```
Device(config)# class-map test_1000
Device(config-cmap)# match wlan user-priority 7
```

max-bandwidth

To configure the wireless media-stream's maximum expected stream bandwidth in Kbps, use the **max-bandwidth** command.

max-bandwidth *bandwidth*

Syntax Description

bandwidth	Maximum Expected Stream Bandwidth in Kbps. Valid range is 1 to 35000 Kbps.

Command Default

None

Command Modes

media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure wireless media-stream bandwidth in Kbps:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group doc-grp 224.0.0.0 224.0.0.223
Device(config-media-stream)# max-bandwidth 3500
```

max-through

To limit multicast router advertisements (RAs) per VLAN per throttle period, use the **max-through** command in IPv6 RA throttle policy configuration mode. To reset the command to its defaults, use the **no** form of this command.

max-through {*mt-value* | **inherit** | **no-limit**}

Syntax Description

mt-value	Number of multicast RAs allowed on the VLAN before throttling occurs. The range is from 0 through 256.
inherit	Merges the setting between target policies.
no-limit	Multicast RAs are not limited on the VLAN.

Command Default

10 RAs per VLAN per 10 minutes

Command Modes

IPv6 RA throttle policy configuration (config-nd-ra-throttle)

Command History

Release	Modification
Cisco IOS XE Release 3.2XE	This command was introduced.

Usage Guidelines

The **max-through** command limits the amount of multicast RAs that are passed through to the VLAN per throttle period. This command can be configured only on a VLAN.

Example

```
Device(config)# ipv6 nd ra-throttle policy policy1
Device(config-nd-ra-throttle)# max-through 25
```

mdns-sd

To configure the mDNS service discovery gateway, use the **mdns-sd** command. To disable the configuration, use the **no** form of this command.

mdns-sd { **gateway** | **service-definition** *service-definition-name* | **service-list** *service-list-name* { **IN** | **OUT** } | **service-policy** *service-policy-name* }

no mdns-sd { **gateway** | **service-definition** *service-definition-name* | **service-list** *service-list-name* { **IN** | **OUT** } | **service-policy** *service-policy-name* }

Syntax Description

mdns-sd	Configures the mDNS service discovery gateway.
gateway	Configures mDNS gateway.
service-definition	Configures mDNS service definition.
service-definition-name	Specifies the mDNS service definition name.
service-list	Configures mDNS service list.
service-list-name	Specifies the mDNS service definition name.
IN	Specifies the inbound filtering.
OUT	Specifies the outbound filtering.
service-policy	Configures mDNS service policy.
service-policy-name	Specifies the mDNS service policy name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to configure the mDNS service discovery gateway:

```
Device(config)# mdns-sd gateway
```

mdns-sd-interface

To configure the mDNS service discovery per WLAN, use the **mdns-sd-interface** command. To disable the command, use the **no** form of this command.

mdns-sd-interface { **drop** | **gateway** }

no mdns-sd-interface { **drop** | **gateway** }

Syntax Description

mdns-sd-interface	Configures the mDNS service discovery per WLAN
drop	Disables mDNS gateway and bridging for WLAN.
gateway	Enables mDNS gateway for WLAN.

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to configure the mDNS service discovery per WLAN:

```
Device(config-wlan)# mdns-sd-interface gateway
```

mdns-sd flex-profile

To configure the mDNS service discovery flex profile, use the **mdns-sd flex-profile** command. To disable the command, use the **no** form of this command.

mdns-sd flex-profile *flex-profile-name*

no mdns-sd flex-profile *flex-profile-name*

Syntax Description

mdns-sd flex-profile	Configures the mDNS service discovery flex profile.
flex-profile-name	Specifies the mDNS flex profile name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to configure the mDNS service discovery flex profile:

```
Device(config)# mdns-sd flex-profile mdns-flex-profile
```

mdns-sd profile

To apply the mDNS flex profile to the wireless flex profile, use the **mdns-sd profile** command in the wireless flex profile mode. To disable the command, use the **no** form of this command.

mdns-sd profile *flex-profile-name*

no mdns-sd profile *flex-profile-name*

Syntax Description

mdns-sd profile	Configures the mDNS flex profile in the wireless flex profile.
flex-profile-name	Specifies the mDNS flex profile name.

Command Default

None

Command Modes

Wireless flex profile configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to apply the mDNS flex profile to the wireless flex profile:

```
Device(config-wireless-flex-profile)# mdns-sd profile mdns-flex-profile
```

method fast

To configure EAP profile to support EAP-FAST method, use the **method fast** command.

method fast [**profile** *profile-name*]

Syntax Description

profile-name	Specify the method profile.

Command Default

None

Command Modes

config-eap-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable EAP Fast method on a EAP profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# eap profile profile-name
Device(config-eap-profile)# method fast
```

mgmtuser username

To set a username and password for AP management, use the **mgmtuser username** command. To disable this feature, use the **no** form of this command.

mgmtuser username *username* **password {0 | 8}** *password*

Syntax Description

username	Enter a username for AP management.
0	Specifies an UNENCRYPTED password.
8	Specifies an AES encrypted password.
password	Configures the encryption password (key).

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.6.1	This command was introduced.

Examples

The following example shows how to set a username and password for AP management:

```
Device# enable
Device# configure terminal
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# mgmtuser username myusername password 0
Device(config-ap-profile)# end
```

mobility backhaul-check coordinator-down

To configure URWB mobility backhaul-check when coordinator is unreachable, use the **mobility backhaul-check coordinator-down** {**handoff-inhibition** | **relay-switch**} command. Use the **no** form of this command to disable URWB mobility backhaul-check with coordinator-down

mobility backhaul-check coordinator-down { **handoff-inhibition** | **relay-switch** }

no mobility backhaul-check coordinator-down { **handoff-inhibition** | **relay-switch** }

Syntax Description

handoff-inhibition	Inhibits handoff if the coordinator is unreachable.
relay-switch	Switches to Infrastructure Wireless Relay mode if the coordinator is unreachable.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure URWB mobility backhaul-check when coordinator is unreachable:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility backhaul-check coordinator-down
handoff-inhibition
```

mobility backhaul-check eth-down

To configure URWB mobility backhaul-check when all Ethernet ports are disconnected, use the **mobility backhaul-check eth-down** {**handoff-inhibition** | **relay-switch**} command. Use the **no** form of this command to disable URWB mobility backhaul-check with the Ethernet ports disconnected.

mobility backhaul-check eth-down { **handoff-inhibition** | **relay-switch** }

no mobility backhaul-check eth-down { **handoff-inhibition** | **relay-switch** }

Syntax Description

handoff-inhibition	Inhibits handoff if all the Ethernet ports are down.
relay-switch	Switches to Infrastructure Wireless Relay mode if all the Ethernet ports are down.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how configure URWB mobility backhaul-check when all Ethernet ports are disconnected:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility backhaul-check eth-down handoff-inhibition
```

mobility mpo cos

To configure the class-of-service (COS) packets to be protected through MPO, use the **mobility mpo cos** *cos-value* command.

mobility mpo cos *cos-value*

Syntax Description

cos-value	Specifies the COS value.

Command Default

The default value is 6.

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the class-of-service (COS) packets to be protected through MPO:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility mpo cos 5
```

mobility mpo enable

To enable multipath operation (MPO) on RX and TX traffic, use the **mobility mpo enable** {**rx-only** | **tx-rx**}

mobility mpo enable { **rx-only** | **tx-rx** }

Syntax Description

rx-only	Enables the MPO feature only on the received traffic.
tx-rx	Enables the MPO feature bidirectionally.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure URWB mobility backhaul-check when all Ethernet ports are disconnected:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility mpo enable rx-only
```

mobility mpo path

To configure the maximum number of links on the backhaul radio, use the **mobility mpo path** *number-of-links* command.

mobility mpo path *number-of-links*

Syntax Description

number-of-links	Specifies the maximum number of links that need to be established for traffic duplication.

Command Default

The default value is 1.

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how configure the maximum number of links on the backhaul radio:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility mpo path 1
```

mobility mpo rssi

To configure minimum RSSI to establish MPO redundant links, use the **mobility mpo rssi** *rssi-value*

mobility mpo rssi *rssi-value (0-96)*

Syntax Description

rssi-value	Specifies the RSSI value. The range is from 0 to 96.

Command Default

The default value is 0.

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure minimum RSSI to establish MPO redundant links:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility mpo rssi 0
```

mobility mpo telemetry

To configure multipath operation telemety, use the **mobility mpo telemetry** command.

mobility mpo telemetry

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the class-of-service (COS) packets to be protected through MPO:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility mpo telemetry
```

mobility role

To configure URWB mobility role, use the **mobility role**{ **base** | **base-relay** | **client**}

mobility role { **base** | **base-relay** | **client** }

Syntax Description

base	Specifies the mobility role base.
base-relay	Specifies the mobility role base relay.
client	Specifies the mobility role client.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB mobility role:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility role base
```

mobility scan

To configure mobility frequency scan feature, use the **mobility scan**{**isolation** *0-65535* | **periodic** *0-65535* | **rssi-threshold** *0-96*} command.

mobility scan { **isolation** *0-65535* | **periodic** *0-65535* | **rssi-threshold** *0-96* }

no mobility scan isolation

no mobility scan periodic

no mobility scan rssi-threshold

Syntax Description

isolation	Specifies that scanning takes place when the device is disconnected from the infrastructure.
periodic	Specifies a periodic background scanning.
rssi-threshold	Specifies that scanning takes place when RSSI falls below threshold.
0-65535	Specifies the maximum waiting-time after which the scanning is triggered (ms), for isolation and periodic scanning.
0-96	Specifies the threshold value.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure mobility frequency scan feature:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mobility scan isolation 3600
```

monitor capture (access list/class map)

To configure a monitor capture specifying an access list or a class map as the core filter for the packet capture, use the **monitor capture** command in privileged EXEC mode. To disable the monitor capture with the specified access list or class map as the core filter, use the **no** form of this command.

monitor capture *capture-name* { **access-list** *access-list-name* | **class-map** *class-map-name* }
no monitor capture *capture-name* { **access-list** *access-list-name* | **class-map** *class-map-name* }

Syntax Description

capture-name	The name of the capture.
access-list *access-list-name*	Configures an access list with the specified name.
class-map *class-map-name*	Configures a class map with the specified name.

Command Default

A monitor capture with the specified access list or a class map as the core filter for the packet capture is not configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced.

Usage Guidelines

Configure the access list using the **ip access-list** command or the class map using the **class-map** command before using the **monitor capture** command. You can specify a class map, or an access list, or an explicit inline filter as the core filter. If you have already specified the filter when you entered the **monitor capture match** command, the command replaces the existing filter.

Examples

The following example shows how to define a core system filter using an existing access control list:

```
Device> enable
Device# configure terminal
Device(config)# ip access-list standard acl1
Device(config-std-nacl)# permit any
Device(config-std-nacl)# exit
Device(config)# exit
Device# monitor capture mycap access-list acl1
Device# end
```

The following example shows how to define a core system filter using an existing class map:

```
Device> enable
Device# configure terminal
Device(config)# ip access-list standard acl1
Device(config-std-nacl)# permit any
Device(config-std-nacl)# exit
Device(config)# class-map match-all cmap
Device(config-cmap)# match access-group name acl
Device(config-cmap)# exit
```

```
Device(config)# exit
Device# monitor capture mycap class-map classmap1
Device# end
```

monitor capture export

To store captured packets in a file, use the **monitor capture export** command in privileged EXEC mode.

monitor capture *capture-name* **export** *filelocation* / *file-name*

Syntax Description

capture-name	Name of the capture.
export	Stores all the packets in capture buffer to a file of type .PCAP.
file-location/*file-name*	Destination file location and name.

Command Default

The captured packets are not stored.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use the **monitor capture export** command only when the storage destination is a capture buffer. The file may be stored either remotely or locally. Use this command either during capture or after the packet capture has stopped. The packet capture could have stopped because one or more end conditions has been met or you entered the **monitor capture stop** command.

Examples

The following example shows how to export capture buffer contents:

```
Device> enable
Device# monitor capture mycap export tftp://10.1.88.9/mycap.pcap
Device# end
```

monitor capture (interface/control plane)

To configure monitor capture specifying an attachment point and the packet flow direction, use the **monitor capture** command in privileged EXEC mode. To disable the monitor capture with the specified attachment point and the packet flow direction, use the **no** form of this command.

monitor capture *capture-name* { **interface** *type number* | **control-plane** } { **in** | **out** | **both** }
no monitor capture *capture-name* { **interface** *type number* | **control-plane** } { **in** | **out** | **both** }

Syntax Description

capture-name	Name of the capture.
interface *type number*	Configures an interface with the specified type and number as an attachment point.
control-plane	Configures a control plane as an attachment point.
in	Specifies the inbound traffic direction.
out	Specifies the outbound traffic direction.
both	Specifies both inbound and outbound traffic directions.

Command Default

The monitor packet capture filter specifying is not configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Repeat the **monitor capture** command as many times as required to add multiple attachment points.

Examples

The following example shows how to add an attachment point to an interface:

```
Device> enable
Device# monitor capture mycap interface GigabitEthernet 0/0/1 in
Device# end
```

The following example shows how to add an attachment point to a control plane:

```
Device> enable
Device# monitor capture mycap control-plane out
Device# end
```

monitor capture limit

To configure capture limits, use the **monitor capture limit** command in privileged EXEC mode. To remove the capture limits, use the **no** form of this command.

monitor capture *capture-name* **limit** [**duration** *seconds*] [**every** *number*] [**packet-length** *size*] [**packets** *number*] [**pps** *number*]
no monitor capture *name* **limit** [**duration**] [**every**] [**packet-length**] [**packets**] [**pps**]

Syntax Description

capture-name	Name of the packet capture.
duration *seconds*	(Optional) Specifies the duration of the capture, in seconds. The range is from 1 to 1000000.
every *number*	(Optional) Specifies that, in a series of packets, the packet whose numerical order is denoted by the *number* argument should be captured. The range is from 2 to 100000.
packet-length *bytes*	(Optional) Specifies the packet length, in bytes. If the actual packet is longer than the specified length, only the first set of bytes whose number is denoted by the *bytes* argument is stored.
packets *packets-number*	(Optional) Specifies the number of packets to be processed for capture.
pps *pps-number*	(Optional) Specifies the number of packets to be captured per second. The range is from 1 to 1000000.

Command Default

No capture limits are configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

If no duration is specified, the capture does not stop until it is manually interrupted. The entire packet is processed if the **packet-length** *bytes* keyword-argument pair is not specified. All matched packets are captured, if the **every** *number* keyword-argument pair is not specified. All matched packets are captured if the **packets** *packets-number* keyword-argument pair is not specified. The incoming packets are captured at the rate of 1 million packets per second if the **pps** *number* keyword-argument pair is not specified.

Examples

The following example shows how to specify capture limits:

```
Device> enable
Device# monitor capture mycap limit duration 10
Device# monitor capture mycap limit packet-length 128
Device# monitor capture mycap limit packets 100
Device# monitor capture mycap limit pps 1000
```

```
Device# monitor capture mycap limit duration 10 packet-length 128 packets 100
Device# end
```

monitor capture match

To define an explicit inline core filter, use the **monitor capture match** command in privileged EXEC mode. To remove this filter, use the **no** form of this command.

monitor capture *capture-name* **match**
{ **any** | { **ipv4** | **ipv6** } { *source-prefix/length* | **any** | **host** } *source-ip-address* { { *destination-prefix/length* | **any** | **host** } *destination-ip-address* } | **protocol** { **tcp** | **udp** } { { *source-prefix/length* | **any** | **host** } { { *destination-prefix/length* | **any** | **host** } | [[**eq** | **gt** | **lt** | **neg**] *port-number*] | **range** *start-port-number end-port-number* | [**eq** | **gt** | **lt** | **neg**] *port-number* | **range** *start-port-number end-port-number* } } | **mac** { *source-mac-address* | { **any** | **host** } *source-mac-address* } *source-mac-address-mask* { *destination-mac-address* | { **any** | **host** } *destination-mac-address* } *destination-mac-address-mask* }
no monitor capture *capture-name* **match**

Syntax Description

epc-capture-name	Name of the capture.
any	Specifies all packets.
ipv4	Specifies IPv4 packets.
ipv6	Specifies IPv6 packets.
source-prefix/length	The network prefix and length of the IPv4 or IPv6 source address.
any	Specifies network prefix of any source IPv4 or IPv6 address.
host	Specifies the source host.
source-ip-address	Source IPv4 or IPv6 address.
destination-prefix/length	Destination IPv4 or IPv6 address.
any	Specifies the network prefix and length of any IPv4 or IPv6 destination address.
host	Specifies the destination host.
destination-ip-address	Destination IPv4 or IPv6 address.
protocol	Specifies the protocol.
tcp	Specifies the TCP protocol.
udp	Specifies the UDP protocol.
eq	(Optional) Specifies that only packets with a port number that is equal to the port number associated with the IP address are matched.

gt	(Optional) Specifies that only packets with a port number that is greater than the port number associated with the IP address are matched.
lt	(Optional) Specifies that only packets with a port number that is lower than the port number associated with the IP address are matched.
neq	(Optional) Specifies that only packets with a port number that is not equal to the port number associated with the IP address are matched.
port-number	(Optional) The port number associated with the IP address. The range is from 0 to 65535.
range	(Optional) Specifies the range of port numbers.
start-port-number	(Optional) The start of the range of port numbers. The range is from 0 to 65535.
end-port-number	(Optional) The end of the range of port numbers. The range is from 0 to 65535.
mac	Specifies a Layer 2 packet.
source-mac-address	The source MAC address.
any	Specifies the network prefix of any source MAC address.
host	Specifies the MAC source host.
source-mac-address-mask	The source MAC address mask.
destination-mac-address	The destination MAC address.
any	Specifies the network prefix of any destination MAC address.
host	Specifies the MAC source host.
destination-mac-address-mask	The destination MAC address mask.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.12.1	This command was introduced.

Usage Guidelines

Use the **monitor capture** command to specify the core filter as a class map, access list, or explicit inline filter. Any filter has already specified before you enter the **monitor capture match** command is replaced.

Examples

The following example shows how to set various explicit filters:

```
Device> enable
Device# monitor capture mycap match any
Device# monitor capture mycap match mac any any
Device# monitor capture mycap match ipv4 any any
Device# monitor capture mycap match ipv4 protocol udp 198.51.100.0/24 eq 20001 any
Device# end
```

The following example shows how to set a filter for MAC addresses:

```
Device> enable
Device# monitor capture match mycap mac 0030.9629.9f84 0000.0000.0000 0030.7524.9f84
0000.0000.0000
Device# end
```

The following example shows how to set a filter for IPv4 traffic:

```
Device> enable
Device# monitor capture match mycap ipv4 198.51.100.0/24 198.51.100.1 203.0.113.0/24
203.0.113.254
Device# end
```

monitor capture start

To start the capture of packet data at a traffic trace point into a buffer, use the **monitor capture start** command in privileged EXEC mode.

monitor capture *epc-capture-name* **start**

Syntax Description

epc-capture-name	Name of the capture.

Command Default

Data packets are not captured into a buffer.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use the **monitor capture start** command to enable the packet data capture after the capture point is defined. To stop the capture of packet data, use the **monitor capture stop** command.

Ensure that system resources such as CPU and memory are available before starting a capture.

Examples

The following example shows how to start capture buffer contents:

```
Device> enable
Device# monitor capture mycap start
Device# monitor capture mycap export tftp://10.1.88.9/mycap.pcap
Device# monitor capture mycap limit packets 100 duration 60
Device# monitor capture mycap start
Device# end
```

monitor capture stop

To stop the capture of packet data at a traffic trace point, use the **monitor capture stop** command in privileged EXEC mode.

monitor capture *epc-capture-name* **stop**

Syntax Description

epc-capture-name	Name of the capture.

Command Default

The packet data capture is ongoing.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use the **monitor capture start** command to start the capture of packet data that you started by using the **monitor capture start** command. You can configure two types of capture buffers: linear and circular. When the linear buffer is full, data capture stops automatically. When the circular buffer is full, data capture starts from the beginning and the data is overwritten.

Examples

The following example shows how to stop capture buffer contents:

```
Device> enable
Device# monitor capture mycap stop
Device# end
```

mop sysid

To enable an interface to send out periodic Maintenance Operation Protocol (MOP) system identification messages, use the **mopsysid** command in interface configuration mode. To disable MOP message support on an interface, use the **no** form of this command.

mop sysid
no mop sysid

Syntax Description

This command has no arguments or keywords.

Command Default

Enabled

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

You can still run MOP without having the background system ID messages sent. This command lets you use the MOP remote console, but does not generate messages used by the configurator.

Examples

The following example enables serial interface 0 to send MOP system identification messages:

```
Router(config)# interface serial 0
Router(config-if)# mop sysid
```

Related Commands

Command	Description
mop device-code	Identifies the type of device sending MOP sysid messages and request program messages.
mop enabled	Enables an interface to support the MOP.

mpls ether-filter ethernet-I

To configure URWB ether-filter Ethernet-I frames forwarding, use the **mpls ether-filter ethernet-I** command.

mpls ether-filter ethernet-I

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure URWB ether-filter Ethernet-I frames forwarding:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mpls ether-filter ethernet-I
```

mpls ether-filter ethertypes filtering

To configure Ethernet type (L2 transparency) filtering method, use the **mpls ether-filter ethertypes filtering** {**allow-all** | **use-allow-list**}. Use the no form of this command to disable the feature.

mpls ether-filter ethertypes filtering { **allow-all** | **use-allow-list** }

no mpls ether-filter ethertypes filtering { **allow-all** | **use-allow-list** }

Syntax Description

allow-all	Specifies that the Ethernet type allows all ethertypes filtering.
use-allow-list	Specifies that only configured ethertypes allow-list is used.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure Ethernet type (L2 transparency) filtering method:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mpls ether-filter ethertypes filtering use-allow-list
```

mpls high-availability timeout

To configure the Multiprotocol Label Switching (MPLS) high availability node failure detection timeout, use the **mpls high-availability timeout** *timeout-value*. Use

mpls high-availability timeout *timeout-value*

no mpls high-availability

Syntax Description

timeout	Specifies the high availability node failure detection timeout, in seconds. The range is from 0 to 65535 seconds.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the Multiprotocol Label Switching (MPLS) high availability node failure detection timeout:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# mpls high-availability timeout 180
```

multicast (URWB)

To configure the multicast settings for the URWB profile, use the **multicast** {**all** | **coordinator-only**} command. Use the **no** form of the command to disable the URWB multicast settings.

multicast { **all** | **coordinator-only** }

no multicast

Syntax Description

all	Enables the multicast rule as a broadcast.
coordinator-only	Enables the multicast rule to the coordinator only.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the multicast settings for the URWB profile:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# multicast coordinator-only
```

multicast vlan

To configure multicast on a single VLAN, use the **multicast vlan** command. To remove the multicast, use the **no** form of the command.

multicast vlan *vlan-id*
no multicast vlan *vlan-id*

Syntax Description

vlan-id	Specifies the VLAN ID.

Command Default

Disabled.

Command Modes

Wireless policy configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to configure multicast:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy policy-test
Device(config-wireless-policy)# multicast vlan 12
```

nac

To enable RADIUS Network Admission Control (NAC) support, use the **nac** command. To disable NAC support, use the **no** form of this command.

nac [**ise** | **xwf**]
no nac

Syntax Description

ise	Configures Radius NAC support (Identity Service Engine)
xwf	Configures Express Wi-Fi NAC support.

Command Default

NAC is disabled.

Command Modes

Wireless policy configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to configure RADIUS NAC:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy default-policy-profile
Device(config-wireless-policy)# nac
```

nas-id option2

To configure option 2 parameters for a NAS-ID, use the **nas-id option2** command.

nas-id option2 {**sys-ip** | **sys-name** | **sys-mac** }

Syntax Description

sys-ip	System IP Address.
sys-name	System Name.
sys-mac	System MAC address.

Command Default

None

Command Modes

config-aaa-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the system IP address for the NAS-ID:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless aaa policy profile-name
Device(config-aaa-policy)# nas-id option2 sys-ip
```

network

To configure the network number in decimal notation, use the **network** command.

network *network-number* [*network-mask* | **secondary**]

Syntax Description

ipv4-address	Network number in dotted-decimal notation.
network-mask	Network mask or prefix length.
secondary	Configure as secondary subnet.

Command Default

None

Command Modes

dhcp-config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure network number and the mask address:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ip dhcp pool name
Device(dhcp-config)# network 209.165.200.224 255.255.255.0
```

network-key key

To configure the shared network key, use the **network-key key** {**0** | **8**} *network-key*

network-key key { **0** | **8** } *network-key*

Syntax Description

0 | 8	Here, **0** specifies that an unencrypted network key will follow, and **8** specifies that an AES encrypted network-key will follow.
network-key	Specifies the shared key of the network.

Command Default

None

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Usage Guidelines

The network key is shared with all the devices in the same URWB network.

Examples

The following example shows how to configure the shared network key:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# network-key key {0 | 8} network-key
```

nmsp cloud-services enable

To configure NMSP cloud services, use the **nmsp cloud-services enable** command.

nmsp cloud-services enable

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable NMSP cloud services:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# nmsp cloud-services enable
```

nmsp cloud-services http-proxy

To configure the proxy for NMSP cloud server, use the **nmsp cloud-services http-proxy** command.

nmsp cloud-services http-proxy *proxy-server port*

Syntax Description

proxy-server	Enter the hostname or the IP address of the proxy server for NMSP cloud services.
port	Enter the proxy server port number for NMSP cloud services.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the proxy for NMSP cloud server:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# nmsp cloud-services http-proxy host-name port-number
```

nmsp cloud-services server token

To configure the NMSP cloud services server parameters, use the **nmsp cloud-services server token** command.

nmsp cloud-services server token *token*

Syntax Description

token	Authentication token for the NMSP cloud services.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the for the NMSP cloud services server parameters:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# nmsp cloud-services server token authentication-token
```

nmsp cloud-services server url

To configure NMSP cloud services server URL, use the **nmsp cloud-services server url** command.

nmsp cloud-services server url *url*

Syntax Description

url	URL of the NMSP cloud services server.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a URL for NMSP cloud services server:

```
Device(config)# nmps cloud-services server url http://www.example.com
```

nmsp notification interval

To modify the Network Mobility Services Protocol (NMSP) notification interval value on the controller to address latency in the network, use the **nmsp notification interval** command in global configuration mode.

nmsp notification interval { **attachment** | **location** | **rssi** {**clients** | **rfid** | **rogues** {**ap** | **client** } } }

Syntax Description

attachment	Specifies the time used to aggregate attachment information.
location	Specifies the time used to aggregate location information.
rssi	Specifies the time used to aggregate RSSI information.
clients	Specifies the time interval for clients.
rfid	Specifies the time interval for rfid tags.
rogues	Specifies the time interval for rogue APs and rogue clients .
ap	Specifies the time used to aggregate rogue APs .
client	Specifies the time used to aggregate rogue clients.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to set the NMSP notification interval for the active RFID tags to 25 seconds:

```
Device# configure terminal
Device(config)# nmsp notification-interval rfid 25
Device(config)# end
```

This example shows how to modify NMSP notification intervals for device attachment (connecting to the network or disconnecting from the network) every 10 seconds:

```
Device# configure terminal
Device(config)# nmsp notification-interval attachment 10
Device(config)# end
```

This example shows how to configure NMSP notification intervals for location parameters (location change) every 20 seconds:

```
Device# configure terminal
Device(config)# nmsp notification-interval location 20
Device(config)# end
```

nmsp strong-cipher

To enable the new ciphers, use the **nmsp strong-cipher** command in global configuration mode. To disable, use the **no** form of this command.

nmsp strong-cipher
no nmsp strong-cipher

Syntax Description

This command has no arguments or keywords.

Command Default

The new ciphers are not enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.2(2)E	This command was introduced.

Usage Guidelines

The **nmsp strong-cipher** command enables strong ciphers for new Network Mobility Service Protocol (NMSP) connections.

Note The existing NMSP connections will use the default cipher.

Examples

The following example shows how to enable a strong-cipher for NMSP:

```
Device> enable
Device> configure terminal
Device(config)# nmsp strong-cipher
```

Related Commands

Command	Description
show nmsp status	Displays the status of active NMSP connections.

no shutdown (URWB)

To enable the URWB profile, use the **no shutdown** command in the wireless URWB profile configuration mode.

no shutdown

Syntax Description

This command has no keywords or arguments.

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to enable the URWB profile:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# no shutdown
```

ntp auth-key

To configure the Network Time Protocol (NTP) server authentication key information on an AP profile, use the **ntp auth-key** command. To remove the NTP server authentication key information from an AP profile, use the **no ntp auth-key** command.

ntp auth-key index *key-index* **type** { **md5** | **sha1** } **format** { **ascii** | **hex** } **key** { **0** | **8** } *server-key*

Syntax Description

key-index	Key index. Valid range is from 1 to 65535.
md5	Specifies that a Message Digest 5 (MD5) authentication key will follow.
sha1	Specifies that a Secure Hash Algorithm 1 (SHA1) authentication key will follow.
format	Defines the key format—ASCII or HEX..
ascii	Specifies that an ASCII key will follow.
hex	Specifies that a hex key will follow.
key	Defines the NTP server key—unencrypted or encrypted.
0	Specifies that an UNENCRYPTED password will follow.
8	Specifies that an AES encrypted password will follow.
server-key	NTP server key. For ASCII key, ensure that the length is less than 21 bytes. For HEX key, the length should be less than 41, using only numbers between 0-9 and characters from a-f.

Command Default

NTP server authentication is not set.

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to configure NTP server authentication key information on an AP profile:

```
Device# configure terminal
Device(config)# ap profile test
Device(config-ap-profile)# ntp ip 198.51.100.5
Device(config-ap-profile)# ntp auth-key index 12 type
md5 format ascii key 0 test
```

option

To configure optional data parameters for a flow exporter for , use the **option** command in flow exporter configuration mode. To remove optional data parameters for a flow exporter, use the **no** form of this command.

option {**exporter-stats** | **interface-table** | **sampler-table**} [**timeout** *seconds*]
no option {**exporter-stats** | **interface-table** | **sampler-table**}

Syntax Description

exporter-stats	Configures the exporter statistics option for flow exporters.
interface-table	Configures the interface table option for flow exporters.
sampler-table	Configures the export sampler table option for flow exporters.
timeout *seconds*	(Optional) Configures the option resend time in seconds for flow exporters. The range is 1 to 86400. The default is 600.

Command Default

The timeout is 600 seconds. All other optional data parameters are not configured.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **option exporter-stats** command causes the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent. This command allows the collector to estimate packet loss for the export records it receives. The optional timeout alters the frequency at which the reports are sent.

The **option interface-table** command causes the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names. The optional timeout can alter the frequency at which the reports are sent.

The **option sampler-table** command causes the periodic sending of an options table, which details the configuration of each sampler and allows the collector to map the sampler ID provided in any flow record to a configuration that it can use to scale up the flow statistics. The optional timeout can alter the frequency at which the reports are sent.

To return this command to its default settings, use the **no option** or **default option** flow exporter configuration command.

The following example shows how to enable the periodic sending of the sampler option table, which allows the collector to map the sampler ID to the sampler type and rate:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option sampler-table
```

The following example shows how to enable the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option exporter-stats
```

The following example shows how to enable the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option interface-table
```

parameter-map type subscriber attribute-to-service

To configure parameter map type and name, use the **parameter-map type subscriber attribute-to-service** command.

parameter-map type subscriber attribute-to-service *parameter-map-name*

Syntax Description

attribute-to-service	Name the attribute to service.
parameter-map-name	Name of the parameter map. The map name is limited to 33 characters.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure parameter map type and name:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type subscriber attribute-to-service parameter-map-name
```

pae

To enable product telemetry collection, use the **pae** command. To disable product telemetry collection, use the **no** form of this command.

pae

no pae

Command Default

Product telemetry is enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Dublin 17.10.1	This command was introduced.

Examples

The following example shows how to disable product telemetry collection:

```
Device# configure terminal
Device(config)# no pae
```

parameter-map type webauth

To configure the webauth parameter type for a specific parameter map or all the parameter maps, use the **parameter-map type webauth** command.

parameter-map type webauth { *parameter-map-name* | **global** }

Syntax Description

parameter-map-name	Name of the parameter map. The map name is limited to 99 characters.
global	Applies the configuration to all the parameter maps.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the webauth parameter type for a parameter map named *parameter-map1*:

```
Device# configure terminal
Device(config)# parameter-map type webauth parameter-map1
```

password encryption aes

To enable strong (AES) password encryption, use the **password encryption aes** command. To disable this feature, use the **no** form of this command.

password encryption aes
`no password encryption aes`

Syntax Description

password	Configures the encryption password (key).
encryption	Encrypts system passwords.
aes	Enables stronger (AES) password encryption.

Command Default

None

Command Modes

Global configuration mode.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to enable AES password encryption :

```
Device(config)#password encryption aes
```

peer-blocking

To configure peer-to-peer blocking on a WLAN, use the **peer-blocking** command. To disable peer-to-peer blocking, use the **no** form of this command.

peer-blocking {**drop** | **forward-upstream**}
no peer-blocking

Syntax Description

drop	Specifies the device to discard the packets.
forward-upstream	Specifies the packets to be forwarded on the upstream VLAN. The device next in the hierarchy to the device decides what action to take regarding the packets.

Command Default

Peer blocking is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable the drop and forward-upstream options for peer-to-peer blocking:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan1

Device(config-wlan)# peer-blocking  drop
Device(config-wlan)# peer-blocking forward-upstream
```

This example shows how to disable the drop and forward-upstream options for peer-to-peer blocking:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan1

Device(config-wlan)# no peer-blocking  drop
Device(config-wlan)# no peer-blocking forward-upstream
```

pmf-deauth

To enable PMF-denial type deauthentication rogue AP containment, use the **pmf-deauth** command. To disable PMF-denial type deauthentication rogue AP containment, use the **no** form of this command.

pmf-deauth

no pmf-deauth

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

PMF denail configuration (config-pmf-denial)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to enable PMF-denial type deauthentication rogue AP containment.

```
Device# configure terminal
Device(config)# ap profile xyz-ap-profile
Device(config-ap-profile)# rogue detection containment pmf-denial
Device(config-pmf-denial)# pmf-deauth
```

policy

To configure media stream admission policy, use the **policy** command.

policy {**admit** | **deny**}

Syntax Description

admit	Allows traffic for a media stream group.
deny	Denies traffic for a media stream group.

Command Default

None

Command Modes

media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to allow traffic for a media stream group:

```
Device # configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group ms-group 224.0.0.0 224.0.0.223
Device(media-stream)# policy admit
```

police

To define a policer for classified traffic, use the **police** command in policy-map class configuration mode. Use the **no** form of this command to remove an existing policer.

police *rate-bps burst-byte* [**conform-action transmit**]
no police rate-bps *burst-byte* [**conform-action transmit**]

Syntax Description

rate-bps	Specify the average traffic rate in bits per second (b/s). The range is 1000000 to 1000000000.
burst-byte	Specify the normal burst size in bytes. The range is 8000 to 1000000.
conform-action transmit	(Optional) When less than the specified rate, specify that the switch transmits the packet.

Command Default

No policers are defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

A policer defines a maximum permissible rate of transmission, a maximum burst size for transmissions, and an action to take if either maximum is exceeded.

When configuring hierarchical policy maps, you can only use the **police** policy-map command in a secondary interface-level policy map.

The port ASIC device, which controls more than one physical port, supports 256 policers on the switch (255 user-configurable policers plus 1 policer reserved for internal use). The maximum number of configurable policers supported per port is 63. Policers are allocated on demand by the software and are constrained by the hardware and ASIC boundaries. You cannot reserve policers per port. There is no guarantee that a port will be assigned to any policer.

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to configure a policer that transmits packets if traffic is less than 1 Mb/s average rate with a burst size of 20 KB. There is no packet modification.

```
Device(config)# class-map class1
Device(config-cmap)# exit
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# police 1000000 20000 conform-action transmit
Device(config-pmap-c)# exit
```

This example shows how to configure a policer that transmits packets if traffic is less than 1 Mb/s average rate with a burst size of 20 KB. There is no packet modification. This example uses an abbreviated syntax:

```
Device(config)# class-map class1
Device(config-cmap)# exit
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# police 1m 20000 conform-action transmit
Device(config-pmap-c)# exit
```

This example shows how to configure a policer, which marks down the DSCP values with the values defined in policed-DSCP map and sends the packet:

```
Device(config)# policy-map policy2
Device(config-pmap)# class class2
Device(config-pmap-c)# police 1000000 20000 exceed-action policed-dscp-transmit
Device(config-pmap-c)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

police cir

To set the policing of committed information rate, use the **police cir** command.

police cir *<target bit rate>*

Syntax Description

police cir	Polices committed information rate.
8000-10000000000	Sets the target bit rate at bits per second. The range is between 8000 and 10000000000.

Command Default

None

Command Modes

Policy map class configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to set the committed information rate:

```
Device(config-pmap-c)#police cir 8000
```

policy-map

To create or modify a policy map that can be attached to multiple physical ports or switch virtual interfaces (SVIs) and to enter policy-map configuration mode, use the **policy-map** command in global configuration mode. Use the **no** form of this command to delete an existing policy map and to return to global configuration mode.

policy-map *policy-map-name*
no policy-map *policy-map-name*

Syntax Description

policy-map-name	Name of the policy map.

Command Default

No policy maps are defined.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

After entering the **policy-map** command, you enter policy-map configuration mode, and these configuration commands are available:

- **class**—Defines the classification match criteria for the specified class map.
- **description**—Describes the policy map (up to 200 characters).
- **exit**—Exits policy-map configuration mode and returns you to global configuration mode.
- **no**—Removes a previously defined policy map.
- **sequence-interval**—Enables sequence number capability.

To return to global configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Before configuring policies for classes whose match criteria are defined in a class map, use the **policy-map** command to specify the name of the policy map to be created, added to, or modified. Entering the **policy-map** command also enables the policy-map configuration mode in which you can configure or modify the class policies for that policy map.

You can configure class policies in a policy map only if the classes have match criteria defined for them. To configure the match criteria for a class, use the **class-map** global configuration and **match** class-map configuration commands. You define packet classification on a physical-port basis.

Only one policy map per ingress port is supported. You can apply the same policy map to multiple physical ports.

You can apply a nonhierarchical policy maps to physical ports. A nonhierarchical policy map is the same as the port-based policy maps in the device.

A hierarchical policy map has two levels in the format of a parent-child policy. The parent policy cannot be modified but the child policy (port-child policy) can be modified to suit the QoS configuration.

In VLAN-based QoS, a service policy is applied to an SVI interface.



Note Not all MQC QoS combinations are supported for wired ports. For information about these restrictions, see chapters "Restrictions for QoS on Wired Targets" in the QoS configuration guide.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress port, it matches all the incoming traffic defined in class1, sets the IP DSCP to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic less than the profile is sent.

```
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# police 1000000 20000 conform-action transmit
Device(config-pmap-c)# exit
```

This example show you how to configure hierarchical polices:

```
Device# configure terminal
Device(config)# class-map c1
Device(config-cmap)# exit

Device(config)# class-map c2
Device(config-cmap)# exit

Device(config)# policy-map child
Device(config-pmap)# class c1
Device(config-pmap-c)# priority level 1
Device(config-pmap-c)# police rate percent 20 conform-action transmit exceed action drop
Device(config-pmap-c-police)# exit
Device(config-pmap-c)# exit

Device(config-pmap)# class c2
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit

Device(config-pmap)# class class-default
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit
Device(config-pmap)# exit

Device(config)# policy-map parent
Device(config-pmap)# class class-default
Device(config-pmap-c)# shape average 1000000
Device(config-pmap-c)# service-policy child
Deviceconfig-pmap-c)# end
```

This example shows how to delete a policy map:

```
Device(config)# no policy-map policymap2
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

policy-map

To create or modify a policy map that can be attached to multiple physical ports or switch virtual interfaces (SVIs) and to enter policy-map configuration mode, use the **policy-map** command in global configuration mode. Use the **no** form of this command to delete an existing policy map and to return to global configuration mode.

policy-map *policy-map-name*
no policy-map *policy-map-name*

Syntax Description

policy-map-name	Name of the policy map.

Command Default

No policy maps are defined.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

After entering the **policy-map** command, you enter policy-map configuration mode, and these configuration commands are available:

- **class**—Defines the classification match criteria for the specified class map.
- **description**—Describes the policy map (up to 200 characters).
- **exit**—Exits policy-map configuration mode and returns you to global configuration mode.
- **no**—Removes a previously defined policy map.
- **sequence-interval**—Enables sequence number capability.

To return to global configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Before configuring policies for classes whose match criteria are defined in a class map, use the **policy-map** command to specify the name of the policy map to be created, added to, or modified. Entering the **policy-map** command also enables the policy-map configuration mode in which you can configure or modify the class policies for that policy map.

You can configure class policies in a policy map only if the classes have match criteria defined for them. To configure the match criteria for a class, use the **class-map** global configuration and **match** class-map configuration commands. You define packet classification on a physical-port basis.

Only one policy map per ingress port is supported. You can apply the same policy map to multiple physical ports.

You can apply a nonhierarchical policy maps to physical ports. A nonhierarchical policy map is the same as the port-based policy maps in the device.

A hierarchical policy map has two levels in the format of a parent-child policy. The parent policy cannot be modified but the child policy (port-child policy) can be modified to suit the QoS configuration.

In VLAN-based QoS, a service policy is applied to an SVI interface.



Note Not all MQC QoS combinations are supported for wired ports. For information about these restrictions, see chapters "Restrictions for QoS on Wired Targets" in the QoS configuration guide.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress port, it matches all the incoming traffic defined in class1, sets the IP DSCP to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic less than the profile is sent.

```
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# police 1000000 20000 conform-action transmit
Device(config-pmap-c)# exit
```

This example show you how to configure hierarchical polices:

```
Device# configure terminal
Device(config)# class-map c1
Device(config-cmap)# exit

Device(config)# class-map c2
Device(config-cmap)# exit

Device(config)# policy-map child
Device(config-pmap)# class c1
Device(config-pmap-c)# priority level 1
Device(config-pmap-c)# police rate percent 20 conform-action transmit exceed action drop
Device(config-pmap-c-police)# exit
Device(config-pmap-c)# exit

Device(config-pmap)# class c2
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit

Device(config-pmap)# class class-default
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit
Device(config-pmap)# exit

Device(config)# policy-map parent
Device(config-pmap)# class class-default
Device(config-pmap-c)# shape average 1000000
Device(config-pmap-c)# service-policy child
Deviceconfig-pmap-c)# end
```

This example shows how to delete a policy map:

```
Device(config)# no policy-map policymap2
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

port

To configure the port number to use when configuring the custom application, use the **port** command.

port *port-no*

Syntax Description

port-no	Port number.

Command Default

None

Command Modes

config-custom

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the port number to use when configuring the custom application:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ip nbar custom custom-protocol http host host-string
Device(config-custom)# http host hostname
Device(config-custom)# port port-no
```

priority priority-value

To configure media stream priority, use the **priority** *priority-value* command.

priority *priority-value*

Syntax Description

priority-value	Media stream priority value. Valid range is 1 to 8, with 1 being lowest priority and 8 being highest priority.

Command Default

None

Command Modes

config-media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to set the media stream priority value to the highest, that is 8:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group my-media-group 224.0.0.0 224.0.0.223
Device(config-media-stream)# priority 8
```

public-ip

To configure the NAT public IP address of the controller, use the **public-ip** command.

public-ip { *ipv4-address* | *ipv6-address* }

Syntax Description

ipv4-address	Sets IPv4 address.
ipv6-address	Sets IPv6 address.

Command Default

None

Command Modes

Management Interface Configuration(config-mgmt-interface)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Example

The following example shows how to configure the NAT public IP address of the controller:

```
Device# configure terminal
Device(config)# wireless management interface Vlan1
Device(config-mgmt-interface)# public-ip 192.168.172.100
```

qos video

To configure over-the-air QoS class to video only, use the **qos video** command.

qos video

Command Default None

Command Modes config-media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure over-the-air QoS class to video only:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group my-media-group 224.0.0.0 224.0.0.223
Device(config-media-stream)# qos video
```

radius server

To configure the RADIUS server, use the **radius server** command in global configuration mode.

radius server *server-name*

Syntax Description

server-name	RADIUS server name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The length of the radius name is a variable. However, the parser restricts the CLI length of 256 characters including the **no** form of the command.

The following example shows how to configure a radius server:

```
Device(config)# radius server ISE
```

radius-server deadtime

To improve RADIUS response times when some servers might be unavailable, use the **radius-server deadtime** command to cause the unavailable servers to be skipped immediately. To set dead-time to the default value of 0, use the **no** form of this command.

radius-server deadtime *time-in-minutes*

no radius-server deadtime

Syntax Description

time-in-minutes	Length of time, in minutes, for which a RADIUS server is skipped over by transaction requests, up to a maximum of 1440 minutes (24 hours).

Command Default

Dead time is set to 0.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Use this command to mark as "dead" any RADIUS servers that fail to respond to authentication requests, thus avoiding the wait for the request to time out before trying the next configured server. A RADIUS server marked as "dead" is skipped by additional requests for the duration of minutes or unless there are no servers not marked "dead."

Example

The following example shows how to set deadtime for RADIUS servers that fail to respond to authentication requests:

```
Device(config)# radius-server deadtime 5
```

radius-server attribute wireless accounting call-station-id

To configure call station identifier sent in the RADIUS accounting messages, use the **radius-server attribute wireless accounting call-station-id** command. To remove the call station identifier from the radius accounting messages, use the **no** form of the command.

radius-server attribute wireless authentication call-station-id { **ap-ethmac-only** | **ap-ethmac-ssid** | **ap-ethmac-ssid-flexprofilename** | **ap-ethmac-ssid-policytagname** | **ap-ethmac-ssid-sitetagname** | **ap-group-name** | **ap-label-address** | **ap-label-address-ssid** | **ap-location** | **ap-macaddress** | **ap-macaddress-ssid** | **ap-macaddress-ssid-flexprofilename** | **ap-macaddress-ssid-policytagname** | **ap-macaddress-ssid-sitetagname** | **ap-name** | **ap-name-ssid** | **flex-profile-name** | **ipaddress** | **macaddress** | **policy-tag-name** | **site-tag-name** | **vlan-id** }

Syntax Description

ap-ethmac-only	Sets the call station identifier type to be AP's radio MAC address.
ap-ethmac-ssid	Sets the call station identifier type AP's radio MAC address with SSID.
ap-ethmac-ssid-flexprofilename	Sets the call station identifier type AP's radio MAC address with SSID and flex profile name.
ap-ethmac-ssid-policytagname	Sets the call station identifier type AP's radio MAC address with SSID and policy tag name.
ap-ethmac-ssid-sitetagname	Sets the call station identifier type AP's radio MAC address with SSID and site tag name.
ap-group-name	Sets the call station identifier type to use the AP group name.
ap-label-address	Sets the call station identifier type to the AP's radio MAC address that is printed on the AP label.
ap-label-address-ssid	Sets the call station identifier type to the AP's radio MAC address and SSID that is printed on the AP label.
ap-location	Sets the call station identifier type to the AP location.
ap-macaddress	Sets the call station identifier type to the AP's radio MAC address.
ap-macaddress-ssid	Sets the call station identifier type to the AP's radio MAC address with SSID.
ap-macaddress-ssid-flexprofilename	Sets the call station identifier type to the AP's radio MAC address with SSID and flex profile name.
ap-macaddress-ssid-policytagname	Sets the call station identifier type to the AP's radio MAC address with SSID and policy tag name.
ap-macaddress-ssid-sitetagname	Sets the call station identifier type to the AP's radio MAC address with SSID and site tag name.
ap-name	Sets the call station identifier type to the AP name.

ap-name-ssid	Sets the call station identifier type to the AP name with SSID.
flex-profile-name	Sets the call station identifier type to the flex profile name.
ipaddress	Sets the call station identifier type to the IP address of the system.
macaddress	Sets the call station identifier type to the MAC address of the system.
policy-tag-name	Sets the call station identifier type to the policy tag name.
site-tag-name	Sets the call station identifier type to the site tag name.
vlan-id	Sets the call station identifier type to the system's VLAN ID.

Command Default

Call station identifier is not configured.

Command Modes

Global Configuration(config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Cisco IOS XE Bengaluru 17.4.1	This command was modified. The **policy-tag-name**, **flex-profile-name**, **ap-macaddress-ssid-flexprofilename**, **ap-macaddress-ssid-policytagname**, **ap-macaddress-ssid-sitetagname**, **ap-ethmac-ssid-flexprofilename**, **ap-ethmac-ssid-policytagname**, and **ap-ethmac-ssid-sitetagname** keywords were introduced.

Usage Guidelines

Example

The following example shows how to configure a call station identifier sent in the RADIUS accounting messages:

```
Device(config)# radius-server attribute wireless accounting call-station-id site-tag-name
```

radius-server attribute wireless authentication call-station-id

To configure call station identifier sent in the RADIUS authentication messages, use the **radius-server attribute wireless authentication call-station-id** command. To remove the call station identifier from the radius accounting messages, use the **no** form of the command.

radius-server attribute wireless authentication call-station-id { **ap-ethmac-only** | **ap-ethmac-ssid** | **ap-ethmac-ssid-flexprofilename** | **ap-ethmac-ssid-policytagname** | **ap-ethmac-ssid-sitetagname** | **ap-group-name** | **ap-label-address** | **ap-label-address-ssid** | **ap-location** | **ap-macaddress** | **ap-macaddress-ssid** | **ap-macaddress-ssid-flexprofilename** | **ap-macaddress-ssid-policytagname** | **ap-macaddress-ssid-sitetagname** | **ap-name** | **ap-name-ssid** | **flex-profile-name** | **ipaddress** | **macaddress** | **policy-tag-name** | **site-tag-name** | **vlan-id** }

Syntax Description

ap-ethmac-only	Sets the call station identifier type to be AP's radio MAC address.
ap-ethmac-ssid	Sets the call station identifier type AP's radio MAC address with SSID.
ap-ethmac-ssid-flexprofilename	Sets the call station identifier type AP's radio MAC address with SSID and flex profile name.
ap-ethmac-ssid-policytagname	Sets the call station identifier type AP's radio MAC address with SSID and policy tag name.
ap-ethmac-ssid-sitetagname	Sets the call station identifier type AP's radio MAC address with SSID and site tag name.
ap-group-name	Sets the call station identifier type to use the AP group name.
ap-label-address	Sets the call station identifier type to the AP's radio MAC address that is printed on the AP label.
ap-label-address-ssid	Sets the call station identifier type to the AP's radio MAC address and SSID that is printed on the AP label.
ap-location	Sets the call station identifier type to the AP location.
ap-macaddress	Sets the call station identifier type to the AP's radio MAC address.
ap-macaddress-ssid	Sets the call station identifier type to the AP's radio MAC address with SSID.
ap-macaddress-ssid-flexprofilename	Sets the call station identifier type to the AP's radio MAC address with SSID and flex profile name.
ap-macaddress-ssid-policytagname	Sets the call station identifier type to the AP's radio MAC address with SSID and policy tag name.
ap-macaddress-ssid-sitetagname	Sets the call station identifier type to the AP's radio MAC address with SSID and site tag name.
ap-name	Sets the call station identifier type to the AP name.

ap-name-ssid	Sets the call station identifier type to the AP name with SSID.
flex-profile-name	Sets the call station identifier type to the flex profile name.
ipaddress	Sets the call station identifier type to the IP address of the system.
macaddress	Sets the call station identifier type to the MAC address of the system.
policy-tag-name	Sets the call station identifier type to the policy tag name.
site-tag-name	Sets the call station identifier type to the site tag name.
vlan-id	Sets the call station identifier type to the system's VLAN ID.

Command Default

Call station identifier is not configured.

Command Modes

Global Configuration(config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Cisco IOS XE Bengaluru 17.4.1	This command was modified. The **policy-tag-name**, **flex-profile-name**, **ap-macaddress-ssid-flexprofilename**, **ap-macaddress-ssid-policytagname**, **ap-macaddress-ssid-sitetagname**, **ap-ethmac-ssid-flexprofilename**, **ap-ethmac-ssid-policytagname**, and **ap-ethmac-ssid-sitetagname** keywords were introduced.

Usage Guidelines

Example

The following example shows how to configure a call station identifier sent in the RADIUS authentication messages:

```
Device(config)# radius-server attribute wireless authentication call-station-id site-tag-name
```

range

To configure range from MAP to RAP bridge, use the **range** command.

range *range-in-feet*

Syntax Description

range-in-feet	Configure the range value in terms of feet. Valid range is from 150 feet to 132000 feet.

Command Default

1200

Command Modes

config-wireless-mesh-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure range from MAP to RAP bridge for a mesh AP profile:

```
Device # configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device (config)# wireless profile mesh mesh-profile
Device (config-wireless-mesh-profile)# range 300
```

record wireless avc basic

To apply the *wireless avc basic* AVC flow record to a flow monitor, use the **record wireless avc basic** command.

record wireless avc basic

Command Default None

Command Modes config-flow-monitor

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines This command specifies the basic wireless AVC template. When you are configuring AVC, you will need to create a flow monitor using the **record wireless avc basic** command.

Examples

The following example shows how to apply the *wireless avc basic* AVC flow record to a flow monitor named *test-flow*:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# flow monitor test-flow
Device(config-flow-monitor)# record wireless avc basic
```

redirect

To configure a redirect to an external portal, use the **redirect** command.

redirect {**for-login** | **on-failure** | **on-success** }*redirect-url-name*

Syntax Description

for-login	To login, redirect to this URL.
on-failure	If login fails, redirect to this URL.
on-success	If login is sucessful, redirect to this URL.
redirect-url-name	Redirect URL name.

Command Default

None

Command Modes

config-params-parameter-map

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure an redirect to an external IPv4 URL to login:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type webauth parameter-name
Device(config-params-parameter-map)# redirect for-login cisco.com
```

redirect portal

To configure external IPv4 or IPv6 portal, use the **redirect portal** command.

redirect portal {**ipv4** | **ipv6** } *ip-addr*

Syntax Description

ipv4	IPv4 portal address
ipv6	IPv6 portal address

Command Default None

Command Modes config-params-parameter-map

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure an external IPv4 portal address:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type webauth parameter-name
Device(config-params-parameter-map)# redirect portal ipv4 192.168.1.100
```

remote-lan

To map an RLAN policy profile to an RLAN profile, use the **remote-lan** command.

remote-lan *remote-lan-profile-name* **policy** *rlan-policy-profile-name* **port-id** *port-id*

Syntax Description

remote-lan-profile-name	Remote LAN profile name.
rlan-policy-profile-name	Remote LAN policy profile name.
port-id	Port ID.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to map an RLAN policy profile to an RLAN profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless tag policy remote-lan-policy-tag
Device(config-policy-tag)# remote-lan rlan_profile_name policy rlan_policy_profile port-id
 2
Device(config-policy-tag)# end
```

request platform software trace archive last

To archive all the trace logs relevant to all the processes running on a system, use the **request platform software trace archive last** command in privileged EXEC mode.

request platform software trace archive last *number* [**days** | **hours** | **minutes** | **seconds**] **target** { **bootflash:** | **cloudfs:** | **crashinfo:** | **flash:** }

Syntax Description

number	Archive timeframe, in days, hours, minutes, or seconds.
days	Specifies the number of days for which the trace files have to be archived.
hours	Specifies the number of hours for which the trace files have to be archived.
minutes	Specifies the number of minutes for which the trace files have to be archived.
seconds	Specifies the number of seconds for which the trace files have to be archived.
target	Specifies the location and name of the archive file.
bootflash:	Specifies the archive file name and location.
cloudfs:	Specifies the archive file name and location.
crashinfo:	Specifies the archive file name and location.
flash:	Specifies the archive file name and location.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to archive all the trace logs relevant to all the processes running on a system:

```
Device# request platform software trace archive last 5 days target flash:
```

rf tag

To configure an RF tag to the AP, use the **rf tag**command.

rf tag *rf-tag-name*

Syntax Description

rf-tag-name	RF tag name.

Command Default

None

Command Modes

config-ap-tag

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The AP will disconnect and rejoin after running this command.

Example

The following example shows how to configure an RF tag:

```
Device(config-ap-tag)# rf-tag rftag1
```

rogue detection containment pmf-denial

To enable PMF-denial rogue AP containment, use the **rogue detection containment pmf-denial** command. To disable PMF-denial rogue AP containment, use the **no** form of this command.

rogue detection containment pmf-denial

no rogue detection containment pmf-denial

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Examples

The following example shows how to enable PMF-denial rogue AP containment:

```
Device# configure terminal
Device(config)# ap profile xyz-ap-profile
Device(config-ap-profile)# rogue detection containment pmf-denial
Device(config-pmf-denial)# pmf-deauth
```

rrc-evaluation

To configure Resource Reservation Control (RRC) reevaluation admission, use the **rrc-evaluation** command.

rrc-evaluation {**initial** | **periodic**}

Syntax Description

initial	Configures initial admission evaluation.
periodic	Configures periodic admission evaluation.

Command Default

None

Command Modes

config-media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the RRC reevaluation admission to initial admission evaluation.

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group my-media-group 224.0.0.0 224.0.0.223
Device(config-media-stream)# rrc-evaluation initial
```

security

To configure mesh security, use the **security** command.

security { **eap** | **psk** }

Syntax Description

eap	Configure mesh security EAP for Mesh AP.
psk	Configure mesh security PSK for Mesh AP

Command Default

EAP

Command Modes

config-wireless-mesh-profile

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure mesh security with EAP protcol on an Mesh AP:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile mesh profile-name
Device(config-wireless-mesh-profile)# security eap
```

security dot1x authentication-list

To configure security authentication list for IEEE 802.1x, use the **security dot1x authentication-list** *auth-list-name* command.

security dot1x authentication-list *auth-list-name*

Syntax Description

Parameter	Description
auth-list-name	Authentication list name.

Command Default

None

Command Modes

config-wlan

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure security authentication list for IEEE 802.1x:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan wlan-name
Device(config-wlan)# security dot1x authentication-list auth-list-realm
```

security ft

To configure 802.11r fast transition parameters, use the **security ft** command. To configure fast transition **over the air**, use the **no security ft over-the-ds** command.

security ft [**over-the-ds** | **reassociation-timeout** *timeout-jn-seconds*]
no security ft [**over-the-ds** | **reassociation-timeout**]

Syntax Description

over-the-ds	(Optional) Specifies that the 802.11r fast transition occurs over a distributed system. The no form of the command with this parameter configures security ft over the air.
reassociation-timeout	(Optional) Configures the reassociation timeout interval.
timeout-in-seconds	(Optional) Specifies the reassociation timeout interval in seconds. The valid range is between 1 to 100. The default value is 20.

Command Default

The feature is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

WLAN Security must be enabled.

Example

The following example configures security FT configuration for an open WLAN:

```
Device#wlan test
Device(config-wlan)# client vlan 0140
Device(config-wlan)# no mobility anchor sticky
Device(config-wlan)# no security wpa
Device(config-wlan)# no security wpa akm dot1x
Device(config-wlan)# no security wpa wpa2
Device(config-wlan)# no security wpa wpa2 ciphers aes
Device(config-wlan)# security ft
Device(config-wlan)# shutdown
```

The following example shows a sample security FT on a WPA-enabled WLAN:

```
Device# wlan test
Device(config-wlan)# client vlan 0140
Device(config-wlan)# no security wpa akm dot1x
Device(config-wlan)# security wpa akm ft psk
Device(config-wlan)# security wpa akm psk set-key ascii 0 test-test
```

```
Device(config-wlan)# security ft
Device(config-wlan)# no shutdown
```

security pmf

To configure 802.11w Management Frame Protection (PMF) on a WLAN, use the **security pmf** command. To disable management frame protection, use the **no** form of the command.

security pmf {**association-comeback** *association-comeback-time-seconds* | **mandatory** | **optional** | **saquery-retry-time** *saquery-retry-time-milliseconds*}
no security pmf [**association-comeback** *association-comeback-time-seconds* | **mandatory** | **optional** | **saquery-retry-time** *saquery-retry-time-milliseconds*]

Syntax Description

association-comeback	Configures the 802.11w association comeback time.
association-comeback-time-seconds	Association comeback interval in seconds. Time interval that an associated client must wait before the association is tried again after it is denied with a status code 30. The status code 30 message is "Association request rejected temporarily; Try again later." The range is from 1 through 20 seconds.
mandatory	Specifies that clients are required to negotiate 802.1w PMF protection on the WLAN.
optional	Specifies that the WLAN does not mandate 802.11w support on clients. Clients with no 802.11w capability can also join.
saquery-retry-time	Time interval identified before which the SA query response is expected. If the device does not get a response, another SA query is tried.
saquery-retry-time-milliseconds	The saquery retry time in milliseconds. The range is from 100 to 500 ms. The value must be specified in multiples of 100 milliseconds.

Command Default

PMF is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You must have WPA (Wi-Fi Protected Access) and AKM (Authentication Key Management) configured to use this feature. See Related Command section for more information on configuring the security parameters.

802.11w introduces an Integrity Group Temporal Key (IGTK) that is used to protect broadcast or multicast robust management frames. IGTK is a random value, assigned by the authenticator station (device) used to protect MAC management protocol data units (MMPDUs) from the source STA. The 802.11w IGTK key is

derived using the four-way handshake and is used only on WLANs that are configured with WPA2 security at Layer 2.

This example shows how to enable the association comeback value at 15 seconds.

```
Device(config-wlan)# security pmf association-comeback 15
```

This example shows how to configure mandatory 802.11w MPF protection for clients on a WLAN:

```
Device(config-wlan)# security pmf mandatory
```

This example shows how to configure optional 802.11w MPF protection for clients on a WLAN:

```
Device(config-wlan)# security pmf optional
```

This example shows how to configure the saquery parameter:

```
Device(config-wlan)# security pmf saquery-retry-time 100
```

This example shows how to disable the PMF feature:

```
Device(config-wlan)# no security pmf
```

security static-wep-key

To configure static WEP keys on a WLAN, use the **security static-wep-key** command.

security static-wep-key {**authentication** {**open** | **sharedkey** } | **encryption** {**104** | **40** } {**ascii** | **hex** | {**0** | **8** }*wep-key* | **wep-index** }}

Syntax Description

open	Open system authentication.
sharedkey	Shared key authentication.
0	Specifies an UNENCRYPTED password is used.
8	Specifies an AES encrypted password is used.
wep-key	Enter the name of the WEP key.

Command Default

None

Command Modes

config-wlan

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to authenticate 802.11 using shared key:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wlan profile-name wlan-id
Device(config-wlan)# security static-wep-key authentication sharedkey
```

security web-auth

To change the status of web authentication used on a WLAN, use the **security web-auth** command. To disable web authentication on a WLAN, use the **no** form of the command.

security web-auth [**authentication-list** *authentication-list-name* | **on-macfilter-failure** | **parameter-map** *parameter-map-name*]
no security web-auth [**authentication-list** [**authentication-list-name**] | **on-macfilter-failure** | **parameter-map** [**parameter-name**]]

Syntax Description

authentication-list *authentication-list-name*	Sets the authentication list for IEEE 802.1x.
on-macfilter-failure	Enables web authentication on MAC failure.
parameter-map *parameter-map-name*	Configures the parameter map.

Command Default

Web authentication is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Examples

The following example shows how to configure the authentication-list web authentication on a WLAN:

```
Device(config-wlan)# security web-auth authentication-list test
```

security wpa akm

To configure authentication key management using Cisco Centralized Key Management (CCKM), use the **security wpa akm** command. To disable the authentication key management for Cisco Centralized Key Management, use the **no** form of the command.

security wpa [**akm** { **cckm** | **dot1x** | **ft** | **pmf** | **psk** } | **wpa1** [**ciphers** { **aes** | **tkip** }] | **wpa2** [**ciphers** { **aes** }]]
no security wpa [**akm** { **cckm** | **dot1x** | **ft** | **pmf** | **psk** } | **wpa1** [**ciphers** { **aes** | **tkip** }] | **wpa2** [**ciphers** { **aes** }]]

Syntax Description

akm	Configures the Authentication Key Management (AKM) parameters.
aes	Configures AES (Advanced Encryption Standard) encryption support.
cckm	Configures Cisco Centralized Key Management support.
ciphers	Configures WPA ciphers.
dot1x	Configures 802.1x support.
ft	Configures fast transition using 802.11r.
pmf	Configures 802.11w management frame protection.
psk	Configures 802.11r fast transition pre-shared key (PSK) support.
tkip	Configures Temporal Key Integrity Protocol (TKIP) encryption support.
wpa2	Configures Wi-Fi Protected Access 2 (WPA2) support.

Command Default

By default Wi-Fi Protected Access2, 802.1x are enabled. WPA2, PSK, CCKM, FT dot1x, FT PSK, PMF dot1x, PMF PSK, FT Support are disabled. The FT Reassociation timeout is set to 20 seconds, PMF SA Query time is set to 200.

Command Modes

WLAN Configuration (config-wlan)

Command History

Release	Modification
	This command was introduced.

Example

The following example shows how to configure CCKM on the WLAN.

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
```

```
Device(config)# wlan wlan1
Device(config-wlan)#security wpa akm cckm
```

security wpa akm sae

To enable Auth Key Management (AKM) Secure Agile Exchange (SAE), use the **security wpa akm sae** command. Use the **no** form of this command to disable the feature.

security wpa akm sae

no security wpa akm sae

Syntax Description

security	Configures the security policy for a WLAN.
wpa	Configures WPA/WPA2 Support for a WLAN.
akm	Configures Auth Key Management.
sae	Configures SAE support.

Command Default

None

Command Modes

WLAN configuration mode (config-wlan)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

The following example shows how to enable Auth Key Management (AKM) Secure Agile Exchange (SAE):

```
Device# configure terminal
Device(config)# wlan wlan-test 3 ssid-test
Device(config-wlan)# security wpa akm sae
```

sensor-name

To set the sensor name for Stealthwatch Cloud registration, use the **sensor-name** *swc-sensor-name* command. To disable the command, use the **no** form of this command.

sensor-name *swc-sensor-name*

no sensor-name *swc-sensor-name*

Syntax Description

sensor-name	Sets the sensor name for Stealthwatch Cloud registration.
swc-sensor-name	Specifies the Stealthwatch service key. The device serial number is the default value.

Command Default

None

Command Modes

Stealthwatch Cloud monitor configuration mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to set the sensor name for Stealthwatch Cloud registration:

```
Device(config-stealthwatch-cloud-monitor)# sensor-name SwC-sensor-name
```

service-key

To set the Stealthwatch Cloud service key, use the **service-key** *swc-service-key*. To disable the command, use the **no** form of this command.

service-key *swc-service-key*

no service-key *swc-service-key*

Syntax Description

service-key	Sets the Stealthwatch Cloud service key. Service-key is provided by the Stealthwatch Cloud portal. The alternative to service-key is the authentication through the IP address allowed list.
swc-service-key	Specifies the Stealthwatch service key.

Command Default

None

Command Modes

Stealthwatch Cloud monitor configuration mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to set the Stealthwatch Cloud service key:

```
Device(config-stealthwatch-cloud-monitor)# service-key xxxxxxxxxxxxxxxxxxxxx
```

service-policy

To configure the quality of service (QoS) service policy, use the **service-policy** command. To disable a QoS policy, use the **no** form of this command.

service-policy { **client** | **input** | **output** } *policy-name*
no { **client** | **input** | **output** } *policy-name*

Syntax Description

client	Assigns a policy map to all clients in the WLAN.
input	Assigns an input policy map.
output	Assigns an output policy map.
policy-name	The policy map name.

Command Default

None

Command Modes

Wireless policy configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

This example shows how to configure the input service policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy default-policy-profile
Device(config-wireless-policy)# service-policy input test1
```

service-policy qos

To configure a QoS service policy, use the **service-policy qos** command.

service-policy qos {**input** | **output**}*policy-name*

Syntax Description

input	Input QoS policy.
output	Output QoS policy.
policy-name	Policy name.

Command Default

None

Command Modes

config-service-template

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure an output QoS policy:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# service-template fabric-profile-name
Device(config-service-template)# service-policy qos output policy-name
```

service-template

To configure service template, use the **service-template** command.

service-template *service-template-name* {**access-group** *acl_list* | **vlan** *vlan_id* | **absolute-timer** *seconds* | **service-policy qos** {**input** | **output**}}

Syntax Description

service-template-name	Name of the service template.
acl_list	Access list name to be applied.
vlan_id	VLAN ID. The VLAN ID value ranges from 1 to 4094.
seconds	Session timeout value for service template. The session timeout value ranges from 1 to 65535 seconds.
service-policy qos {**input** | **output**	QoS policies for client.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

The following example shows how to configure service template:

```
Device#configure terminal
Device(config)#service-template cisco-phone-template
Device(config-service-template)#access-group foo-acl
Device(config-service-template)#vlan 100
Device(config-service-template)#service-policy qos input foo-qos
Device(config-service-template)#end
```

service timestamps

To configure the system to time-stamp debugging or logging messages, use the**service timestamps** command in global configuration commands. Use the **no** form of this command to disable this service.

service timestamps debug log {**datetime** | **uptime***localtimemsecshow-timezoneyear*}
no service timestamps debuglog

Syntax Description

debug	Debug as the timestamp message type.
log	Log as the timestamp message type.
datetime	**datetime**
uptime	(Optional) Time stamp with time since the system was rebooted.
localtime	(Optional) Time stamp relative to the local time zone.
msec	(Optional) Include milliseconds in the date and time stamp.
show-timezone	(Optional) Include the time zone name in the time stamp.
year	(Optional) Include year in timestamp.

Command Default

No time-stamping.

If **service timestamps** is specified with no arguments or keywords, default is **service timestamps debug uptime**.

The default for **service timestamps debugdatetime** is to format the time in UTC, with no milliseconds and no time zone name.

The command **no service timestamps** by itself disables time stamps for both debug and log messages.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.1.1s.

Usage Guidelines

Time stamps can be added to either debugging or logging messages independently. The uptime form of the command adds time stamps in the format HHHH:MM:SS, indicating the time since the system was rebooted. The datetime form of the command adds time stamps in the format MMM DD HH:MM:SS, indicating the date and time according to the system clock. If the system clock has not been set, the date and time are preceded by an asterisk (*) to indicate that the date and time are probably not correct.

Example

The following example enables time stamps on debugging messages, showing the time since reboot:

```
Device(config)# service timestamps debug uptime
```

The following example enables time stamps on logging messages, showing the current time and date relative to the local time zone, with the time zone name included:

```
Device(config)# service timestamps log datetime localtime show-timezone
```

session-timeout

To configure session timeout for clients associated to a WLAN, use the **session-timeout** command. To restore the default value, use the **no** form of this command.

session-timeout seconds
no session-timeout

Syntax Description

seconds	Timeout or session duration in seconds. The range is from 300 to 86400. The default value is 28,800. Configuring 86400 is equivalent to max timeout. And value 0 is not recommended.

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to configure a session timeout to 3600 seconds:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#wireless profile policy policy1
Device(config-wireless-policy)#session-timeout 3600
```

set

To classify IP traffic by setting a Differentiated Services Code Point (DSCP) or an IP-precedence value in the packet, use the **set** command in policy-map class configuration mode. Use the **no** form of this command to remove traffic classification.

set
cos | **dscp** | **precedence** | **ip** | **qos-group** | **wlan**
set cos
{*cos-value* } | {**cos** | **dscp** | **precedence** | **qos-group** | **wlan**} [**table** *table-map-name*]
set dscp
{*dscp-value* } | {**cos** | **dscp** | **precedence** | **qos-group** | **wlan**} [**table** *table-map-name*]
set ip {**dscp** | **precedence**}
set precedence {*precedence-value* } | {**cos** | **dscp** | **precedence** | **qos-group**} [**table** *table-map-name*]
set qos-group
{*qos-group-value* | **dscp** [**table** *table-map-name*] | **precedence** [**table** *table-map-name*]}
set wlan user-priority
user-priority-value | **costable** *table-map-name* | **dscptable** *table-map-name* | **qos-grouptable** *table-map-name* | **wlantable** *table-map-name*

Syntax Description

cos	Sets the Layer 2 class of service (CoS) value or user priority of an outgoing packet. You can specify these values:
	• *cos-value*—CoS value from 0 to 7. You also can enter a mnemonic name for a commonly used value.
	• Specify a packet-marking category to set the CoS value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords:
	  • **cos**—Sets a value from the CoS value or user priority.
	  • **dscp**—Sets a value from packet differentiated services code point (DSCP).
	  • **precedence**—Sets a value from packet precedence.
	  • **qos-group**—Sets a value from the QoS group.
	  • **wlan**—Sets the WLAN user priority values.
	• (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map are used to set the CoS value. Enter the name of the table map used to specify the CoS value. The table map name can be a maximum of 64 alphanumeric characters.
	If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the CoS value. For example, if you enter the **set cos precedence** command, the precedence (packet-marking category) value is copied and used as the CoS value.

dscp	Sets the differentiated services code point (DSCP) value to mark IP(v4) and IPv6 packets. You can specify these values:
	• *cos-value*—Number that sets the DSCP value. The range is from 0 to 63. You also can enter a mnemonic name for a commonly used value.
	• Specify a packet-marking category to set the DSCP value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords:
	  • **cos**—Sets a value from the CoS value or user priority.
	  • **dscp**—Sets a value from packet differentiated services code point (DSCP).
	  • **precedence**—Sets a value from packet precedence.
	  • **qos-group**—Sets a value from the QoS group.
	  • **wlan**—Sets a value from WLAN.
	• (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the DSCP value. Enter the name of the table map used to specify the DSCP value. The table map name can be a maximum of 64 alphanumeric characters.
	If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the DSCP value. For example, if you enter the **set dscp cos** command, the CoS value (packet-marking category) is copied and used as the DSCP value.

ip	Sets IP values to the classified traffic. You can specify these values: • **dscp**—Specify an IP DSCP value from 0 to 63 or a packet marking category. • **precedence**—Specify a precedence-bit value in the IP header; valid values are from 0 to 7 or specify a packet marking category.

precedence	Sets the precedence value in the packet header. You can specify these values:
	• *precedence-value*— Sets the precedence bit in the packet header; valid values are from 0 to 7. You also can enter a mnemonic name for a commonly used value.
	• Specify a packet marking category to set the precedence value of the packet.
	  • **cos**—Sets a value from the CoS or user priority.
	  • **dscp**—Sets a value from packet differentiated services code point (DSCP).
	  • **precedence**—Sets a value from packet precedence.
	  • **qos-group**—Sets a value from the QoS group.
	• (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the precedence value. Enter the name of the table map used to specify the precedence value. The table map name can be a maximum of 64 alphanumeric characters.
	If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the precedence value. For example, if you enter the **set precedence cos** command, the CoS value (packet-marking category) is copied and used as the precedence value.

qos-group	Assigns a QoS group identifier that can be used later to classify packets. • *qos-group-value*—Sets a QoS value to the classified traffic. The range is 0 to 31. You also can enter a mnemonic name for a commonly used value. • **dscp**—Sets the original DSCP field value of the packet as the QoS group value. • **precedence**—Sets the original precedence field value of the packet as the QoS group value. • (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the DSCP or precedence value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters. If you specify a packet-marking category (**dscp** or **precedence**) but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the QoS group value. For example, if you enter the **set qos-group precedence** command, the precedence value (packet-marking category) is copied and used as the QoS group value.

wlan user-priority *wlan-user-priority*	Assigns a WLAN user-priority to the classified traffic. You can specify these values: • *wlan-user-priority*—Sets a WLAN user priority to the classified traffic. The range is 0 to 7. • **cos**—Sets the Layer 2 CoS field value as the WLAN user priority. • **dscp**—Sets the DSCP field value as the WLAN user priority. • **precedence**—Sets the precedence field value as the WLAN user priority. • **wlan**—Sets the WLAN user priority field value as the WLAN user priority. • (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the WLAN user priority value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters. If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the WLAN user priority. For example, if you enter the **set wlan user-priority cos** command, the cos value (packet-marking category) is copied and used as the WLAN user priority.

Command Default

No traffic classification is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was intro

Usage Guidelines

For the **set dscp** *dscp-value* command, the **set cos** *cos-value* command, and the **set ip precedence** *precedence-value* command, you can enter a mnemonic name for a commonly used value. For example, you can enter the **set dscp af11** command, which is the same as entering the **set dscp 10** command. You can enter the **set ip precedence critical** command, which is the same as entering the **set ip precedence 5** command. For a list of supported mnemonics, enter the **set dscp ?** or the **set ip precedence ?** command to see the command-line help strings.

When you configure the **set dscp cos**command, note the following: The CoS value is a 3-bit field, and the DSCP value is a 6-bit field. Only the three bits of the CoS field are used.

When you configure the **set dscp qos-group** command, note the following:

- The valid range for the DSCP value is a number from 0 to 63. The valid value range for the QoS group is a number from 0 to 99.
- If a QoS group value falls within both value ranges (for example, 44), the packet-marking value is copied and the packets is marked.
- If QoS group value exceeds the DSCP range (for example, 77), the packet-marking value is not be copied and the packet is not marked. No action is taken.

The **set qos-group** command cannot be applied until you create a service policy in policy-map configuration mode and then attach the service policy to an interface or ATM virtual circuit (VC).

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to assign DSCP 10 to all FTP traffic without any policers:

```
Device(config)# policy-map policy_ftp
Device(config-pmap)# class-map ftp_class
Device(config-cmap)# exit
Device(config)# policy policy_ftp
Device(config-pmap)# class ftp_class
Device(config-pmap-c)# set dscp 10
Device(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

sftp-image-path (image-download-mode sftp)

To configure the image path of the SFTP server for image download, use the **sftp-image-path** command. Use the **no** form of the command to negate the command or to set the command to its default.

`sftp-image-path`*sftp-image-path*

`no sftp-image-path`*sftp-image-path*

Syntax Description

sftp-image-path	Specifies the image path of the SFTP server.

Command Default

None

Command Modes

Wireless image download profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode sftp
Device(config-wireless-image-download-profile-sftp)# sftp-image-path
/download/object/stream/images/ap-images
```

sftp-image-server (image-download-mode sftp)

To configure the SFTP server address for image download, use the **sftp-image-server** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
sftp-image-server {A.B.C.D | X:X:X:X::X}

no sftp-image-server {A.B.C.D | X:X:X:X::X}
```

Syntax Description

A.B.C.D	Specifies the SFTP IPv4 server address.
X:X:X:X::X	Specifies the SFTP IPv6 server address.

Command Default

None

Command Modes

Wireless image download profile SFTP configuration mode.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode sftp
Device(config-wireless-image-download-profile-sftp)# sftp-image-server 10.1.1.1
```

sftp-password (image-download-mode sftp)

To configure the SFTP server password for image dowload, use the **sftp-password** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
sftp-password {0| 8}<Enter password> <Re-enter password>

no sftp-password {0 | 8}<Enter password> <Re-enter password>
```

Syntax Description

0	Specifies that an unencrypted password will follow.
8	Specifies that an AES encrypted password will follow.
password	Specifies the SFTP server password.
re-enter password	Indicates that the user must re-enter the SFTP server password.

Command Default

None

Command Modes

Wireless image download profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode sftp
Device(config-wireless-image-download-profile-sftp)# sftp-password 0 xxxxxxxx
```

sftp-password (trace-export)

To configure the SFTP server password for trace export, use the **sftp-password** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`sftp-password<`*Enter password*`> <`*Re-enter password*`>`

`no sftp-password<`*Enter password*`> <`*Re-enter password*`>`

Syntax Description

password	Specifies the SFTP server password.
re-enter password	Indicates that the user must re-enter the SFTP server password.

Command Default

None

Command Modes

Wireless trace export profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode sftp
Device(config-wireless-trace-export-profile-sftp)# sftp-password xxxxxxxx xxxxxxxx
```

sftp-path

To configure the path at the SFTP server for trace log export, use the **sftp-path** command. Use the **no** form of the command to negate the command or to set the command to its default.

`sftp-path`*sftp-path*

`no sftp-path`*sftp-path*

Syntax Description

sftp-path	Specifies the path at the SFTP server.

Command Default

None

Command Modes

Wireless trace export profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode sftp
Device(config-wireless-trace-export-profile-sftp)# sftp-path
/download/object/stream/images/ap-images
```

sftp-server

To configure the SFTP server address for trace export, use the **sftp-server** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
sftp-server{A.B.C.D  | X:X:X:X::X}

no sftp-server {A.B.C.D  | X:X:X:X::X}
```

Syntax Description

A.B.C.D	Specifies the SFTP IPv4 server address.
X:X:X:X::X	Specifies the SFTP IPv6 server address.

Command Default

None

Command Modes

Wireless trace export profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode sftp
Device(config-wireless-trace-export-profile-sftp)# sftp-server 10.1.1.1
```

sftp-username (image-download-mode sftp)

To configure the SFTP server username for image download, use the **sftp-username**command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`sftp-username` *Username*

`no sftp-username` *Username*

Syntax Description

username	Specifies the SFTP server username.

Command Default

None

Command Modes

Wireless image download profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode sftp
Device(config-wireless-image-download-profile-sftp)# sftp-username sftp-server-username
```

sftp-username (trace-export)

To configure the SFTP server username for trace export, use the **sftp-username**command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`sftp-username` *Username*

`no sftp-username` *Username*

Syntax Description

username	Specifies the SFTP server username.

Command Default

None

Command Modes

Wireless trace export profile SFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode sftp
Device(config-wireless-trace-export-profile-sftp)# sftp-username sftp-server-username
```

snmp-server enable traps wireless

To enable wireless notifications for a host, use the **snmp-server enable traps wireless** command.

snmp-server enable traps wireless [**AP** | **bsnMobileStation** | **MESH** | **bsnAutoRF** | **rogue** | **wireless_mobility** | **RRM** | **bsnGeneral**]

Syntax Description

AP	Enables wireless SNMP traps for APs
bsnMobileStation	Enables wireless client traps
MESH	Enables wireless mesh traps
bsnAutoRF	Enables wireless RF related traps
rogue	Enables traps for wireless rogue
wireless_mobility	Enables traps for wireless mobility
RRM	Enables traps for wireless RRM
bsnGeneral	Enables general controller traps

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Examples

The following example shows how to enable wireless notifications for a host:

```
Device# snmp-server enable traps wireless MESH
```

snmp-server subagent cache

To prevent CPU spikes in the controller during Simple Network Management Protocol (SNMP) polling, use the **snmp-server subagent cache** command. To disable the subagent cache, use the **no** form of this command.

snmp-server subagent cache [**timeout** *seconds*]

snmp-server subagent cache [**timeout** *seconds*]

Syntax Description

timeout	Specifies the subagent cache timeout.
seconds	The server timeout value, in seconds. The valid values range from 1 to 100, with a default of 60.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Usage Guidelines

Use this command to prevent CPU spikes in the controller by clearing the cache at regular intervals.

Examples

The following example shows how to prevent CPU spikes in the controller during SNMP polling:

```
Device# configure terminal
Device(config)# snmp-server subagent cache
```

ssid broadcast persistent

To enable the SSID broadcast mode, use the **ssid broadcast persistent** command. Use the **no** form of the command to disable the feature.

ssid broadcast persistent

no ssid broadcast persistent

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Enabling or disabling this feature causes the AP to re-join.

Examples

The following example shows how to enable the SSID broadcast mode:

```
Device# configure terminal
Device(config)# ap profile ap-profile-name
Device(config-ap-profile)# ssid broadcast persistent
```

statistics ap-system-monitoring alarm-enable

To enable alarms for AP real-time statistics (CPU and Memory), use the **statistics ap-system-monitoring alarm-enable** command. Use the **no** form of this command to disable the feature.

[no] statistics ap-system-monitoring alarm-enable

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring alarm-enable	Enables alarms for AP real-time statistics (CPU and Memory).

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to enable alarms for AP real-time statistics (CPU and Memory):

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring alarm-enable
```

statistics ap-system-monitoring alarm-hold-time

To define the hold time interval before triggering the alarm, use the **statistics ap-system-monitoring alarm-hold-time** command.

statistics ap-system-monitoring alarm-hold-time *0-3600*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring alarm-hold-time	Enables alarms for AP real-time statistics (CPU and Memory).
0-3600	Specifies the alarm hold time interval in seconds.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the hold time interval before triggering the alarm:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring alarm-hold-time 60
```

statistics ap-system-monitoring alarm-retransmit-time

To define the interval between retransmissions of the trap alarm, use the **statistics ap-system-monitoring alarm-retransmit-time**

statistics ap-system-monitoring alarm-retransmit-time *0-65535*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring alarm-retransmit-time	Define the interval between retransmissions of the trap alarm.
0-65535	Specifies the interval between retransmissions of the trap alarm, in seconds.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the interval between retransmissions of the trap alarm:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring alarm-retransmit-time 60
```

statistics ap-system-monitoring cpu-threshold

To define the threshold precentage for CPU usage on the AP to trigger alarms, use the **statistics ap-system-monitoring cpu-threshold** command.

statistics ap-system-monitoring cpu-threshold *0-100*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring cpu-threshold	Defines the threshold for CPU usage on AP to trigger alarms.
0-100	Specifies the percentage of threshold for CPU usage on AP to trigger alarms.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the threshold precentage for CPU usage on the AP to trigger alarms:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring cpu-threshold 70
```

statistics ap-system-monitoring enable

To enable monitoring of AP real-time statistics (CPU and Memory), use the **statistics ap-system-monitoring enable** command. Use the **no** form of this command to disable the feature.

[no] statistics ap-system-monitoring enable

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring enable	Enables monitoring of AP real-time statistics (CPU and Memory).

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to enable monitoring of AP real-time statistics (CPU and Memory):

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring enable
```

statistics ap-system-monitoring mem-threshold

To define the threshold percentage for memory usage on the AP, to trigger alarms.

statistics ap-system-monitoring mem-threshold *0-100*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring mem-threshold	Defines the threshold for memory usage on AP to trigger alarms.
0-100	Specifies the percentage of threshold for memory usage on AP to trigger alarms.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the threshold precentage for memory usage on the AP to trigger alarms:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring mem-threshold 60
```

statistics ap-system-monitoring sampling-interval

To define the sampling interval, use the **statistics ap-system-monitoring sampling-interval**

statistics ap-system-monitoring sampling-interval *2-900*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring sampling-interval	Defines the sampling interval.
2-900	Specifies the sampling interval, in seconds.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the sampling interval:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring sampling-interval 100
```

statistics ap-system-monitoring stats-interval

To define the statistics interval, which gives more weight in the calculations to the statistics received in the last statistic interval seconds, use the **statistics ap-system-monitoring stats-interval**

statistics ap-system-monitoring stats-interval *120-900*

Syntax Description

statistics	Configures the AP statistics.
ap-system-monitoring stats-interval	Defines the statistics interval, which gives more weight in the calculations to the statistics received in the last statistic interval seconds.
120-900	Specifies the statistics interval, in seconds.

Command Default

None

Command Modes

AP Profile Configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Example

The following example shows how to define the statistics interval:

```
Device(config)# ap profile default-ap-profile
Device(config-ap-profile)# statistics ap-system-monitoring stats-interval 120
```

stealthwatch-cloud-monitor

To configure Stealthwatch Cloud monitor and enter the Stealthwatch Cloud Monitor configuration mode, use the **stealthwatch-cloud-monitor** command. To disable the command, use the **no** form of this command.

stealthwatch-cloud-monitor

no stealthwatch-cloud-monitor

Command Default None

Command Modes Global Configuration

Syntax Description

stealthwatch-cloud-monitor	Configures Stealthwatch Cloud monitor.

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines None

Example

This example shows how to configure Stealthwatch Cloud monitor:

```
Device(config)# stealthwatch-cloud-monitor
```

stopbits

To configure the stop bits for the console port, use the **stopbits** command. To revert to the default values, use the **no** form of this command.

stopbits { *1* | *2* }

no stopbits { *1* | *2* }

Syntax Description

1	Specifies one stop bit.
2	Specifies two stop bits.

Command Default

1 stop bit

Command Modes

Line configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

You can configure the console ports only from a session on the console port.

Examples

The following example shows how to configure the stop bits for the console port:

```
Device# configure terminal
Device(config)# line console 0
Device(config-line)# stopbits 1
```

strong-network-key

To enable strong password evaluation for network key, use the **strong-network-key**command.

strong-network-key

Syntax Description

This command has no keywords or arguments.

Command Modes

Wireless URWB profile configuration (config-wireless-urwb-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to enable strong password evaluation for network key:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
Device(config-wireless-urwb-profile)# strong-network-key
```

tag rf

To configure a policy tag for an AP filter, use the **tag rf** command.

tag rf *rf-tag*

Syntax Description

rf-tag	RF tag name.

Command Default

None

Command Modes

config-ap-filter

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a policy tag for an AP filter:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap filter name ap-filter-name
Device(config-ap-filter)# rf tag rf-tag-name
```

tag site

To configure a site tag for an AP filter, use the **tag site** *site-tag* command.

tag site *site-tag*

Syntax Description

site-tag	Name of the site tag.

Command Default

None

Command Modes

config-ap-filter

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a site tag for an AP filter:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# ap filter name ap-filter-name
Device(config-ap-filter)# site tag site-tag-name
```

tftp-image-path (image-download-mode tftp)

To configure the image path at the TFTP server for image download, use the **tftp-image-path** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

`tftp-image-path` *tftp-image-path*

`no tftp-image-path` *tftp-image-path*

Syntax Description

tftp-image-path	Specifies the image path of the TFTP server.

Command Default

None

Command Modes

Wireless image dowload profile TFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode tftp
Device(config-wireless-image-download-profile-tftp)# tftp-image-path
/download/object/stream/images/ap-images
```

tftp-image-server (image-download-mode tftp)

To configure the TFTP server address for image download, use the **tftp-image-server** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
image-download-mode tftp

tftp-image-server {A.B.C.D | X:X:X:X::X}

no tftp-image-server {A.B.C.D | X:X:X:X::X}
```

Syntax Description

A.B.C.D	Specifies the TFTP IPv4 server address.
X:X:X:X::X	Specifies the TFTP IPv6 server address.

Command Default

None

Command Modes

Wireless image download profile TFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile image-download default
Device(config-wireless-image-download-profile)# image-download-mode tftp
Device(config-wireless-image-download-profile-tftp)# tftp-image-server 10.1.1.1
```

tftp-path

To configure the path at the TFTP server for trace log export, use the **tftp-path** command. Use the **no** form of the command to negate the command or to set the command to its default.

`tftp-path`*tftp-path*

`no tftp-path`*tftp-path*

Syntax Description

tftp-path	Specifies the path at the TFTP server.

Command Default

None

Command Modes

Wireless trace export profile TFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode tftp
Device(config-wireless-trace-export-profile-tftp)# tftp-path
/download/object/stream/images/ap-images
```

tftp-server

To configure the TFTP server address for trace export, use the **tftp-server** command. Use the **no** form of this command to negate the configuration or to set the command to its default.

```
tftp-server {A.B.C.D | X:X:X:X::X}

no tftp-server {A.B.C.D | X:X:X:X::X}
```

Syntax Description

A.B.C.D	Specifies the TFTP IPv4 server address.
X:X:X:X::X	Specifies the TFTP IPv6 server address.

Command Default

None

Command Modes

Wireless trace export profile TFTP configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device(config)# wireless profile transfer trace-export trace_export_name
Device(config-wireless-trace-export-profile)# log-export-mode tftp
Device(config-wireless-trace-export-profile-tftp)# tftp-server 10.1.1.1
```

timezone delta

To configure timezone offset for an AP, use the **timezone delta** command. To remove the timezone offset for an AP, use the **no timezone** command.

timezone delta hour *offset-hour* **minute** *offset-minute*

Syntax Description

hour *offset-hour*	Local hour difference from Coordinated Universal Time (UTC). Valid range is from -12 to 14.
minute *offset-minute*	Local minute difference from UTC. Valid range is from 0 to 59.

Command Default

AP timezone is not set.

Command Modes

AP profile configuration (config-ap-profile)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Usage Guidelines

You can configure the AP timezone only for each AP profile. You cannot configure the AP timezone for each AP. To configure the timezone, either apply the current controller timezone or the time difference. By default, timezone is disabled.

Examples

The following example shows how to configure timezone offset for AP:

```
Device# configure terminal
Device(config)# ap profile test
Device(config-ap-profile)# timezone delta hour -12 minute 2
```

udp-timeout

To configure timeout value for UDP sessions, use the **udp-timeout** command.

udp-timeout *timeout_value*

Syntax Description

timeout_value	Is the timeout value for UDP sessions. The range is from 1 to 30 seconds. **Note** The *public-key* and *resolver* parameter-map options are automatically populated with the default values. So, you need not change them.

Command Default

None

Command Modes

Profile configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure timeout value for UDP sessions:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# parameter-map type umbrella global
Device(config-profile)# token 57CC80106C087FB1B2A7BAB4F2F4373C00247166
Device(config-profile)# local-domain dns_wl
Device(config-profile)# udp-timeout 2
Device(config-profile)# end
```

umbrella-param-map

To configure the Umbrella OpenDNS feature for WLAN, use the **umbrella-param-map** command.

umbrella-param-map *umbrella-name*

Syntax Description

umbrella-name

Command Default

None

Command Modes

config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to configure the Umbrella OpenDNS feature for WLAN:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy default-policy-profile
Device(config-wireless-policy)# umbrella-param-map global
Device(config-wireless-policy)# end
```

update-timer

To configure the mDNS update timers for flex profile, use the **update-timer** command. To disable the command, use the **no** form of this command.

update-timer { **service-cache** *<1-100>* | **statistics** *<1-100>* }

update-timer { **service-cache** *<1-100>* | **statistics** *<1-100>* }

Syntax Description

update-timer	Configures the mDNS update timers for flex profile.
service-cache *<1-100>*	Specifies the mDNS update service-cache timer for flex profile. The default value is one minute,
statistics *<1-100>*	Specifies the mDNS update statistics timer for flex profile. The default value is one minute,

Command Default

None

Command Modes

mDNS flex profile configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Examples

The following example shows how to configure the mDNS update timers for flex profile:

```
Device(config-mdns-flex-prof)# update-timer service-cache 20
```

url

To configure the Stealthwatch Cloud server URL, use the **url** *swc-server-url* command. To disable the command, use the **no** form of this command.

url *swc-server-url*

no url *swc-server-url*

Syntax Description

url	Sets the Stealthwatch Cloud server URL.
swc-server-url	Stealthwatch Cloud URL.

Command Default

None

Command Modes

Stealthwatch Cloud Monitor Configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the Stealthwatch Cloud server URL:

```
Device(config-stealthwatch-cloud-monitor)# url https://sensors.eu-2.obsrvbl.com
```

urlfilter list

To configure Flex URL filtering commands for ACL binding, use the **urlfilter list** c in the wireless flex profile ACL mode. To disable the feature, use the **no** form of the ommand.

urlfilter list *urlfilter-list-name*

[no] urlfilter list *urlfilter-list-name*

Syntax Description

urlfilter list	Configures the Flex URL filtering commands for ACL binding.
urlfilter-list-name	Specifies the URL filter list name.

Command Default

None

Command Modes

Wireless Flex Profile ACL configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1	This command was introduced.

Example

This example shows how the Flex URL filtering commands for ACL binding, is configured:

```
Device(config-wireless-flex-profile-acl)# urlfilter list urlfilter-list-name
```

urwb chan-list channel

To configure the channel list for mobility and DFS backup, use the **urwb chan-list channel** *channel-num* **cwidth** {**160MHz** | **20MHz** | **40MHz** | **80MHz**} command. Use the **no** form of this command to disable the feature.

urwb chan-list channel *channel-num* **cwidth** { **160MHz** | **20MHz** | **40MHz** | **80MHz** }

urwb chan-list channel *channel-num* **cwidth** { **160MHz** | **20MHz** | **40MHz** | **80MHz** }

Syntax Description

channel-num	Specifes the channel number.
cwidth	Specifies the channel width.
160MHz	Specifies the channel width as 160MHz.
20MHz	Specifies the channel width as 20MHz
40MHz	Specifies the channel width as 40MHz
80MHz	Specifies the channel width as 80MHz

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the channel list for mobility and DFS backup:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb chan-list channel 100 cwidth 40MHz
```

urwb channel

To configure the URWB radio channel, use the **urwb channel 5ghz** *channel-number*

urwb channel 5ghz *channel-number (1-233)*

Syntax Description

channel-number	Specifies the channel number of the URWB radio. The channel number range is from 1 to 233.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB radio channel:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb channel 5ghz 100
```

urwb crypto policy

To configure AES-based encryption policy, use the **urwb crypto policy** { **fixed-key** | **none** | **rotating-key**} command.

urwb crypto policy { **fixed-key** | **none** | **rotating-key** }

Syntax Description

fixed	Enables AES-based encryption with fixed key.
none	Disable AES-based encryption.
rotating-key	Enables AES-based encryption with rotating key.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to AES-based encryption policy:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb crypto policy fixed
```

urwb crypto rotating-key-timeout

To configure AES-based encryption rotating-key timeout, use the **urwb crypto rotating-key-timeout** *timeout* command. Use the **no** form of this command to disable the feature.

urwb crypto rotating-key-timeout *timeout*

no urwb crypto rotating-key-timeout *timeout*

Syntax Description

timeout	Specifes the rotating-key timeout in seconds. The range is from 0 to 65535.

Command Default

The default value is 15 seconds.

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure AES-based encryption rotating-key timeout:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb crypto rotating-key-timeout 15
```

urwb cwidth

To configure the URWB channel width, use the **urwb cwidth** {**160MHz** | **20MHz** | **40MHz** | **80MHz**}. Use the **no** form of this command to disable this feature.

urwb cwidth { **160MHz** | **20MHz** | **40MHz** | **80MHz** }

no urwb cwidth

Syntax Description

160MHz	Configures the radio channel width as 160MHz.
20MHz	Configures radio channel width as 20MHz.
40MHz	Configures radio channel width as 40MHz.
80MHz	Configure radio channel width as 80MHz.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB radio channel width:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb cwidth 40MHz
```

urwb-profile

Syntax Description

Command Default

Command Modes

Command History

Release	Modification

Usage Guidelines

Task ID

Task ID	Operation

Example

urwb ptmp autoscan

To configure the URWB point-to-multi-point (PTMP) automatic scan, use the **urwb ptmp autoscan** command. Use the **no** form of this command to disable the feature.

urwb ptmp autoscan

no urwb ptmp autoscan

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Usage Guidelines

This setting is applicable only if the URWB role is set to point-to-multi-point and if the URWB PTMP role is secondary.

Examples

The following example shows how to configure the URWB point-to-multi-point (PTMP) automatic scan

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb ptmp autoscan
```

urwb ptmp cluster-id

To configure the URWB point-to-multi-point (PTMP) cluster ID, use the **urwb ptmp cluster-id** *cluster-id* command. Use the **no** form of this command to disable the feature.

urwb ptmp cluster-id *cluster-id*

no urwb ptmp cluster-id *cluster-id*

Syntax Description

cluster-id	Specifes the ID of the cluster.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Usage Guidelines

When more than one point-to-multi-point cluster operates in the same location, each cluster can be logically separated from every other cluster by using a cluster ID value that is unique to that cluster. A Fixed client radio only communicates wirelessly with a Fixed Base radio that shares the same cluster ID.

This setting is applicable only if the URWB role is set to point-to-multi-point.

Examples

The following example shows how to configure the URWB point-to-multi-point (PTMP) cluster ID:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb ptmp cluster-id ptmp-cluster
```

urwb ptmp rssi-threshold

To configure the URWB point-to-multi-point (PTMP) RSSI threshold at which a scan for new Principal units are triggered, use the **urwb ptmp rssi-threshold** *threshold-value* command. Use the **no** form of this command to disable the feature.

urwb ptmp rssi-threshold *threshold-value*

no urwb ptmp rssi-threshold *threshold-value*

Syntax Description

threshold-value	Specifes the RSSI threshold value. The range is from 1 to 100.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB point-to-multi-point (PTMP) RSSI threshold:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb ptmp rssi-threshold 3
```

urwb ptmp tower-id

To configure the URWB point-to-multi-point (PTMP) tower ID, use the **urwb ptmp tower-id** *tower-id* command. Use the **no** form of this command to disable the feature.

urwb ptmp tower-id *tower-id*

no urwb ptmp tower-id *tower-id*

Syntax Description

tower-id	Specifes the ID of the tower.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Usage Guidelines

Tower ID: To avoid connectivity issues when multiple towers are serving the same cluster, the tower-id parameter can be enabled on base radios. All radios mounted on the same tower share the same tower ID. Even if two base radios see each other through a physical link and wirelessly, they know that they are on a different tower and will continue to advertise themselves.

When a client is connected to one tower (Tower 1) and moves close to another one (Tower 2), it automatically connects to a new base on Tower 2. This gives a wider coverage area and continuous connectivity. The same tower design, with different tower IDs, can be replicated to provide more coverage zones.

This setting is applicable only if URWB role is set to point-to-multi-point and if URWB PTMP role is Fixed Base.

Examples

The following example shows how to configure the URWB point-to-multi-point (PTMP) tower ID:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb ptmp tower-id tower1
```

urwb role

To configure the URWB role associated radio slot, use the **urwb role** {**fixed** | **mobility** | **point-to-multi-point**}

urwb role { **fixed** | **mobility** | **point-to-multi-point** }

Syntax Description

fixed	Configures the radio role as fixed.
mobility	Configures the radio role as mobility.
point-to-multi-point	Configures the radio role as point-to-multi-point.

Command Default

None

Command Modes

Wireless radio profile configuration (config-wireless-radio-profile)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB mobility role:

```
Device# configure terminal
Device(config)# wireless profile radio radio-profile-name
Device(config-wireless-radio-profile)# urwb role fixed
```

usb-enable

To enable USB for Cisco access points (APs), use the **usb-enable** command. To disable the command, use the **no** form of this command.

usb-enable

no usb-enable

Syntax Description

usb-enable	Enables USB for Cisco APs.

Command Default

None

Command Modes

AP profile configuration mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to enable USB for Cisco APs:

```
Device(config-ap-profile)# usb-enable
```

username

To add a user who can access the Cisco Catalyst 9800 Series Controller using SSH, use the **username** command in configuration mode. If the user already exists, the password, the privilege level, or both change with this command. To delete the user from the system, use the **no** form of this command.

[no] username *username* **password** {**hash** | **plain**} *password* **role** {**admin** | **user**] [**disabled** [**email** email-address]] [**email** email-address]

For an existing user, use the following command option:

username username **password role** {admin | **user**} password

Syntax Description

username	You should enter only one word which can include hyphen (-), underscore (_) and period (.). **Note** Only alphanumeric characters are allowed at an initial setup.
password	The command to use specify password and user role.
password	Password character length up to 40 alphanumeric characters. You must specify the password for all new users.
hash | plain	Type of password. Up to 34 alphanumeric characters.
role admin | user	Sets the privilege level for the user.
disabled	Disables the user according to the user's email address.
email *email-address*	The user's email address. For example, user1@example.com.
wlan-profile-name	Displays details of the WLAN profile.

Command Default

The initial user during setup.

Command Modes

Configuration

Usage Guidelines

The **username** command requires that the username and password keywords precede the hash | plain and the admin | user options.

Example 1

```
ncs/admin(config)# username admin password hash ###### role admin
ncs/admin(config)#
```

Example 2

```
ncs/admin(config)# username admin password plain Secr3tp@swd role admin
ncs/admin(config)#
```

Example 3

```
ncs/admin(config)# username admin password plain Secr3tp@swd role admin email
admin123@example.com
ncs/admin(config)#
```

violation

To configure stream violation policy on periodic reevaluation, use the **violation** command.

violation {**drop** | **fallback**}

Syntax Description

Parameter	Description
drop	Stream will be dropped on periodic reevaluation.
fallback	Stream will be demoted to BestEffort class on periodic reevaluation.

Command Default

None

Command Modes

config-media-stream

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure stream violation policy on periodic reevaluation:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless media-stream group my-media-group 224.0.0.0 224.0.0.223
Device(config-media-stream)# violation drop
```

wgb broadcast-tagging

To configure WGB broadcast tagging for a wireless policy profile, use the **wgb broadcast-tagging** command.

wgb broadcast-tagging

Command Default None

Command Modes config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable WGB broadcast tagging for a wireless policy profile:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy profile-policy-name
Device(config-wireless-policy)# wgb broadcast-tagging
```

wgb vlan

To configure WGB VLAN client support for a WLAN policy profile, use the **wgb vlan** command.

wgb vlan

Command Default None

Command Modes config-wireless-policy

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to enable WGB VLAN client support for the WLAN policy profile named *wlan1-policy-profile*:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy wlan1-policy-profile
Device(config-wireless-policy)# wgb vlan
```

whitelist acl

To configure the whitelist ACL, use the **whitelist acl** command.

whitelist acl {*standard_acl_value* | *extended_acl_value* | *acl_name*}

Syntax Description

standard_acl_value	Specifies the standard access list. Range is from 1 to 199.
extended_acl_value	Specifies the extended access list. Range is from 1300 to 2699.
acl_name	Specifies the named access list.

Command Default

None

Command Modes

ET-Analytics configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to enable in-active timer in the ET-Analytics configuration mode:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# et-analytics
Device(config-et-analytics)# whitelist acl
eta-whitelist
Device((config-et-analytics)# ip access-list
extended eta-whitelist
Device(config-ext-nacl)# permit udp any any eq tftp
Device(config-ext-nacl)# end
```

wired-vlan-range

To configure wired VLANs on which mDNS service discovery should take place, use the **wired-vlan-range** command. To disable the command, use the **no** form of this command.

wired-vlan-range *wired-vlan-range-value*

Syntax Description

wired-vlan-range	Configures wired VLANs on which mDNS service discovery should take place.
wired-vlan-range-value	Specifies the wired VLAN range value.

Command Default

None

Command Modes

mDNS flex profile configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Examples

The following example shows how to configure wired VLANs on which mDNS service discovery should take place:

```
Device(config-mdns-flex-prof)# wired-vlan-range range-value
```

config wlan assisted-roaming

To configure assisted roaming on a WLAN, use the **config wlan assisted-roaming** command.

config wlan assisted-roaming {**neighbor-list** | **dual-list** | **prediction**} {**enable** | **disable**} *wlan_id*

Syntax Description

neighbor-list	Configures an 802.11k neighbor list for a WLAN.
dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
prediction	Configures an assisted roaming optimization prediction for a WLAN.
enable	Enables the configuration on the WLAN.
disable	Disables the configuration on the WLAN.
wlan_id	Wireless LAN identifier between 1 and 512 (inclusive).

Command Default

The 802.11k neighbor list is enabled for all WLANs.

By default, dual band list is enabled if the neighbor list feature is enabled for the WLAN.

Command History

Release	Modification
8.3	This command was introduced.

Usage Guidelines

When you enable the assisted roaming prediction list, a warning appears and load balancing is disabled for the WLAN, if load balancing is already enabled on the WLAN.

The following example shows how to enable an 802.11k neighbor list for a WLAN:

```
(Cisco Controller) >config wlan assisted-roaming neighbor-list enable 1
```

wireless aaa policy

To configure a wireless AAA policy, use the **wireless aaa policy** command.

wireless aaa policy *aaa-policy*

Syntax Description

aaa-policy	Name of the wireless AAA policy.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a wireless AAA policy named *aaa-policy-test*

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless aaa policy aaa-policy-test
```

wireless aaa policy

To configure a new AAA policy, use the **wireless aaa policy** command.

wireless aaa policy *aaa-policy-name*

Syntax Description

aaa-policy-name	AAA policy name.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a AAA policy name:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless aaa policy my-aaa-policy
```

wireless autoqos policy-profile

To enable the **autoqos** wireless policy with an executable command, use the autoqos command. Use the **disable** command to disable wireless AutoQos.

wireless autoqos policy-profile*policy-profile-name* **default_policy_profile mode** { **clear** | **enterprise-avc** | **fastlane** | **guest** | **voice** }

wireless autoqos disable

Syntax Description

autoqos	Configures wireless Auto QoS.
mode	Specifies the wireless AutoQoS mode.
enterprise-avc	Enables AutoQos wireless enterprise AVC policy.
clear	Clears the configured wireless policy.
fastlane	Enables the AutoQos fastlane policy. This will disable and enable the 2.4GHz or 5GHz 802.11 network.
guest	Enables AutoQos wireless guest policy.
voice	Enables AutoQos wireless voice policy. This will disable and enable the 2.4GHz or 5GHz 802.11 network.

Command Default

None

Command Modes

Privilege EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

This example shows how to enable AutoQoS wireless enterprise policy:

```
Device# wireless autoqos policy-profile default-policy-profile mode enterprise-avc
```

wireless broadcast vlan

To enable broadcast support on a VLAN, use the **wireless broadcast vlan** command in global configuration mode. To disable Ethernet broadcast support, use the **no** form of the command.

wireless broadcast vlan [*vlan-id*]
no wireless broadcast vlan [*vlan-id*]

Syntax Description

vlan-id	(Optional) Specifies the VLAN ID to enable broadcast support to that VLAN. The value ranges from 1 to 4095.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use this command in the global configuration mode only.

This example shows how to enable broadcasting on VLAN 20:

```
Device(config)# wireless broadcast vlan 20
```

wireless client

To configure client parameters, use the **wireless client** command in global configuration mode.

wireless client {**association limit** *assoc-number* **interval** *interval* | **band-select** {**client-rssi** *rssi* | **cycle-count** *count* | **cycle-threshold** *threshold* | **expire dual-band** *timeout* | **expire suppression** *timeout*} | **max-user-login** *max-user-login* | **timers auth-timeout** *seconds* | **user-timeout** *user-timeout*}

Syntax Description

association limit *assoc-number* **interval** *interval*	Enables association request limit per access point slot at a given interval and configures the association request limit interval. You can configure number of association request per access point slot at a given interval from one through 100. You can configure client association request limit interval from 100 through 10000 milliseconds.
band-select	Configures the band select options for the client.
client-rssi *rssi*	Sets the client received signal strength indicator (RSSI) threshold for band select. The minimum dBm of a client RSSI to respond to probe is between -90 and -20.
cycle-count *count*	Sets the band select probe cycle count. You can configure the cycle count from 1 to 10.
cycle-threshold *threshold*	Sets the time threshold for a new scanning cycle. You can configure the cycle threshold from 1 to 1000 milliseconds.
expire dual-band *timeout*	Sets the timeout before stopping to try to push a given client to the 5-GHz band. You can configure the timeout from 10 to 300 seconds, and the default value is 60 seconds.
expire suppression *timeout*	Sets the expiration time for pruning previously known dual-band clients. You can configure the suppression from 10 to 200 seconds, and the default timeout value is 20 seconds.
max-user-login *max-user-login*	Configures the maximum number of login sessions for a user.
timers auth-timeout *seconds*	Configures the client timers.
user-timeout *user-timeout*	Configures the idle client timeout.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to set the proble cycle count for band select to 8:

```
Device# configure terminal
Device(config)# wireless client band-select cycle-count 8
Device(config)# end
```

This example shows how to set the time threshold for a new scanning cycle with threshold value of 700 milliseconds:

```
Device# configure terminal
Device(config)# wireless client band-select cycle-threshold 700
Device(config)# end
```

This example shows how to suppress dual-band clients from the dual-band database after 70 seconds:

```
Device# configure terminal
Device(config)# wireless client band-select expire suppression 70
Device(config)# end
```

wireless client mac-address

To configure the wireless client settings, use the **wireless client mac-address** command in global configuration mode.

wireless client mac-address *mac-addr* **ccx** {**clear-reports** | **clear-results** | **default-gw-ping** | **dhcp-test** | **dns-ping** | **dns-resolve hostname** *host-name* | **get-client-capability** | **get-manufacturer-info** | **get-operating-parameters** | **get-profiles** | **log-request** {**roam** | **rsna** | **syslog**} | **send-message** *message-id* | **stats-request** *measurement-duration* {**dot11** | **security**} | **test-abort** | **test-association** *ssid bssid dot11 channel* | **test-dot1x** [*profile-id*] *bssid dot11 channel* | **test-profile** {**any***profile-id*}}

Syntax Description

mac-addr	MAC address of the client.
ccx	Cisco client extension (CCX).
clear-reports	Clears the client reporting information.
clear-results	Clears the test results on the controller.
default-gw-ping	Sends a request to the client to perform the default gateway ping test.
dhcp-test	Sends a request to the client to perform the DHCP test.
dns-ping	Sends a request to the client to perform the Domain Name System (DNS) server IP address ping test.
dns-resolve hostname *host-name*	Sends a request to the client to perform the Domain Name System (DNS) resolution test to the specified hostname.
get-client-capability	Sends a request to the client to send its capability information.
get-manufacturer-info	Sends a request to the client to send the manufacturer's information.
get-operating-parameters	Sends a request to the client to send its current operating parameters.
get-profiles	Sends a request to the client to send its profiles.
log-request	Configures a CCX log request for a specified client device.
roam	(Optional) Specifies the request to specify the client CCX roaming log
rsna	(Optional) Specifies the request to specify the client CCX RSNA log.
syslog	(Optional) Specifies the request to specify the client CCX system log.

send-message *message-id*

Sends a message to the client.

Message type that involves one of the following:

- 1—The SSID is invalid
- 2—The network settings are invalid.
- 3—There is a WLAN credibility mismatch.
- 4—The user credentials are incorrect.
- 5—Please call support.
- 6—The problem is resolved.
- 7—The problem has not been resolved.
- 8—Please try again later.
- 9—Please correct the indicated problem.
- 10—Troubleshooting is refused by the network.
- 11—Retrieving client reports.
- 12—Retrieving client logs.
- 13—Retrieval complete.
- 14—Beginning association test.
- 15—Beginning DHCP test.
- 16—Beginning network connectivity test.
- 17—Beginning DNS ping test.
- 18—Beginning name resolution test.
- 19—Beginning 802.1X authentication test.
- 20—Redirecting client to a specific profile.
- 21—Test complete.
- 22—Test passed.
- 23—Test failed.
- 24—Cancel diagnostic channel operation or select a WLAN profile to resume normal operation.
- 25—Log retrieval refused by the client.
- 26—Client report retrieval refused by the client.
- 27—Test request refused by the client.
- 28—Invalid network (IP) setting.
- 29—There is a known outage or problem with the network.

- 30—Scheduled maintenance period.
- 31—The WLAN security method is not correct.
- 32—The WLAN encryption method is not correct.
- 33—The WLAN authentication method is not correct.

stats-request *measurement-duration*	Senda a request for statistics.
dot11	Optional) Specifies dot11 counters.
security	(Optional) Specifies security counters.
test-abort	Sends a request to the client to abort the current test.
test-association *ssid bssid dot11 channel*	Sends a request to the client to perform the association test.
test-dot1x	Sends a request to the client to perform the 802.1x test.
profile-id	(Optional) Test profile name.
bssid	Basic SSID.
dot11	Specifies the 802.11a, 802.11b, or 802.11g network.
channel	Channel number.
test-profile	Sends a request to the client to perform the profile redirect test.
any	Sends a request to the client to perform the profile redirect test.
profile-id	Test profile name. **Note** The profile ID should be from one of the client profiles for which client reporting is enabled.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **default-gw-ping** test does not require the client to use the diagnostic channel.

This example shows how to clear the reporting information of the client MAC address 00:1f:ca:cf:b6:60:

```
Device# configure terminal
Device(config)# wireless client mac-address 00:1f:ca:cf:b6:60 ccx clear-reports
Device(config)# end
```

wireless client vlan-persistent

To enable client roaming across different policy profiles, use the **wireless client vlan-persistent** command.

wireless client vlan-persistent

no wireless client vlan-persistent

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Examples

The following example shows how to enable client roaming across different policy profiles:

```
Device(config) # wireless client vlan-persistent
```

wireless config validate

To validate whether the wireless configuration is complete and consistent (all the functional profiles and tags are defined, and all the associations are complete and consistent), use the **wireless config validate** command in privileged EXEC mode.

wireless config validate

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

In Cisco vEWLC, the wireless configuration is built using a collection of profiles, with each profile defining a functional block. These functional blocks are defined independently and is used to realize well-defined associations through intent based work-flows in building the wireless LAN. Such flexibility of modularizing the functional blocks requires the administrator to ensure that all associations are consistent and complete.

To ensure completeness and consistency of the wireless configuration, a configuration validation library is used to validate the configuration definitions across tables. The **wireless config validate** exec command is introduced from this release to validate the wireless configuration and report inconsistencies, if any, using contextual error message that is visible in btrace infra and on the console (if console logging is enabled). This command calls out any inconsistencies (unresolved associations) enabling you to realize a functional wireless LAN.

Use the following command to direct the output to a file: **show logging | redirect bootflash:** *filename* .

The following set of wireless configurations are validated:

RF tag	Site tag	Policy tag	Policy profile	Flex profile
site-tag	flex-profile	wlan profile	IPv4 ACL name	VLAN ACL
poliy-tag	ap-profile	policy profile	Fabric name	ACL-policy
rf-tag	-—	-—	service-policy input and output name	RF Policy (5GHz and 24GHz)
-—	-—	-—	service-policy input and client output name	-—

Example

The following is sample output from the **wireless config validate** command

```
Device# wireless config validate

Oct 10 18:21:59.576 IST: %CONFIG_VALIDATOR_MESSAGE-5-EWLC_GEN_ERR: Chassis 1 R0/0: wncmgrd:
 Error in AP: fc99.473e.0a90  Applied site-tag : mysite definitiondoes not exist
Oct 10 18:21:59.576 IST: %CONFIG_VALIDATOR_MESSAGE-5-EWLC_GEN_ERR: Chassis 1 R0/0: wncmgrd:
 Error in AP: fc99.473e.0a90  Applied policy-tag : mypolicy definition does not exist
Oct 10 18:21:59.576 IST: %CONFIG_VALIDATOR_MESSAGE-5-EWLC_GEN_ERR: Chassis 1 R0/0: wncmgrd:
 Error in AP: fc99.473e.0a90  Applied rf-tag : myrf definition does not exist
```

wireless country

To configure one or more country codes for a device, use the **wireless country** command.

wireless country *country-code*

Syntax Description

country-code	Two-letter country code.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

The Cisco must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.

This example shows how to configure country code on the device to IN (India):

```
Device(config)# wireless country IN
```

wireless exclusionlist mac address

To manually add clients to the exclusionlist, use the wireless exclusion list command. To remove the manual entry, use the no form of the command.

wireless exclusionlist *mac_address* **description**

Syntax Description

description *value*	Configures the entry description.

Command Default

None

Command Modes

Global Configuration

Command History

Cisco IOS XE Gibraltar 16.10.1	Modification
	This command was introduced in this release.

Usage Guidelines

If a client was added to the exclusion list dynamically, the command to remove it is **wireless client mac-address xxxx.xxxx.xxxx deauthenticate** from enable mode.

Example

This example shows how to manage exclusion entries:

```
Device(config)# wireless exclusion list xxxx.xxxx.xxxx
```

wireless ipv6 ra wired

To enable the forwarding of Router Advertisement message to the wired clients, use the **wireless ipv6 ra wired** command.

wireless ipv6 ra wired { **nd** { **na-forward** | **ns-forward** } | **ra-wired** }

Syntax Description

nd	Configures wireless IPv6 ND parameters.
na-forward	Enables forwarding of Neighbor Advertisement to wireless clients.
ns-forward	Enable forwarding of Neighbor Solicitation to wireless clients.
ra	Configures wireless IPv6 Router Advertisement parameters.
wired	Enables forwarding of Router Advertisement message to the wired clients.

Command Default

None

Command Modes

Global Configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.3	This command was introduced.

Example

The following example shows how to enable the forwarding of Router Advertisement message to the wired clients:

```
Device(config)# wireless ipv6 ra wired
```

Warning The **wireless ipv6 ra wired** command must be enabled only for certification purpose and not during the deployment.

wireless load-balancing

To globally configure aggressive load balancing on the controller, use the **wireless load-balancing** command in global configuration mode.

wireless load-balancing {**denial** *denial-count* | **window** *client-count*}

Syntax Description

denial *denial-count*	Specifies the number of association denials during load balancing. Maximum number of association denials during load balancing is from 1 to 10 and the default value is 3.
window *client-count*	Specifies the aggressive load balancing client window, with the number of clients needed to trigger aggressive load balancing on a given access point. Aggressive load balancing client window with the number of clients is from 0 to 20 and the default value is 5.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Load-balancing-enabled WLANs do not support time-sensitive applications like voice and video because of roaming delays.

When you use Cisco 7921 and 7920 Wireless IP Phones with controllers, make sure that aggressive load balancing is disabled on the voice WLANs for each controller. Otherwise, the initial roam attempt by the phone might fail, causing a disruption in the audio path.

This example shows how to configure association denials during load balancing:

```
Device# configure terminal
Device(config)# wireless load-balancing denial 5
Device(config)# end
```

wireless macro-micro steering transition-threshold

To configure micro-macro transition thresholds, use the **wireless macro-micro steering transition-threshold** command.

wireless macro-micro steering transition-threshold {**balancing-window** | **client count** *number-clients* } {**macro-to-micro** | **micro-to-macro** *RSSI in dBm*}

Syntax Description

balancing-window	Active instance of the configuration in Route-processor slot 0.
client	Standby instance of the configuration in Route-processor slot 0.
number-clients	Valid range is 0 to 65535 clients.
macro-to-micro	Configures the macro to micro transition RSSI.
micro-to-macro	Configures micro-macro client load balancing window.
RSSI in dBm	RSSI in dBm. Valid range is –128 to 0.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure balancing-window:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless macro-micro steering transition-threshold balancing-window
number-of-clients
```

wireless macro-micro steering probe-suppression

To configure micro-macro probe suppressions, use the **wireless macro-micro steering probe-suppression** command.

wireless macro-micro steering probe-suppression {**aggressiveness** *number-of-cycles* | | **hysteresis***RSSI in dBm* | **probe-auth** | **probe-only**}

Syntax Description

aggressiveness	Configures probe cycles to be suppressed. The number of cycles range between 0 - 255.
hysteresis	Indicate show much greater the signal strength of a neighboring access point must be in order for the client to roam to it. The RSSI decibel value ranges from -6 to -3.
probe-auth	Enables mode to suppress probes and single auth
probe-only	Enables mode to suppress only probes

Command Default

None

Command Modes

Global configuration (config)

Command History

Examples

The following example shows how to configure balancing-window:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless macro-micro steering probe-suppression aggressiveness
number-of-cycles
```

wireless management certificate

To create a wireless management certificate details, use the **wireless management certificate** command.

wireless management certificate ssc {**auth-token** {**0** | **8**} *token* | **trust-hash** *hash-key* }

Syntax Description

auth-token	Authentication token.
token	Token name.
trust-hash	Trusted SSC hash list.
hash-key	SHA1 fingerprint.
0	Specifies an UNENCRYPTED token.
8	Specifies an AES encrypted token.

Command Default

None

Command Modes

Global Configuration(config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to configure a wireless management certificate:

```
Device# configure terminal
Device(config)# wireless management certificate ssc trust-hash test
```

wireless management interface

To create a wireless management interface, use the **wireless management interface** command.

wireless management interface { **GigabitEthernet** | **Loopback** | **Vlan** } *interface-number*

Syntax Description

interface-number	Interface number.

Command Default

None

Command Modes

Global Configuration(config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to configure a wireless management interface:

```
Device# configure terminal
Device(config)# wireless management interface vlan vlan1
```

wireless management trustpoint

To create a wireless management trustpoint, use the **wireless management trustpoint** command.

wireless management trustpoint *trustpoint-name*

Syntax Description

trustpoint-name	Trustpoint name.

Command Default

None

Command Modes

Global Configuration(config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Use this command only on the Cisco Catalyst 9800 Wireless Controller for Cloud platform and not on appliances as the appliances use the SUDI certificate by default without the need for this command.

Example

The following example shows how to configure a wireless management trustpoint:

```
Device# configure terminal
Device(config)# wireless management trustpoint test
```

wireless mesh alarm association count

To configure the mesh alarm association count, use the **wireless mesh alarm association count** command.

wireless mesh alarm association count *count*

Syntax Description

count	Number of alarm associations. The vlaid range is between 1 and 30.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh alarm association count:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy wireless mesh alarm association count 10
```

wireless mesh alarm high-snr

To configure the mesh alarm high-snr value, use the **wireless mesh alarm high-snr** command.

wireless mesh alarm high-snr *high-snr*

Syntax Description

high-snr	Set the high-snr value. The valid range is between 31 and 100.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh high-snr:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy wireless mesh alarm high-snr 75
```

wireless mesh alarm low-snr

To configure the mesh alarm low-snr value, use the **wireless mesh alarm low-snr** command.

wireless mesh alarm low-snr *low-snr*

Syntax Description

low-snr	Set the low-snr value. The valid range is between 1 and 30.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh high-snr:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless profile policy wireless mesh alarm low-snr 5
```

wireless mesh alarm max-children map

To configure the mesh alarm max-children map value, use the **wireless mesh alarm max-children map** command.

wireless mesh alarm max-children map *max-children*

Syntax Description

max-children	Set the mesh alarm max-children map parameter. The valid range is between 1 and 50.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh alarm max-children map value:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh alarm max-children map 35
```

wireless mesh alarm max-children rap

To configure the mesh alarm max-children rap value, use the **wireless mesh alarm max-children rap** command.

wireless mesh alarm max-children rap *max-children*

Syntax Description

max-children	Set the mesh alarm max-children rap parameter. The valid range is between 1 and 50.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh alarm max-children rap value:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh alarm max-children rap 40
```

wireless mesh alarm max-hop

To configure the mesh alarm max-hop paramter, use the **wireless mesh alarm max-hop** command.

wireless mesh alarm max-hop *max-hop*

Syntax Description

max-hop	Set the mesh alarm max-hop count. Valid range is between 1 and 16.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh alarm max-hop parameter:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh alarm max-hop 15
```

wireless mesh alarm parent-change count

To configure the max parent-change count value, use the **wireless mesh alarm parent-change count** command.

wireless mesh alarm parent-change count *count*

Syntax Description

count	Set the max parent-change count value. Valid range is between 1 and 30.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the alarm parent change count value:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh alarm parent-change count 6
```

wireless mesh backhaul bdomain-channels

To configure and allow the Extended UNII B Domain channels for Outdoor mesh APs backhaul radio, use the **wireless mesh backhaul bdomain-channels** command.

wireless mesh backhaul bdomain-channels

Syntax Description

bdomain-channels	Allows the Extended UNII B Domain channels for Outdoor mesh APs backhaul radio. The **[no]** form of the command disables the use of the Extended UNII B Domain channels by the mesh APs backhaul radio.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to disable the use of Extended UNII B Domain channels by the Outdoor mesh APs backhaul radio:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# no wireless mesh backhaul bdomain-channels
```

wireless mesh backhaul rrm

To configure the mesh backhaul, use the **wireless mesh backhaul** command.

wireless mesh backhaul {**bdomain-channels** | **rrm**}

Syntax Description

backhaul	Configures the Mesh Backhaul.
bdomain-channels	Allows Extended UNII B Domain channels for Outdoor mesh APs backhaul radio.
rrm	Configures RRM for the mesh backhaul.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure RRM for the mesh backhaul:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh backhaul rrm
```

wireless mesh cac

To configure the mesh CAC Mode, use the **wireless mesh cac** command.

wireless mesh cac

Syntax Description

cac	Configures the mesh CAC Mode.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure the mesh CAC mode:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh cac
```

wireless mesh ethernet-bridging allow-bdpu

To configure STP BPDUs for wired mesh uplink, use the **wireless mesh ethernet-bridging allow-bdpu** command.

wireless mesh ethernet-bridging allow-bdpu

Syntax Description

ethernet-bridging	Configure ethernet bridging.
allow-bdpu	Configures STP BPDUs towards wired MESH uplink.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure STP BPDUs towards wired MESH uplink:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh ethernet-bridging allow-bdpu
```

wireless mesh security psk provisioning

To provision the mesh security psk parameters, use the **wireless mesh security psk provisioning** command.

wireless mesh security psk provisioning {**default_psk** | **inuse** *psk-index* | **key** *psk-index* {**0** | **8**}*enter-psk-name psk-description*}

Syntax Description

provisioning	configuring mesh psk provisioning parameters.
default_psk	Set the mesh provisioning to the default-psk settings.
inuse	Configuring the psk inuse index
psk-index	Enter PSK key index. Valid range is between 1 and 5.
key	Configure a pre-shared-key
psk-index	Enter PSK key index. Valid range is between 1 and 5.
0	Choose to enter an UNENCRYPTED password.
8	Choose to enter an AES encrypted password.
enter-psk-name	Enter a name for the configured psk key.
psk-description	Enter a description for this key.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to provision the default psk key for the mesh security:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh security psk provisioning default_psk
```

wireless mesh subset-channel-sync

To configure the subset channel sync for mobility group, use the **wireless mesh subset-channel-sync** command.

wireless mesh subset-channel-sync

Syntax Description

subset-channel-sync	Configures the subset channel sync for mobility group

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure subset channel sync for mobility group:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless mesh subset-channel-sync
```

wireless ewc-ap ap ap-type

To convert a single AP to CAPWAP or to embedded wireless controller, use the **wireless ewc-ap ap ap-type** command.

wireless ewc-ap ap ap-type *Cisco-AP-name* { **capwap** | **ewc** }

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
ap-type	Configures the AP parameter.
Cisco-AP-name	Indicates the name of the Cisco AP.
capwap	Changes to Capwap ap-type.
ewc	Changes to the embedded wireless controller ap-type.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This message was introduced.

Example

The following example shows how to convert a single AP to a CAPWAP ap-type or a embedded wireless controller ap-type:

```
Device#wireless ewc-ap ap ap-type ap_name {capwap | ewc}
```

wireless ewc-ap ap capwap

To specify the CAPWAP parameters for an AP, use the **wireless ewc-ap ap capwap** command.

wireless ewc-ap ap capwap *Primay-Controller-Name* { **A.B.C.D** | **X:X:X:X::X** }

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
capwap	Configures the CAPWAP parameters.
Primay-Controller-Name	Indicates the name of the controller.
A.B.C.D	Indicates the IPv4 address of the primary controller.
X:X:X:X::X	Indicates the IPv6 address of the primary controller.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE 16.12.1	This message was introduced.

Example

The following example shows how to specify the CAPWAP parameters for an AP:

```
Device#wireless ewc-ap ap capwap controller_name {10.1.1.1 | 9:0:0:0::1}
```

wireless ewc-ap ap reload

To reload the embedded wireless controller AP, use the **wireless ewc-ap ap reload** command.

wireless ewc-ap ap reload

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
reload	Reloads the embedded wireless controller AP.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE 16.12.1	This message was introduced.

Example

The following example shows how to reload the embedded wireless controller AP:

```
Device#wireless ewc-ap ap reload
```

wireless ewc-ap ap shell

To access the AP parameters on the embedded wireless controller AP shell, use the **wireless ewc-ap ap shell** command.

wireless ewc-ap ap shell { **chassis** { *chassis-number* | **active** | **standby** } **R0** | **username** }

Syntax Description

chassis	Specifies the chassis.
chassis-number	Specifies the chassis number as either 1 or 2.
active	Configures the active instance in route processor slot 0.
standby	Configures the standby instance in route processor slot 0.
R0	Specifies the route processor in slot 0.
username	Specifies the AP management username.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device#wireless ewc-ap ap shell chassis 1 R0
```

wireless ewc-ap ap shell username

To configure the AP management username on the embedded wireless controller AP shell, use the **wireless ewc-ap ap shell username** command.

wireless ewc-ap ap shell username *username* **chassis** { *chassis-number* | **active** | **standby** } **R0**

Syntax Description

chassis	Specifies the chassis.
chassis-number	Specifies the chassis number as either 1 or 2.
active	Configures the active instance in route processor slot 0.
standby	Configures the standby instance in route processor slot 0.
R0	Specifies the route processor in slot 0.
username	Specifies the AP management username.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device#wireless ewc-ap ap shell username username1 chassis 1 R0
```

wireless ewc-ap preferred-master

To select the standby controller when the network is up and running, use the **wireless ewc-ap preferred-master** command.

wireless ewc-ap preferred-master *AP-name*

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
preferred-master	Configures the preferred primary AP.
AP-name	Indicates the name of the preferred primary AP.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This message was introduced.

Example

The following example shows how to set a preferred primary ap-type:

```
Device(config)#wireless ewc-ap preferred-master AP-name
```

wireless ewc-ap factory-reset

To perform factory reset on the embedded wireless controller and on all the access points connected to the controller, use the **wireless ewc-ap factory-reset** command.

wireless ewc-ap factory-reset

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters .
factory-reset	Resets Cisco AP configuration to factory default.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Example

The following example shows how to factory-reset the embedded wireless controller network:

```
Device#wireless ewc-ap factory-reset
```

wireless ewc-ap vrrp vrid

To configure the embedded wireless controller VRRP network identifier, use the **wireless ewc-ap vrrp vrid** command.

wireless ewc-ap vrrp vrid*value <1-255>*

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
vrrp	Configires the preferred primary APembedded wireless controller VRRP.
vrid	Indicates the VRRP VRID. Values are from 1-255. The default value is 1.
value	Indicates the VRRP VRID value.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This message was introduced.

Example

The following example shows how to configure the VRRP network identifier:

```
Device#wireless ewc-ap vrrp vrid 1
```

wireless profile flex

To configures a wireless flex profile and enter wireless flex profile configuration mode, use the **wireless profile flex** command. To disable the feature, use the **no** form of the command.

wireless profile flex *custom-flex-profile*

[no] wireless profile flex *custom-flex-profile*

Syntax Description

wireless profile flex	Configures a wireless flex profile and enter wireless flex profile configuration mode.
custom-flex-profile	Specifies the flex profile name.

Command Default

None

Command Modes

Wireless flex profile mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This examples shows how the wireless flex profile is configured:

```
Device(config)#wireless profile flex custom-flex-profile
```

wireless profile image-download default

To configure the default image download profile for AP Join Download and Predownload, use the following command:

Note **Default** is the only profile name that you can enter.

wireless profile image-download default

Syntax Description

wireless profile	Configures the wireless profile parameters.
image-download	Configures the EWC-AP image download parameters.
default	Specifies the profile name - default. Default is the only profile name that you can enter.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device# wireless profile image-download default
```

wireless profile mesh

To configure the mesh profile on an access point (AP), use the **wireless profile mesh** *profile-name* command.

wireless profile mesh *profile-name*

Syntax Description

profile-name	Name of the profile.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to configure the mesh profile on an AP:

```
Device# configure terminal
(config)#wireless profile mesh test1
```

wireless profile policy

To configure WLAN policy profile, use the **wireless profile policy** command.

wireless profile policy *policy-profile*

Syntax Description

policy-profile	Name of the WLAN policy profile.

Command Default

The default profile name is default-policy-profile.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a WLAN policy profile:

```
Device(config)# wireless profile policy mywlan-profile-policy
```

wireless profile transfer

To configure the export of trace logs on the embedded wireless controller, use the **wireless profile transfer** command. Use the **no** form of this command to negate the command or to set the command to its default.

[**no**] **wireless profiletransfertrace-export** *trace-export-profile-name*

Syntax Description

trace-export	Configures the trace export parameters.
trace-export-profile-name	Specifies the trace export profile name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

```
Device# wireless profile transfer trace-export trace-export-profile-name
```

wireless profile urwb

To configure the URWB profile, use the **wireless profile urwb** command in the global configuration mode.

wireless profile urwb

Syntax Description

urwb-profile-name	Specifies the URWB profile name.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to configure the URWB profile:

```
Device# configure terminal
Device(config)# wireless profile urwb urwb-profile-name
```

wireless rfid

To set the static radio-frequency identification (RFID) tag data timeout value, use the **wireless rfid** command in global configuration mode.

wireless rfid timeout *timeout-value*

Syntax Description

timeout	Configures the static RFID tag data timeout value.
timeout-value	RFID tag data timeout value. Valid values range from 60-7200.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to set the static RFID tag data timeout value.

```
Device(config)# wireless rfid timeout 70
```

wireless security dot1x

To configure IEEE 802.1x global configurations, use the **wireless security dot1x** command.

wireless security dot1x [**eapol-key** {**retries** *retries* | **timeout** *milliseconds*} | **group-key interval** *sec* | **identity-request** {**retries** *retries* | **timeout** *seconds*} | **radius** [**call-station-id**] {**ap-macaddress** | **ap-macaddress-ssid** | **ipaddress** | **macaddress**} | **request** {**retries** *retries* | **timeout** *seconds*} | **wep key** {**index 0** | **index 3**}]

Syntax Description

eapol-key	Configures eapol-key related parameters.
retries *retries*	(Optional) Specifies the maximum number of times (0 to 4 retries) that the controller retransmits an EAPOL (WPA) key message to a wireless client. The default value is 2.
timeout *milliseconds*	(Optional) Specifies the amount of time (200 to 5000 milliseconds) that the controller waits before retransmitting an EAPOL (WPA) key message to a wireless client using EAP or WPA/WPA-2 PSK. The default value is 1000 milliseconds.
group-key interval *sec*	Configures EAP-broadcast key renew interval time in seconds (120 to 86400 seconds).
identity-request	Configures EAP ID request related parameters.
retries *retries*	(Optional) Specifies the maximum number of times (0 to 4 retries) that the controller request the EAP ID. The default value is 2.
timeout *seconds*	(Optional) Specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting an EAP Identity Request message to a wireless client. The default value is 30 seconds.
radius	Configures radius messages.
call-station-id	(Optional) Configures Call-Station Id sent in radius messages.
ap-macaddress	Sets Call Station Id Type to the AP's MAC Address.
ap-macaddress-ssid	Sets Call Station Id Type to 'AP MAC address':'SSID'.
ipaddress	Sets Call Station Id Type to the system's IP Address.
macaddress	Sets Call Station Id Type to the system's MAC Address.
request	Configures EAP request related parameters.

retries *retries*	(Optional) For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the maximum number of times (0 to 20 retries) that the controller retransmits the message to a wireless client. The default value is 2.
timeout *seconds*	(Optional) For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting the message to a wireless client. The default value is 30 seconds.
wep key	Configures 802.1x WEP related paramters.
index 0	Specifies the WEP key index value as 0
index 3	Specifies the WEP key index value as 3

Command Default

Default for eapol-key-timeout: 1 second.

Default for eapol-key-retries: 2 retries.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example lists all the commands under **wireless security dot1x** .

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#wireless security dot1x ?
  eapol-key         Configure eapol-key related parameters
  group-key         Configures EAP-broadcast key renew interval time in seconds
  identity-request  Configure EAP ID request related parameters
  radius            Configure radius messages
  request           Configure EAP request related parameters
  wep               Configure 802.1x WEP related paramters
  <cr>
```

wireless security dot1x radius accounting mac-delimiter

To configure a MAC delimiter for called-station-ID or a calling-station-ID, use the **wireless security dot1x radius accounting mac-delimiter** command.

To remove MAC delimiter for a called-station-ID or a calling-station-ID, use the **no** form of the command.

wireless security dot1x radius accounting mac-delimiter {**colon** | **hyphen** | **none** | **single-hyphen** }

Syntax Description

colon	Sets the delimiter to colon.
hyphen	Sets the delimiter to hyphen.
none	Disables delimiters.
single-hyphen	Sets the delimiters to single hyphen.

Command Default

None

Command Modes

Global Configuration Mode

Command History

Release	Modification
Cisco IOS XE 3.6.0 E	This command was introduced.

This example shows how to configure a MAC delimiter for called-station-ID or a calling-station-ID to colon:

```
Device(config)# wireless security dot1x radius accounting mac-delimiter colon
```

wireless security dot1x radius accounting username-delimiter

To set the delimiter type, use **wireless security dot1x radius accounting username-delimiter** command, to remove the configuration, use the **no** form of this command.

wireless security dot1x radius accounting username-delimiter {**colon | hyphen | none | single-hyphen**}

Syntax Description

colon	Sets the delimiter to colon.
hyphen	Sets the delimiter to hyphen.
none	Disables delimiters.
single-hyphen	Sets the delimiters to single hyphen.

Command Default

None

Command Modes

Global Configuration Mode.

Command History

Release	Modification
Cisco IOS XE 3.7.2 E	This command was introduced.

This example shows how to sets the delimiter to colon.

```
Device(config)# wireless security dot1x radius acounting username-delimiter colon
```

wireless security dot1x radius callStationIdCase

To configure Call Station Id CASE send in RADIUS messages, use the **wireless security dot1x radius callStationIdCase** command.

To remove the Call Station Id CASE send in RADIUS messages, use the **no** form of the command.

wireless security dot1x radius callStationIdCase {**lower** | **upper**}

Syntax Description

lower	Sends all Call Station Ids to RADIUS in lowercase
upper	Sends all Call Station Ids to RADIUS in uppercase

Command Default

None

Command Modes

Global Configuration Mode

Command History

Release	Modification
Cisco IOS XE 3.6.0 E	This command was introduced.

This example shows how to configure Call Station Id CASE send in RADIUS messages in lowercase:

```
Device(config)# wireless security dot1x radius callstationIdCase lower
```

wireless security dot1x radius mac-authentication call-station-id

To configure call station ID type for mac-authentication, use the **wireless security dot1x radius mac-authentication call-station-id** command. To remove the configuration, use the **no** form of it.

wireless security dot1x radius mac-authentication call-station-id ap-ethmac-only | ap-ethmac-ssid | ap-group-name | ap-label-address | ap-label-address-ssid | ap-location | ap-macaddress | ap-macaddress-ssid | ap-name | ap-name-ssid | ipaddress | macaddress | vlan-id

Syntax Description

ap-ethmac-only	Sets call station ID type to the AP Ethernet MAC address.
ap-ethmac-ssid	Sets call station ID type to the format 'AP Ethernet MAC address':'SSID'.
ap-group-name	Sets call station ID type to the AP Group Name.
ap-label-address	Sets call station ID type to the AP MAC address on AP Label.
ap-label-address-ssid	Sets call station ID type to the format 'AP Label MAC address': 'SSID'.
ap-location	Sets call station ID type to the AP Location.
ap-macaddress	Sets call station ID type to the AP Radio MAC Address.
ap-macaddress-ssid	Sets call station ID type to the 'AP radio MAC Address':'SSID'.
ap-name	Sets call station ID type to the AP name.
ap-name-ssid	Sets call station ID type to the format 'AP name':'SSID'.
ipaddress	Sets call station ID type to the system IP Address.
macaddress	Sets call station ID type to the system MAC Address.
vlan-id	Sets call station ID type to the VLAN ID.

Command Default

None

Command Modes

Global Configuration Mode

Command History

Release	Modification
Cisco IOS XE 3.7.2 E	This command was introduced.

The example show how to set call station ID type to the AP Ethernet MAC address:

```
Device(config)# wireless security dot1x radius mac-authentication call-station-id
ap-ethmac-only
```

wireless security dot1x radius mac-authentication mac-delimiter

To configure MAC-Authentication attributes, use the **wireless security dot1x radius mac-authentication mac-delimiter** command.

To remove MAC-Authentication attributes, use the **no** form of the command.

wireless security dot1x radius mac-authentication mac-delimiter {**colon** | **hyphen** | **none** | **single-hyphen** }

Syntax Description

colon	Sets the delimiter to colon.
hyphen	Sets the delimiter to hyphen.
none	Disables delimiters.
single-hyphen	Sets the delimiters to single hyphen.

Command Default

None

Command Modes

Global Configuration Mode

Command History

Release	Modification
Cisco IOS XE 3.6.0 E	This command was introduced.

This example shows how to configure MAC-Authentication attributes to colon:

```
Device(config)# Scurity dot1x radius mac-authentication mac-delimiter colon
```

wireless security web-auth retries

To enable web authentication retry on a particular WLAN, use the **wireless wireless security web-auth retries** command. To disable, use the **no** form of the command.

wireless securityweb-authretries*retries*
nowireless securityweb-authretries

Syntax Description

wireless security web-auth	Enables web authentication on a particular WLAN.
retries *retries*	Specifies maximum number of web authentication request retries. The range is from 0 through 30. The default value is 3.

Command Default

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to enable web authentication retry on a particular WLAN.

```
Device#configure terminal
Device# wireless security web-auth retries 10
```

wireless tag policy

To configure wireless tag policy, use the **wireless tag policy** command.

wireless tag policy *policy-tag*

Syntax Description

policy-tag	Name of the wireless tag policy.

Command Default

The default policy tag is default-policy-tag.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to configure a wireless policy tag:

```
Device(config)# wireless tag policy guest-policy
```

wireless tag site

To configure a wireless site tag, use the **wireless tag site** *site-tag*command.

wireless tag site *site-tag*

Syntax Description

site-tag	Name of the site tag.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to configure a site tag:

```
Device(config)# wireless tag site test-site
```

wireless wps ap-authentication threshold

To configure the alarm trigger threshold for access point neighbor authentication, use the **wireless wps ap-authentication threshold** command. To remove the access point neighbor authentication, use the no form of the command.

wireless wps ap-authentication threshold *value*

no wireless wps ap-authentication threshold *value*

Syntax Description

threshold *value*	Specifies that the WMM-enabled clients are on the wireless LAN. The threshold value range is between 1 and 255. The default value is 1.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the alarm trigger threshold for access point neighbor authentication:

```
Device(config)# wireless wps ap-authentication threshold 1
```

wireless wps client-exclusion

To configure client exclusion policies, use the **wireless wps client-exclusion** command. To remove the client exclusion policies, use the **no** form of the command.

wireless wps client-exclusion {**all** | **dot11-assoc** | **dot11-auth** | **dot1x-auth** | **ip-theft** | **web-auth**}
no wireless wps client-exclusion {**all** | **dot11-assoc** | **dot11-auth** | **dot1x-auth** | **ip-theft** | **web-auth**}

Syntax Description

dot11-assoc	Specifies that the controller excludes clients on the sixth 802.11 association attempt, after five consecutive failures.
dot11-auth	Specifies that the controller excludes clients on the sixth 802.11 authentication attempt, after five consecutive failures.
dot1x-auth	Specifies that the controller excludes clients on the sixth 802.11X authentication attempt, after five consecutive failures.
ip-theft	Specifies that the control excludes clients if the IP address is already assigned to another device. For more information, see the Usage Guidelines section.
web-auth	Specifies that the controller excludes clients on the fourth web authentication attempt, after three consecutive failures.
all	Specifies that the controller excludes clients for all of the above reasons.

Command Default

Enabled.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

In IP-theft scenarios, there are differences between the older Cisco IOS XE releases and the Cisco IOS XE Denali 16.x releases:

Older Cisco IOS XE Releases	Cisco IOS XE Denali 16.x Releases
Priority wise, wired clients have higher priority over wireless clients, and DHCP IP has higher priority over static IP. The client security type is not checked; security of all client types are treated with same priority. If the existing binding is from a higher priority source, the new binding is ignored and an IP-theft is signaled. If the existing binding has the same source-priority as the new binding, the binding is ignored and an IP-theft is signaled. This ensures that the bindings are not toggled if two hosts send traffic using the same IP. Only the initial binding is retained in the software. If the new binding is from a higher priority source, the existing binding is replaced. This results in an IP-theft notification of existing binding and also a new binding notification.	There is not really a fundamental difference between wired and wireless; what matters is the trust (preflevel) of the entry, which is a function on how it was learnt (ARP, DHCP, ND, and so on) and the policy that is attached to the port. When preflevel is equal, the IP takeover is denied if the old entry is still reachable. IP takeover occurs when the update comes from a trusted port or a new entry gets IP from the DHCP server. Otherwise, you must explicitly grant it. The IP-theft is not reported if an old entry is replaced by a new and a more trusted one.

This example shows how to disable clients on the 802.11 association attempt after five consecutive failures.

```
Device#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)#wireless wps client-exclusion dot11-assoc
```

wireless wps mfp ap-impersonation

To configure AP impersonation detection, use the **wireless wps mfp ap-impersonation** command. Use the **no** form of this command to disable the configuration.

wireless wps mfp ap-impersonation

no wireless wps mfp ap-impersonation

Syntax Description

ap-impersonation	Configures AP impersonation detection.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure AP impersonation detection:

```
Device(config)# wireless wps mfp ap-impersonation
```

wireless wps rogue network-assurance enable

To enable the rogue wireless service assurance (WSA) events, use the **wireless wps rogue network-assurance enable** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue network-assurance enable

no wireless wps rogue network-assurance enable

Syntax Description

network-assurance enable	Enables rogue WSA events.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to enable the rogue wireless service assurance events:

```
Device(config)# wireless wps rogue network-assurance enable
```

wireless wps rogue ap aaa

To configure the use of AAA/local database to detect valid AP MAC addresses, use the **wireless wps rogue ap aaa** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap aaa

no wireless wps rogue ap aaa

Syntax Description

aaa	Configures the use of AAA or local database to detect valid AP MAC addresses.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the use of AAA/local database to detect valid AP MAC addresses:

```
Device(config)# wireless wps rogue ap aaa
```

wireless wps rogue ap aaa polling-interval

To configures Rogue AP AAA validation interval, in seconds, use the **wireless wps rogue ap aaa polling-interval** command. To disable the configuration, use the no form of this command.

wireless wps rogue ap aaa polling-interval *60 - 86400*

no wireless wps rogue ap aaa polling-interval *60 - 86400*

Syntax Description

aaa	Sets the use of AAA or local database to detect valid AP MAC addresses.
polling-interval	Configures the rogue AP AAA validation interval.
60 - 86400	Specifies AP AAA validation interval, in seconds.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configures Rogue AP AAA validation interval, in seconds:

```
Device(config)# wireless wps rogue ap aaa polling-interval 120
```

wireless wps rogue ap init-timer

To configure the init timer for rogue APs, use the **wireless wps rogue ap init-timer** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap init-timer

no wireless wps rogue ap init-timer

Syntax Description

init-timer	Configures the init timer for rogue APs.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the init timer for rogue APs:

```
Device(config)# wireless wps rogue ap init-timer
```

wireless wps rogue ap mac-address rldp initiate

To initiate and configure Rogue Location Discovery Protocol on rogue APs, use the **wireless wps rogue ap mac-address rldp initiate** command.

wireless wps rogue ap mac-address <*MAC Address*> **rldp initiate**

Syntax Description

wps	Configures the WPS settings.
rogue	Configures the global rogue devices.
ap mac-address <*MAC Address*>	The MAC address of the APs.
rldp initiate	Initiates RLDP on rogue APs.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to initiate and configure Rogue Location Discovery Protocol on rogue APs:

```
Device# wireless wps rogue ap mac-address 10.1.1 rldp initiate
```

wireless wps rogue ap notify-min-rssi

To configure the minimum RSSI notification threshold for rogue APs, use the **wireless wps rogue ap notify-min-rssi** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap notify-min-rssi

no wireless wps rogue ap notify-min-rssi

Syntax Description

notify-min-rssi	Configure the minimum RSSI notification threshold for rogue APs.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the minimum RSSI notification threshold for rogue APs:

```
Device(config)# wireless wps rogue ap notify-min-rssi
```

wireless wps rogue ap notify-rssi-deviation

To configure the RSSI deviation notification threshold for rogue APs, use the **wireless wps rogue ap notify-rssi-deviation** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap notify-rssi-deviation

no wireless wps rogue ap notify-rssi-deviation

Syntax Description

notify-rssi-deviation	Configures the RSSI deviation notification threshold for rogue APs.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the RSSI deviation notification threshold for rogue APs:

```
Device(config)# wireless wps rogue ap notify-rssi-deviation
```

wireless wps rogue ap rldp alarm-only

To set Rogue Location Discovery Protocol (RLDP) and alarm if rogue is detected, use the **wireless wps rogue ap rldp alarm-only** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap rldp alarm-only

no wireless wps rogue ap rldp alarm-only

Syntax Description

alarm-only	Sets RLDP and alarm if rogue is detected.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to set RLDP and alarm if rogue is detected:

```
Device(config)# wireless wps rogue ap rldp alarm-only
```

wireless wps rogue ap rldp alarm-only monitor-ap-only

To perform RLDP only on monitor APs, use the **wireless wps rogue ap rldp alarm-only monitor-ap-only** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap rldp alarm-only monitor-ap-only

no wireless wps rogue ap rldp alarm-only monitor-ap-only

Syntax Description

monitor-ap-only	Performs RLDP on monitor APs only.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to perform RLDP only on monitor APs,:

```
Device(config)# wireless wps rogue ap rldp alarm-only monitor-ap-only
```

wireless wps rogue ap rldp auto-contain

To configure RLDP, alarm and auto-contain if rogue is detected, use **wirelesswps rogueaprldp auto-contain** command. Use the **no** form of the command to disable the alarm.

[no] wireless wps rogue ap rldp auto-contain monitor-ap-only

Syntax Description

monitor-ap-only	Perform RLDP only on monitor AP

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Cisco IOS XE 3.7.3E	The **no** form of the command was introduced.

Example

This example shows how to configure an alarm for a detected rogue.

```
Device wireless wps rogue ap rldp auto-contain
```

wireless wps rogue ap rldp retries

To configure RLDP retry times on rogue APs, use the **wireless wps rogue ap rldp retries** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap rldp retries

no wireless wps rogue ap rldp retries

Syntax Description

retries	Configures RLDP retry times on rogue APs.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure RLDP retry times on rogue APs:

```
Device(config)# wireless wps rogue ap rldp retries
```

wireless wps rogue ap rldp schedule

To configure RLDP scheduling, use the **wireless wps rogue ap rldp schedule** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap rldp schedule

no wireless wps rogue ap rldp schedule

Syntax Description

schedule	Configures RLDP scheduling.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure RLDP scheduling:

```
Device(config)# wireless wps rogue ap rldp schedule
```

wireless wps rogue ap rldp schedule day

To configure the day when RLDP scheduling is to be done, use the **wireless wps rogue ap rldp schedule day** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap rldp schedule day { **friday** | **monday** | **saturday** | **sunday** | **thursday** | **tuesday** | **wednesday** } **start** *[HH:MM:SS]* **end** *[HH:MM:SS]*

no wireless wps rogue ap rldp schedule day { **friday** | **monday** | **saturday** | **sunday** | **thursday** | **tuesday** | **wednesday** } **start** *[HH:MM:SS]* **end** *[HH:MM:SS]*

Syntax Description

day {**friday** | **monday** | **saturday** | **sunday** | **thursday** | **tuesday** | **wednesday**}	Configures the day of the week when RLDP scheduling is to be done.
start *[HH:MM:SS]*	Configures the start time for RLDP schedule for the day.
end *[HH:MM:SS]*	Configures the end time for RLDP schedule for the day.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the day of the week, when RLDP scheduling is to be done:

```
Device(config)# wireless wps rogue ap rldp schedule day friday start 10:10:10 end 15:15:15
```

wireless wps rogue ap timeout

To configure the expiry time for rogue APs, in seconds, use the **wireless wps rogue ap timeout** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue ap timeout *240-3600*

no wireless wps rogue ap timeout *240-3600*

Syntax Description

rogue ap timeout	Configures the expiry time for rogue APs, in seconds.
240-3600	Specifies the number of seconds before rogue entries are flushed.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the expiry time for rogue APs, in seconds:

```
Device(config)# wireless wps rogue ap timeout 250
```

wireless wps rogue auto-contain

To configure the auto contain level and to configure auto containment for monitor AP mode, use the **wireless wps rogue auto-contain** command. To disable the configuration, use the **no** form of this command.

wireless wps rogue auto-contain { **level** *1 - 4* | **monitor-ap-only** }

no wireless wps rogue auto-contain { **level** *1 - 4* | **monitor-ap-only** }

Syntax Description

auto-contain	Configures auto contain for rogue devices.
level	Configures auto contain levels.
1 - 4	Specifies the auto containment levels.
monitor-ap-only	Configures auto contain for monitor AP mode.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the auto contain level and to configure auto containment for monitor AP mode:

```
Device(config)# wireless wps rogue auto-contain level 2
Device(config)# wireless wps rogue auto-contain monitor-ap-only
```

wireless wps rogue client aaa

To configure the use of AAA or local database to detect valid MAC addresses of rogue clients, use the **wireless wps rogue client aaa** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue client aaa

no wireless wps rogue client aaa

Syntax Description

aaa	Configures the use of AAA or local database to detect valid MAC addresses of rogue clients.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure the use of AAA or local database to detect valid MAC addresses of rogue clients:

```
Device(config)# wireless wps rogue client aaa
```

wireless wps rogue client mse

To configure Mobility Services Engine (MSE) to detect valid MAC addresses of rogue clients, use the **wireless wps rogue client mse** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue client mse

no wireless wps rogue client mse

Syntax Description

mse	Configures the MSE to detect valid MAC addresses of rogue clients.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 16.12.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows you how to configure Mobility Services Engine (MSE) to detect valid MAC addresses of rogue clients:

```
Device(config)# wireless wps rogue client mse
```

wireless wps rogue client client-threshold

To configure rogue client per a rogue AP SNMP trap threshold, use the **wireless wps rogue client client-threshold** command. To disable the configuration, use the **no** form of this command.

wireless wps rogue client client-threshold *0 - 256*

no wireless wps rogue client client-threshold *0 - 256*

Syntax Description

rogue client	Configures rogue clients.
client-threshold	Configures the rogue client per a rogue AP SNMP trap threshold.
0 - 256	Specifies the client threshold.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure rogue client per a rogue AP SNMP trap threshold:

```
Device(config)# wireless wps rogue ap timeout 250
```

wireless wps rogue client notify-min-rssi

To configure the minimum RSSI notification threshold for rogue clients, use the **wireless wps rogue client notify-min-rssi** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue client notify-min-rssi *-128 - -70*

no wireless wps rogue client notify-min-rssi *-128 - -70*

Syntax Description

rogue clients	Configures rogue clients.
notify-min-rssi	Configures the minimum RSSI notification threshold for rogue clients.
-128 - -70	Specifies the RSSI threshold in decibels.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the minimum RSSI notification threshold for rogue clients:

```
Device(config)# wireless wps rogue client notify-min-rssi -125
```

wireless wps rogue client notify-rssi-deviation

To configure the RSSI deviation notification threshold for rogue clients, use the **wireless wps rogue client notify-rssi-deviation** command. To disable the configuration, use the **no** form of this command.

wireless wps rogue client notify-rssi-deviation *0 - 10*

no wireless wps rogue client notify-rssi-deviation *0 - 10*

Syntax Description

notify-rssi-deviation	Configures the RSSI deviation notification threshold for rogue clients.
0 - 10	Specifies the RSSI threshold in decibels.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the RSSI deviation notification threshold for rogue clients:

```
Device(config)# wireless wps rogue client notify-rssi-deviation 6
```

wireless wps rogue rule

To configure rogue classification rule, use the **wireless wps rogue rule** command.

wireless wps rogue rule *rule-name* **priority** *priority* {**classify** {**friendly** | **malicious**} | **condition** {**client-count number** | **duration** | **encryption** | **infrastructure** | **rssi** | **ssid**} | **default** | **exit** | **match** {**all** | **any**} | **no** | **shutdown**}

Syntax Description

rule *rule-name*	Specifies a rule name.
priority *priority*	Changes the priority of a specific rule and shifts others in the list accordingly.
classify	Specifies the classification of a rule.
friendly	Classifies a rule as friendly.
malicious	Classifies a rule as malicious.
condition {**client-count number** | **duration** | **encryption** | **infrastructure** | **rssi** | **ssid**}	Specifies the conditions for a rule that the rogue access point must meet. Type of the condition to be configured. The condition types are listed below: • client-count—Requires that a minimum number of clients be associated to a rogue access point. The valid range is 1 to 10 (inclusive). • duration—Requires that a rogue access point be detected for a minimum period of time. The valid range is 0 to 3600 seconds (inclusive). • encryption—Requires that the advertised WLAN does not have encryption enabled. • infrastructure—Requires the SSID to be known to the controller • rssi—Requires that a rogue access point have a minimum RSSI value. The range is from –95 to –50 dBm (inclusive). • ssid—Requires that a rogue access point have a specific SSID.
default	Sets the command to its default settings.
exit	Exits the sub-mode.
match {**all** | **any**}	Configures matching criteria for a rule. Specifies whether a detected rogue access point must meet all or any of the conditions specified by the rule in order for the rule to be matched and the rogue access point to adopt the classification type of the rule.
no	Negates a command or set its defaults.
shutdown	Shuts down the system.

Command Default

None.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to create a rule that can organize and display rogue access points as Friendly:

```
Device# configure terminal
Device(config)# wireless wps rogue rule ap1 priority 1
Device(config-rule)# classify friendly
Device(config)# end
```

wireless wps rogue security-level

To configure the wireless WPS rogue detection security levels, use the **wireless wps rogue security-level** command. Use the **no** form of this command to disable the configuration.

wireless wps rogue security-level { **critical** | **custom** | **high** | **low** }

no wireless wps rogue security-level { **critical** | **custom** | **high** | **low** }

Syntax Description

rogue security-level	Configures the rogue detection security level.
critical	Specifies the rogue detection setup for highly sensitive deployments.
custom	Specifies the customizable security level.
high	Specifies the rogue detection setup for medium-scale deployments.
low	Specifies the basic rogue detection setup for small-scale deployments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None

Example

This example shows how to configure the wireless WPS rogue detection security levels:

```
Device(config)# wireless wps rogue security-level critical
```

wireless-default radius server

To configure multiple radius servers, use the **wireless-default radius server** command.

wireless-default radius server *IP* **key** *secret*

Command Default None

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines Using this utility, you can configure a maximum of ten radius servers.

Example

This example shows how to configure multiple radius servers:

```
Device# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Device(config)# wireless-default radius server 9.2.58.90 key cisco123
Device(config)# end
```

wlan policy

To map a policy profile to a WLAN profile, use the **wlan policy** command.

wlan *wlan-name* **policy** *policy-name*

Syntax Description

wlan-name	Name of the WLAN profile.
policy	Map a policy profile to the WLAN profile.
policy-name	Name of the policy profile.

Command Default

None

Command Modes

config-policy-tag

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.



Show Commands

- show aaa dead-criteria radius, on page 704
- show aaa servers, on page 706
- show aaa server brief, on page 708
- show access-list, on page 709
- show ap auth-list, on page 711
- show ap auto-rf, on page 712
- show ap config, on page 715
- show ap config slots , on page 717
- show ap crash-file, on page 718
- show ap dot11, on page 719
- show ap dot11, on page 725
- show ap dot11 24ghz , on page 726
- show ap dot11 24ghz SI config, on page 727
- show ap dot11 24ghz SI device type, on page 728
- show ap dot11 5ghz, on page 729
- show ap dot11 24ghz cleanair air-quality, on page 731
- show ap dot11 24ghz cleanair air-quality, on page 732
- show ap dot11 cleanair config, on page 733
- show ap dot11 cleanair summary, on page 735
- show ap dot11 dual-band summary, on page 736
- show ap environment, on page 737
- show ap filters active, on page 738
- show ap filters all, on page 739
- show ap fra, on page 740
- show ap gps location, on page 741
- show history channel interface dot11Radio all, on page 742
- show ap image details, on page 743
- show ap link-encryption, on page 744
- show ap urwb status, on page 745
- show ap name ntp status, on page 746
- show ap ntp status, on page 747
- show ap primary list, on page 748
- show ap multicast mom (multicast over multicast), on page 749

- show ap name auto-rf, on page 750
- show ap name ble detail, on page 753
- show ap name cablemodem, on page 754
- show ap name config, on page 755
- show ap name config slot , on page 757
- show ap name config ethernet, on page 758
- show ap name dot11, on page 759
- show ap name dot11 5ghz slot urwb detail, on page 760
- show ap name environment, on page 761
- show ap name gps location, on page 762
- show ap name mesh backhaul, on page 763
- show ap name mesh bhrate, on page 764
- show ap name mesh linktest, on page 765
- show ap name mesh path, on page 766
- show ap name mesh stats, on page 767
- show ap name urwb coord-routes, on page 768
- show ap name urwb fixed-links, on page 769
- show ap name urwb info, on page 770
- show ap name urwb mobility-links, on page 771
- show ap name urwb network, on page 772
- show ap name urwb wireless-stats, on page 773
- show ap name wlan, on page 774
- show ap name temperature, on page 776
- show ap profile, on page 777
- show ap rf-profile summary, on page 778
- show ap summary, on page 779
- show ap tag sources, on page 780
- show ap tag summary, on page 781
- show ap timezone, on page 782
- show ap upgrade, on page 783
- show ap upgrade method, on page 785
- show arp, on page 786
- show arp summary , on page 787
- show ap upgrade site, on page 788
- show avc client, on page 789
- show avc wlan, on page 790
- show chassis, on page 791
- show checkpoint, on page 792
- show cts environment data , on page 799
- show cts role-based sgt-map all, on page 801
- show cts role-based counters, on page 803
- show flow exporter, on page 804
- show flow interface, on page 806
- show flow monitor, on page 808
- show flow record, on page 810
- show interfaces, on page 811

- show install package, on page 815
- show install rollback, on page 816
- show install summary, on page 817
- show inventory, on page 818
- show ip, on page 820
- show ip nbar protocol-id, on page 821
- show ldap attributes, on page 822
- show ldap server, on page 823
- show license air entities, on page 824
- show license all, on page 826
- show license authorization, on page 832
- show license data conversion, on page 837
- show license eventlog, on page 838
- show license history message, on page 839
- show license reservation, on page 840
- show license rum, on page 841
- show license status, on page 846
- show license summary, on page 856
- show license tech, on page 859
- show license udi, on page 874
- show license usage, on page 875
- show platform software sl-infra, on page 878
- show platform software tls client summary, on page 879
- show platform software client detail, on page 880
- show platform software tls statistics, on page 882
- show platform software tls session summary, on page 884
- show logging profile wireless end timestamp, on page 885
- show logging profile wireless filter, on page 886
- show logging profile wireless fru, on page 887
- show logging profile wireless internal, on page 888
- show logging profile wireless level, on page 889
- show logging profile wireless module, on page 890
- show logging profile wireless reverse, on page 891
- show logging profile wireless start, on page 892
- show logging profile wireless switch, on page 893
- show logging profile wireless to-file, on page 894
- show mdns-sd cache, on page 895
- show mdns-sd cache detail, on page 896
- show mdns-sd cache upn shared, on page 897
- show mdns-sd cache upn detail, on page 899
- show mdns-sd flexconnect summary , on page 900
- show mdns-sd statistics, on page 901
- show mdns-sd summary, on page 902
- show monitor capture, on page 903
- show nmsp, on page 906
- show nmsp cloud-services statistics, on page 907

- show nmsp cloud-services summary, on page 908
- show nmsp subscription group detail all, on page 909
- show nmsp subscription group detail ap-list, on page 910
- show nmsp subscription group detail services, on page 911
- show nmsp subscription group summary, on page 912
- show ntp associations, on page 913
- show parameter-map type webauth name, on page 914
- show platform conditions, on page 915
- show platform software wlavc status cp-exporter, on page 916
- show platform hardware slot R0 ha_port interface stats, on page 917
- show platform software system all, on page 920
- show platform software trace filter-binary, on page 921
- show platform software trace level, on page 922
- show platform software trace message, on page 925
- show platform software trace message license-manager chassis active R0, on page 927
- show platform software trace message license-manager , on page 930
- show policy-map, on page 933
- show rate-limit client, on page 938
- show ssh , on page 939
- show stealthwatch-cloud connection, on page 940
- show stealthwatch-cloud wireless-shim, on page 941
- show tech-support wireless, on page 942
- show tech-support wireless ap, on page 944
- show tech-support wireless client, on page 954
- show tech-support wireless radio, on page 958
- show tunnel eogre global-configuration, on page 969
- show tunnel eogre domain detailed, on page 970
- show tunnel eogre domain summary, on page 971
- show tunnel eogre gateway summary, on page 972
- show tunnel eogre gateway detailed , on page 973
- show tunnel eogre manager stats global, on page 974
- show tunnel eogre manager stats instance, on page 976
- show wireless stats ap history, on page 978
- show wireless stat redundancy statistics client-recovery mobilityd , on page 979
- show wireless stat redundancy statistics client-recovery sisf, on page 980
- show wireless stat redundancy client-recovery wncd, on page 981
- show wireless band-select, on page 982
- show wireless certification config, on page 983
- show wireless client , on page 984
- show wireless client mac-address , on page 985
- show wireless client mac-address (Call Control), on page 987
- show wireless client mac-address (TCLAS), on page 988
- show wireless client summary, on page 989
- show wireless client timers, on page 990
- show wireless country, on page 991
- show wireless detail, on page 994

- show wireless dhcp relay statistics, on page 995
- show wireless dot11h , on page 996
- show wireless dtls connections, on page 997
- show wireless exclusionlist , on page 998
- show wireless load-balancing, on page 999
- show wireless mesh rrm dca changed, on page 1000
- show wireless mesh rrm dca status, on page 1003
- show wireless ewc-ap ap summary, on page 1006
- show wireless ewc-ap ap config-sync, on page 1007
- show wireless ewc-ap ap image predownload status, on page 1008
- show wireless ewc-ap country-code, on page 1009
- show wireless ewc-ap image-master, on page 1010
- show wireless ewc-ap invalid-image-master, on page 1011
- show wireless ewc-ap predownload, on page 1012
- show wireless ewc-ap redundancy summary, on page 1013
- show wireless ewc-ap redundancy peers, on page 1014
- show wireless mesh ethernet daisy-chain summary, on page 1015
- show wireless mesh ethernet daisy-chain bgn, on page 1016
- show wireless pmk-cache, on page 1017
- show wireless profile flex , on page 1018
- show wireless profile policy detailed , on page 1019
- show wireless profile urwb detailed, on page 1020
- show wireless rfid, on page 1021
- show wireless stats client delete reasons, on page 1022
- show wireless stats redundancy config database, on page 1028
- show wireless summary, on page 1029
- show wireless urlfilter details, on page 1030
- show wireless urlfilter summary, on page 1031
- show wireless vlan details , on page 1032
- show wireless wgb mac-address , on page 1033
- show wireless wgb summary , on page 1034
- show wireless wps rogue ap summary , on page 1035
- show wireless wps rogue client detailed, on page 1036
- show wireless wps rogue ap detailed, on page 1037
- show wireless wps rogue client summary, on page 1039

show aaa dead-criteria radius

To verify the dead-server-detection information for a RADIUS server, use the **show aaa dead-criteria radius** command.

show aaa dead-criteria radius *ipaddr* **auth-port** *authport* **acct-port** *acctport*

Syntax Description

ipaddr	IP address.
authport	Authentication port.
acctport	Accounting port.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The **show aaa dead-criteria radius** *ipaddr* command displays output only if default ports are used. For non-default ports, use the **show aaa dead-criteria radius** *ipaddr* **auth-port** *authport* **acct-port** *acctport* command.

Example

The following example shows how to see the dead-server-detection information for a RADIUS server with non-default authorization and accounting ports:

```
Device# show aaa dead-criteria radius 4.4.4.4 auth-port 4444 acct-port 3333

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
============================
Server Details:
Address : 4.4.4.4
Auth Port : 4444
Acct Port : 3333
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 5
Estimated Outstanding Access Transactions: 0
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====================================================
Max Computed Outstanding Transactions: 0
Max Computed Dead Detect Time: 0s
```

```
Max Computed Retransmits : 0
```

The following example shows how to see the dead-server-detection information for a RADIUS server using default ports:

```
Device# show aaa dead-criteria radius 9.3.13.37

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
============================
Server Details:
Address : 9.3.13.37
Auth Port : 1812
Acct Port : 1813
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 30
Estimated Outstanding Access Transactions: 1
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====================================================
Max Computed Outstanding Transactions: 4
Max Computed Dead Detect Time: 48s
Max Computed Retransmits : 30
```

show aaa servers

To display the status and number of packets that are sent to and received from all public and private authentication, authorization, and accounting (AAA) RADIUS servers as interpreted by the AAA Server MIB, use the **show aaa servers** command.

show aaa servers [private | public]

Syntax Description

private	(Optional) Displays private AAA servers only, which are also displayed by the AAA Server MIB.
private	(Optional) Displays public AAA servers only, which are also displayed by the AAA Server MIB.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

Only RADIUS servers are supported by the **show aaa servers** command.

Example

The following command displays information about packets sent and received for all AAA transaction types--authentication, authorization, and accounting.

```
Device# show aaa servers

RADIUS: id 2, priority 1, host 124.2.2.12, auth-port 1645, acct-port 1612, hostname rsim
     State: current UP, duration 20699s, previous duration 0s
     Dead: total time 0s, count 0
     Platform State from SMD: current UP, duration 20699s, previous duration 0s
     SMD Platform Dead: total time 0s, count 0
     Platform State from WNCD (1) : current UP
     Platform State from WNCD (2) : current UP
     Platform State from WNCD (3) : current UP
     Platform State from WNCD (4) : current UP
     Platform State from WNCD (5) : current UP
     Platform State from WNCD (6) : current UP
     Platform State from WNCD (7) : current UP
     Platform State from WNCD (8) : current UP, duration 964s, previous duration 0s
     Platform Dead: total time 0s, count 0UP
     Quarantined: No
.
.
.

     Elapsed time since counters last cleared: 5h44m
     Estimated Outstanding Access Transactions: 0
     Estimated Outstanding Accounting Transactions: 0
     Estimated Throttled Access Transactions: 0
     Estimated Throttled Accounting Transactions: 0
```

```
Maximum Throttled Transactions: access 0, accounting 0
Consecutive Response Failures: total 0
        SMD Platform : max 0, current 0 total 0
        WNCD Platform: max 0, current 0 total 0
        IOSD Platform : max 0, current 0 total 0
Consecutive Timeouts: total 0
        SMD Platform : max 0, current 0 total 0
        WNCD Platform: max 0, current 0 total 0
        IOSD Platform : max 0, current 0 total 0
Requests per minute past 24 hours:
        high - 5 hours, 44 minutes ago: 0
        low  - 5 hours, 44 minutes ago: 0
        average: 0
```

show aaa server brief

To view the summary information of Authentication, Authorization, and Accounting (AAA) servers, use the **show aaa server brief** command.

show aaa server brief

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to view the summary information of AAA servers:

```
Device# show aaa server brief

Access            Access   Access Access   Outstndg Acct.  Acct.  Acct.     Outstndg   Total
    Reqs         Total Resp  Uptime  Uptime  Uptime
                  Requests Accept Reject   timeouts Access tx Req Responses timeouts   Acct.
 tx (Auth+Acct) (Auth+Acct) (IOSD)  (SMD)    (WNCD)
-------------------------------------------------------------------------------------------
rsim              0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
R1                0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
free-radius-aut
hc-server         0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
cisco-dnac-auth
z-server          0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
r1                0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
ise               0        0      0        0        0      0      0         0          0
      0            0           2372790 2372790 964
Radius-2          0        0      0        0        0      0      0         0          0
      0            0           2274176 2274176 296805
```

show access-list

To display access control lists (ACLs) configured on the device, use the **show access-lists** command in privileged EXEC mode.

show access-lists[*namenumber* | **hardware counters** | **ipc**]

Syntax Description

number	(Optional) ACL number. The range is 1 to 2799.
name	(Optional) Name of the ACL.
hardware counters	(Optional) Displays the access list hardware counters.
ipc	(Optional) Display Interprocess Communication (IPC) protocol access-list configuration download information

Command Default

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Usage Guidelines

Though visible in the command-line help strings, the **rate-limit** keyword is not supported

The device supports only IP standard and extended access lists. Therefore, the allowed numbers are only 1 to 199 and 1300 to 2799.

This command also displays the MAC ACLs that are configured.

This is an example of output from the **show access-lists** command:

```
Device# show access-lists

Extended IP access list 103
    10 permit ip any any dscp af11
Extended IP access list ssm-range
    10 deny ip any 232.0.0.0 0.255.255.255
    20 permit ip any any
Extended MAC access list mac1
```

This is an example of output from the **show access-lists hardware counters** command:

```
Device# show access-lists hardware counters
 L3 ACL INPUT Statistics
     All  Drop:                      frame count: 0
     All  Bridge Only:               frame count: 0
     All  Forwarding To CPU:         frame count: 294674
     All  Forwarded:                 frame count: 2577677
```

```
    All  Drop And Log:             frame count: 0
    All  Bridge Only And Log:      frame count: 0
    All  Forwarded And Log:        frame count: 0
    All  IPv6 Drop:                frame count: 0
    All  IPv6 Bridge Only:         frame count: 0
    All  IPv6 Forwarding To CPU:   frame count: 0
    All  IPv6 Forwarded:           frame count: 102
    All  IPv6 Drop And Log:        frame count: 0
    All  IPv6 Bridge Only And Log: frame count: 0
    All  IPv6 Forwarded And Log:   frame count: 0

L3 ACL OUTPUT Statistics
    All  Drop:                     frame count: 0
    All  Bridge Only:              frame count: 0
    All  Forwarding To CPU:        frame count: 0
    All  Forwarded:                frame count: 266050
    All  Drop And Log:             frame count: 0
    All  Bridge Only And Log:      frame count: 0
    All  Forwarded And Log:        frame count: 0
    All  IPv6 Drop:                frame count: 0
    All  IPv6 Bridge Only:         frame count: 0
    All  IPv6 Forwarding To CPU:   frame count: 0
    All  IPv6 Forwarded:           frame count: 0
    All  IPv6 Drop And Log:        frame count: 0
    All  IPv6 Bridge Only And Log: frame count: 0
    All  IPv6 Forwarded And Log:   frame count: 0
```

show ap auth-list

To see the access point authorization list, use the **show ap auth-list** command.

show ap auth-list [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the access point authorization list:

```
Device# show ap auth-list
```

show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

show ap auto-rf dot11 { **24ghz** | **5ghz** | **6ghz** | **dual-band** } *cisco_ap*

Syntax Description

24ghz	Specifies the 802.11b radio.
5ghz	Specifies the 802.11a radio.
6ghz	Specifies 6ghz band.
dual-band	Specifies dual bands.

Command Default

None

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.12.1.

Usage Guidelines

The **show ap auto-rf command** output will not display neighbor AP names.

The following example shows how to display auto-RF information for an access point:

```
Device# show ap auto-rf dot11 24ghz AP1

######################################################################

Number of Slots                                 : 3
AP Name                                         : APA023.9FD8.EA22
MAC Address                                     : 40ce.24bf.8ca0
Ethernet MAC Address                            : a023.9fd8.ea22
  Slot ID                                       : 0
  Radio Type                                    : 802.11n - 2.4 GHz
  Current TX/RX Band                            : 2.4Ghz band
  Subband Type                                  : All
  Noise Information
    Noise Profile                               : Passed
    Channel   1                                 :  -91 dBm
    Channel   2                                 :  -67 dBm
    Channel   3                                 :  -54 dBm
    Channel   4                                 :  -55 dBm
    Channel   5                                 :  -71 dBm
    Channel   6                                 :  -85 dBm
    Channel   7                                 :  -50 dBm
    Channel   8                                 :  -54 dBm
    Channel   9                                 :  -77 dBm
    Channel  10                                 :  -88 dBm
    Channel  11                                 :  -65 dBm
  Interference Information
    Interference Profile                        : Failed
    Channel   1                                 :  -47 dBm @ 21% busy
    Channel   2                                 :  -45 dBm @  2% busy
    Channel   3                                 : -128 dBm @  0% busy
    Channel   4                                 : -128 dBm @  0% busy
```

```
  Channel   5                                 :  -48 dBm @  2% busy
  Channel   6                                 :  -45 dBm @  2% busy
  Channel   7                                 :  -42 dBm @  3% busy
  Channel   8                                 : -128 dBm @  0% busy
  Channel   9                                 : -128 dBm @  0% busy
  Channel  10                                 :  -39 dBm @  3% busy
  Channel  11                                 :  -46 dBm @  3% busy
  Rogue Histogram (20)
    Channel   1                               : 36
    Channel   2                               :  0
    Channel   3                               :  0
    Channel   4                               :  1
    Channel   5                               :  0
    Channel   6                               : 11
    Channel   7                               :  0
    Channel   8                               :  1
    Channel   9                               :  3
    Channel  10                               :  0
    Channel  11                               : 14
Load Information
  Load Profile                                : Failed
  Receive Utilization                         : 0%
  Transmit Utilization                        : 0%
  Channel Utilization                         : 98%
  Attached Clients                            : 0 clients
Coverage Information
  Coverage Profile                            : Passed
  Failed Clients                              : 0 clients
Client Signal Strengths
  RSSI -100 dBm                               : 0 clients
  RSSI  -92 dBm                               : 0 clients
  RSSI  -84 dBm                               : 0 clients
  RSSI  -76 dBm                               : 0 clients
  RSSI  -68 dBm                               : 0 clients
  RSSI  -60 dBm                               : 0 clients
  RSSI  -52 dBm                               : 0 clients
Client Signal to Noise Ratios
  SNR    0 dB                                 : 0 clients
  SNR    5 dB                                 : 0 clients
  SNR   10 dB                                 : 0 clients
  SNR   15 dB                                 : 0 clients
  SNR   20 dB                                 : 0 clients
  SNR   25 dB                                 : 0 clients
  SNR   30 dB                                 : 0 clients
  SNR   35 dB                                 : 0 clients
  SNR   40 dB                                 : 0 clients
  SNR   45 dB                                 : 0 clients
Nearby APs
  AP d0ec.3572.b9a0 slot 0                    :  -23 dBm on ( 11, 20 MHz) (181.22.0.22)
  AP 0c75.bdb3.9000 slot 0                    :  -28 dBm on ( 11, 20 MHz) (181.21.0.21)
  AP a4b2.3980.3740 slot 0                    :  -28 dBm on (  1, 20 MHz) (181.21.0.21)
  AP d0ec.3576.8320 slot 0                    :  -33 dBm on ( 11, 20 MHz) (50.1.1.122)
  AP a0f8.49dc.9780 slot 0                    :  -34 dBm on (  1, 20 MHz) (9.9.57.94)
  AP a0f8.49dc.8260 slot 0                    :  -34 dBm on (  6, 20 MHz) (9.9.57.94)
  AP d0ec.3573.7c80 slot 0                    :  -36 dBm on (  6, 20 MHz) (192.185.183.44)

  AP 00b0.e192.9d20 slot 0                    :  -36 dBm on ( 11, 20 MHz) (9.9.42.47)
  AP a4b2.397f.41c0 slot 0                    :  -36 dBm on (  1, 20 MHz) (185.10.0.10)
  AP 2c5a.0fd5.b8c0 slot 0                    :  -36 dBm on (  6, 20 MHz) (9.7.97.51)
  AP a488.7351.4740 slot 0                    :  -36 dBm on ( 11, 20 MHz) (9.7.97.51)
  AP 10b3.d5e9.c8e0 slot 0                    :  -36 dBm on (  1, 20 MHz) (50.1.1.122)
  AP 0c75.bdb3.ab00 slot 0                    :  -37 dBm on (  6, 20 MHz) (185.10.0.10)
  AP 68ca.e451.5120 slot 0                    :  -37 dBm on (  1, 20 MHz) (9.4.155.15)
  AP a0f8.49dc.97a0 slot 0                    :  -37 dBm on ( 11, 20 MHz) (9.9.57.94)
```

```
  AP 188b.4501.7940 slot 0                    :  -38 dBm on ( 11, 20 MHz) (9.9.57.94)
  AP 002c.c88a.f8e0 slot 0                    :  -38 dBm on ( 11, 20 MHz) (9.9.50.55)
  AP 7069.5a78.4960 slot 0                    :  -38 dBm on ( 11, 20 MHz) (9.7.97.51)
  AP 3c41.0ea7.0880 slot 0                    :  -39 dBm on ( 11, 20 MHz) (185.10.0.10)
  AP a0f8.49dc.93a0 slot 0                    :  -39 dBm on (  6, 20 MHz) (9.9.57.94)
  AP f4db.e685.7360 slot 0                    :  -39 dBm on (  6, 20 MHz) (50.1.1.122)
  AP 7070.8bb4.4120 slot 0                    :  -40 dBm on ( 11, 20 MHz) (9.9.57.94)
  AP 707d.b93e.39e0 slot 0                    :  -40 dBm on (  1, 20 MHz) (4.4.4.1)
  AP 706d.150c.6860 slot 0                    :  -40 dBm on ( 11, 20 MHz) (50.1.1.122)
Radar Information
Channel Assignment Information via DCA
  Current Channel Average Energy                :  -50 dBm
  Previous Channel Average Energy               :  -50 dBm
  Channel Change Count                          : 9
  Last Channel Change Time                      : 02/14/2021 20:54:57
  Recommended Best Channel                      : 1
RF Parameter Recommendations
  Power Level                                   : 8
  RTS/CTS Threshold                             : 2347
  Fragmentation Threshold                       : 2346
  Antenna Pattern                               : 0
Persistent Interference Devices
Class Type                Channel  DC (%%)  RSSI (dBm)  Last Update Time
------------------------  -------  ------   ---------   ----------------
All third party trademarks are the property of their respective owners.
```

show ap config

To display configuration settings for all access points that join the device, use the **show ap config** command.

show ap config {**general** | **slots**}

Syntax Description

ethernet	Displays ethernet related information for all Cisco APs.
general	Displays common information for all Cisco APs.
slots	Displays configuration information for all slots of all Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display global syslog server settings:

```
Device# show ap config general
Cisco AP Name   : APA023.9FAE.E190
================================================

Cisco AP Identifier                             : 40ce.24f7.50e0
Country Code                                    : US
Regulatory Domain Allowed by Country            : 802.11bg:-A   802.11a:-AB
AP Country Code                                 : US  - United States
AP Regulatory Domain
  Slot 0                                        : -B
  Slot 1                                        : -B
MAC Address                                     : a023.9fae.e190
IP Address Configuration                        : DHCP
IP Address                                      : 9.12.33.244
IP Netmask                                      : 255.255.255.0
Gateway IP Address                              : 9.12.33.1
Fallback IP Address Being Used                  :
Domain                                          :
Name Server                                     :
CAPWAP Path MTU                                 : 1485
Capwap Active Window Size                       : 1
Telnet State                                    : Disabled
SSH State                                       : Disabled
Cisco AP Location                               : default location
Site Tag Name                                   : default-site-tag
RF Tag Name                                     : default-rf-tag
Policy Tag Name                                 : default-policy-tag
AP join Profile                                 : default-ap-profile
Flex Profile                                    : default-flex-profile
Primary Cisco Controller Name                   : ewlc-doc-17.1.1
Primary Cisco Controller IP Address             : 9.12.35.10
Secondary Cisco Controller Name                 : Doc-86
Secondary Cisco Controller IP Address           : 9.12.33.10
Tertiary Cisco Controller Name                  : Cisco-docvwlc-85
```

```
Tertiary Cisco Controller IP Address            : 9.12.35.16
Administrative State                            : Enabled
Operation State                                 : Registered
NAT External IP Address                         : 9.12.33.244
AP Certificate type                             : Manufacturer Installed Certificate
AP Mode                                         : Local
AP VLAN tagging state                           : Disabled
AP VLAN tag                                     : 0
.
.
.
```

show ap config slots

To display configuration settings for all the slots, use the **show ap config slots** command.

show ap config slots

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Examples

The following example displays the configuration settings for all the slots in a Cisco wireless controller:

```
Device# show ap config slots

============================================================
Cisco AP Identifier                             : 40ce.24bf.8ca0
Cisco AP Name                                   : APA023.9FD8.EA22
AP Country Code                                 : IN
.
.
.

  Zero Wait DFS Parameters
    Zero Wait DFS Capable                       : Yes
    CAC Domain                                  :
```

show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

show ap crash-filechassis *chassis-number <1-2>***active standby**

Syntax Description

chassis	Displays the chassis details.
chassis-number	Specifies the chassis number, either 1 or 2.
active	Specifies an active instance.
standby	Specifies a standby instance.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display the crash file generated by the access point:

```
Device# show ap crash-file
```

show ap dot11

To view 802.11a or 802.11b configuration information, use the **show ap dot11** command.

show ap dot11 { **24ghz** | **5ghz** } { **channel** | **coverage** | **group** | **load-info** | **logging** | **media-stream** | **monitor** | **network** | **profile** | **summary** | **txpower** | }

Syntax Description

24ghz	Specifies the 2.4-GHz band.
5ghz	Specifies the 5-GHz band.
6ghz	Specifies the 6-GHz band.
channel	Displays the automatic channel assignment configuration and statistics.
coverage	Displays the configuration and statistics for coverage hole detection.
group	Displays 802.11a or 802.11b Cisco radio RF grouping.
load-info	Displays channel utilization and client count information for all Cisco APs.
logging	Displays 802.11a or 802.11b RF event and performance logging.
media-stream	Display 802.11a or 802.11b Media Resource Reservation Control configurations.
monitor	Displays the 802.11a or 802.11b default Cisco radio monitoring.
network	Displays the 802.11a or 802.11b network configuration.
profile	Displays the 802.11a or 802.11b lightweight access point performance profiles.
receiver	Displays the configuration and statistics of the 802.11a or 802.11b receiver.
summary	Displays the 802.11a or 802.11b Cisco lightweight access point name, channel, and transmit level summary.
txpower	Displays the 802.11a or 802.11b automatic transmit power assignment.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display the automatic channel assignment configuration and statistics:

```
Device# show ap dot11 5ghz channel
Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 12 Hours
  Anchor time (Hour of the day)             : 20
  Channel Update Contribution               : SNI.
  Channel Assignment Leader                 : web (9.9.9.2)
  Last Run                                  : 13105 seconds ago
  DCA Sensitivity Level                     : MEDIUM (15 dB)
  DCA 802.11n Channel Width                 : 40 Mhz
  Channel Energy Levels
      Minimum                               : unknown
      Average                               : unknown
      Maximum                               : unknown
  Channel Dwell Times
      Minimum                               : unknown
      Average                               : unknown
      Maximum                               : unknown
  802.11a 5 GHz Auto-RF Channel List
  Allowed Channel List                      : 36,40,44,48,52,56,60,64,149,153,1
57,161
  Unused Channel List                       : 100,104,108,112,116,132,136,140,1
65
  802.11a 4.9 GHz Auto-RF Channel List
  Allowed Channel List                      :
  Unused Channel List                       : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
15,16,17,18,19,20,21,22,23,24,25,26
  DCA Outdoor AP option                     : Disabled
```

This example shows how to display the statistics for coverage hole detection:

```
Device# show ap dot11 5ghz coverage
Coverage Hole Detection
  802.11a Coverage Hole Detection Mode          : Enabled
  802.11a Coverage Voice Packet Count           : 100 packet(s)
  802.11a Coverage Voice Packet Percentage      : 50 %
  802.11a Coverage Voice RSSI Threshold         : -80dBm
  802.11a Coverage Data Packet Count            : 50 packet(s)
  802.11a Coverage Data Packet Percentage       : 50 %
  802.11a Coverage Data RSSI Threshold          : -80dBm
  802.11a Global coverage exception level       : 25
  802.11a Global client minimum exception level   : 3 clients
```

This example shows how to display Cisco radio RF group settings:

```
Device# show ap dot11 5ghz group
Radio RF Grouping

  802.11a Group Mode                : STATIC
  802.11a Group Update Interval     : 600 seconds
  802.11a Group Leader              : web (10.10.10.1)
  802.11a Group Member              : web(10.10.10.1)
                                      nb1(172.13.21.45) (*Unreachable)
  802.11a Last Run                  : 438 seconds ago
```

```
  Mobility Agents RF membership information
  ------------------------------------------------------------
  No of 802.11a MA RF-members : 0
```

This example shows how to display 802.11a RF event and performance logging:

```
Device# show ap dot11 5ghz logging
RF Event and Performance Logging

  Channel Update Logging             : Off
  Coverage Profile Logging           : Off
  Foreign Profile Logging            : Off
  Load Profile Logging               : Off
  Noise Profile Logging              : Off
  Performance Profile Logging        : Off
  TxPower Update Logging             : Off
```

This example shows how to display the 802.11a media stream configuration:

```
Device# show ap dot11 5ghz media-stream
Multicast-direct                : Disabled
Best Effort                     : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio      : Auto
Max Allowed Streams Per Client     : Auto
Max Video Bandwidth              : 0
Max Voice Bandwidth              : 75
Max Media Bandwidth              : 85
Min PHY Rate (Kbps)              : 6000
Max Retry Percentage             : 80
```

This example shows how to display the radio monitoring for the 802.11b network:

```
Device# show ap dot11 5ghz monitor
Default 802.11a AP monitoring

  802.11a Monitor Mode                         : Enabled
  802.11a Monitor Mode for Mesh AP Backhaul    : disabled
  802.11a Monitor Channels                     : Country channels
  802.11a RRM Neighbor Discover Type           : Transparent
  802.11a AP Coverage Interval                 : 180 seconds
  802.11a AP Load Interval                     : 60 seconds
  802.11a AP Noise Interval                    : 180 seconds
  802.11a AP Signal Strength Interval          : 60 seconds
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz profile
Default 802.11a AP performance profiles
802.11a Global Interference threshold.............. 10%
802.11a Global noise threshold..................... -70 dBm
802.11a Global RF utilization threshold............ 80%
802.11a Global throughput threshold................ 1000000 bps
802.11a Global clients threshold................... 12 clients
802.11a Global coverage threshold.................. 12 dB
802.11a Global coverage exception level............ 80%
802.11a Global client minimum exception lev........ 3 clients
```

This example shows how to display the network configuration of an 802.11a profile:

```
Device# show ap dot11 5ghz network
802.11a Network : Enabled
```

```
11nSupport : Enabled
  802.11a Low Band : Enabled
  802.11a Mid Band : Enabled
  802.11a High Band : Enabled

802.11a Operational Rates
  802.11a 6M : Mandatory
  802.11a 9M : Supported
  802.11a 12M : Mandatory
  802.11a 18M : Supported
  802.11a 24M : Mandatory
  802.11a 36M : Supported
  802.11a 48M : Supported
  802.11a 54M : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported
  MCS 6 : Supported
  MCS 7 : Supported
  MCS 8 : Supported
  MCS 9 : Supported
  MCS 10 : Supported
  MCS 11 : Supported
  MCS 12 : Supported
  MCS 13 : Supported
  MCS 14 : Supported
  MCS 15 : Supported
  MCS 16 : Supported
  MCS 17 : Supported
  MCS 18 : Supported
  MCS 19 : Supported
  MCS 20 : Supported
  MCS 21 : Supported
  MCS 22 : Supported
  MCS 23 : Supported
802.11n Status:
  A-MPDU Tx:
    Priority 0 : Enabled
    Priority 1 : Disabled
    Priority 2 : Disabled
    Priority 3 : Disabled
    Priority 4 : Enabled
    Priority 5 : Enabled
    Priority 6 : Disabled
    Priority 7 : Disabled
  A-MSDU Tx:
    Priority 0 : Enabled
    Priority 1 : Enabled
    Priority 2 : Enabled
    Priority 3 : Enabled
    Priority 4 : Enabled
    Priority 5 : Enabled
    Priority 6 : Disabled
    Priority 7 : Disabled
  Guard Interval : Any
  Rifs Rx : Enabled
Beacon Interval : 100
CF Pollable mandatory : Disabled
CF Poll Request Mandatory : Disabled
CFP Period : 4
```

```
CFP Maximum Duration : 60
Default Channel : 36
Default Tx Power Level : 1
DTPC Status : Enabled
Fragmentation Threshold : 2346
Pico-Cell Status : Disabled
Pico-Cell-V2 Status : Disabled
TI Threshold : 0
Legacy Tx Beamforming setting : Disabled
Traffic Stream Metrics Status : Disabled
Expedited BW Request Status : Disabled
EDCA profile type check : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM) : Disabled
  Voice Stream-Size : 84000
  Voice Max-Streams : 2
  Voice Max RF Bandwidth : 75
  Voice Reserved Roaming Bandwidth : 6
  Voice Load-Based CAC mode : Enabled
  Voice tspec inactivity timeout : Enabled
CAC SIP-Voice configuration
  SIP based CAC : Disabled
  SIP call bandwidth : 64
  SIP call bandwith sample-size : 20
Video AC
  Video AC - Admission control (ACM) : Disabled
  Video max RF bandwidth : Infinite
  Video reserved roaming bandwidth : 0
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz receiver
Default 802.11a AP performance profiles
802.11a Global Interference threshold.............. 10%
802.11a Global noise threshold..................... -70 dBm
802.11a Global RF utilization threshold............ 80%
802.11a Global throughput threshold................ 1000000 bps
802.11a Global clients threshold................... 12 clients
802.11a Global coverage threshold.................. 12 dB
802.11a Global coverage exception level............ 80%
802.11a Global client minimum exception lev........ 3 clients
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Device# show ap dot11 5ghz service-policy
```

This example shows how to display a summary of the 802.11b access point settings:

```
Device# show ap dot11 5ghz summary
AP Name MAC Address       Admin State Operation State Channel TxPower
------- ----------------- ----------- --------------- ------- -------
CJ-1240 00:21:1b:ea:36:60 ENABLED     UP              161     1( )
CJ-1130 00:1f:ca:cf:b6:60 ENABLED     UP              56*     1(*)
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz txpower
Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
```

```
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Transmit Power Update Contribution      : SNI.
Transmit Power Assignment Leader        : web (10.10.10.1)
Last Run                                : 437 seconds ago
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz ccx global
 802.11a Client Beacon Measurements:
     disabled
```

show ap dot11

To display 802.11 band parameters, use the **show ap dot11** command.

show ap dot11 {**24ghz** | **5ghz**} {**media-stream rrc**}

Syntax Description

media-stream rrc	Displays Media Stream configurations.

Command Default

None

Command Modes

User EXEC command mode or Privileged EXEC command mode

Usage Guidelines

None.

The following is a sample output of the **show ap dot11 24ghz media-stream rrc** command.

```
Device#show ap dot11 24ghz media-stream rrc

Multicast-direct                : Disabled
Best Effort                     : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio      : Auto
Max Allowed Streams Per Client     : Auto
Max Video Bandwidth               : 0
Max Voice Bandwidth               : 75
Max Media Bandwidth               : 85
Min PHY Rate (Kbps)               : 6000
Max Retry Percentage              : 80
```

show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

show ap dot11 24ghz {**channel** | **coverage** | **group** | **logging** | **monitor** | **profile** | **summary** | **txpower**}

Syntax Description

ccx	Displays the 802.11b CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11b channel assignment.
coverage	Displays the configuration and statistics of the 802.11b coverage.
group	Displays the configuration and statistics of the 802.11b grouping.
l2roam	Displays 802.11b l2roam information.
logging	Displays the configuration and statistics of the 802.11b event logging.
monitor	Displays the configuration and statistics of the 802.11b monitoring.
profile	Displays 802.11b profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11b receiver.
summary	Displays the configuration and statistics of the 802.11b Cisco APs.
txpower	Displays the configuration and statistics of the 802.11b transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Usage Guidelines

None.

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Device#show ap dot11 24ghz coverage

Coverage Hole Detection
  802.11b Coverage Hole Detection Mode            : Enabled
  802.11b Coverage Voice Packet Count             : 100 packet(s)
  802.11b Coverage Voice Packet Percentage        : 50%
  802.11b Coverage Voice RSSI Threshold           : -80 dBm
  802.11b Coverage Data Packet Count              : 50 packet(s)
  802.11b Coverage Data Packet Percentage         : 50%
  802.11b Coverage Data RSSI Threshold            : -80 dBm
  802.11b Global coverage exception level         : 25 %
  802.11b Global client minimum exception level   : 3 clients
```

show ap dot11 24ghz SI config

To see the spectrum intelligence (SI) configuration details for the 2.4-GHz band, use the **show ap dot11 24ghz SI config** command.

show ap dot11 24ghz SI config [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the SI configuration details for the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI config chassis 1 R0
```

show ap dot11 24ghz SI device type

To see the spectrum intelligence (SI) interferers of different types for the 2.4-GHz band, use the **show ap dot11 24ghz SI device type** command.

show ap dot11 24ghz SI device type {**cont_tx** | **mw_oven** | **si_fhss**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

cont_tx	SI interferers of type Continuous transmitter for the 2.4-GHz band.
mw_oven	SI interferers of type microwave oven for the 2.4-GHz band.
si_fhss	SI interferers of type Frequency Hopping Spread Spectrum for the 2.4-GHz band.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of SI interferers of type microwave oven in the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI device type mw_oven chassis 1 R0
```

show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

show ap dot11 5ghz {**channel** | **coverage** | **group** | **logging** | **monitor** | **profile** | **summary** | **txpower**}

Syntax Description

ccx	Displays the 802.11a CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11a channel assignment.
coverage	Displays the configuration and statistics of the 802.11a coverage.
group	Displays the configuration and statistics of the 802.11a grouping.
l2roam	Displays 802.11a l2roam information.
logging	Displays the configuration and statistics of the 802.11a event logging.
monitor	Displays the configuration and statistics of the 802.11a monitoring.
profile	Displays 802.11a profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11a receiver.
summary	Displays the configuration and statistics of the 802.11a Cisco APs.
txpower	Displays the configuration and statistics of the 802.11a transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Usage Guidelines

None.

This example shows configuration and statistics of 802.11a channel assignment.

```
Device#show ap dot11 5ghz channel

Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 12 Hours
  Anchor time (Hour of the day)             : 20
  Channel Update Contribution               : SNI..
  Channel Assignment Leader                 : web (9.9.9.2)
  Last Run                                  : 16534 seconds ago
  DCA Sensitivity Level                     : MEDIUM (15 dB)
  DCA 802.11n Channel Width                 : 40 Mhz
  Channel Energy Levels
      Minimum                               : unknown
```

```
    Average                                 : unknown
    Maximum                                 : unknown
Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List                        : 36,40,44,48,52,56,60,64,149,153,1

              57,161
Unused Channel List                         : 100,104,108,112,116,132,136,140,1

              65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List                        :
Unused Channel List                         : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,

              15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option                       : Disabled
```

show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair** command.

show ap dot11 {**24ghz** | **5ghz** | **dual-band**} **cleanair** {**air-quality** | **config** | **device** | **summary**}

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
dual-band	Displays 802.11 dual-band radios.
cleanair	Displays cleanair configurations.
air-quality	Displays the Cleanair Air-Quality (AQ) data for 2.4GHz band.
device	Displays the CleanAir Interferers of device for 2.4GHz band.
config	Displays CleanAir Configuration for 2.4GHz band.
summary	Displays cleanair configurations for all 802.11a Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 36      95     70     0           40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 1       83     57     3           5
```

show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair air-quality** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair air-quality** {**summary** | **worst**}

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
summary	Displays a summary of 802.11 radio band air-quality information.
worst	Displays the worst air-quality information for 802.11 networks.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 36      95     70     0           40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
------------ ------- ------ ------ ----------- -----
CISCO_AP3500 1       83     57     3           5
```

show ap dot11 cleanair config

To display the CleanAir configuration for the 802.11 networks, use the **show ap dot11 cleanair config** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair config**

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to display the CleanAir configuration for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair config
Clean Air Solution..............................: Disabled
Air Quality Settings:
    Air Quality Reporting.......................: Disabled
    Air Quality Reporting Period (min)..........: 15
    Air Quality Alarms..........................: Enabled
    Air Quality Alarm Threshold.................: 10
Interference Device Settings:
    Interference Device Reporting...............: Enabled
        Bluetooth Link..........................: Enabled
        Microwave Oven..........................: Enabled
        802.11 FH...............................: Enabled
        Bluetooth Discovery.....................: Enabled
        TDD Transmitter.........................: Enabled
        Jammer..................................: Enabled
        Continuous Transmitter..................: Enabled
        DECT-like Phone.........................: Enabled
        Video Camera............................: Enabled
        802.15.4................................: Enabled
        WiFi Inverted...........................: Enabled
        WiFi Invalid Channel....................: Enabled
        SuperAG.................................: Enabled
        Canopy..................................: Enabled
        Microsoft Device........................: Enabled
        WiMax Mobile............................: Enabled
        WiMax Fixed.............................: Enabled
    Interference Device Types Triggering Alarms:
        Bluetooth Link..........................: Disabled
        Microwave Oven..........................: Disabled
        802.11 FH...............................: Disabled
        Bluetooth Discovery.....................: Disabled
        TDD Transmitter.........................: Disabled
        Jammer..................................: Disabled
        Continuous Transmitter..................: Disabled
        DECT-like Phone.........................: Disabled
```

```
        Video Camera.............................. : Disabled
        802.15.4.................................. : Disabled
        WiFi Inverted............................. : Enabled
        WiFi Invalid Channel...................... : Enabled
        SuperAG................................... : Disabled
        Canopy.................................... : Disabled
        Microsoft Device.......................... : Disabled
        WiMax Mobile.............................. : Disabled
        WiMax Fixed............................... : Disabled
    Interference Device Alarms.................... : Enabled
Additional Clean Air Settings:
    CleanAir Event-driven RRM State............... : Disabled
    CleanAir Driven RRM Sensitivity............... : LOW
    CleanAir Persistent Devices state............. : Disabled
```

show ap dot11 cleanair summary

To view CleanAir configurations for all 802.11a Cisco APs, use the **show ap dot11 cleanair summary** command.

show ap dot11 {**24ghz** | **5ghz**} **cleanair summary**

Syntax Description

24ghz	Specifies the 2.4-GHz band
5ghz	Specifies the 5-GHz band
cleanair summary	Summary of CleanAir configurations for all 802.11a Cisco APs

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

show ap dot11 dual-band summary

To view a brief summary of access points with dual-band radios, use the **show ap dot11 dual-band summary** command.

show ap dot11 dual-band summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Example

The following example shows how to view brief summary of tag names:

```
Device# show ap dot11 dual-band summary
```

show ap environment

To see the AP environment information of all APs, use the **show ap environment** command.

show ap environment [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP environment information:

```
Device# show ap environment
```

show ap filters active

To see the details of active AP filters, use the **show ap filters active** command.

show ap filters active [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the active AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of the active AP filters for the active instance:

```
Device# show ap filters active chassis active R0
```

show ap filters all

To see the details of all AP filters, use the **show ap filters all** command.

show ap filters all [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the details of all the AP filters for the active instance:

```
Device# show ap filters all chassis active R0
```

show ap fra

To see the flexible radio assignment (FRA) configurations in APs, use the **show ap fra** command.

show ap fra [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the FRA configurations in APs:

```
Device# show ap fra
```

show ap gps location

To see the GPS location of all APs, use the **show ap gps location** command.

show ap gps location [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the GPS location of all APs:

```
Device# show ap gps location
```

show history channel interface dot11Radio all

To check channel change or trigger reason and history, use the **show history channel interface dot11Radio all** command.

show history channel interface dot11Radio all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Examples

This example shows how to check channel change or trigger reason and history:

```
Device# show history channel interface dot11Radio all

               Timestamp Slot Client count Channel Trigger
Fri May 31 12:57:04 2019    0            0      11 RRM-DCA
Fri May 31 13:10:02 2019    0            0       1 RRM-DCA
Fri May 31 12:57:04 2019    1            0      60  Manual
Fri May 31 13:00:16 2019    1            0     149     DFS
```

show ap image details

To view the AP image details, use the **show ap image details** command.

show ap image details

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.13.1	This command was introduced.

Example

The following example shows how to view the AP image details:

```
Device# show ap image details
AP Image Details
=============================================================================================
                                          Primary image status                    Backup
image status
Ap-Name                           Kernel       RootFs       IOX           Kernel
RootFs       IOX
Veena-AP                         Good         Good         Good          Good          Good
         Good
```

show ap link-encryption

To display the link encryption status, use the **show ap link-encryption** command.

show ap link-encryption[**chassis** | {*chassis-number* | **active** | **standby**} | **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example show how to display the link-encryption status:

```
Device# show Cisco IOS XE Gibraltar 16.12.2s link-encryption
```

show ap urwb status

To view the configuration status of the URWB APs, use the **show ap urwb status**.

show ap urwb status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the configuration status of the URWB APs:

```
Device# show ap urwb status
```

show ap name ntp status

To display the Network Time Protocol (NTP) status of an AP, use the **show ap name ntp status** command.

show ap name *ap-name* **ntp status**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to view the NTP status of an AP:

```
Device# show ap name AP-G1-230 ntp status

ap-name       enabled v4/v6 IPAddress       Status     Stratum LastSync  SyncOffset
AP-G1-230     Y       v4    198.51.100.5    AuthFail   4       1000      100
```

show ap ntp status

To display the Network Time Protocol (NTP) status for all the APs, use the **show ap name ntp status** command.

show ap ntp status

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to view the NTP status for all the APs:

```
Device# show ap ntp status

ap-name       enabled    v4/v6 IPAddress       Status   Stratum LastSync SyncOffset
AP-G1-230         Y      v4    198.51.100.5    AuthFail 2       Never
AP-G1-231         Y      v4    198.51.100.10   Synced   3       1000     100
AP-G1-232         Y      v4    198.51.100.15   Synced   16      2000     50
```

show ap primary list

To see the AP primary list, use the **show ap primary list** command.

show ap primary list [**chassis** | { *chassis-number* | **active** | **standby** } | **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP primary list:

```
Device# show ap primary list
```

show ap multicast mom (multicast over multicast)

To confirm if the APs receive multicast to multicast (mom) traffic sent by the controller, using CAPWAP multicast group, use the **show ap multicast mom** command.

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Previleged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2	This command was introduced.

This example shows how to confirm if the APs receive multicast to multicast traffic sent by the controller using CAPWAP multicast group:

```
Device# show ap multicast mom

AP Name                      MOM-IP     TYPE MOM- STATUS
-------------------------------------------------------
SS-E-1                       IPv4             Up
SS-E-2                       IPv4             Up
9130E-r3-sw2-g1012           IPv4             Up
9115i-r3-sw2-te1-0-38        IPv4             Up
AP9120-r3-sw3-Gi1-0-46       IPv4             Up
ap3800i-r2-sw1-te2-0-2       IPv4             Up
```

Note With CSCwd12261, the MOM-STATUS has the value UNKNOWN for some Cisco Wave 1 (IOS-based) APs such as Cisco Aironet 1702i, 3702i, 3702e, and IW3702. This behaviour is because these APs do not send the MoM payload to the controller.

show ap name auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap name auto-rf** command.

show ap name *ap-name* **auto-rf dot11** {**24ghz** | **5ghz** | **dual-band**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
dual-band	Displays dual band.

Command Default

None

Command Modes

Privileged EXEC.

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display auto-RF information for an access point:

```
Device# show ap name AP01 auto-rf dot11 24ghz

Number of Slots                                 : 2
AP Name                                         : TSIM_AP-1
MAC Address                                     : 0000.2000.02f0
Slot ID                                         : 0
Radio Type                                      : 802.11b/g
Subband Type                                    : All

Noise Information
  Noise Profile                                 : Failed
  Channel   1                                    :   24 dBm
  Channel   2                                    :   48 dBm
  Channel   3                                    :   72 dBm
  Channel   4                                    :   96 dBm
  Channel   5                                    :  120 dBm
  Channel   6                                    : -112 dBm
  Channel   7                                    :  -88 dBm
  Channel   8                                    :  -64 dBm
  Channel   9                                    :  -40 dBm
  Channel  10                                    :  -16 dBm
  Channel  11                                    :    8 dBm

Interference Information
  Interference Profile                          : Passed
  Channel   1                                    : -128 dBm @  0% busy
  Channel   2                                    :  -71 dBm @  1% busy
  Channel   3                                    :  -72 dBm @  1% busy
  Channel   4                                    :  -73 dBm @  2% busy
  Channel   5                                    :  -74 dBm @  3% busy
  Channel   6                                    :  -75 dBm @  4% busy
  Channel   7                                    :  -76 dBm @  5% busy
```

```
  Channel   8                                      :  -77 dBm @  5% busy
  Channel   9                                      :  -78 dBm @  6% busy
  Channel  10                                      :  -79 dBm @  7% busy
  Channel  11                                      :  -80 dBm @  8% busy

Rogue Histogram (20/40_ABOVE/40_BELOW)
    Channel  36                                    : 27/ 4/ 0
    Channel  40                                    : 13/ 0/ 0
    Channel  44                                    :  5/ 0/ 0
    Channel  48                                    :  6/ 0/ 1
    Channel  52                                    :  4/ 0/ 0
    Channel  56                                    :  5/ 0/ 0
    Channel  60                                    :  1/ 3/ 0
    Channel  64                                    :  3/ 0/ 0
    Channel 100                                    :  0/ 0/ 0
    Channel 104                                    :  0/ 0/ 0
    Channel 108                                    :  0/ 1/ 0

Load Information
  Load Profile                                   : Passed
  Receive Utilization                            : 10%
  Transmit Utilization                           : 20%
  Channel Utilization                            : 50%
  Attached Clients                               : 0 clients

Coverage Information
  Coverage Profile                               : Passed
  Failed Clients                                 : 0 clients

Client Signal Strengths
  RSSI -100 dBm                                  : 0 clients
  RSSI  -92 dBm                                  : 0 clients
  RSSI  -84 dBm                                  : 0 clients
  RSSI  -76 dBm                                  : 0 clients
  RSSI  -68 dBm                                  : 0 clients
  RSSI  -60 dBm                                  : 0 clients
  RSSI  -52 dBm                                  : 0 clients

Client Signal to Noise Ratios
  SNR    0 dB                                    : 0 clients
  SNR    5 dB                                    : 0 clients
  SNR   10 dB                                    : 0 clients
  SNR   15 dB                                    : 0 clients
  SNR   20 dB                                    : 0 clients
  SNR   25 dB                                    : 0 clients
  SNR   30 dB                                    : 0 clients
  SNR   35 dB                                    : 0 clients
  SNR   40 dB                                    : 0 clients
  SNR   45 dB                                    : 0 clients

Nearby APs
  AP 0000.2000.0300 slot 0                       : -68 dBm on  11 (10.10.10.1)
  AP 0000.2000.0400 slot 0                       : -68 dBm on  11 (10.10.10.1)
  AP 0000.2000.0600 slot 0                       : -68 dBm on  11 (10.10.10.1)

Radar Information

Channel Assignment Information
  Current Channel Average Energy                 : 0 dBm
  Previous Channel Average Energy                : 0 dBm
  Channel Change Count                           : 0
  Last Channel Change Time                       : Wed Oct 17 08:13:36 2012
  Recommended Best Channel                       : 11
```

```
RF Parameter Recommendations
  Power Level                                  : 1
  RTS/CTS Threshold                            : 2347
  Fragmentation Threshold                      : 2346
  Antenna Pattern                              : 0

Persistent Interference Devices
```

show ap name ble detail

To display BLE management details, use the **show ap name ble detail** command.

show ap name *ap-name* **ble detail**

Syntax Description

ap-name	Specifies the name of the AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to display the BLE management details:

```
Device(config)# show ap name ap-name ble detail
```

show ap name cablemodem

To see cable modem information of an AP, use the **show ap name** *ap-name* **cablemodem** command.

show ap name *ap-name* **cablemodem** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see cable modem information of an AP:

```
Device# show ap name my-ap cablemodem
```

show ap name config

To display common information and Ethernet VLAN tagging information for a specific Cisco lightweight access point, use the **show ap name config** command.

show ap name *ap-name* **config** {**ethernet** | **general**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
ethernet	Displays Ethernet tagging configuration information for an access point.
general	Displays common information for an access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to display Ethernet tagging information for an access point:

```
Device# show ap name AP01 config ethernet

VLAN Tagging Information for AP01
```

This example shows how to display common information for an access point:

```
Device# show ap name AP01 config general

Cisco AP Name                                   : AP01
Cisco AP Identifier                             : 5
Country Code                                    : US  - United States
Regulatory Domain Allowed by Country            : 802.11bg:-A     802.11a:-A
AP Country Code                                 : US  - United States
AP Regulatory Domain                            : Unconfigured
Switch Port Number                              : Te1/0/1
MAC Address                                     : 0000.2000.02f0
IP Address Configuration                        : Static IP assigned
IP Address                                      : 10.10.10.12
IP Netmask                                      : 255.255.0.0
Gateway IP Address                              : 10.10.10.1
Fallback IP Address Being Used                  : 10.10.10.12
Domain                                          : Cisco
Name Server                                     : 0.0.0.0
CAPWAP Path MTU                                 : 1485
Telnet State                                    : Enabled
SSH State                                       : Disabled
Cisco AP Location                               : sanjose
Cisco AP Group Name                             : default-group
Primary Cisco Controller Name                   : CAPWAP Controller
Primary Cisco Controller IP Address             : 10.10.10.1
Secondary Cisco Controller Name                 :
Secondary Cisco Controller IP Address           : Not Configured
```

```
Tertiary Cisco Controller Name                  :
Tertiary Cisco Controller IP Address            : Not Configured
Administrative State                            : Enabled
Operation State                                 : Registered
AP Mode                                         : Local
AP Submode                                      : Not Configured
Remote AP Debug                                 : Disabled
Logging Trap Severity Level                     : informational
Software Version                                : 7.4.0.5
Boot Version                                    : 7.4.0.5
Stats Reporting Period                          : 180
LED State                                       : Enabled
PoE Pre-Standard Switch                         : Disabled
PoE Power Injector MAC Address                  : Disabled
Power Type/Mode                                 : Power Injector/Normal Mode
Number of Slots                                 : 2
AP Model                                        : 1140AG
AP Image                                        : C1140-K9W8-M
IOS Version                                     :
Reset Button                                    :
AP Serial Number                                : SIM1140K001
AP Certificate Type                             : Manufacture Installed
Management Frame Protection Validation          : Disabled
AP User Mode                                    : Customized
AP User Name                                    : cisco
AP 802.1X User Mode                             : Not Configured
AP 802.1X User Name                             : Not Configured
Cisco AP System Logging Host                    : 255.255.255.255
AP Up Time                                      : 15 days 16 hours 19 minutes 57
 seconds
AP CAPWAP Up Time                               : 4 minutes 56 seconds
Join Date and Time                              : 10/18/2012 04:48:56
Join Taken Time                                 : 15 days 16 hours 15 minutes 0
seconds
Join Priority                                   : 1
Ethernet Port Duplex                            : Auto
Ethernet Port Speed                             : Auto
AP Link Latency                                 : Disabled
Rogue Detection                                 : Disabled
AP TCP MSS Adjust                               : Disabled
AP TCP MSS Size                                 : 6146
```

show ap name config slot

To display the configuration of a Cisco AP and also display the common information for a slot, use the **show ap name config slot** command.

show ap name *Cisco-ap-name* **slot** *0-3*

Syntax Description

Cisco-ap-name	Specifies the name of the Cisco AP.
0-3	Specifies the slot ID.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

This example shows how to display common information for a slot in an access point:

```
Device# show ap name Cisco-ap-name config slot 3
```

show ap name config ethernet

To see Ethernet related configuration information of an AP, use the **show ap name** *ap-name* **config ethernet** command.

show ap name *ap-name* **config ethernet** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see Ethernet related configuration information of an AP:

```
Device# show ap name my-ap config ethernet
```

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

show ap name *ap-name* **dot11** { **24ghz** | **5ghz** } { **SI** | **airtime-fairness** | **call-control** | **cleanair** **radio-reset** | **voice** }

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4-GHz band.
5ghz	Displays the 5-GHz band.
SI	Displays the SI configurations.
airtime-fairness	Displays the stats of 24Ghz or 5Ghz airtime-fairness.
call-control	Displays the call control information.
radio-reset	Displays radio-reset.
slot	Displays slot information.
voice	Displays voice information.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

This example shows how to display the cleanair air-quality that is associated with the access point:

```
Device# show ap name test-ap dot11 24ghz cleanair air-quality chassis active r0
```

show ap name dot11 5ghz slot urwb detail

To display the URWB details of the AP on 5-GHz band, use the **show ap name** *ap-name* **dot11 5ghz slot** *slot-id* **urwb detail**

show ap name *ap-name* **dot11 5ghz slot** *slot-id* **urwb detail**

Syntax Description

ap-name	Specifies the name of the Cisco AP.
slot-id	

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to display the URWB details of the AP on 5-GHz band:

```
Device# show ap name ap-name dot11 5ghz slot 1 urwb detail
```

show ap name environment

To see the AP environment information of an AP, use the **show ap name** *ap-name* **environment** command.

show ap name *ap-name* **environment** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP environment information of an AP:

```
Device# show ap name my-ap environment
```

show ap name gps location

To see the GPS location of the AP, use the **show ap name gps location** command.

show ap name *ap-name* **gps location** [{*chassis-number* | **active** | **standby**}**R0**

Syntax Description

ap-name	Name of the Access Point
gps	See the GPS information of a Cisco AP
location	Shows the Mesh linktest data
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the active AP filters in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the GPS location of an AP:

```
Device# show ap name mesh-profile-name gps location
```

show ap name mesh backhaul

To see mesh backhaul statistics of an AP, use the **show ap name** *ap-name* **mesh backhaul** command.

show ap name *ap-name* **mesh backhaul** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh backhaul statistics of an AP:

```
Device# show ap name mymeshap mesh backhaul
```

show ap name mesh bhrate

To see mesh bachkhaul data rate for an AP, use the **show ap name** *ap-name* **mesh bhrate** command.

show ap name *ap-name* **mesh bhrate** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

ap-name	Name of the AP.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh bachkhaul data rate for an AP:

```
Device# show ap name mymeshap mesh bhrate
```

show ap name mesh linktest

To see the mesh linktest data, use the **show ap name mesh linktest data** command.

show ap name *ap-name* **mesh linktest data** *dest-mac* [**chassis** {*chassis-number* | **active** | **standby**}**R0**]

Syntax Description

ap-name	Name of the Access Point
linktest	Shows the Mesh linktest
data	Shows the Mesh linktest data
dest-mac	Enter the AP MAC address.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the mesh linktest data of an AP:

```
Device# show ap name mesh-profile-namemesh linktest data 83-88-15-0C-83-72
```

show ap name mesh path

To see information about the mesh AP's path, use the **show ap name** *ap-name* **mesh path** command.

show ap name *ap-name* **mesh path** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see information about the mesh AP's path:

```
Device# show ap name mymeshap mesh path
```

show ap name mesh stats

To see mesh statistics, use the **show ap name** *ap-name* **mesh stats** command.

show ap name *ap-name*[**packet error** | **queue** | **security**]

Syntax Description

ap-name	Name of the AP.
packet error	Mesh packet error statistics.
queue	Mesh queue statistics.
security	Mesh security statistics.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see mesh statistics:

```
Device# show ap name mymeshap mesh stats
```

show ap name urwb coord-routes

To view the URWB coordinator routes, use the **show ap name** *ap-name* **urwb coord-routes**

show ap name *ap-name* **urwb coord-routes**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB coordinator routes:

```
Device# show ap name ap-name urwb coord-routes
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
Coordinator Mode                 : Enabled
URWB Coordinator routes
Index: 0
Peer: 5.23.15X.19X
Peer: 5.23.15X.12X
Index: 1
Peer: 5.23.15X.19X
Peer: 5.23.18X.80
```

show ap name urwb fixed-links

To view the URWB fixed links, use the **show ap name** *ap-name* **urwb fixed-links**

show ap name *ap-name* **urwb fixed-links**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB fixed links:

```
Device# show ap name ap-name urwb fixed-links
Mesh ID                          : 5.23.159.192
URWB Status                      : Enabled
URWB Node Links:
Link ID(src)    Link ID(dest)    Radio Role
-------------------------------------------------------------------------------------------------------
1.23.159.192    1.23.156.128     Fixed Infrastructure
1.23.159.192    1.23.183.80      Fixed Infrastructure
URWB fixed links:
Link ID(src)    Link ID(dest)    Link type
-----------------------------------------------------------
1.23.159.192    1.23.156.128     Wired
1.23.159.192    1.23.183.80      Wired
```

show ap name urwb info

To view the URWB information of the AP, use the **show ap name** *ap-name* **urwb info**

show ap name *ap-name* **urwb info**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB information of the AP:

```
Device# show ap name ap-name urwb info
```

show ap name urwb mobility-links

To view the URWB coordinator routes, use the **show ap name** *ap-name* **urwb mobility-links**

show ap name *ap-name* **urwb mobility-links**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB mobility-links:

```
Device# show ap name ap-name urwb mobility-links
```

show ap name urwb network

To view the URWB network, use the **show ap name** *ap-name* **urwb network**

show ap name *ap-name* **urwb network**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB network:

```
Device# show ap name ap-name urwb network
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
Coordinator Mode                 : Enabled
Gateway AP MAC Address           : 2cXX.8eXX.6aXX
Gateway ID                       : 5.23.15X.19X
Number of Connected Devices      : 2
Connected Devices:
  IP                : 192.71.0.1
  VLAN ID           : 1
  IP                : 192.71.0.71
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
  IP                : 192.71.0.2XX
  VLAN ID           : 1
Number of Nodes                  : 3
Number of Coordinator routes     : 2
Number of Fixed Links            : 2
Number of Mobility Links         : 0
URWB Network Nodes summary:
Node ID         Node Name                Device Model      Role            IP Address
-------------------------------------------------------------------------------------------------
5.23.15X.12X    AP8CXX.81XX.9CXX.fx       CW9166I         Backbone        192.71.0.2XX
5.23.15X.19X    AP8CXX.81XX.9FXX          CW9166I         Coordinator     192.71.0.2XX
5.23.18XA.80     AP8CXX.81XX.B7XX          CW9166I         Backbone        192.71.0.2XX
```

show ap name urwb wireless-stats

To view the URWB wireless statistics, use the **show ap name** *ap-name* **urwb wireless-stats**

show ap name *ap-name* **urwb wireless-stats**

Syntax Description

ap-name	Specifies the name of the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the URWB wireless statistics:

```
Device# show ap name ap-name urwb wireless-stats
Mesh ID                          : 5.23.15X.19X
URWB Status                      : Enabled
URWB wireless statistics
Rx statistics
Source          Destination    Timestamp           RSSI      Received-Packets        Bytes
               BW        MCS  MCS-Index  gi
-------------------------------------------------------------------------------------------
3.23.15X.12X    3.23.15X.19X    08/11/25 22:35:46    12         12099096
2718875388           20 MHz   NO_HT 0          GI 0-8
3.23.15X.19X    3.23.15X.12X    08/11/25 22:35:45    11         12231995
2734350012           20 MHz   NO_HT 0          GI 0-8
4.23.15X.12X    4.23.18X.80     08/11/25 22:35:46    34         9667683
2184097058           20 MHz   NO_HT 0          GI 0-8
4.23.18X.80     4.23.15X.12X    08/11/25 22:35:45    32         11830571
2672218215           20 MHz   NO_HT 0          GI 0-8
Tx statistics
Source          Destination    Timestamp           Transmitted-Packets   Retries
    Bytes              BW        MCS  MCS-Index  gi
-------------------------------------------------------------------------------------------
3.23.15X.12X    3.23.15X.19X    01/01/70 05:30:00    0                     0
     0                  20 MHz   NO_HT 0      GI 0-8
3.23.15X.19X    3.23.15X.12X    01/01/70 05:30:00    0                     0
     0                  20 MHz   NO_HT 0      GI 0-8
4.23.15X.12X    4.23.18X.80     01/01/70 05:30:00    0                     0
     0                  20 MHz   NO_HT 0      GI 0-8
4.23.18X.80     4.23.15X.12X    01/01/70 05:30:00    0                     0
     0                  20 MHz   NO_HT 0      GI 0-8
```

show ap name wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point and to display WLAN statistics, use the **show ap name wlan** command.

show ap name *ap-name* **wlan** {**dot11** {**24ghz** | **5ghz**} | **statistic**}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays 802.11b network settings.
5ghz	Displays 802.11a network settings.
statistic	Displays WLAN statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to display BSSID information of an access point in an 802.11b network:

```
Device# show ap name AP01 wlan dot11 24ghz

Site Name                                       : default-group
Site Description                                :

WLAN ID  Interface  BSSID
-------------------------------------
1        default    00:00:20:00:02:00
12       default    00:00:20:00:02:0b
```

This example shows how to display WLAN statistics for an access point:

```
Device# show ap name AP01 wlan statistic

WLAN ID  : 1
WLAN Profile Name  : maria-open

   EAP Id Request Msg Timeouts           : 0
   EAP Id Request Msg Timeouts Failures  : 0
   EAP Request Msg Timeouts              : 0
   EAP Request Msg Timeouts Failures     : 0
   EAP Key Msg Timeouts                  : 0
   EAP Key Msg Timeouts Failures         : 0


WLAN ID  : 12
WLAN Profile Name  : 24
```

```
EAP Id Request Msg Timeouts           : 0
EAP Id Request Msg Timeouts Failures  : 0
EAP Request Msg Timeouts              : 0
EAP Request Msg Timeouts Failures     : 0
EAP Key Msg Timeouts                  : 0
EAP Key Msg Timeouts Failures         : 0
```

show ap name temperature

To view the temperature information of an AP, use the **show ap name temperature** command.

show ap name *ap-name* **temperature**

Syntax Description

ap-name	AP name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Examples

This example shows how to view the temperature information of an AP:

```
Device# show ap name ap-3702 temperature
```

show ap profile

To see overall status of Hyperlocation for an AP profile, use the **show ap profile** command.

show ap profile *profile-name* {**detailed** | **hyperlocation** {**ble-beacon** | **detail** | **summary**}} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

profile-name	AP profile name.
detailed	Shows the detailed parameters of the AP join profile.
hyperlocation	Shows Hyperlocation information for the AP profile.
ble-beacon	Show the list of configured BLE beacons for the AP profile.
detail	Shows detailed status of Hyperlocation for the AP profile.
summary	Shows overall status of Hyperlocation for the AP profile
chassis-number	Chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the overall status of Hyperlocation for an AP profile:

```
Device# show ap profile my-ap-profile detailed
```

show ap rf-profile summary

To display the ap RF-Profile summary, use the **show ap rf-profile summary** command.

show ap rf-profile summary

Syntax Description

summary	Show summary of RF Profiles

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

None

This example shows how to display the ap RF-Profile summary .

```
Device#show ap rf-profile summary
Number of RF Profiles : 1

RF Profile Name                  Band      Description           Applied   State
------------------------------------------------------------------------------
doctest                          2.4 GHz                         No        Down
```

show ap summary

To display the status summary of all Cisco lightweight access points attached to the device, use the **show ap summary** command.

show ap summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Use this command to display a list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the device port number.

This example shows how to display a summary of all connected access points:

```
Controller# show ap summary

Number of APs: 1

Global AP User Name: Cisco
Global AP Dot1x User Name: Not configured

AP Name                          AP Model  Ethernet MAC    Radio MAC       State
-----------------------------------------------------------------------------------
3602a                            3502I     003a.99eb.3fa8  d0c2.8267.8b00  Registered
```

show ap tag sources

To see AP tag sources with priorities, use the **show ap tag sources** command.

show ap tag sources [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the AP filters in Route-processor slot 0.
standby R0	Standby instance of the AP filters in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the AP tag sources with priorities for the active instance:

```
Device# show ap tag sources chassis active R0
```

show ap tag summary

To view brief summary of tag names, use the **show ap tag summary** command.

show ap tag summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to view brief summary of tag names:

```
Device# show ap tag summary
```

show ap timezone

To check the AP timezone information, use the **show ap timezone** command.

show ap timezone

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

The following example shows how to check the AP timezone information:

```
Device# show ap timezone

AP Name   Status     Offsets(h/m)
--------------------------------
AP1       Disabled    0:0
AP2       Enabled     1:0
```

show ap upgrade

To see AP upgrade information, use the **show ap upgrade** command.

show ap upgrade [**name** *ap-upgrade-report-name* | **summary** | **chassis** {*chassis-number* | **active** | **standby**}]

Syntax Description

name *ap-upgrade-report-name*	Enter the name of the AP upgrade report.
summary	Shows a summary of AP upgrade information.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Release 17.18.1	Support was added for **serial** and **1%** percent batch sizes.
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The example displays output from a staggered upgrade in which the batch size is set to one percent of APs per iteration.

```
Device# show ap upgrade

Status: Complete
From version: 17.19.0.9
To version: 17.19.0.9

Started at: 12/19/2025 18:01:38 IST
Configured percentage: One AP at a time
Percentage complete: 100
End time: 12/19/2025 18:01:38 IST

Client steering: Enabled
Client de-authentication: Enabled
Accounting percentage: 90%
Iteration expiry time: 9 minutes

Progress Report
---------------
Iterations
----------
```

```
Iteration              Start time                          End time                    AP
count
-------------------------------------------------------------------------------------------
0                      12/19/2025 18:01:38 IST             12/19/2025 18:01:38 IST     1

Upgraded
-------
--------
Number of APs: 3
AP Name                          Radio MAC               Iteration       Status
    Site
-------------------------------------------------------------------------------------------------------
AP00F2.8B27.BB2C                 0896.ad9b.f9e0          0               Joined
    default-site-tag
AP4C77.6D92.C654                 00be.7570.06a0          1               Joined
    default-site-tag
APA0F8.49DC.0F78                 a0f8.49dc.9780          2               Joined
    default-site-tag

Failed
------
Number of APs: 0
AP Name                          Radio MAC               Iteration
-----------------------------------------------------------------

In Progress
-----------
Number of APs: 0
AP Name                          Radio MAC
-------------------------------------------------
```



Note

- The **Configured Percentage** field is not available for the destination controller during an N+1 upgrade.
- The **Iterations** section does not appear for serial upgrades because serial upgrades do not include iterations.

show ap upgrade method

To verify the status of the configuration of the image download over HTTPS method, use the **show ap upgrade method** command.

show ap upgrade method

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.11.1	This command was introduced.

Examples

The following example shows how to verify the status of HTTPS image download configuration:

```
Device# show ap upgrade method

AP upgrade method https : Enabled
```

show arp

To view the ARP table, use the **show arp** command.

show arp

Syntax Description

arp	Shows ARP table

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

The following example shows a sample output of the command:

```
Device# show arp

Address Age (min)     Hardware Addr
   9.11.8.1         0 84:80:2D:A0:D2:E6
9.11.32.111         0 3C:77:E6:02:33:3F
```

show arp summary

To see the ARP table summary, use the **show arp summary** command.

show arp summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the ARP table summary:

```
Device# show arp summary
```

show ap upgrade site

To view the upgrade site-related infromation, use the **show ap upgrade site** command.

show ap upgrade site [**summary**]

Syntax Description

summary	(Optional) Displays a summary of access point (AP) upgrade on individual sites.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Examples

The following example shows how to view the upgrade site-related infromation:

```
Device# show ap upgrade site

Site-filtered AP upgrade report data
====================================
Source controller: Controller1
Destination controller: Controller2
Site-filters present: Yes

AP image upgrade site summary
-----------------------------
Operation: N+1 move

Site Tag                                    Status
------------------------------------------------------------
site1                                       In Progress

AP upgrade reports linked to these site-filters
-----------------------------------------------

Start time               Operation type             Report name
------------------------------------------------------------------------------
01/30/2022 10:34:36 IST  AP image upgrade/move CLI  AP_upgrade_to_Controller2_3002022103435
```

show avc client

To display information about top number of applications, use the **show avc client** command in privileged EXEC mode.

show avc client *client-mac* **top** *n* **application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

client *client-mac*	Specifies the client MAC address.
top *n* **application**	Specifies the number of top "N" applications for the given client.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show avc client** command:

```
Device# sh avc client 0040.96ae.65ec top 10 application aggregate

Cumulative Stats:

No.  AppName      Packet-Count    Byte-Count       AvgPkt-Size     usage%
---------------------------------------------------------------------------
1    skinny          7343           449860           61              94
2    unknown         99             13631            137             3
3    dhcp            18             8752             486             2
4    http            18             3264             181             1
5    tftp            9              534              59              0
6    dns             2              224              112             0

Last Interval(90 seconds) Stats:

No.  AppName     Packet-Count     Byte-Count       AvgPkt-Size      usage%
---------------------------------------------------------------------------
1    skinny          9              540              60               100
```

show avc wlan

To display information about top applications and users using the applications, use the **show avc wlan** command in privileged EXEC mode.

show avc wlan *ssid* **top** *n* **application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

wlan *ssid*	Specifies the Service Set IDentifier (SSID) for WLAN.
top *n* **application**	Specifies the number of top "N" applications.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show avc wlan** command:

```
Device# show avc wlan Lobby_WLAN top 10 application aggregate

Cumulative Stats:

No.  AppName           Packet-Count          Byte-Count          AvgPkt-Size  usage%
-------------------------------------------------------------------------------------
1    ssl               10598677              1979525706            997          42
2    vnc               5550900               3764612847            678          14
3    http              3043131               2691327197            884          10
4    unknown           1856297               1140264956            614          4
5    video-over-http   1625019               2063335150            1269         8
6    binary-over-http  1329115               1744190344            1312         6
7    webex-meeting     1146872               540713787             471          2
8    rtp               923900                635650544             688          2
9    unknown           752341                911000213             1210         3
10   youtube           631085                706636186             1119         3

Last Interval(90 seconds) Stats:

No.  AppName          Packet-Count          Byte-Count           AvgPkt-Size  usage%
-------------------------------------------------------------------------------------
1    vnc               687093                602731844             877          68
2    video-over-http   213272                279831588             1312         31
3    ssl               6515                  5029365               771          1
4    webex-meeting     3649                  1722663               472          0
5    http              2634                  1334355               506          0
6    unknown           1436                  99412                 69           0
7    google-services   722                   378121                523          0
8    linkedin          655                   393263                600          0
9    exchange          432                   167390                387          0
10   gtalk-chat        330                   17330                 52           0
```

show chassis

To see the chassis information, use the **show chassis** command.

show chassis [*1 2* | **detail** | **mode** | **neighbors** | **ha-status** {**active** | **local** | **standby**}]

Syntax Description

{*1* | *2*}	Chassis number as 1 or 2 to see the information about the relevant chassis.
detail	Shows detailed information about the chassis.
mode	Shows information about the chassis mode.
neighbors	Shows information about the chassis neighbors.
ha-status	Option to see information about the High Availability (HA) status.
active	Shows HA status on the chassis that is in active state.
local	Shows HA status on the local .
standby	Shows HA status on the chassis that is in standby state.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the HA status on the active chassis:

```
Device# show chassis ha-status active
```

show checkpoint

To display information about the Checkpoint Facility (CF) subsystem, use the **show checkpoint** command.

show checkpoint { **clients** *client-ID <0-381>* | **entities***entity-ID <1-7>* | **statisticsbuffer-usage** }

Syntax Description

clients	Displays detailed information about checkpoint clients.
entities	Displays detailed information about checkpoint entities.
statistics	Displays detailed information about checkpoint statistics.
buffer-usage	Displays the checkpoint statistics of clients using large number of buffers.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
	This command was introduced.

This example shows how to display all the CF clients.

```
   Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_MOBILITY
    Client ID                  : 24105
    Total DB inserts           : 0
    Total DB updates           : 0
    Total DB deletes           : 0
    Total DB reads             : 0
    Number of tables           : 6
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_DOT1X
    Client ID                  : 24106
    Total DB inserts           : 2
    Total DB updates           : 1312
    Total DB deletes           : 2
    Total DB reads             : 0
    Number of tables           : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_APFROGUE
    Client ID                  : 24107
    Total DB inserts           : 0
    Total DB updates           : 0
    Total DB deletes           : 0
    Total DB reads             : 0
    Number of tables           : 1
    Client residing in process  : 8135
------------------------------------------------------------------------------
Checkpoint client: WCM_CIDS
    Client ID                  : 24110
    Total DB inserts           : 0
```

```
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 0
    Client residing in process  : 8135
----------------------------------------------------------------------------
Checkpoint client: WCM_NETFLOW
    Client ID                   : 24111
    Total DB inserts            : 7
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 1
    Client residing in process  : 8135
----------------------------------------------------------------------------
Checkpoint client: WCM_MCAST
    Client ID                   : 24112
    Total DB inserts            : 0
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 1
    Client residing in process  : 8135
----------------------------------------------------------------------------
Checkpoint client: wcm_comet
    Client ID                   : 24150
    Total DB inserts            : 0
    Total DB updates            : 0
    Total DB deletes            : 0
    Total DB reads              : 0
    Number of tables            : 0
    Client residing in process  : 8135
----------------------------------------------------------------------------

All iosd checkpoint clients

----------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
----------------------------------------------------------------------------
Network RF Client           3         --       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                0
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
----------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
```

```
                            ID         ID       Mode
-------------------------------------------------------------------------------
SNMP CF Client              12         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
  Buffers Held:                                   0
  Buffers Held Peak:                              0
  Huge Buffers Requested:                         0
  Transport Frag Count:                           0
  Transport Frag Peak:                            0
  Transport Sends w/Flow Off:                     0
  Send Errs:                                      0
  Send Peer Errs:                                 0
  Rcv Xform Errs:                                 0
  Xmit Xform Errs:                                0
  Incompatible Messages:                          0
  Client Unbundles to Process Memory:             T
-------------------------------------------------------------------------------
Client Name             Client     Entity     Bundle
                            ID         ID       Mode
-------------------------------------------------------------------------------
Online Diags HA             14         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
  Buffers Held:                                   0
  Buffers Held Peak:                              0
  Huge Buffers Requested:                         0
  Transport Frag Count:                           0
  Transport Frag Peak:                            0
  Transport Sends w/Flow Off:                     0
  Send Errs:                                      0
  Send Peer Errs:                                 0
  Rcv Xform Errs:                                 0
  Xmit Xform Errs:                                0
  Incompatible Messages:                          0
  Client Unbundles to Process Memory:             T
-------------------------------------------------------------------------------
Client Name             Client     Entity     Bundle
                            ID         ID       Mode
-------------------------------------------------------------------------------
ARP                         22         --       Off

  Total API Messages Sent:                        0
  Total Transport Messages Sent:                  0
  Length of Sent Messages:                        0
  Total Blocked Messages Sent:                    0
  Length of Sent Blocked Messages:                0
  Total Non-blocked Messages Sent:                0
  Length of Sent Non-blocked Messages:            0
  Total Bytes Allocated:                          0
```

```
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
Tableid CF                 27         --       Off

  Total API Messages Sent:                     0
  Total Transport Messages Sent:               0
  Length of Sent Messages:                     0
  Total Blocked Messages Sent:                 0
  Length of Sent Blocked Messages:             0
  Total Non-blocked Messages Sent:             0
  Length of Sent Non-blocked Messages:         0
  Total Bytes Allocated:                       0
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
Event Manager              33          0       Off

  Total API Messages Sent:                     0
  Total Transport Messages Sent:               --
  Length of Sent Messages:                     0
  Total Blocked Messages Sent:                 0
  Length of Sent Blocked Messages:             0
  Total Non-blocked Messages Sent:             0
  Length of Sent Non-blocked Messages:         0
  Total Bytes Allocated:                       0
  Buffers Held:                                0
  Buffers Held Peak:                           0
  Huge Buffers Requested:                      0
  Transport Frag Count:                        0
  Transport Frag Peak:                         0
  Transport Sends w/Flow Off:                  0
  Send Errs:                                   0
  Send Peer Errs:                              0
  Rcv Xform Errs:                              0
  Xmit Xform Errs:                             0
  Incompatible Messages:                       0
  Client Unbundles to Process Memory:          T
```

```
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
LAN-Switch Port Mana       35          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
LAN-Switch PAgP/LACP       36          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
  Length of Sent Non-blocked Messages:          0
  Total Bytes Allocated:                        0
  Buffers Held:                                 0
  Buffers Held Peak:                            0
  Huge Buffers Requested:                       0
  Transport Frag Count:                         0
  Transport Frag Peak:                          0
  Transport Sends w/Flow Off:                   0
  Send Errs:                                    0
  Send Peer Errs:                               0
  Rcv Xform Errs:                               0
  Xmit Xform Errs:                              0
  Incompatible Messages:                        0
  Client Unbundles to Process Memory:           T
------------------------------------------------------------------------------
Client Name            Client     Entity     Bundle
                           ID         ID       Mode
------------------------------------------------------------------------------
LAN-Switch VLANs           39          0       Off

  Total API Messages Sent:                      0
  Total Transport Messages Sent:                --
  Length of Sent Messages:                      0
  Total Blocked Messages Sent:                  0
  Length of Sent Blocked Messages:              0
  Total Non-blocked Messages Sent:              0
```

```
  Length of Sent Non-blocked Messages:           0
  Total Bytes Allocated:                         0
  Buffers Held:                                  0
  Buffers Held Peak:                             0
  Huge Buffers Requested:                        0
  Transport Frag Count:                          0
  Transport Frag Peak:                           0
  Transport Sends w/Flow Off:                    0
  Send Errs:                                     0
  Send Peer Errs:                                0
  Rcv Xform Errs:                                0
```

This example shows how to display all the CF entities.

```
KATANA_DOC#show checkpoint entities
                        Check Point List of Entities

 CHKPT on ACTIVE server.

------------------------------------------------------------------------------
Entity ID         Entity Name
------------------------------------------------------------------------------
        0         CHKPT_DEFAULT_ENTITY

  Total API Messages Sent:             0
  Total Messages Sent:                 0
  Total Sent Message Len:              0
  Total Bytes Allocated:               0
  Total Number of Members:            10

  Member(s) of entity 0 are:
    Client ID          Client Name
-----------------------------------------
          168          DHCP Snooping
          167          IGMP Snooping
           41          Spanning-tree
           40          AUTH MGR CHKPT CLIEN
           39          LAN-Switch VLANs
           33          Event Manager
           35          LAN-Switch Port Mana
           36          LAN-Switch PAgP/LACP
          158          Inline Power Checkpoint
```

This example shows how to display the CF statistics.

```
KATANA_DOC#show checkpoint statistics
        IOSd Check Point Status
 CHKPT on ACTIVE server.

Number Of Msgs In Hold Q:              0
CHKPT MAX Message Size:                0
TP MAX Message Size:               65503
CHKPT Pending Msg Timer:             100 ms

  FLOW_ON  total:                      0
  FLOW_OFF total:                      0
  Current FLOW status is:             ON
  Total API Messages Sent:             0
  Total Messages Sent:                 0
  Total Sent Message Len:              0
  Total Bytes Allocated:               0
  Rcv  Msg Q Peak:                     0
  Hold Msg Q Peak:                     0
```

```
Buffers Held Peak:                  0
Current Buffers Held:               0
Huge Buffers Requested:             0
```

show cts environment data

To display the TrustSec environment data on the AP, use the **show cts environment data** command:

show cts environment data

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the TrustSec environment data on the AP:

```
Device# show cts environment

CTS Environment Data
====================
Current state = COMPLETE
Last status   = Successful
Local Device SGT:
SGT tag = 0-07:Unknown
Server List Info:
Installed list: CTSServerList1-0001, 1 server(s):
Server: 8.109.0.85, port 1812, A-ID 9818EE1ECA02B7BFE359C28B30EA7E2A
Status = ALIVE
auto-test = FALSE, keywrap-enable = FALSE, idle-time = 60 mins, deadtime = 20 secs
Security Group Name Table:
0-07:Unknown
2-00:TrustSec_Devices
3-00:Network_Services
4-00:Employees
5-00:Contractors
6-00:Guests
7-00:Production_Users
8-00:Developers
9-00:Auditors
10-00:Point_of_Sale_Systems
11-02:Production_Servers
12-00:Development_Servers
13-00:Test_Servers
14-00:PCI_Servers
15-00:BYOD
16-06:BGL15
17-00:BGL12
255-00:Quarantined_Systems
Environment Data Lifetime = 86400 secs
Last update time = 11:50:49 UTC Sun Jan 9 2022
Env-data expires in   0:00:28:54 (dd:hr:mm:sec)
Env-data refreshes in 0:00:28:54 (dd:hr:mm:sec)
```

```
Cache data applied = NONE
State Machine is running
```

show cts role-based sgt-map all

To display the bindings of IP address and SGT source names on the AP, use the **show cts role-based sgt-map all** command:

show cts role-based sgt-map all

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the bindings of IP address and SGT source names on the AP:

```
Device# show cts role-based stg-map all

Active IPv4-SGT Bindings Information
IP Address                                      SGT       Source
============================================================================
8.73.1.101                                       16      LOCAL
8.73.1.102                                       16      LOCAL
8.73.1.103                                       16      LOCAL
8.73.1.104                                       16      LOCAL
8.73.1.105                                       16      LOCAL
8.73.1.106                                       16      LOCAL
8.73.1.107                                       16      LOCAL
8.73.1.108                                       16      LOCAL
8.73.1.109                                       16      LOCAL
8.73.1.110                                       16      LOCAL
8.73.1.111                                       16      LOCAL
8.73.1.112                                       16      LOCAL
8.73.1.113                                       16      LOCAL
8.73.1.114                                       16      LOCAL
8.73.1.115                                       16      LOCAL
8.73.1.116                                       16      LOCAL
8.73.1.117                                       16      LOCAL
8.73.1.118                                       16      LOCAL
8.73.1.119                                       16      LOCAL
8.73.1.120                                       16      LOCAL
8.73.1.121                                       16      LOCAL
8.73.1.122                                       16      LOCAL
8.73.1.123                                       16      LOCAL
8.73.1.124                                       16      LOCAL
8.73.1.125                                       16      LOCAL
8.73.1.126                                       16      LOCAL
8.73.1.127                                       16      LOCAL
8.73.1.128                                       16      LOCAL
8.73.1.129                                       16      LOCAL
8.73.1.130                                       16      LOCAL
8.73.1.131                                       16      LOCAL
```

```
8.73.1.132                                16      LOCAL
8.73.1.133                                16      LOCAL
8.73.1.134                                16      LOCAL
8.73.1.135                                16      LOCAL
8.73.1.136                                16      LOCAL
8.73.1.137                                16      LOCAL
8.73.1.138                                16      LOCAL
8.73.1.139                                16      LOCAL
8.73.1.140                                16      LOCAL
8.73.1.141                                16      LOCAL
8.73.1.142                                16      LOCAL
FD09:8::                                  16      LOCAL
FD09:8:73:0:4051:EB27:B4A2:F6DB           16      LOCAL
FD09:8:73:0:4C3C:1D75:81E0:DB94           16      LOCAL
FD09:8:73:0:5136:9045:9D11:E191           16      LOCAL
FD09:8:73:0:6903:B84E:5BDF:9D54           16      LOCAL
FD09:8:73:0:A9F8:7825:B07:75A8            16      LOCAL
FD09:8:73:0:B505:626B:51D7:6DB6           16      LOCAL
FD09:8:73:0:D0B4:3316:7CE9:8AE8           16      LOCAL
FD09:8:73:0:ECA8:F5E:CCF5:FFD7            16      LOCAL

IP-SGT Active Bindings Summary
============================================
Total number of LOCAL    bindings = 9
Total number of active   bindings = 9
```

show cts role-based counters

To clear all role-based counters on the AP, use the **show cts role-based counters** command:

show cts role-based counters

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco Amsterdam 17.1.1	This command was introduced.

Examples

The following example shows the clear all role-based counters on the AP:

```
Device# show cts role-based counters

From  To   SW-Denied HW-Denied SW-Permitt HW-Permitt  SW-Monitor HW-Monitor
==============================================================================
*     *     0          0          0          178837189  0          0
16    0     0          0          0          39250482   0          0
16    16    0          52835      0          0          0          0
17    16    0          0          0          0          0          0
```

show flow exporter

To display flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

show flow exporter [**export-ids netflow-v9** | [**name**] *exporter-name* [**statistics** | **templates**] | **statistics** | **templates**]

Syntax Description

export-ids netflow-v9	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
name	(Optional) Specifies the name of a flow exporter.
exporter-name	(Optional) Name of a flow exporter that was previously configured.
statistics	(Optional) Displays statistics for all flow exporters or for the specified flow exporter.
templates	(Optional) Displays template information for all flow exporters or for the specified flow exporter.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter
Flow Exporter FLOW-EXPORTER-1:
  Description:              Exports to the datacenter
  Export protocol:          NetFlow Version 9
  Transport Configuration:
    Destination IP address: 192.168.0.1
    Source IP address:      192.168.0.2
    Transport Protocol:     UDP
    Destination Port:       9995
    Source Port:            55864
    DSCP:                   0x0
    TTL:                    255
    Output Features:        Used
```

This table describes the significant fields shown in the display:

Table 9: show flow exporter Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.

Field	Description
Description	The description that you configured for the exporter, or the default description User defined.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.
Output Features	Specifies whether the **output-features** command, which causes the output features to be run on Flexible NetFlow export packets, has been used or not.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter name FLOW-EXPORTER-1 statistics
Flow Exporter FLOW-EXPORTER-1:
  Packet send statistics (last cleared 2w6d ago):
    Successfully sent:         0                     (0 bytes)
```

show flow interface

To display the configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

show flow interface [*type number*]

Syntax Description

type	(Optional) The type of interface on which you want to display accounting configuration information.
number	(Optional) The number of the interface on which you want to display accounting configuration information.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Examples

The following example displays the accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Device# show flow interface gigabitethernet1/0/1

Interface Ethernet1/0
        monitor:         FLOW-MONITOR-1
        direction:       Output
        traffic(ip):     on
Device# show flow interface gigabitethernet1/0/2
Interface Ethernet0/0
        monitor:         FLOW-MONITOR-1
        direction:       Input
        traffic(ip):     sampler SAMPLER-2#
```

The table below describes the significant fields shown in the display.

Table 10: show flow interface Field Descriptions

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.
direction:	The direction of traffic that is being monitored by the flow monitor. The possible values are: • Input—Traffic is being received by the interface. • Output—Traffic is being transmitted by the interface.

Field	Description
traffic(ip)	Indicates if the flow monitor is in normal mode or sampler mode. The possible values are: • on—The flow monitor is in normal mode. • sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
monitor-name	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Displays the contents of the cache for the flow monitor.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	(Optional) Displays the flow monitor cache contents in record format.
table	(Optional) Displays the flow monitor cache contents in table format.
statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor** *monitor-name* **cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor** *monitor-name* **cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Device# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:       Used for basic traffic analysis
  Flow Record:       flow-record-1
  Flow Exporter:     flow-exporter-1
                     flow-exporter-2
  Cache:
    Type:              normal
    Status:            allocated
    Size:              4096 entries / 311316 bytes
    Inactive Timeout:  15 secs
    Active Timeout:    1800 secs
```

This table describes the significant fields shown in the display.

Table 11: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show flow record

To display the status and statistics for a flow record, use the **show flow record** command in privileged EXEC mode.

show flow record [[**name**] *record-name*]

Syntax Description

name	(Optional) Specifies the name of a flow record.
record-name	(Optional) Name of a user-defined flow record that was previously configured.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following example displays the status and statistics for FLOW-RECORD-1:

```
Device# show flow record FLOW-RECORD-1
flow record FLOW-RECORD-1:
  Description:        User defined
  No. of users:       0
  Total field space:  24 bytes
  Fields:
    match ipv6 destination address
    match transport source-port
    collect interface input
```

show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in privileged EXEC mode.

show interfaces [*interface-id* | **vlan** *vlan-id*] [**accounting** | **capabilities** [**module** *number*] | **debounce** | **description** | **etherchannel** | **flowcontrol** | **private-vlan mapping** | **pruning** | **stats** | **status** [**err-disabled**] | **trunk**]

Syntax Description

interface-id	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member , module, and port number) and port channels. The port channel range is 1 to 48.
vlan *vlan-id*	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets. **Note** The display shows only packets processed in software; hardware-switched packets do not appear.
capabilities	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module *number*	(Optional) Displays capabilities of all interfaces on the switch or specified stack member. This option is not available if you entered a specific interface ID.
description	(Optional) Displays the administrative status and description set for an interface.
etherchannel	(Optional) Displays interface EtherChannel information.
flowcontrol	(Optional) Displays interface flow control information.
private-vlan mapping	(Optional) Displays private-VLAN mapping information for the VLAN switch virtual interfaces (SVIs). This keyword is not available if the switch is running the LAN base feature set.
pruning	(Optional) Displays trunk VTP pruning information for the interface.
stats	(Optional) Displays the input and output packets by switching the path for the interface.
status	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.

err-disabled	(Optional) Displays interfaces in an error-disabled state.
trunk	(Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.

Note Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, **rate-limit**, and **shape** keywords are not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module** *number* command to display the capabilities of all interfaces on that in the stack. If there is no with that module number in the stack, there is no output.
- Use the **show interfaces** *interface-id* **capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.

This is an example of output from the **show interfaces** command for an interface on stack member 3:

```
Device#show interfaces gigabitEthernet 0
GigabitEthernet0 is up, line protocol is up
Hardware is MEWLC management port, address is 0000.5e00.0101 (bia 0000.0000.0000)
Internet address is 20.61.1.12/16
MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ARPA, loopback not set
Keepalive set (10 sec)
Unknown, Unknown, media type is unknown media type
output flow-control is unsupported, input flow-control is unsupported
ARP type: ARPA, ARP Timeout 04:00:00
Last input 03:06:36, output 00:00:07, output hang never
Last clearing of "show interface" counters never
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
0 packets input, 0 bytes, 0 no buffer
Received 0 broadcasts (0 IP multicasts)
0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 watchdog, 0 multicast, 0 pause input
0 packets output, 0 bytes, 0 underruns
```

```
0 output errors, 0 collisions, 1 interface resets
0 unknown protocol drops
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out
```

This is an example of output from the **show interfaces** *interface* **description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```
Device# show interfaces gigabitethernet1/0/2 description
Interface                      Status         Protocol Description
Gi1/0/2                        up             down     Connects to Marketing
```

This is an example of output from the **show interfaces** *interface-id* **pruning** command when pruning is enabled in the VTP domain:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port      Vlans pruned for lack of request by neighbor
Gi1/0/2   3,4

Port      Vlans traffic requested of neighbor
Gi1/0/2   1-3
```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```
Device# show interfaces vlan 1 stats
Switching path    Pkts In    Chars In    Pkts Out    Chars Out
     Processor    1165354   136205310      570800     91731594
   Route cache          0           0           0            0
         Total    1165354   136205310      570800     91731594
```

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25:

```
Device# show interfaces gigabitethernet1/0/22 status
Port       Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/22             connected   20,25     a-full      a-100      10/100BaseTX
```

In this example, port 20 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20:

```
Device# show interfaces gigabitethernet1/0/20 status
Port       Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/20             connected   20        a-full      a-100      10/100BaseTX
```

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```
Device# show interfaces status err-disabled
Port      Name       Status         Reason
Gi1/0/2              err-disabled   gbic-invalid
Gi2/0/3              err-disabled   dtp-flap
```

This is an example of output from the **show interfaces** *interface-id* **pruning** command:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port Vlans pruned for lack of request by neighbor
```

```
Device# show interfaces gigabitethernet1/0/1 trunk
Port        Mode             Encapsulation  Status        Native vlan
Gi1/0/1     on               802.1q         other         10

Port        Vlans allowed on trunk
Gi1/0/1     none

Port        Vlans allowed and active in management domain
Gi1/0/1     none

Port        Vlans in spanning tree forwarding state and not pruned
Gi1/0/1     none
```

show install package

To view the install package details, use the **show install package** command.

show install package

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to view the install package details:

```
Device#show install package
```

show install rollback

To view the package information for a rollback point, use the **show install rollback** command.

show install rollback

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to view the package information for a rollback point:

```
Device#show install rollback
```

show install summary

To view the install manager summary, use the **show install summary** command.

show install summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

This example shows how to view the install summary information:

```
Device#show install summary
```

show inventory

To display the product inventory listing of all Cisco products installed in the networking device, use the **show inventory** command.

show inventory [*entity-name* | [**fru** | **oid** | **raw**] *entity-name*]

Syntax Description

entity-name	(Optional) Name of a Cisco entity (for example, chassis, backplane, module, or slot). A quoted string may be used to display very specific UDI information; for example "sfslot 1" shows the UDI information for slot 1 of an entity named sfslot.
fru	(Optional) To display the component details of the **fru** entities within the container hierarchy in Cisco products.
oid	(Optional) To display the vendor specific hardware registration number for each part of the device.
raw	(Optional) To view the information about all Cisco products—referred to as entities—installed in the Cisco networking device, even if the entities do not have a product ID (PID) value, a unique device identifier (UDI), or other physical identification.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The **show inventory** command retrieves and displays inventory information about each Cisco product in the form of a UDI. The UDI is a combination of three separate data elements: a product identifier (PID), a version identifier (VID), and the serial number (SN).

The PID is the name by which the product can be ordered; it has been historically called the "Product Name" or "Part Number." This is the identifier that one would use to order an exact replacement part.

The VID is the version of the product. Whenever a product has been revised, the VID will be incremented. The VID is incremented according to a rigorous process derived from Telcordia GR-209-CORE, an industry guideline that governs product change notices.

The SN is the vendor-unique serialization of the product. Each manufactured product will carry a unique serial number assigned at the factory, which cannot be changed in the field. This is the means by which to identify an individual, specific instance of a product.

The UDI refers to each product as an entity. Some entities, such as a chassis, will have subentities like slots. Each entity will display on a separate line in a logically ordered presentation that is arranged hierarchically by Cisco entities.

Use the **show inventory** command without options to display a list of Cisco entities installed in the networking device that are assigned a PID.

Examples

This example shows how to display the product inventory listing of a Cisco product installed in the networking device:

```
Device# show inventory

NAME: "module R0", DESCR: "Cisco C9800-CL Route Processor"
PID: C9800-CL-K9       , VID: V00  , SN: Jxx1xxxxx1x
```

show ip

To view the IP information, use the **show ip** command.

Syntax Description

access-lists	Lists the IP access lists
interface	Displays the IP interface status and configuration
brief	Displays the brief summary of IP status and configuration
route	Displays the IP routing table
tunnel	Displays the IP tunnel information
eogre	Displays the EoGRE tunnel information
domain	Displays the EoGRE tunnel domain information
forwarding-table	Displays the EoGRE tunnel encapsulation and decapsulation information
gateway	Displays the EoGRE tunnel gateway information
fabric	Displays the IP fabric tunnel information
summary	Displays the information for all tunnels

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
8.1.111.0	This command was introduced.

The following example shows how to view information about the lists the IP access lists:

```
cisco-wave2-ap# show ip access-lists
```

show ip nbar protocol-id

To see NBAR protocol classification ID, use the **show ip nbar protocol-id** command.

show ip nbar protocol-id name

Syntax Description

protocol-id	The protocol classification ID.
name	Host server name

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 16.12.1	This command was introduced.

Examples

The following example shows how to see the NBAR protocol classification ID:

```
Device# show ip nbar protocol-id name
```

show ldap attributes

To view information about the default LDAP attribute mapping, use the **show ldap attributes** command.

show ldap attributes

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view information about the default LDAP attribute mapping:

```
Device# show ldap attributes
LDAP Attribute                    Format     AAA Attribute
==============                    ======     =============
airespaceBwDataBurstContract      Ulong      bsn-data-bandwidth-burst-contr
userPassword                      String     password
airespaceBwRealBurstContract      Ulong      bsn-realtime-bandwidth-burst-c
employeeType                      String     employee-type
airespaceServiceType              Ulong      service-type
airespaceACLName                  String     bsn-acl-name
priv-lvl                          Ulong      priv-lvl
memberOf                          String DN  supplicant-group
cn                                String     username
airespaceDSCP                     Ulong      bsn-dscp
policyTag                         String     tag-name
airespaceQOSLevel                 Ulong      bsn-qos-level
airespace8021PType                Ulong      bsn-8021p-type
airespaceBwRealAveContract        Ulong      bsn-realtime-bandwidth-average
airespaceVlanInterfaceName        String     bsn-vlan-interface-name
airespaceVapId                    Ulong      bsn-wlan-id
airespaceBwDataAveContract        Ulong      bsn-data-bandwidth-average-con
sAMAccountName                    String     sam-account-name
meetingContactInfo                String     contact-info
telephoneNumber                   String     telephone-number
Map: att_map_1
department                        String DN  element-req-qos
```

show ldap server

To view the LDAP server information, use the **show ldap server** command.

show ldap server { *server-name* | **all** }

Syntax Description

server-name	Name of the server.
all	Information of all the servers.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the LDAP server information:

```
Device# show ldap server all
```

show license air entities

To display information about active APs, new APs, and deleted APs in connection with a Cisco Catalyst Wireless Controller, enter the **show license air entities** command in privileged EXEC mode.

show license air entities { **added** | **bulk** | **deleted** | **no-change** | **summary** }

Syntax Description

`added`	Displays the list of newly reported APs. A newly added AP is one that was not listed in the last RUM report that the product instance generated.
bulk	Displays the list of all currently active APs for the product instance
deleted	Displays the list of deleted APs. A delete AP is one that was listed as active APs in the last RUM report that the product instance generated but is now disconnected.
no-change	Displays the list of APs where there has been no change in the status since the last report.
summary	Displays the RUM report generation particulars and information about active APs, new APs, and deleted APs, and indicates by when an acknowledgement (ACK) must be installed on the product instance.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to display information relating to Smart Licensing Using Policy.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Examples

For information about fields shown in the display for the **show license air entities summary** command, see Table 12: show license air entities summary Field Descriptions, on page 824 .

For sample output, see

- #unique_664 unique_664_Connect_42_section_gtj_hjm_frb
- show license air entities summary on a Cisco Catalyst 9800-L Wireless Controller, on page 825

Table 12: show license air entities summary Field Descriptions

Field	Description
Last license report time	When the last RUM report was generated, in the local time zone.

Field	Description
Upcoming license report time	When the next RUM report will be generated, in the local time zone.
No. of APs active at last report	Total number of APs listed as active APs in the last RUM report that was generated.
No. of APs newly added with last report	Number of new APs in the last RUM report that was generated. For example, if the number displayed here is 2, this means the *last but one* RUM report did not list these 2 APs, and are therefore newly added in the last RUM report that the product instance generated.
No. of APs deleted with last report	Total number of APs deleted as of the last RUM report that was generated. For example, if the number displayed here is 2, this means 2 APs were in the *last but one* RUM report, but were deleted in the *last* RUM report was generated.

show license air entities summary on a Cisco Catalyst 9800-L Wireless Controller

The following is sample output on a Cisco Catalyst 9800-L Wireless Controller. Note how the output on this device does not display the `License Ack expected within` field. Reporting requirements on all Cisco Catalyst Wireless Controllers (except Cisco Catalyst 9800-CL Wireless Controller) are as per the standard guidelines in the Smart Licensing Using Policy environment: Reporting is required if the policy (**show license status**) or system messages indicate that it is.

```
Device# show license air entities summary
Upcoming license report time.....................: 15:13:27.403 IST Tue Oct 26 2021
No. of APs active at last report.................: 1
No. of APs newly added with last report..........: 1
No. of APs deleted with last report.............: 0
```

show license all

To display all licensing information enter the **show license all** command in Privileged EXEC mode. This command displays status, authorization, UDI, and usage information, all combined.

show license all

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to display information relating to Smart Licensing Using Policy. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	The output of the command was enhanced to display the following information: • RUM report statistics, in section `Usage Report Summary`. • Smart Account and Virtual Account information, in section `Account Information`.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

This command concatenates the output of other **show license** commands, enabling you to display different kinds of licensing information together. For field descriptions, refer to the corresponding commands in the links provided below.

The `Smart Licensing Status` and `Account Information` sections of the **show license all** command corresponds with the output of the show license status, on page 846 command.

The `License Usage` section of the **show license all** command corresponds with the output of the show license usage, on page 875 command.

The `Product Information` section of the **show license all** command corresponds with the output of the show license udi, on page 874 command.

The `Agent Version` section of the **show license all** command displays the Smart Agent version and is available only in this command.

The `License Authorizations` section of the **show license all** command corresponds with the output of the show license authorization, on page 832 command.

The `Usage Report Summary` section of the **show license all** command corresponds with the output in the show license tech, on page 859 command.

Examples

For sample output, see:

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers, 17.7.1), on page 827

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers), on page 828

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers, 17.7.1)

The following is sample output of the **show license all** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1. Note the addition of the two new sections in this release: `Account Information` and `Usage Report Summary`:

```
Device# show license all

Smart Licensing Status
======================

Smart Licensing is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured
  VRF:
    Not Configured

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
```

```
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>

License Usage
=============

No licenses in use

Product Information
===================
UDI: PID:C9800-CL-K9,SN:9KGIXIDOXFE

HA UDI List:
    Active:PID:C9800-CL-K9,SN:9KGIXIDOXFE
    Standby:PID:C9800-CL-K9,SN:9UBKZU955E4

Agent Version
=============
Smart Agent for Licensing: 5.3.14_rel/47

License Authorizations
======================
Overall status:
  Active: PID:C9800-CL-K9,SN:9KGIXIDOXFE
      Status: NOT INSTALLED
  Standby: PID:C9800-CL-K9,SN:9UBKZU955E4
      Status: NOT INSTALLED

Purchased Licenses:
  No Purchase Information Available

Usage Report Summary:
=====================
Total: 0,  Purged: 0
Total Acknowledged Received: 0,  Waiting for Ack: 0
Available to Report: 0  Collecting Data: 0
```

Example: show license all (Cisco Catalyst 9800-CL Wireless Controllers)

The following is sample output of the **show license all** command on a Cisco Catalyst 9800-CL Wireless Controller. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license all

Smart Licensing Status
======================

Smart Licensing is ENABLED
License Reservation is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Transport Off

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: Nov 01 20:31:46 2020 IST
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>

License Usage
=============
```

```
air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

Product Information
===================
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN

Agent Version
=============
Smart Agent for Licensing: 5.0.6_rel/47

License Authorizations
======================
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
      Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      Last Confirmation code: ad4382fe

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
```

```
            Start Date: 2020-JUN-18 UTC
            End Date: 2020-DEC-15 UTC
            Term Count: 5
        Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
          Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
          License type: TERM
            Start Date: 2020-OCT-14 UTC
            End Date: 2021-APR-12 UTC
            Term Count: 10
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10

Purchased Licenses:
  No Purchase Information Available
```

show license authorization

To display authorization-related information for (export-controlled and enforced) licenses, enter the **show license authorization** command in privileged EXEC mode.

show license authorization

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

Only export-controlled or enforced licenses require authorization before use.

While there are no export-controlled or enforced licenses on Cisco Catalyst Wireless Controllers, you can use this command to display migrated SLR authorization codes.

Examples

See Table 13: show license authorization Field Descriptions, on page 833 for information about fields shown in the display.

See show license authorization Displaying Migrated Authorization Code, on page 835 for sample output.

Table 13: show license authorization Field Descriptions

Field		Description
Overall Status	Header for UDI information for all product instances in the set-up, the type of authorization that is installed, and configuration errors, if any. In a High Availability set-up, all UDIs in the set-up are listed.	
	Active: Status:	The active product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	Standby: Status:	The standby product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	Member: Status:	The member product instance UDI, followed by the status of the authorization code installation for this UDI. If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.
	ERROR:	Configuration errors or discrepancies in the High Availability set-up, if any.

Field		Description
Authorizations	Header for detailed license authorization information. All licenses, their enforcement types, and validity durations are displayed. Errors are displayed for each product instance if its authorization or mode does not match what is installed on the active. This section is displayed only if the product instance is using a license with an authorization code.	
	():	License name and a shortened form of the license name.
	Description	License description.
	Total available count:	Total count of licenses that are available to consume. This includes licenses of all durations (perpetual and subscription), including expired subscription licenses, for all the product instances in a High Availability setup.
	Enforcement type	Enforcement type for the license. This may be one of the following: • Enforced • Not enforced • Export-Controlled
	Term information:	

Field		Description
		Header providing license duration information. The following fields maybe included under this header: • Active: The active product instance UDI, followed by the status of the authorization code installation for this UDI. • Authorization type: Type of authorization code installed and date of installation. The type can be: SLAC, UNIVERSAL, SPECIFIED, PAK, RTU. • Start Date: Displays validity start date if the license is for a specific term or time period. • Start Date: Displays validity end date if the license is for a specific term or time period. • Term Count: License count. • Subscription ID: Displays ID if the license is for a specific term or time period. • License type: License duration. This can be: SUBSCRIPTION or PERPETUAL. • Standby: The standby product instance UDI, followed by the status of the authorization code installation for this UDI. • Member: The member product instance UDI, followed by the status of the authorization code installation for this UDI. For more information about the duration or term of a license's validity, see <link tbd>.
Purchased Licenses	Header for license purchase information.	
	Active:	The active product instance and its the UDI.
	Count:	License count.
	Description:	License description.
	License type:	License duration. This can be: SUBSCRIPTION or PERPETUAL.
	Standby:	The standby product instance UDI.
	Member:	The member product instance UDI.

show license authorization Displaying Migrated Authorization Code

The following is sample output of the **show license authorization** command on a Cisco Catalyst 9800-CL Wireless Controller. The `Last Confirmation code:` shows that SLR authorization code is available after migration. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license authorization
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
      Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      Last Confirmation code: ad4382fe

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10

Purchased Licenses:
  No Purchase Information Available
```

show license data conversion

To display license data conversion information, enter the **show license data** command in privileged EXEC mode.

show license data conversion

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

Although visible on the CLI, this command is not applicable to Cisco Catalyst Wireless Controllers.

show license eventlog

To display event logs relating to Smart Licensing Using Policy, enter the **show license eventlog** command in privileged EXEC mode.

show license eventlog [*days*]

Syntax Description

days	Enter the number of days for which you want to display event logs. The valid value range is from 0 to 2147483647.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Additional events were added with the introduction of Smart Licensing Using Policy: • Installation and removal of a policy • Request, installation and removal of an authorization code. • Installation and removal of a trust code. • Addition of authorization source information for license usage.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

show license history message

To display communication history between the product instance and CSSM or CSLU (as the case may be), enter the **show license history message** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting.

show license history message

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra** privileged EXEC commands.

show license reservation

To display license reservation information, enter the **show license reservation** command in privileged EXEC mode.

show license reservation

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

The command continues to be available on the CLI and corresponding output is displayed, but with the introduction of Smart Licensing Using Policy, the notion of reservation is not longer applicable. Use the **show license all** command in privileged EXEC mode, to display *migrated* SLR licenses instead (the SLR authorization code is migrated to Smart Licensing Using Policy).

show license rum

To display information about Resource Utilization Measurement reports (RUM report) available on the product instance, including report IDs, the current processing state of a report, error information (if any), and to save the detailed or summarized view that is displayed, enter the **show license rum** command in privileged EXEC mode.

show license rum { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*]

Syntax Description

feature { *license_name* | **all** }	Displays RUM report information based on the license name. Specify a particular license name to display all RUM reports for that license, or use the **all** keyword to display all RUM reports available on the product instance.
id { *rum_id* | **all** }	Displays RUM report information based on the RUM report ID. Specify a report ID to display information for a single report, or use the **all** keyword to display all RUM reports available on the product instance.
detail	Displays detailed RUM report information. You can use this to display detailed information by license name and detailed information by RUM report ID.
save *path*	Saves the information that is displayed. This can be the simplified or detailed version and depends on the preceeding keywords you have entered. Information about 200 RUM reports can be displayed. If there are more 200 RUM reports on the product instance, you can view information about all the RUM reports by saving it to a text (.txt) file. **Note** This option saves the information *about* RUM reports and is not for reporting purposes. It does not save the RUM report, which is an XML file containing usage information.

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Usage Guidelines

A RUM report is a license usage report, which the product instance generates, to fulfil reporting requirements as specified by the policy. An acknowledgement (ACK) is a response from CSSM and provides information about the status of a RUM report. Once the ACK for a report is available on the product instance, it indicates

that the corresponding RUM report is no longer required and can be deleted. You can use the **show license rum** command to:

- Display information about the available RUM reports on the product instance - filtered by ID or license name.
- Display a short summary of the information or display a detailed view of the information.
- Track a RUM report throughout its lifecycle (from the time it is first generated until its acknowledgement from CSSM). By displaying the current processing state and condition of a report you can ascertain if and when there is a problem in the reporting workflow.
- Save the displayed information. The CLI displays information about up to 200 reports. If there are more than 200 reports on the product instance and you want to view information about all of them, save the displayed info in a .txt file and export to the desired location to view.

To display a statistical view of RUM report information (the total number of reports on the product instance, the number of reports that have a corresponding ACK, the number of reports waiting for an ACK etc.) refer to the `Usage Report Summary:` section of the **show license all** and **show license tech** privileged EXEC commands.

The **show license tech** command also provides RUM report related information that the Cisco technical support team can use to troubleshoot, if there are problems with RUM reporting.

Examples

Table 14: show license rum (simplified view) Field Descriptions

Field Name	Description
Report Id	A numeric field that identifies a RUM report. The product instance automatically assigns an ID to every RUM report it generates. An ID may be up to 20 characters long.
State	This field displays the current processing state of a RUM report, and can be only one of the following: • OPEN: This means new measurements are been added into this report. • CLOSED: This means no new measurements can be added to this report, and the report is ready for communication to CSSM. • PENDING: This is a transitional status that you may see if you display a report while it is being transmitted. • UNACK: This means the report was transmitted and is waiting for confirmation from CSSM, that it is processed. • ACK: This means the report was processed or acknowledged by CSSM and is eligible for deletion.

Field Name	Description

Flag	Indicates the condition of the RUM report, and is displayed in the form of a character. Each character represents a specific condition, and can be only one of the following values:
	• N: Normal; This means no errors have been detected and the report is going through normal operation.
	• P: Purged; This means the report was removed due to system resource limitation, and can refer to a shortage of disk space or insufficient memory. If this flag is displayed, refer to the `State Change Reason` field in the detailed view for more information.
	• E: Error; This means an error was detected in the RUM report. If this flag is displayed, refer to the detailed view for more information. Possible workflow issues include and are not limited to the following:
	  • RUM report was dropped by CSSM. If this is the issue, the `State` field displays value `ACK`, but the `State Change Reason` does not change to `ACKED`.
	  • RUM Report data is missing. If this is the issue, the `Storage State` field displays value `MISSING` .
	  • Tracking information is missing. If this is the case the `State` field displays value `UNACK` and the `Transaction ID` field has no information.
	Note
	Occasional errors in RUM reports do not require any action from you and are not an indication of a problem. It is only if you see a large number of reports (greater than 10) with errors that you must contact the Cisco technical support team.

Feature Name	The name of the license that the RUM report applies to.

Table 15: show license rum (detailed view) Field Descriptions

Field Name	Description
Report Id	A numeric field that identifies a RUM report. The product instance automatically assigns an ID to every RUM report it generates. An ID may be up to 20 characters long.
Metric Name:	Shows the type of data that is recorded. For a RUM report, the only possible value is ENTITLEMENT, and refers to measurement of license usage.
Feature Name:	The name of the license that the RUM report applies to.
Metric Value	A unique identifier for the data that is recorded. This is the same as the “Entitlement Tag” in the output of the **show license tech** commad and it displays information about the license being tracked.

Field Name	Description
UDI	Composed of the Product ID (PID) and serial number of the product instance.
Previous Report Id:	ID of the previous RUM report that the product instance generated for a license.
Next Report Id:	The ID that the product instance will use for the next RUM report it generates for a llicense.
State:	Displays the current processing state of a RUM report. The value displayed here is always the same as the value displayed in the simplified view.
State Change Reason:	Displays the reason for a RUM report state change. Not all state changes provide a reason. • NONE: This means the RUM report is going through its normal lifecycle (for instance, from OPEN → CLOSED → ACK). This state change reason is usually accompanied by an `N` flag (meaning Normal) in the simplified view and requires no action from you. • ACKED: RUM report was processed normally by CSSM. • REMOVED: RUM report was received and requested to be removed by CSSM. • RELOAD: RUM report state was changed due to some type of device reload.
Start Time: End Time:	Timestamps for measurement start and measurement end for a RUM report. Together, the start time and end time provide the time duration that the measurements cover.
Storage State:	Displays current storage state of the RUM report and can be one of the following values: • EXIST: This means the data for the RUM report is located in storage. • DELETED: This means the data was intentionally deleted. Refer to the `Storage State Change Reason` in the output of the **show license tech** command for more information about this storage state. • PURGED: This means the data was deleted due to a system resource limitation. Refer to the `Storage State Change Reason` in the output of the **show license tech** command for more information about this storage state. • MISSING: This means data is missing from storage. If reports are identified as missing, there is no recovery process.
Transaction ID: Transaction Message:	Contains tracking information for the RUM report. This information can be either polling information or ACK import information. The Transaction Message contains the error message, if the product instance receives one when importing an ACK. The information in these fields is used by the Cisco technical support team when troubleshooting problems with RUM reports.

Example: show license rum feature: Simplified and Detailed View

The following is sample output of the **show license rum feature***license-name* and **show license rum feature***license-name***detail** commands on a Cisco Catalyst 9500 Series Switch. Similar output is displayed on all other Catalyst switches.

The output is filtered to display all RUM reports for the DNA Advantage license, followed by a detailed view of all RUM reports for the DNA Advantage license.

```
Device# show license rum feature air-dna-advantage

Smart Licensing Usage Report:

====================================

Report Id,          State,    Flag, Feature Name

1638055644          CLOSED    N     air-dna-advantage

1638055646          OPEN      N     air-dna-advantage


Device# show license rum feature air-dna-advantage detail
Smart Licensing Usage Report Detail:
====================================
Report Id: 1638055644
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 0,    Next Report Id: 1638055646
  State: CLOSED,      State Change Reason: RELOAD
  Start Time: Nov 28 12:02:09 2021 UTC,      End Time: Nov 30 22:02:13 2021 UTC
  Storage State: EXIST
  Transaction ID: 0
  Transaction Message: <none>

Report Id: 1638055646
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 1638055644,    Next Report Id: 0
  State: OPEN,      State Change Reason: None
  Start Time: Nov 30 23:12:56 2021 UTC,      End Time: Dec 01 02:12:56 2021 UTC
  Storage State: EXIST
  Transaction ID: 0
  Transaction Message: <none>
```

Saving a RUM Report View

The following example shows you how to save the information that is displayed.

By using the **feature** and **all** keywords, the output is filtered to display all RUM reports for all licenses being used on the product instance. It is then transferred it to a TFTP location, from where it can opened, to view the information.

```
Device# show license rum feature all save bootflash:all-rum-stats.txt
Device# copy tftp://10.8.0.6/bootflash:all-rum-stats.txt
```

show license status

To display information about licensing settings such as data privacy, policy, transport, usage reporting and trust codes, enter the **show license status** command in privileged EXEC mode.

show license status

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC (Device#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes `Trust code installed:`, `Policy in use`, `Policy name:` , reporting requirements as in the policy (`Attributes:`), and fields related to usage reporting. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	Command output was updated to display Smart Account and Virtual account information.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Account Information in the output

Starting with Cisco IOS XE Cupertino 17.7.1, every ACK includes the Smart Account and Virtual Account that was reported to, in CSSM. When it receives the ACK, the product instance securely stores only the latest version of this information - as determined by the timestamp in the ACK. The Smart Account and Virtual Account information that is displayed in the `Account Information` section of this command's output is therefore always as per the latest available ACK on the product instance.

If a product instance is moved from one Smart Account and Virtual Account to another, the next ACK after the move will have this updated information. The output of this command is updated once this ACK is available on the product instance.

The ACK may be received directly (where the product instance is connected to CSSM), or indirectly (where the product instance is connect to CSSM through CSLU, Cisco DNA Center, or SSM On-Prem), or by manually importing the ACK (where a product instance is in an air-gapped network).

Examples

For information about the fields shown in the display, see Table 16: show license status Field Descriptions for Smart Licensing Using Policy, on page 847 .

For sample output, see:

- show license status with Account Information (Smart Licensing Using Policy), on page 852
- show license status with Cisco Default Policy (Smart Licensing Using Policy), on page 853
- show license status with Custom Policy (Smart Licensing Using Policy), on page 854

Table 16: show license status Field Descriptions for Smart Licensing Using Policy

Field		Description
Utility	Header for utility settings that are configured on the product instance.	
	Status:	Status
	Utility report:	Last attempt:
	Customer Information:	The following fields are displayed: • Id: • Name: • Street • City: • State: • Country: • Postal Code:
Smart Licensing Using Policy:	Header for policy settings on the product instance.	
	Status:	Indicates if Smart Licensing Using Policy is enabled. Smart Licensing Using Policy is supported starting from Cisco IOS XE Amsterdam 17.3.2 and is always enabled on supported software images.

Field		Description
Data Privacy:	Header for privacy settings that are configured on the product instance.	
	Sending Hostname:	A *yes* or *no* value which shows if the hostname is sent in usage reports.
	Callhome hostname privacy:	Indicates if the Call Home feature is configured as the mode of transport for reporting. If configured, one of these values is displayed: • ENABLED • DISABLED
	Smart Licensing hostname privacy:	One of these values is displayed: • ENABLED • DISABLED
	Version privacy:	One of these values is displayed: • ENABLED • DISABLED
Transport:	Header for transport settings that are configured on the product instance.	
	Type:	Mode of transport that is in use. Additional fields are displayed for certain transport modes. For example, if transport type is set to CSLU, the CSLU address is also displayed.

Field		Description
Policy:	Header for policy information that is applicable to the product instance.	
	Policy in use:	Policy that is applied This can be one of the following: Cisco default, Product default, Permanent License Reservation, Specific License Reservation, PAK license, Installed on <date>, Controller.
	Policy name:	Name of the policy
	Reporting ACK required:	A *yes* or *no* value which specifies if the report for this product instance requires CSSM acknowledgement (ACK) or not. The default policy is always set to "yes".
	Unenforced/Non-Export Perpetual Attributes	Displays policy values for perpetual licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Unenforced/Non-Export Subscription Attributes	Displays policy values for subscription licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Enforced (Perpetual/Subscription) License Attributes	

Field		Description
		Displays policy values for enforced licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name
	Export (Perpetual/Subscription) License Attributes	Displays policy values for export-controlled licenses. • First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name. • Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name. • Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name
Miscellaneous	Header for custom ID.	
	Custom Id:	ID

Field		Description
Usage Reporting:	Header for usage reporting (RUM reports) information.	
	Last ACK received:	Date and time of last ACK received, in the local time zone.
	Next ACK deadline:	Date and time for next ACK. If the policy states that an ACK is not requires then this field displays `none`. **Note** If an ACK is required and is not received by this deadline, a syslog is displayed.
	Reporting Interval:	Reporting interval in days The value displayed here depends on what you configure in the **license smart usage interval***interval_in_days* and the policy value. For more information, see the corresponding Syntax Description: license smart (global config), on page 395.
	Next ACK push check:	Date and time when the product instance will submit the next polling request for an ACK. Date and time are in the local time zone. This applies only to product instance- initiated communication to CSSM or CSLU. If the reporting interval is zero, or if no ACK polling is pending, then this field displays `none`.
	Next report push:	Date and time when the product instance will send the next RUM report. Date and time are in the local time zone. If the reporting interval is zero, or if there are no pending RUM reports, then this field displays `none`.
	Last report push:	Date and time for when the product instance sent the last RUM report. Date and time are in the local time zone.
	Last report file write:	Date and time for when the product instance last saved an offline RUM report. Date and time are in the local time zone.
	Last report pull:	Date and time for when usage reporting information was retrieved using data models. Date and time are in the local time zone.

Field		Description
Trust Code Installed:	Header for trust code-related information. Displays date and time if trust code is installed. Date and time are in the local time zone. If a trust code is not installed, then this field displays `none`.	
	Active:	Active product instance. In a High Availability set-up, the the UDIs of all product instances in the set-up, along with corresponding trust code installation dates and times are displayed.
	Standby:	Standby product instance.
	Member:	Member product instance

show license status with Account Information (Smart Licensing Using Policy)

The following is sample output of the **show license status** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1:

```
Device# show license status
Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured
  VRF:
    Not Configured

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
```

```
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Miscellaneous:
  Custom Id: <empty>

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>
```

show license status with Cisco Default Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a default is policy applied here.

```
Device# show license status

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
```

```
    Report on change (days): 0 (CISCO default)

Miscellaneous:
  Custom Id: <empty>

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>
```

show license status with Custom Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a custom policy applied here.

```
Device# show license status
Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured

Policy:
  Policy in use: Installed On Nov 02 05:09:31 2020 IST
  Policy name: SLE Policy
  Reporting ACK required: yes (Customer Policy)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 60 (Customer Policy)
    Reporting frequency (days): 60 (Customer Policy)
    Report on change (days): 60 (Customer Policy)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 30 (Customer Policy)
    Reporting frequency (days): 30 (Customer Policy)
    Report on change (days): 30 (Customer Policy)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 90 (Customer Policy)
    Report on change (days): 90 (Customer Policy)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 90 (Customer Policy)
    Report on change (days): 90 (Customer Policy)

Miscellaneous:
  Custom Id: <empty>
```

```
Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
    INSTALLED on Nov 02 05:09:31 2020 IST
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
    INSTALLED on Nov 02 05:09:31 2020 IST
```

show license summary

To display a brief summary of license usage, which includes information about licenses being used, the count, and status, enter the **show license summary** command in privileged EXEC mode.

show license summary

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect valid license status for Smart Licensing Using Policy. Valid license statuses include: `IN USE`, `NOT IN USE`, `NOT AUTHORIZED`. Command output was also updated to remove registration and authorization information. Command output no longer displays Smart Account and Virtual account information.
Cisco IOS XE Cupertino 17.7.1	Command output was updated to display Smart Account and Virtual account information.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

The licenses on Cisco Catalyst Wireless Controllers are never `NOT AUTHORIZED`, because none of the available licenses are export-controlled or enforced (Only these licenses require authorization before use).

Account Information in the output

Starting with Cisco IOS XE Cupertino 17.7.1, every ACK includes the Smart Account and Virtual Account that was reported to, in CSSM. When it receives the ACK, the product instance securely stores only the latest version of this information - as determined by the timestamp in the ACK. The Smart Account and Virtual Account information that is displayed in the `Account Information` section of this command's output is therefore always as per the latest available ACK on the product instance.

If a product instance is moved from one Smart Account and Virtual Account to another, the next ACK after the move will have this updated information. The output of this command is updated once this ACK is available on the product instance.

The ACK may be received directly (where the product instance is connected to CSSM), or indirectly (where the product instance is connect to CSSM through CSLU, Cisco DNA Center, or SSM On-Prem), or by manually importing the ACK (where a product instance is in an air-gapped network).

Examples

See Table 17: show license summary Field Descriptions, on page 857 for information about fields shown in the display.

show license summary: IN USE (Smart Licensing Using Policy), on page 857

show license summary: NOT IN USE (Smart Licensing Using Policy), on page 857

Table 17: show license summary Field Descriptions

Field	Description
Account Information: Smart Account: Virtual Account:	The Smart Account and Virtual Account that the product instance is part of. This information is always as per the latest available ACK on the product instance. This field is displayed only if the software version on the product instance is Cisco IOS XE Cupertino 17.7.1 or a later release.
License	Name of the licenses in use
Entitlement Tag	Short name for license
Count	License count
Status	License status can be one of the following • In-Use: Valid license, and in-use. • Not In-Use • Not Authorized: Means that the license requires installation of SLAC before use.

show license summary: IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command, on a product instance where the software version is Cisco IOS XE Cupertino 17.7.1:

```
Devide# show license summary

Account Information:
  Smart Account: Eg-SA
  Virtual Account: Eg-VA

License Usage:
  License                 Entitlement Tag               Count Status
  -----------------------------------------------------------------------------
  air-network-essentials  (DNA_NWSTACK_E)                   1 IN USE
  air-dna-essentials      (AIR-DNA-E)                       1 IN USE
```

show license summary: NOT IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command, where no APs have joined the controller. Current consumption (Count) is therefore zero, and the `Status` field shows that the licenses are `NOT IN USE`:

```
Device# show license summary

Device#show license summary
License Reservation is ENABLED

License Usage:
  License                 Entitlement Tag               Count Status
  -----------------------------------------------------------------------------
  Aironet DNA Advantag... (AIR-DNA-A)                       0 NOT IN USE
  AP Perpetual Network... (DNA_NWStack)                     0 NOT IN USE
```

show license tech

To display licensing information to help the technical support team to solve a problem, enter the **show license tech** command in privileged EXEC mode. The output for this command includes outputs of several other **show license** commands and more.

show license tech { **data** { **conversion** } | **eventlog** [*days*] | **reservation** | **support** }

show license tech { **message** | **rum** { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*] | **support** }

Syntax Description

data { **conversion** }	Displays license data conversion information.
eventlog [*days*]	Displays event logs related to Smart Licensing Using Policy. For *days*, enter the number of days for which you want to display event logs. The valid value range is from 0 to 2147483647.
reservation	Displays license reservation information.
support	Displays licensing information that helps the technical support team to debug a problem.

Syntax Description

message	Displays messages concerning trust establishment, usage reporting, result polling, authorization code requests and returns, and trust synchronization. This is the same information as displayed in the output of the **show license history message** command.
rum { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } [**detail**] [**save** *path*]	Displays information about Resource Utilization Measurement reports (RUM reports) on the product instance, including report IDs, the current processing state of a report, error information (if any), and an option save the displayed RUM report information. **Note** This option saves the information *about* RUM reports and is not for reporting purposes. It does not save the RUM report, which is an XML file containing usage information.
support	Displays licensing information that helps the technical support team to debug a problem.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy.
Cisco IOS XE Cupertino 17.7.1	The **rum** keyword and additional options under this keyword were added: { **feature** { *license_name* | **all** } | **id** { *rum_id* | **all** } } The output of the **show license tech support** command was enhanced to display the following information: • RUM report information, in section `License Usage` and `Usage Report Summary`. • Smart Account and Virtual account information, in section `Account Information:`. The **data conversion**, **eventlog** and **reservation** keywords were removed from this command. They continute to be available as separate show commands, that is, **show license data**, **show license eventlog**, and **show license reservation** respectively.

Usage Guidelines

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing (whether smart licensing is enabled, all associated licensing certificates, compliance status, and so on).

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy. Note the following guidelines:

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

- Troubleshooting with a Support Representative

  When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

- RUM Report Information in the output

  - The output of the **show license tech support** command displays the following sections pertaining to RUM reports:

    Table 18: show license tech support: Field Descriptions for Header "License Usage", on page 861

```
<output truncated>
License Usage
=============
  Measurements:
    ENTITLEMENT:
      Interval: 00:15:00
      Current Value: 800
```

```
      Current Report: 1638055645       Previous: 0
 <output truncated>
```

Table 19: show license tech support: Field Descriptions for Header "Usage Report Summary", on page 862

```
<output truncated>
Usage Report Summary:
=====================
Total: 4,  Purged: 0(0)
Total Acknowledged Received: 0,  Waiting for Ack: 0(4)
Available to Report: 4  Collecting Data: 2
Maximum Display: 4  In Storage: 4,  MIA: 0(0)
Report Module Status: Ready

<output truncated>
```

- The output of the **show license tech rum** command when used with the **detail** keyword, displays the following fields pertaining to RUM reports: Table 20: show license tech rum: Field Descriptions for Header "Smart Licensing Usage Report Detail", on page 862.

  The options available under the **show license tech rum** keyword are the same as the options available with the **show license rum** privileged EXEC command. The sample output that is displayed in the *simplified view* is also the same. But if you use the **detail** keyword (for example if you enter **show license tech rum feature** *license_name* **detail**), the detailed view is displayed and this has a few *additional* fields when compared to **show license rum**.

```
<output truncated>
Smart Licensing Usage Report Detail:
====================================
Report Id: 1638055644
  Metric Name: ENTITLEMENT
  Feature Name: air-dna-advantage
  Metric Value:
regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790
  UDI: PID:C9800-CL-K9,SN:93SZ7RXN93Y
  Previous Report Id: 0,    Next Report Id: 1638055646
  Version: 2.0
  State: CLOSED,      State Change Reason: RELOAD
  Start Time: Nov 28 12:02:09 2021 UTC,      End Time: Nov 30 22:02:13 2021 UTC
  Storage State: EXIST,  Storage State Change Reason: None
  Transaction ID: 0
  Transaction Message: <none>
  Report Size: 54880(54987)
<output truncated>
```

Table 18: show license tech support: Field Descriptions for Header "License Usage"

Field Name	Description
Interval:	This is a fixed measurement duration and is always 15 minutes.
Current Value:	Information about the current license count.
Current Report:	ID of the currently OPEN report for the license.
Previous:	ID of the last OPEN report for the license. This report will have state CLOSED now.

Table 19: show license tech support: Field Descriptions for Header "Usage Report Summary"

Field Name	Description
Total:	Total number of reports that the product instance has ever generated. **Note** This total does not refer to the total number of reports *currently available* on and being tracked by the product instance. For this you must sum up the `Total Acknowledged Received:` and `Available to Report` fields.
Purged:	The number of reports deleted due to a system resource limitation. This number includes RUM reports where the product instance no longer has tracking information.
Total Acknowledged Received:	The number of RUM reports acknowledged on this product instance.
Waiting for Ack:	The number of RUM reports waiting for an ACK. This is the total number of reports in an `UNACK` state, where the product instance still has tracking information.
Available to Report:	The number of RUM reports that are available to send to CSSM. This is the total number of reports in an `OPEN` or `CLOSED` state, where the product instance still has tracking information.
Collecting Data:	Number of reports where the product instance is currently collecting measurements.
Maximum Display:	Number of reports available for display in a **show** command's output.
In Storage:	Number of reports currently stored on the disk
MIA:	The number of reports missing.

Table 20: show license tech rum: Field Descriptions for Header "Smart Licensing Usage Report Detail"

Field Name	Description
Version:	Displays the format of the report during transmission. Starting with Cisco IOS XE Cupertino 17.7.1, RUM reports are stored in a new format that reduces processing time. This field indicates if the product instance is using the old format or the new format.

Field Name	Description
Storage State:	Indicates if a given report is currently in storage. In addition to the displaying the current storage state of the RUM report, with these possible values: EXIST, DELETED, PURGED, MISSING, if a "(1)" is displayed next to the label (`Storage State (1)`), this means the RUM report is in the older (pre-17.7.1 format) and will be processed accordingly. If the RUM report is in the new format, the field is displayed as `Storage State` - without any extra information.
Storage State Change Reason:	Displays the reason for the change in the storage state change. Not all state changes provide a reason. • NONE: This means no reason was recorded for the the storage state change. • PROCESSED: This means the RUM report was deleted after CISCO has processed the data. • LIMIT_STORAGE: This means the RUM report was deleted because the product instance reached it's storage limit. • LIMIT_TIME: This means the RUM report was deleted because the report reached the persisted time limit.
Transaction ID: Transaction Message:	If the transaction ID displays a correlation ID and an error status is displayed, the product instance displays the error code field in this section. If there are no errors, no data is displayed here.
Report Size	This field displays two numbers. The first number is the size of raw report for communication, in bytes. The second number is the disk space used for saving the report, also in bytes. The second number is displayed only if report is stored in the new format.

show license tech support on Cisco Catalyst 9800-CL Wireless Controller

The following is sample output from the **show license tech support** command on a Cisco Catalyst 98000-CL Wireless Controller running software version Cisco IOS XE Cupertino 17.7.1:

```
Device# show license tech support
Smart Licensing Tech Support info

Smart Licensing Status
======================

Smart Licensing is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED
```

```
Smart Licensing Using Policy:
  Status: ENABLED

Account Information:
  Smart Account: <none>
  Virtual Account: <none>

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Address: <empty>
    Port: <empty>
    Username: <empty>
    Password: <empty>
  Server Identity Check: True
  VRF: <empty>

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting) State(1) InPolicy(0)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

License Usage
=============
Handle: 1
  License: air-network-advantage
  Entitlement Tag:
regid.2018-06.com.cisco.DNA_NWStack,1.0_e7244e71-3ad5-4608-8bf0-d12f67c80896
  Description: air-network-advantage
  Count: 0
```

```
  Version: 1.0
  Status: NOT IN USE(1)
  Status time: Oct 05 22:24:24 2021 UTC
  Request Time: None
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Measurements:
    ENTITLEMENT:
      Interval: 00:15:00
      Current Value: 0
      Current Report: 0       Previous: 0
  Soft Enforced: True

Handle: 2
  License: air-dna-advantage
  Entitlement Tag: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790

  Description: air-dna-advantage
  Count: 0
  Version: 1.0
  Status: NOT IN USE(1)
  Status time: Oct 05 22:24:24 2021 UTC
  Request Time: None
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Subscription
  Measurements:
    ENTITLEMENT:
      Interval: 00:15:00
      Current Value: 0
      Current Report: 0       Previous: 0
  Soft Enforced: True

Product Information
===================
UDI: PID:C9800-CL-K9,SN:9KGIXIDOXFE

HA UDI List:
    Active:PID:C9800-CL-K9,SN:9KGIXIDOXFE
    Standby:PID:C9800-CL-K9,SN:9UBKZU955E4

Agent Version
=============
Smart Agent for Licensing: 5.3.14_rel/47

Upcoming Scheduled Jobs
=======================
Current time: Oct 06 00:38:46 2021 UTC
Daily: Oct 06 21:24:22 2021 UTC (20 hours, 45 minutes, 36 seconds remaining)
Authorization Renewal: Expired Not Rescheduled
Init Flag Check: Expired Not Rescheduled
Reservation configuration mismatch between nodes in HA mode: Expired Not Rescheduled
Start Utility Measurements: Oct 06 00:39:25 2021 UTC (39 seconds remaining)
Send Utility RUM reports: Oct 06 22:24:54 2021 UTC (21 hours, 46 minutes, 8 seconds remaining)
Save unreported RUM Reports: Oct 06 01:24:35 2021 UTC (45 minutes, 49 seconds remaining)
Data Synchronization: Expired Not Rescheduled
External Event: Expired Not Rescheduled
Operational Model: Expired Not Rescheduled
```

```
Communication Statistics:
=========================
Communication Level Allowed: INDIRECT
Overall State: Insufficient trust for direct communication
Trust Establishment:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Trust Acknowledgement:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Usage Reporting:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Result Polling:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Request:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Confirmation:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Authorization Return:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Trust Sync:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>
Hello Message:
  Attempts: Total=0, Success=0, Fail=0  Ongoing Failure: Overall=0 Communication=0
  Last Response: <none>
    Failure Reason: <none>
  Last Success Time: <none>
  Last Failure Time: <none>

License Certificates
====================
Production Cert: False
Not registered. No certificates installed
```

```
HA Info
==========
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Message Flow Allowed: False

Reservation Info
================
License reservation: DISABLED

Overall status:
  Active: PID:C9800-CL-K9,SN:9KGIXIDOXFE
      Reservation status: NOT INSTALLED
      Request code: <none>
      Last return code: <none>
      Last Confirmation code: <none>
      Reservation authorization code: <none>
  Standby: PID:C9800-CL-K9,SN:9UBKZU955E4
      Reservation status: NOT INSTALLED
      Request code: <none>
      Last return code: <none>
      Last Confirmation code: <none>
      Reservation authorization code: <none>

Specified license reservations:

Purchased Licenses:
  No Purchase Information Available

Usage Report Summary:
=====================
Total: 0,  Purged: 0(0)
Total Acknowledged Received: 0,  Waiting for Ack: 0(0)
Available to Report: 0  Collecting Data: 0
Maximum Display: 0  In Storage: 0,  MIA: 0(0)
Report Module Status: Ready

Other Info
==========
Software ID: regid.2018-05.com.cisco.WLC_9500C,1.0_85665885-b865-4e32-8184-5510412fcb54
Agent State: authorized
TS enable: True
Transport: Smart
  Default URL: https://smartreceiver.cisco.com/licservice/license
Locale: en_US.UTF-8
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char)  : 1
sizeof(int)   : 4
sizeof(long)  : 4
sizeof(char *): 8
sizeof(time_t): 4
sizeof(size_t): 8
Endian: Big
Write Erase Occurred: False
XOS version: 0.12.0.0
Config Persist Received: False
Message Version: 1.3
```

```
connect_info.name: <empty>
connect_info.version: <empty>
connect_info.additional: <empty>
connect_info.prod: False
connect_info.capabilities: <empty>
agent.capabilities: UTILITY, DLC, AppHA, MULTITIER, EXPORT_2, OK_TRY_AGAIN
Check Point Interface: True
Config Management Interface: False
License Map Interface: True
HA Interface: True
Trusted Store Interface: True
Platform Data Interface: True
Crypto Version 2 Interface: False
SAPluginMgmtInterfaceMutex: True
SAPluginMgmtIPDomainName: True
SmartTransportVRFSupport: True
SmartAgentClientWaitForServer: 2000
SmartAgentCmReTrySend: True
SmartAgentClientIsUnified: True
SmartAgentCmClient: True
SmartAgentClientName: UnifiedClient
builtInEncryption: True
enableOnInit: True
routingReadyByEvent: True
systemInitByEvent: True
SmartTransportServerIdCheck: True
SmartTransportProxySupport: True
SmartAgentPolicyDisplayFormat: 0
SmartAgentReportOnUpgrade: False
SmartAgentIndividualRUMEncrypt: 2
SmartAgentMaxRumMemory: 2
SmartAgentConcurrentThreadMax: 10
SmartAgentPolicyControllerModel: False
SmartAgentPolicyModel: True
SmartAgentFederalLicense: True
SmartAgentMultiTenant: False
attr365DayEvalSyslog: True
checkPointWriteOnly: False
SmartAgentDelayCertValidation: False
enableByDefault: False
conversionAutomatic: True
conversionAllowed: False
storageEncryptDisable: False
storageLoadUnencryptedDisable: False
TSPluginDisable: False
bypassUDICheck: False
loggingAddTStamp: False
loggingAddTid: True
HighAvailabilityOverrideEvent: UnknownPlatformEvent
platformIndependentOverrideEvent: UnknownPlatformEvent
platformOverrideEvent: UnknownPlatformEvent
WaitForHaRole: False
standbyIsHot: True
chkPtType: 2
delayCommInit: False
roleByEvent: True
maxTraceLength: 150
traceAlwaysOn: True
debugFlags: 0
Event log max size: 5120 KB
Event log current size: 3 KB
P:C9800-CL-K9,S:9KGIXIDOXFE: No Trust Data
P:C9800-CL-K9,S:9UBKZU955E4: No Trust Data
Overall Trust: No ID
```

```
Clock sync-ed with NTP: True

Platform Provided Mapping Table
===============================
  C9800-CL-K9: Total licenses found: 5
Enforced Licenses:
  P:C9800-CL-K9,S:9KGIXIDOXFE:
    No PD enforced licenses
  P:C9800-CL-K9,S:9UBKZU955E4:
    No PD enforced licenses
```

Example (Smart Licensing Using Policy)

The following is sample output from the **show license tech support** command.

```
Device# show license tech support

Smart Licensing Tech Support info

Smart Licensing Status
======================

Smart Licensing is ENABLED
License Reservation is ENABLED

Registration:
  Status: REGISTERED - SPECIFIC LICENSE RESERVATION
  Export-Controlled Functionality: ALLOWED
  Initial Registration: SUCCEEDED on Nov 02 03:16:01 2020 IST

License Authorization:
  Status: AUTHORIZED - RESERVED on Nov 02 03:16:01 2020 IST

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Data Privacy:
  Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license

Evaluation Period:
  Evaluation Mode: Not In Use
  Evaluation Period Remaining: 89 days, 23 hours, 42 minutes, 47 seconds

License Usage
=============
Handle: 1
  License: AP Perpetual Networkstack Advantage
  Entitlement tag:
regid.2018-06.com.cisco.DNA_NWStack,1.0_e7244e71-3ad5-4608-8bf0-d12f67c80896
  Description: AP Perpetual Network Stack entitled with DNA-A
  Count: 1
  Version: 1.0
```

```
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Handle: 2
  License: Aironet DNA Advantage Term Licenses
  Entitlement tag: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790

  Description: DNA Advantage for Wireless
  Count: 1
  Version: 1.0
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Product Information
===================
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN

Agent Version
=============
Smart Agent for Licensing: 4.8.7_rel/52

Upcoming Scheduled Jobs
=======================
Current time: Nov 02 03:17:23 2020 IST
Daily: Nov 03 02:47:04 2020 IST (23 hours, 29 minutes, 41 seconds remaining)
Certificate Renewal: Not Available
Certificate Expiration Check: Not Available
Authorization Renewal: Not Available
Authorization Expiration Check: Not Available
Init Flag Check: Not Available
Evaluation Expiration Check: Not Available
Ack Expiration Check: Not Available
Evaluation Expiration Warning: Not Available
IdCert Expiration Warning: Not Available
Reservation request in progress warning: Not Available
Reservation configuration mismatch between nodes in HA mode: Nov 09 03:16:30 2020 IST (6
days, 23 hours, 59 minutes, 7 seconds remaining)
Endpoint Report Request: Not Available

License Certificates
====================
Production Cert: True
Not registered. No certificates installed

HA Info
==========
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Message Flow Allowed: False
```

```
Reservation Info
================
License reservation: ENABLED

Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
       Reservation status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
       Export-Controlled Functionality: ALLOWED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: 102fc949
       Reservation authorization code:
<specificLicenseReservationContext><flexEnabled>true</flexEnabled><isPidLevel>false</isPidLevel><udiPid>C9800-CL-K9</udiPid><udiSerialNumber>93BBAH93MGS</udiSerialNumber><entitlements><entitlement><tagId>2708-cisco_AIR-DNA-A_1.0_6b867-3b04-11-ab-5611a079</tag><count>5</count><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID></entitlement><entitlement><tagId>2708-cisco_AIR-DNA-A_1.0_6b867-3b04-11-ab-5611a079</tag><count>5</count><startDate>2020-Jun-18
 UTC</startDate><endDate>2020-Dec-15
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID></entitlement><entitlement><tagId>2806-cisco_DNA_Stack_1.0_e2457-3a54-68-bf-d2678096</tag><count>5</count><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID></entitlement><entitlement><tagId>2806-cisco_DNA_Stack_1.0_e2457-3a54-68-bf-d2678096</tag><count>5</count><startDate>2020-Jun-18
 UTC</startDate><endDate>2020-Dec-15
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID></entitlement></entitlements><authorizationCode><signature>MIQG4wYJKoZIhvcNAQcCoIQG1DCCBtACAQExDzANBglghkgBZQMEAgEFADCCAQcGCSqGSIb3DQEHAaCB+QSB9jwvZGF0YT48c2lnbmF0dXJlPjxTaWduZWRJbmZvPjxDYW5vbmljYWxpemF0aW9uTWV0aG9kPjxBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAxLzEwL3htbC1leGMtYzE0biMiLz48L0Nhbm9uaWNhbGl6YXRpb25NZXRob2Q+PFNpZ25hdHVyZU1ldGhvZCBBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAxLzA0L3htbGRzaWctbW9yZSNyc2Etc2hhMjU2Ii8+PFJlZmVyZW5jZSBVUkk9IiI+PFRyYW5zZm9ybXM+PFRyYW5zZm9ybSBBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAwLzA5L3htbGRzaWcjZW52ZWxvcGVkLXNpZ25hdHVyZSIvPjxUcmFuc2Zvcm0gQWxnb3JpdGhtIEtleT0iYWxnb3JpdGhtIiBWYWx1ZT0iaHR0cDovL3d3dy53My5vcmcvMjAwMS8xMC94bWwtZXhjLWMxNG4jIi8+PC9UcmFuc2Zvcm1zPjxEaWdlc3RNZXRob2QgQWxnb3JpdGhtIEtleT0iYWxnb3JpdGhtIiBWYWx1ZT0iaHR0cDovL3d3dy53My5vcmcvMjAwMS8wNC94bWxlbmMjc2hhMjU2Ii8+PERpZ2VzdFZhbHVlPjwvRGlnZXN0VmFsdWU+PC9SZWZlcmVuY2U+PC9TaWduZWRJbmZvPjxTaWduYXR1cmVWYWx1ZT48L1NpZ25hdHVyZVZhbHVlPjwvZGF0YT48L3NpZ25hdHVyZT4=</signature></authorizationCode></specificLicenseReservationContext>

  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
       Reservation status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
       Export-Controlled Functionality: ALLOWED
       Request code: <none>
       Last return code: <none>
       Last Confirmation code: ad4382fe
       Reservation authorization code:
<specificLicenseReservationContext><flexEnabled>true</flexEnabled><isPidLevel>false</isPidLevel><udiPid>C9800-CL-K9</udiPid><udiSerialNumber>9XECPSUU4XN</udiSerialNumber><entitlements><entitlement><tagId>2806-cisco_DNA_Stack_1.0_e2457-3a54-68-bf-d2678096</tag><count>3</count><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>AP Perpetual Networkstack
Advantage</displayName><tagDescription>AP Perpetual Network Stack entitled with
DNA</tagDescription><subscriptionID></subscriptionID></entitlement><entitlement><tagId>2708-cisco_AIR-DNA-A_1.0_6b867-3b04-11-ab-5611a079</tag><count>10</count><startDate>2020-Oct-14
 UTC</startDate><endDate>2021-Apr-12
UTC</endDate><licenseType>TERM</licenseType><displayName>Aironet DNA Advantage Term
Licenses</displayName><tagDescription>DNA Advantage for
Wireless</tagDescription><subscriptionID></subscriptionID></entitlement></entitlements><authorizationCode><signature>MIQG4wYJKoZIhvcNAQcCoIQG1DCCBtACAQExDzANBglghkgBZQMEAgEFADCCAQcGCSqGSIb3DQEHAaCB+QSB9jwvZGF0YT48c2lnbmF0dXJlPjxTaWduZWRJbmZvPjxDYW5vbmljYWxpemF0aW9uTWV0aG9kPjxBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAxLzEwL3htbC1leGMtYzE0biMiLz48L0Nhbm9uaWNhbGl6YXRpb25NZXRob2Q+PFNpZ25hdHVyZU1ldGhvZCBBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAxLzA0L3htbGRzaWctbW9yZSNyc2Etc2hhMjU2Ii8+PFJlZmVyZW5jZSBVUkk9IiI+PFRyYW5zZm9ybXM+PFRyYW5zZm9ybSBBbGdvcml0aG0gS2V5PSJhbGdvcml0aG0iIFZhbHVlPSJodHRwOi8vd3d3LnczLm9yZy8yMDAwLzA5L3htbGRzaWcjZW52ZWxvcGVkLXNpZ25hdHVyZSIvPjxUcmFuc2Zvcm0gQWxnb3JpdGhtIEtleT0iYWxnb3JpdGhtIiBWYWx1ZT0iaHR0cDovL3d3dy53My5vcmcvMjAwMS8xMC94bWwtZXhjLWMxNG4jIi8+PC9UcmFuc2Zvcm1zPjxEaWdlc3RNZXRob2QgQWxnb3JpdGhtIEtleT0iYWxnb3JpdGhtIiBWYWx1ZT0iaHR0cDovL3d3dy53My5vcmcvMjAwMS8wNC94bWxlbmMjc2hhMjU2Ii8+PERpZ2VzdFZhbHVlPjwvRGlnZXN0VmFsdWU+PC9SZWZlcmVuY2U+PC9TaWduZWRJbmZvPjxTaWduYXR1cmVWYWx1ZT48L1NpZ25hdHVyZVZhbHVlPjwvZGF0YT48L3NpZ25hdHVyZT4=</signature></authorizationCode></specificLicenseReservationContext>

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
          Subscription ID: <none>
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
          Subscription ID: <none>
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
```

```
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
          Subscription ID: <none>
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 5
          Subscription ID: <none>
        License type: TERM
          Start Date: 2020-JUN-18 UTC
          End Date: 2020-DEC-15 UTC
          Term Count: 5
          Subscription ID: <none>
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        License type: TERM
          Start Date: 2020-OCT-14 UTC
          End Date: 2021-APR-12 UTC
          Term Count: 10
          Subscription ID: <none>

Other Info
==========
Software ID: regid.2018-05.com.cisco.WLC_9500C,1.0_85665885-b865-4e32-8184-5510412fcb54
Agent State: authorized
TS enable: True
Transport: Smart
  Default URL: https://smartreceiver.cisco.com/licservice/license
Locale: en_US.UTF-8
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char)  : 1
sizeof(int)   : 4
sizeof(long)  : 4
sizeof(char *): 8
sizeof(time_t): 4
sizeof(size_t): 8
Endian: Big
Write Erase Occurred: False
XOS version: 0.12.0.0
Config Persist Received: False
Message Version: 1.3
connect_info.name: <empty>
connect_info.version: <empty>
connect_info.additional: <empty>
connect_info.prod: False
connect_info.capabilities: <empty>
agent.capabilities: UTILITY, DLC, AppHA, MULTITIER, EXPORT_2, OK_TRY_AGAIN
SmartAgentClientWaitForServer: 2000
SmartAgentCmReTrySend: True
SmartAgentClientIsUnified: True
SmartAgentCmClient: True
SmartAgentClientName: UnifiedClient
builtInEncryption: True
enableOnInit: True
routingReadyByEvent: True
```

```
systemInitByEvent: True
SmartAgentFederalLicense: True
SmartAgent_Crypto_Exit_CB: 0x55B353357A20
SmartAgent_Crypto_Start_CB: 0x55B353357A10
SmartAgentMultiTenant: False
attr365DayEvalSyslog: True
checkPointWriteOnly: False
SmartAgentDelayCertValidation: False
enableByDefault: False
conversionAutomatic: True
conversionAllowed: False
storageEncryptDisable: False
storageLoadUnencryptedDisable: False
TSPluginDisable: False
bypassUDICheck: False
loggingAddTStamp: False
loggingAddTid: True
platformOverrideEvent: UnknownPlatformEvent
WaitForHaRole: False
standbyIsHot: True
chkPtType: 2
delayCommInit: False
roleByEvent: True
maxTraceLength: 150
traceAlwaysOn: True
debugFlags: 0
Event log max size: 5120 KB
Event log current size: 21 KB

Platform Provided Mapping Table
===============================
<empty>
```

show license udi

To display Unique Device Identifier (UDI) information for a product instance, enter the **show license udi** command in privileged EXEC mode. In a High Availability set-up, the output displays UDI information for all connected product instances.

show license udi

Syntax Description

This command has no keywords or arguments

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Examples

show license udi with Standalone Product Instance, on page 874

show license udi with Active and Standby, on page 874

show license udi with Standalone Product Instance

The following is sample output from the **show license udi** command on a standalone product instance.

```
Device# show license udi

UDI: PID:C9800-L-F-K9,SN:FCW2323W016
```

show license udi with Active and Standby

The following is sample output from the **show license udi** command in a High Availability set-up where an active and a standby product instances exist. UDI information is displayed for both.

```
Device# show license udi

UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:
    Active:PID:C9800-CL-K9,SN:93BBAH93MGS
    Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN
```

show license usage

To display license usage information such as status, a count of licenses being used, and enforcement type, enter the **show license usage** command in privileged EXEC mode.

show license usage

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC

Command History

Release	Modification
This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.3.2	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes the `Status`, `Enforcement type` fields. Command output was also updated to remove reservation related information, authorization status information, and export status information.

Usage Guidelines

Smart Licensing Using Policy: If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

Smart Licensing: If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

Examples

See Table 21: show license usage Field Descriptions, on page 875 for information about fields shown in the display.

show license usage with unenforced licenses (Smart Licensing Using Policy), on page 876

show license usage with unenforced SLR licenses (Smart Licensing Using Policy), on page 877

Table 21: show license usage Field Descriptions

Field	Description
License Authorization: Status:	Displays overall authorization status.
():	Name of the license as in CSSM. If this license is one that requires an authorization code, the name of th the code.

Field	Description
Description	Description of the license as in CSSM.
Count	License count. If the license is not in-use, the count is reflected as zero.
Version	Version.
Status	License status can be one of the following • In-Use: Valid license, and in-use. • Not In-Use • Not Authorized: Implies that the license requires installation of SL
Export Status:	Indicates if this license is export-controlled or not. Accordingly, one of the is displayed: • RESTRICTED - ALLOWED • RESTRICTED - NOT ALLOWED • NOT RESTRICTED
Feature name	Name of the feature that uses this license.
Feature Description:	Description of the feature that uses this license.
Utility Subscription id:	ID Not applicable, because the corresponding confiuration option is not sup
Enforcement type	Enforcement type status for the license. This may be one of the followin • ENFORCED • NOT ENFORCED • EXPORT RESTRICTED - ALLOWED • EXPORT RESTRICTED - NOT ALLOWED

show license usage with unenforced licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Unenforced licenses are in-use here.

```
Device# show license usage

License Authorization:
  Status: Not Applicable

air-network-essentials (DNA_NWSTACK_E):
  Description: air-network-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-essentials
```

```
  Feature Description: air-network-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual

air-dna-essentials (AIR-DNA-E):
  Description: air-dna-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-essentials
  Feature Description: air-dna-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual
```

show license usage with unenforced SLR licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Migrated SLR licenses are in-use here:

```
Device# show license usage

air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20
```

show platform software sl-infra

To display troubleshooting information and for debugging, enter the **show platform software sl-infra** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting and debugging.

show platform software sl-infra { **all** | **current** | **debug** | **stored** }

Syntax Description

all	Displays current, debugging, and stored information.
current	Displays current license-related information.
debug	Enables debugging
stored	Displays information that is stored on the product instance.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

show platform software tls client summary

To view the TLS client summary details, use the **show platform software tls client summary** command.

show platform software tls client summary

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls client summary

Name     ID     Gateway   Port   Auth     Trustpoint   DPD Time Rekey Time  Retry Time
-------------------------------------------------------------------------------------
fqdn     0               8443   PSK       N/A           60       300         20
```

show platform software client detail

To display a summary of TLS client session detail, session statistics, tunnel statistics, and DNS counters, use the **show platform software client detail** command.

show platform software client detail

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software client detail

TLS Client           : Session Detail
Session Name         : fqdn
FQDN resolved IP     : 10.194.234.149
ID                   : 0
Created              : 04/20/21 00:36:42
Updated              : 04/22/21 05:56:03
State                : Up (Rekey)
Up Time              : 04/21/21 20:30:21 ( 9 hours 25 minutes 45 seconds )
Down Time            : 04/21/21 20:30:01
Rekey Time           : 04/22/21 05:55:51 ( 15 seconds )

TLS Session Statistics

Up Notifications     : 3
Down Notifications   : 2
Rekey Notifications  : 636
DP State Updates     : 0
DPD Cleanups         : 0

Packets From     Packets To  Packet Errors To     Bytes From           Bytes To
-------------------------------------------------------------------------------
  BinOS              80           0                                      0
  IOSd                0           0                    0                 0

  TLS Client          0           0                    0                 0


TLS Tunnel Statistics
Type            Tx Packets      Rx Packets
-----------------------------------------
  Total              0               80
  CSTP Ctrl       3836             3836
  CSTP Data         80                0

Type            Requests         Responses
-----------------------------------------
```

```
CSTP Cfg          639                 639
CSTP DPD         3197                3197

Invalid CSTP Rx          : 0
Injected Packet Success  : 0
Injected Packet Failed   : 0
Consumed Packets         : 0

TLS Tunnel DNS Counters
DNS Resolve Request Success Count    : 641
DNS Resolve Request Failure Count    :  0
DNS Resolve Success Count            : 639
DNS Resolve Failure Count            :  2
```

show platform software tls statistics

To view the TLS client global statistic details, use the **show platform software tls statistics** command.

show platform software tls statistics

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls statistics

TLS Client - Global Statistics
Session Statistics
Up/Down           : 5/2
Rekeys            : 636
DP Updates        :   0
DPD Cleanups      :   0

Packets From    Packets To   Packet Errors To     Bytes From   Bytes To
-------------------------------------------------------------------------
BinOS              85             0                  0             0
IOSd 0             0              0                  0             0
TLS Client  0      0                                 0             0

Tunnel Statistics
SSL Handshake Init/Done     : 641/641
TCP Connection Req/Done     : 641/641

Tunnel Packets
Rx/Tx                       : 85/0
Injected / Failed           : 0/0
Consumed                    :  0

CSTP Packets
Control Rx/Tx               : 3839 / 3839
Data Rx/Tx                  : 0 / 85
Config Req/Resp             : 641 / 641
DPD Req/Resp                : 3198 / 3198
Invalid Rx                  : 0

FQDN Counters
Req/Resp/Success            : 0/0/0

NAT Counters
Transalte In/Out            : 0/0
Ignore    In/Out            : 0/0
Failed                      : 0
Invalid                     : 0
```

```
No Entry                    : 0
Unsupported                 : 0

Internal Counters
Type           Allocated            Freed
-------------------------------------------------
EV              1299                 1295
Tunnel           5                    4
Conn            643                  642
Sess             3                    2

Config Message Related Counters
Type               Success              Failed
-------------------------------------------------
Create                3                    0
Delete                2                    0
```

show platform software tls session summary

To view the tls client session summary, use the **show platform software tls session summary** command.

show platform software tls session summary

Syntax Description

This command has no keywords or arguments.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls session summary

TLS Client - Session Summary
Name     ID      Created            State    Since               Elapsed
-------------------------------------------------------------------------------------------
fqdn     0      04/20/21 00:36:42    Up     04/21/21 20:30:21   9 hours 26 minutes 44 seconds
```

show logging profile wireless end timestamp

To specify log filtering end location timestamp for filtering, use the **show logging profile wireless end timestamp** command.

show logging profile wireless end timestamp *time-stamp*

Syntax Description

time-stamp	Time to end the filtering. For example, 2017/02/10 14:41:50.849.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable internal keyword using the **show logging profile wireless internal** command to get the trace output.

Example

The following example shows how to specify log filtering end location timestamp for filtering:

```
Device# show logging profile wireless end timestamp 2017/02/10 14:41:50.849
```

show logging profile wireless filter

To specify filter for logs, use the **show logging profile wireless filter** command.

show logging profile wireless filter {**ipv4** | **mac** | **string** | **uuid**}

Syntax Description

ipv4	Selects logs with specific IP address app context.
mac	Selects logs with specific MAC app context.
string	Selects logs with specific string app context.
uuid	Selects logs with specific Universally Unique Identifier (UUID) app context.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify filter for logs:

```
Device# show logging profile wireless filter ipv4 10.10.11.1
```

show logging profile wireless fru

To specify field-replaceable unit (FRU) specific commands, use the **show logging profile wireless fru** command.

show logging profile wireless fru {0 {reverse | to-file}| chassis} {**0** {**reverse** | **to-file**} | **chassis**}

Syntax Description

0	SPA-Inter-Processor slot 0.
reverse	Shows logs in reverse chronological order.
to-file	Decodes files stored in disk and write output to file.
chassis	Chassis name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify FRU specific commands:

```
Device# show logging profile wireless fru 0
```

show logging profile wireless internal

To select all the logs, use the **show logging profile wireless internal** command.

show logging profile wireless internal

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to display all the logs:

```
Device# show logging profile wireless internal
```

show logging profile wireless level

To select logs above a specific level, use the **show logging profile wireless level** command.

show logging profile wireless level { **debug** | **emergency** | **error** | **info** | **noise** | **notice** | **verbose** | **warning** }

Syntax Description

debug	Selects debug messages.
emergency	Selects emergency possible messags.
error	Selects error messages.
info	Selects informational messages.
noise	Selects maximum possible messages.
notice	Selects notice messages.
verbose	Selects verbose debug messages.
warning	Selects warning messages.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to select logs above a specific level:

```
Device# show logging profile wireless level info
```

show logging profile wireless module

To select logs for specific modules, use the **show logging profile wireless module** command.

show logging profile wireless module *module-name*

Syntax Description

module-name	A comma or space separated list of module names. For example, dbal, tdllib or "dbal tdllib".

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to select logs for specific modules:

```
Device# show logging profile wireless module dbal
```

show logging profile wireless reverse

To view logs in reverse chronological order, use the **show logging profile wireless reverse** command.

show logging profile wireless reverse

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to view logs in reverse chronological order:

```
Device# show logging profile wireless reverse
```

show logging profile wireless start

To specify log filtering start location, use the **show logging profile wireless start** command.

show logging profile wireless start {**marker** *marker* | **timestamp** *time-stamp*}

Syntax Description

marker	The marker to start filtering from. It must match with previously set marker.
timestamp	The timestamp for filtering. for example, "2017/02/10 14:41:50.849".

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify log filtering start location:

```
Device# show logging profile wireless start timestamp 2017/02/10 14:41:50.849
```

show logging profile wireless switch

To specify the switch to look for logs, use the **show logging profile wireless switch** command.

show logging profile wireless switch {*switch-num* | **active** | **standby**}

Syntax Description

active	Selects the active instance.
standby	Selects the standby instance.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to specify the number to look for logs:

```
Device# show logging profile wireless switch active
```

show logging profile wireless to-file

To decode files stored in disk and write the output to a file, use the **show logging profile wireless to-file** command.

show logging profile wireless to-file *output-file-name*

Syntax Description

output-file-name	Output file name. File with this name will be created in the flash memory.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

Example

The following example shows how to decode files stored in disk and write the output to a file:

```
Device# show logging profile wireless to-file testfile
```

show mdns-sd cache

To view mDNS cache details, use the **show mdns-sd cache** command.

show mdns-sd cache { **ap-mac** *mac-address (H.H.H)* | **client-mac** *client-mac-address (H.H.H)* | **detail** | **glan-id** *<1 - 5>* | **location-group** *<0 - 4096>* | **mdns-ap** *mdns-ap mac address (H.H.H)* | **rlan-id** *<1 - 128>* | **statistics** | **type** { **A-AAAA** | **PTR** | **SRV** | **TXT** } | **udn** { *<1 - 4294967295>* | **shared** } | **wired** | **wlan-id** *<0 - 4096>* }

Syntax Description

ap-mac *mac-address (H.H.H)*	Specifies the AP Ethernet MAC address.
client-mac *client-mac-address (H.H.H)*	Specifies the client MAC address.
detail	Specifes the cache in detail.
location-group *<0 - 4096>*	Specifies the location group. The value range is from 0 to 4096.
mdns-ap *mdns-ap mac address (H.H.H)*	Specifies the cache learnt from a specific mDNS AP.
rlan-id *<1 - 128>*	Specifies the remote LAN ID. The value range is from 1 - 128.
statistics	Specifies the mDNS cache statistics.
type	Specifies the mDNS record type. The record types are, A-AAAA, PTR, SRV, and TXT.
udn *<1 - 4294967295>*	Specifies the UDN ID. The value range is from 1 to 4294967295.
shared	Specifies the UDN shared services.
wired	Specifies the mDNS services from wired clients.
wlan-id *<0 - 4096>*	Specifies the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the mDNS cache details:

```
Device# show mdns-sd cache
```

show mdns-sd cache detail

To view the multicast DNS (mDNS) cache details, use the **show mdns-sd cache detail** command.

show mdns-sd cache detail

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache detail** command:

```
Device# show mdns-sd cache detail

Name: _printer._tcp.local
  Type: PTR
  TTL: 4500
  VLAN: 21
  Client MAC: ace2.d3bc.047e
  Remaining-Time: 4383
  mDNS Service Policy: default-mdns-service-policy
  Rdata: HP OfficeJet Pro 8720 [BC047E] (2)._printer._tcp.local
```

show mdns-sd cache upn shared

To view the multicast DNS (mDNS) cache user personal network shared services details, use the **show mdns-sd cache upn shared** command.

show mdns-sd cache upn shared

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache upn shared** command that displays the mDNS cache UPN shared services details:

```
Device# show mdns-sd cache upn shared

------------------------------------------------------------- PTR Records
------------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
------------------------------------------------------------------------------------------------------------------------
9.1.1.7.5.D.E.F.F.F.6.C.7.E.2.1.0.0.0.0.0.0.0  4500     WLAN      2     10e7.c6d5.7119
HP10E7C6D57119-2860.local
_services._dns-sd._udp.local                   4500     WLAN      2     10e7.c6d5.7119
_ipps._tcp.local
_universal._sub._ipps._tcp.local               4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_print._sub._ipps._tcp.local                   4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_ePCL._sub._ipps._tcp.local                    4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_ipps._tcp.local                               4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp.
_services._dns-sd._udp.local                   4500     WLAN      2     10e7.c6d5.7119
_ipp._tcp.local
_universal._sub._ipp._tcp.local                4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_print._sub._ipp._tcp.local                    4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_ePCL._sub._ipp._tcp.local                     4500     WLAN      2     10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
.
.
.
------------------------------------------------------------- SRV Records
------------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
```

```
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP DeskJet 5000 series [D57119] (3127)._ipp._  4500     WLAN      2     10e7.c6d5.7119   0
 0 631 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._http.  4500     WLAN      2     10e7.c6d5.7119   0
 0 80 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._ipps.  4500     WLAN      2     10e7.c6d5.7119   0
 0 631 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119   0
 0 8080 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._prive  4500     WLAN      2     10e7.c6d5.7119   0
 0 80 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119   0
 0 443 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._scann  4500     WLAN      2     10e7.c6d5.7119   0
 0 8080 HP10E7C6D57119-2860.local
HP DeskJet 5000 series [D57119] (3127)._pdl-d  4500     WLAN      2     10e7.c6d5.7119   0
 0 9100 HP10E7C6D57119-2860.local

------------------------------------------------------------- A/AAAA Records
-------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP10E7C6D57119-2860.local                      4500     WLAN      2     10e7.c6d5.7119
8.16.16.99

------------------------------------------------------------- TXT Records
-------------------------------------------------------------------
RECORD-NAME                                    TTL      TYPE      ID    CLIENT-MAC
RR-RECORD-DATA
-------------------------------------------------------------------------------------------------------------------
HP DeskJet 5000 series [D57119] (3127)._ipp._  4500     WLAN      2     10e7.c6d5.7119
[502]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._http.  4500     WLAN      2     10e7.c6d5.7119
[1]''
HP DeskJet 5000 series [D57119] (3127)._ipps.  4500     WLAN      2     10e7.c6d5.7119
[502]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119
[280]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._prive  4500     WLAN      2     10e7.c6d5.7119
[124]'txtvers=1''ty=HP DeskJet 5000 series [D57119
HP DeskJet 5000 series [D57119] (3127)._uscan  4500     WLAN      2     10e7.c6d5.7119
[280]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._scann  4500     WLAN      2     10e7.c6d5.7119
[177]'txtvers=1''adminurl=http://HP10E7C6D57119-28
HP DeskJet 5000 series [D57119] (3127)._pdl-d  4500     WLAN      2     10e7.c6d5.7119
[211]'txtvers=1''rp=''priority=40''UUID=9fe36149-9
```

show mdns-sd cache upn detail

To view the multicast DNS (mDNS) cache user personal network identifier details, use the **show mdns-sd cache upn detail** command.

show mdns-sd cache upn*upn-id* **detail**

Syntax Description

upn-id	User personal network identifier.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

Example

The following is sample output from the **show mdns-sd cache upn detail** command that displays the mDNS cache UPN identifier details:

```
Device# show mdns-sd cache upn 777 detail

Name: _services._dns-sd._udp.local
  Type: PTR
  TTL: 4500
  WLAN: 2
  WLAN Name: mdns-psk
  VLAN: 16
  Client MAC: f4f9.51e2.a6a6
  AP Ethernet MAC: 002a.1087.d68a
  Remaining-Time: 4486
  Site-Tag: default-site-tag
  mDNS Service Policy: madhu-mDNS-Policy
  Overriding mDNS Service Policy: NO
  UPN-ID: 7777
  UPN-Status: Enabled
  Rdata: _airplay._tcp.local
```

show mdns-sd flexconnect summary

To view the summary of the mDNS flexconnect sites, use the **show mdns-sd flexconnect summary** command.

show mdns-sd flexconnect summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the summary of mDNS flexconnect sites:

```
Device# show mdns-sd flexconnect summary
```

show mdns-sd statistics

To view the mDNS statistics, use the **show mdns-sd statistics** command.

show mdns-sd statistics { **debug** | **flexconnect** | **rlan-id** *<1 - 128>* **wired** | **wlan-id** *<1 - 4096>* }

Syntax Description

debug	Specifies the mDNS debug statistics.
flexconnect	Specifies the mDNS flexconnect statistics.
rlan-id*<1 - 128>*	Specifies the remote LAN (RLAN) ID. The value range is from 1 to 128.
wired	Specifies the mDNS wired statistics.
wlan-id*<1 - 4096>*	Specifies the WLAN ID. The value range is from 1 to 4096.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the mDNS statistics:

```
Device# show mdns-sd statistics
```

show mdns-sd summary

To view the summary of mDNS service discovery configuration, use the **show mdns-sd summary** command.

show mdns-sd summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the summary of mDNS service discovery configuration:

```
Device# show mdns-sd summary
```

show monitor capture

To display the contents of a monitor capture buffer or a capture point, use the **show monitor capture** command in privileged EXEC mode.

show monitor capture [*epc-capture-name* [**parameter** | **buffer** [**brief** | **detailed** | **dump**]]]

Syntax Description

epc-capture-name	Specifies the name of the embedded packet capture.
buffer	Displays the contents of the specified capture buffer.
dump	(Optional) Displays a hexadecimal dump of the captured packet in addition to the metadata.
brief	(Optional) Provides a brief output of the captured packet information.
detail	(Optional) Provides a detailed output of the captured packet information.
parameter	Reconstructs and displays EXEC commands that were used to specify the capture.
detailed	Provides a detailed output of the captured packet information.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

You can enter the **show monitor capture** command when the capture buffer is not in the running state.

If you enter the **detail** keyword, packets are decoded to the Layer 4 protocol level and displayed. If you enter the **dump** keyword, non-IP packets are displayed in hexadecimal dump format. An ACL can be configured as a display filter so that only packets permitted by the ACL are displayed.

The following example shows how to display all the packets in a capture buffer. The output is self-explanatory.

```
Device# show monitor capture mycap buffer

buffer size (KB) : 2048000
buffer used (KB) : 128
packets in buf : 17
packets dropped : 0
packets per sec : 3
```

The following example shows how to display the list of commands that were used to specify the capture:

```
Device# show monitor capture cap1 parameter

  monitor capture cap1 interface GigabitEthernet 1/0/1 both
```

```
monitor capture cap1 match any
monitor capture cap1 buffer size 10
monitor capture cap1 limit pps 1000
```

The following example shows how to display brief output from the captured packet information. The output is self-explanatory.

```
Device# show monitor capture cap1 buffer brief

----------------------------------------------------------------
#   size   timestamp     source             destination   protocol
----------------------------------------------------------------
   0   62    0.000000   10.0.0.1         ->  203.0.113.254  UDP
   1   46    0.267992   10.0.1.2         ->  203.0.113.204  IGMP
   2   76    0.428979   172.16.255.3     ->  172.16.255.3   UDP
   3   62    1.613982   10.0.29.1        ->  172.16.200.2   UDP
   4   74    1.659970   10.0.1.3         ->  10.0.0.10      EIGRP
   5   90    2.016006   10.29.0.4        ->  203.0.113.224  UDP
   6   74    2.088008   10.1.9.2         ->  203.0.113.10   EIGRP
   7   76    2.114008   172.17.254.1     ->  172.16.255.1   UDP
   8   74    2.245990   10.29.0.3        ->  203.0.113.10   EIGRP
   9   46    2.262987   10.0.0.0         ->  203.0.113.1    IGMP
  10   77    2.362988   10.1.9.2         ->  203.0.113.10   EIGRP
  11   62    2.631971   10.29.0.2        ->  203.0.113.2    UDP
  12   74    2.934009   10.29.0.5        ->  203.0.113.10   EIGRP
  13   74    3.331984   10.29.0.6        ->  203.0.113.10   EIGRP
  14   46    3.499974   10.0.0.0         ->  203.0.113.1    IGMP
  15   46    4.304992   10.0.0.0         ->  203.0.113.1    IGMP
  16   76    5.157005   172.16.255.3     ->  172.17.255.3   UDP
```

The following example shows how to display all the packets in a capture buffer. The output is self-explanatory.

```
Device# show monitor capture cap1 buffer detailed

 ----------------------------------------------------------------
#   size   timestamp     source             destination   protocol
----------------------------------------------------------------
   0   62    0.000000   10.29.0.2        ->  172.16.255.3   UDP
  0000:  01005E00 00020000 0C07AC1D 080045C0   ..^...........E.
  0010:  00300000 00000111 CFDC091D 0002E000   .0..............
  0020:  000207C1 07C1001C 802A0000 10030AFA   .........*......
  0030:  1D006369 73636F00 0000091D 0001       ..example.......

   1   46    0.267992   10.0.0.0         ->  172.16.255.1   IGMP
  0000:  01005E00 0002001B 2BF69280 080046C0   ..^.....+.....F.
  0010:  00200000 00000102 44170000 0000E000   . ......D.......
  0020:  00019404 00001700 E8FF0000 0000       ..............

   2   76    0.428979   172.16.255.3     ->  172.17.255.3    UDP
  0000:  00000C07 AC1DB414 89031124 080045C0   ...........$..E.
  0010:  003E0000 0000FF11 64C5AC10 FF03AC11   .>......d.......
  0020:  FF030286 0286002A 84A40001 001EAC10   .......*........
  0030:  FF030000 01000014 00000000 04000004   ................

   3   62    1.613982   10.26.11.3       ->  172.16.255.1    UDP
  0000:  01005E00 0002001B 2BF68680 080045C0   ..^.....+.....E.
  0010:  00300000 00000111 CFDB091D 0003E000   .0..............
  0020:  000207C1 07C1001C 88B50000 08030A6E   ..............n
  0030:  1D006369 73636F00 0000091D 0001       ..example.......

   4   74    1.659970   10.29.3.2        ->  172.16.255.2   EIGRP
  0000:  01005E00 000A001B 2BF69280 080045C0   ..^.....+.....E.
```

```
 0010:  003C0000 00000258 CE81091D 0002E000   .<.....X........
 0020:  000A0205 F3000000 00000000 00000000   ................
 0030:  00000000 00D10001 000C0100 01000000   ................

  5   90    2.016006   10.22.1.4         ->  203.0.113.1     UDP
 0000:  FFFFFFFF FFFF001C 0F2EDC00 080045C0   ..............E.
 0010:  004C0000 00000111 AFC1091D 0004FFFF   .L..............
 0020:  FFFF007B 007B0038 5B14E500 06E80000   ...{.{.8[.......
 0030:  00000021 BE23494E 49540000 00000000   ...!.#INIT......
```

The following example shows how to display a hexadecimal dump of the captured packet:

```
Device# show monitor capture cap1 buffer dump
0
 0000:  01005E00 00020000 0C07AC1D 080045C0   ..^...........E.
 0010:  00300000 00000111 CFDC091D 0002E000   .0..............
 0020:  000207C1 07C1001C 802A0000 10030AFA   .........*......
 0030:  1D006369 73636F00 0000091D 0001       ..example.......

1
 0000:  01005E00 0002001B 2BF69280 080046C0   ..^.....+.....F.
 0010:  00200000 00000102 44170000 0000E000   . ......D.......
 0020:  00019404 00001700 E8FF0000 0000       ..............

2
 0000:  01005E00 0002001B 2BF68680 080045C0   ..^.....+.....E.
 0010:  00300000 00000111 CFDB091D 0003E000   .0..............
 0020:  000207C1 07C1001C 88B50000 08030A6E   ..............n
 0030:  1D006369 73636F00 0000091D 0001       ..example.......

3
 0000:  01005E00 000A001C 0F2EDC00 080045C0   ..^...........E.
 0010:  003C0000 00000258 CE7F091D 0004E000   .<.....X........
 0020:  000A0205 F3000000 00000000 00000000   ................
 0030:  00000000 00D10001 000C0100 01000000   ................
 0040:  000F0004 00080501 0300                ..........
```

show nmsp

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmsp** command.

show nmsp {**attachment** | {**suppress interfaces**} | **capability** | **notification interval** | **statistics** {**connection** | **summary**} | **status** | **subscription detail** [*ip-addr*] | **summary**}

Syntax Description

attachment suppress interfaces	Displays attachment suppress interfaces.
capability	Displays NMSP capabilities.
notification interval	Displays the NMSP notification interval.
statistics connection	Displays all connection-specific counters.
statistics summary	Displays the NMSP counters.
status	Displays status of active NMSP connections.
subscription detail *ip-addr*	The details are only for the NMSP services subscribed to by a specific IP address.
subscription summary	Displays details for all of the NMSP services to which the controller is subscribed. The details are only for the NMSP services subscribed to by a specific IP address.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show nmsp notification interval** command:

```
Device#  show nmsp notification interval
NMSP Notification Intervals
---------------------------

RSSI Interval:
 Client               : 2 sec
 RFID                 : 2 sec
 Rogue AP             : 2 sec
 Rogue Client         : 2 sec
Attachment Interval   : 30 sec
Location Interval     : 30 sec
```

show nmsp cloud-services statistics

To see NMSP cloud-service statistics, use the **show nmsp cloud-services statistics** command.

show nmsp cloud-services statistics [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the active NMSP cloud services in Route-processor slot 0.
standby R0	Standby instance of the active NMSP cloud services in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

This example shows how to see NMSP cloud-service statistics:

```
Device# show nmsp cloud-services statistics
```

show nmsp cloud-services summary

To see a summary of information about NMSP cloud-services, use the **show nmsp cloud-services summary** command.

show nmsp cloud-services summary [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number as either 1 or 2.
active R0	Active instance of the NMSP cloud services in Route-processor slot 0.
standby R0	Standby instance of the active NMSP cloud services in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

This example shows how to see NMSP cloud-service summary information:

```
Device# show nmsp cloud-services summary
```

show nmsp subscription group detail all

To display the mobility services group subscription details of all CMX connections, use the **show nmsp subscription group detail all** command.

show nmsp subscription group detail all

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to display the mobility services group subscription details of all CMX connections:

```
Device# show nmsp subscription group detail all
```

show nmsp subscription group detail ap-list

To display the AP MAC list subscribed for a group by a CMX connection, use the **show nmsp subscription group detail ap-list** command.

show nmsp subscription group detail ap-list *group-name cmx-IP-addrress*

Syntax Description

group-name	CMX AP group name.
cmx-IP-addrress	CMX IP address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the AP MAC list subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail ap-list Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group AP MACs:
: 00:00:00:00:70:02  00:00:00:00:66:02  00:99:00:00:00:02  00:00:00:bb:00:02
  00:00:00:00:55:02  00:00:00:00:50:02  00:33:00:00:00:02  00:d0:00:00:00:02
  00:10:00:10:00:02  00:00:00:06:00:02  00:00:00:02:00:02  00:00:00:00:40:02
  00:00:00:99:00:02  00:00:00:00:a0:02  00:00:77:00:00:02  00:22:00:00:00:02
  00:00:00:00:00:92  00:00:00:00:00:82  00:00:00:00:03:02  aa:00:00:00:00:02
  00:00:00:50:00:42  00:00:0d:00:00:02  00:00:00:00:00:32  00:00:00:cc:00:02
  00:00:00:88:00:02  20:00:00:00:00:02  10:00:00:00:00:02  01:00:00:00:00:02
  00:00:00:00:00:02  00:00:00:00:00:01  00:00:00:00:00:00
```

show nmsp subscription group detail services

To display the services subscribed for a group by a CMX connection, use the **show nmsp subscription group detail services** command.

show nmsp subscription group detail services *group-name cmx-IP-addrress*

Syntax Description

group-name	CMX AP group name.
cmx-IP-addrress	CMX IP address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the services subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail services Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group filtered services:
Service            Subservice
----------------------------
RSSI               Mobile Station,
Spectrum
Info
Statistics
```

show nmsp subscription group summary

To display the mobility services group subscription summary of all CMX connections, use the **show nmsp subscription group summary** command.

show nmsp subscription group summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

The following example shows how to verify the mobility services group subscription summary of all CMX connections.

```
Device# show nmsp subscription group summary

CMX IP address: 127.0.0.1
  Groups subscribed by this CMX server:
  Group name: Group1
```

show ntp associations

To display the status of Network Time Protocol (NTP) associations, use the **show ntp associations** command in privileged EXEC mode.

show ntp associations

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Example

The following example shows how to view NTP associations. :

```
Device# show ntp associations
  address         ref clock       st   when   poll reach  delay  offset   disp
*~10.1.1.99       72.163.32.44     2    918   1024   377  0.177   7.618  1.102
* sys.peer, # selected, + candidate, - outlyer, x falseticker, ~ configured
--
```

show parameter-map type webauth name

To verify the webauth parameters of a parameter map, use the **show parameter-map type webauth name** command.

show parameter-map type webauth name *parameter-map name*

Syntax Description

parameter-map name	Name of the parameter map.

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to verify the webauth parameters of a parameter map:

```
Device# configure terminal
Device(config)# show parameter-map type webauth name parameter-map-name
```

show platform conditions

To see information about conditional debugs, use the **show platform conditions** command.

show platform conditions

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see information about conditional debugs:

```
Device# show platform conditions
```

show platform software wlavc status cp-exporter

To view the wireless AVC information from the control place exporter, use the **show platform software wlavc status cp-exporter** command.

show platform software wlavc status cp-exporter

Syntax Description

wlavc	Displays the wireless AVC information.
status	Displays information about the AVC status.
cp-exporter	Collects information from the Control Plane exporter.

Command Default

None

Command Modes

Privileged EXEC (#) mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example shows how to display the wireless AVC information from the control place exporter:

```
show platform software wlavc status cp-exporter
AVC FNF Exporter status
IP: 10.10.1.1
connection statistics
Sent bytes : 5672
Sent packets : 569
Received records : 564
Socket statistics
New sockets : 3
Closed sockets : 0
Library statistics AVC
cache errors : 0
Unexpected Flow Monitor ID : 0
Socket creation error : 0
Sent records : 240
Received packets : 800
```

show platform hardware slot R0 ha_port interface stats

To see the HA port interface setting status, use the **show platform hardware slot R0 ha_port interface stats** command.

show platform hardware slot R0 ha_port interface stats

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

Examples

This example shows how to see the HA port interface setting status:

```
Device# show platform hardware slot R0 ha_port interface stats
HA Port
ha_port   Link encap:Ethernet  HWaddr 70:18:a7:c8:80:70
          UP BROADCAST MULTICAST  MTU:1500  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 B)  TX bytes:0 (0.0 B)
          Memory:e0900000-e0920000


Settings for ha_port:
        Supported ports:            [ TP ]
        Supported link modes:       10baseT/Half 10baseT/Full
                                    100baseT/Half 100baseT/Full
                                    1000baseT/Full
        Supported pause frame use:   Symmetric
        Supports auto-negotiation:   Yes
        Supported FEC modes:         Not reported
        Advertised link modes:       10baseT/Half 10baseT/Full
                                     100baseT/Half 100baseT/Full
                                     1000baseT/Full
        Advertised pause frame use:  Symmetric
        Advertised auto-negotiation: Yes
        Advertised FEC modes:        Not reported
        Speed:                       Unknown!
        Duplex:                      Unknown! (255)
        Port:                        Twisted Pair
        PHYAD:                       1
        Transceiver:                 internal
        Auto-negotiation:            on
        MDI-X:                       off (auto)
        Supports Wake-on:            pumbg
        Wake-on:                     g
        Current message level:       0x00000007 (7)
                                     drv probe link
        Link detected:               no
```

```
NIC statistics:
     rx_packets:             0
     tx_packets:             0
     rx_bytes:               0
     tx_bytes:               0
     rx_broadcast:           0
     tx_broadcast:           0
     rx_multicast:           0
     tx_multicast:           0
     multicast:              0
     collisions:             0
     rx_crc_errors:          0
     rx_no_buffer_count:     0
     rx_missed_errors:       0
     tx_aborted_errors:      0
     tx_carrier_errors:      0
     tx_window_errors:       0
     tx_abort_late_coll:     0
     tx_deferred_ok:         0
     tx_single_coll_ok:      0
     tx_multi_coll_ok:       0
     tx_timeout_count:       0
     rx_long_length_errors:  0
     rx_short_length_errors: 0
     rx_align_errors:        0
     tx_tcp_seg_good:        0
     tx_tcp_seg_failed:      0
     rx_flow_control_xon:    0
     rx_flow_control_xoff:   0
     tx_flow_control_xon:    0
     tx_flow_control_xoff:   0
     rx_long_byte_count:     0
     tx_dma_out_of_sync:     0
     tx_smbus:               0
     rx_smbus:               0
     dropped_smbus:          0
     os2bmc_rx_by_bmc:       0
     os2bmc_tx_by_bmc:       0
     os2bmc_tx_by_host:      0
     os2bmc_rx_by_host:      0
     tx_hwtstamp_timeouts:   0
     rx_hwtstamp_cleared:    0
     rx_errors:              0
     tx_errors:              0
     tx_dropped:             0
     rx_length_errors:       0
     rx_over_errors:         0
     rx_frame_errors:        0
     rx_fifo_errors:         0
     tx_fifo_errors:         0
     tx_heartbeat_errors:    0
     tx_queue_0_packets:     0
     tx_queue_0_bytes:       0
     tx_queue_0_restart:     0
     tx_queue_1_packets:     0
     tx_queue_1_bytes:       0
     tx_queue_1_restart:     0
     rx_queue_0_packets:     0
     rx_queue_0_bytes:       0
     rx_queue_0_drops:       0
     rx_queue_0_csum_err:    0
     rx_queue_0_alloc_failed:0
     rx_queue_1_packets:     0
```

```
rx_queue_1_bytes:       0
rx_queue_1_drops:       0
rx_queue_1_csum_err:    0
rx_queue_1_alloc_failed:0
```

show platform software system all

To check status of the current virtual machine and look for performance issues due to inadequate resources (or other issues with the hosting environment), use the **set platform software system all** command in privileged EXEC mode.

show platform software system all

Syntax Description

This command has no keywords or arguments.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Examples

This example shows how to check status of the current virtual machine and its resources:

```
Device# show platform software system all

Processor Details
=================
Number of Processors : 6
Processor : 1 - 6
vendor_id : GenuineIntel
cpu MHz  : 2593.750
cache size : 35840 KB
Crypto Supported : Yes
model name : Intel(R) Xeon(R) CPU E5-2690 v4 @ 2.60GHz

Memory Details
==============
Physical Memory : 16363904KB

VNIC Details
============
Name   Mac Address  Status Platform MTU
GigabitEthernet1 000c.2964.7126  UP 1500
GigabitEthernet2 000c.2964.7130  UP 1500

Hypervisor Details
==================
Hypervisor: VMWARE
Manufacturer: VMware, Inc.
Product Name: VMware Virtual Platform
Serial Number: VMware-56 4d e5 0a a7 dd 27 2b-0e 2f 36 6e 0f 64 71 26
UUID: 564DE50A-A7DD-272B-0E2F-366E0F647126
image_variant :

Boot Details
==================
Boot mode: BIOS
Bootloader version: 1.1
```

show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

show platform software trace filter-binary*modules* [**context** *mac-address*]

Syntax Description

context*mac-address*	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

This command collates and sorts all the logs present in the `/tmp/.../` across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named `collated_log_{system time}` with the same content, in the `/crashinfo/tracelogs` directory.

Examples

This example shows how to display the trace information for a wireless module:

```
Device# show platform software trace filter-binary wireless
```

show platform software trace level

To view the trace levels for all the modules under a specific process, use the **show platform software trace level** command in privileged EXEC or user EXEC mode.

Syntax Description

process	Process whose tracing level is being set. Options include: • **chassis-manager**—The Chassis Manager process. • **cli-agent**—The CLI Agent process. • **cmm**—The CMM process. • **dbm**—The Database Manager process. • **emd**—The Environmental Monitoring process. • **fed**—The Forwarding Engine Driver process. • **forwarding-manager**—The Forwarding Manager process. • **geo**—The Geo Manager process. • **host-manager**—The Host Manager process. • **interface-manager**—The Interface Manager process. • **iomd**—The Input/Output Module daemon (IOMd) process. • **ios**—The IOS process. • **license-manager**—The License Manager process. • **logger**—The Logging Manager process. • **platform-mgr**—The Platform Manager process. • **pluggable-services**—The Pluggable Services process. • **replication-mgr**—The Replication Manager process. • **shell-manager**—The Shell Manager process. • **sif**—The Stack Interface (SIF) Manager process. • **smd**—The Session Manager process. • **stack-mgr**—The Stack Manager process. • **table-manager**—The Table Manager Server. • **thread-test**—The Multithread Manager process. • **virt-manager**—The Virtualization Manager process. • **wireless**—The wireless controller module process.

slot	Hardware slot where the process for which the trace level is set, is running. Options include:
	• *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.
	• *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.
	• **F0**—The Embedded Service Processor in slot 0.
	• **F1**—The Embedded Service Processor in slot 1.
	• **FP active**—The active Embedded Service Processor.
	• **R0**—The route processor in slot 0.
	• **RP active**—The active route processor.
	• **switch** <*number*> —The switch, with its number specified.
	• **switch active**—The active switch.
	• **switch standby**—The standby switch.
	  • *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.
	  • *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.
	  • **F0**—The Embedded Service Processor in slot 0.
	  • **FP active**—The active Embedded Service Processor.
	  • **R0**—The route processor in slot 0.
	  • **RP active**—The active route processor.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Examples

This example shows how to view the trace level:

```
Device#  show platform software trace level dbm chassis active R0
```

```
Module Name                      Trace Level
-------------------------------------------------
binos                            Notice
binos/brand                      Notice
bipc                             Notice
btrace                           Notice
bump_ptr_alloc                   Notice
cdllib                           Notice
chasfs                           Notice
dbal                             Informational
dbm                              Debug
evlib                            Notice
evutil                           Notice
file_alloc                       Notice
green-be                         Notice
ios-avl                          Notice
klib                             Debug
services                         Notice
sw_wdog                          Notice
syshw                            Notice
tdl_cdlcore_message              Notice
tdl_dbal_root_message            Notice
tdl_dbal_root_type               Notice
```

show platform software trace message

To display the trace messages for a process, use the **set platform software trace** command in privileged EXEC or user EXEC mode.

show platform software trace message *process slot*

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Examples

This example shows how to display the trace messages for the Stack Manager and the Forwarding Engine Driver processes:

```
Device# show platform software trace message stack-mgr switch active R0
10/30 09:42:48.767 [btrace] [8974]: (note): Successfully registered module [97] [uiutil]
10/30 09:42:48.762 [btrace] [8974]: (note): Successfully registered module [98]
[tdl_cdlcore_message]
10/29 13:28:19.023 [stack_mgr] [8974]: (note): Examining peer state
10/29 13:28:19.023 [stack_mgr] [8974]: (note): no switch eligible for standby election
presently
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Posting event
stack_fsm_event_wait_standby_elect_timer_expired, curstate stack_fsm_state_active_ready
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Timer HDL - STACK_WAIT_STANDBY_ELECT_TIMER
expired
10/29 13:26:46.584 [btrace] [8974]: (note): Successfully registered module [99]
[tdl_ui_message]
10/29 13:26:46.582 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:36.582 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect
10/29 13:26:36.582 [evutil] [8974]: (ERR): Asynchronous connect failed for [uipeer uplink
to slot 1] (fd == -1)
10/29 13:26:36.581 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:26.581 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect

Device# show platform software trace message fed switch active
11/02 10:55:01.832 [btrace]: [11310]:  UUID: 0, ra: 0 (note): Successfully registered module
 [86] [uiutil]
11/02 10:55:01.848 [btrace]: [11310]:  UUID: 0, ra: 0 (note): Single message size is greater
 than 1024
11/02 10:55:01.822 [btrace]: [11310]:  UUID: 0, ra: 0 (note): Successfully registered module
 [87] [tdl_cdlcore_message]
11/01 09:54:41.474 [btrace]: [12312]:  UUID: 0, ra: 0 (note): Successfully registered module
 [88] [tdl_ngwc_gold_message]
11/01 09:54:11.228 [btrace]: [12312]:  UUID: 0, ra: 0 (note): Successfully registered module
 [89] [tdl_doppler_iosd_matm_type]
11/01 09:53:37.454 [btrace]: [11310]:  UUID: 0, ra: 0 (note): Successfully registered module
 [90] [tdl_ui_message]
11/01 09:53:37.382 [bipc]: [11310]:  UUID: 0, ra: 0 (note): Pending connection to server
10.129.1.0
11/01 09:53:34.227 [xcvr]: [18846]:  UUID: 0, ra: 0 (ERR): FRU hardware authentication Fail,
```

```
 result = 1.
11/01 09:53:33.775 [ng3k_scc]: [18846]:  UUID: 0, ra: 0 (ERR): SMART COOKIE: SCC I2C receive
 failed: rc=10
11/01 09:53:33.775 [ng3k_scc]: [18846]:  UUID: 0, ra: 0 (ERR):
SMART COOKIE receive failed, try again
11/01 09:53:33.585 [ng3k_scc]: [18846]:  UUID: 0, ra: 0 (ERR):
```

show platform software trace message license-manager chassis active R0

To display the trace message for license-manager process of active route processor, use the **show platform software trace message license-manager chassis active R0** command in privileged EXEC mode.

```
show platform software trace message license-managerchassis {chassis-number
| active | standby}R0reverse
```

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to display the trace messages for the Forwarding Engine Driver processes:

```
Device# show platform software trace message license-manager chassis active R0
.......
2018/06/25 07:16:53.121 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 35
 msecs
/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy: DECODE(50:50:0:7)
2018/06/25 07:16:53.088 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/25 06:53:20.421 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 34
 msecs
2018/06/25 06:53:20.389 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Processing all-modules
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Empty trace conf file
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Constructing domain iosd_lmrp for RP/0/0 to RP/0/0
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received registration msg from [IOS]
2018/06/20 07:54:46.449 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/license_mgr_socket
2018/06/20 07:54:45.557 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:44.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:43.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:42.555 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:41.554 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
```

```
2018/06/20 07:54:40.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:39.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:38.552 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:37.551 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:36.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:35.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:34.549 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:33.548 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:32.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:31.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.537 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Pending connection to server 10.0.1.0
2018/06/20 07:54:29.546 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:28.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:27.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:26.544 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:25.543 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:24.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:23.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:22.541 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:21.540 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Peer
 attach: from location R0:0 is successful
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Not
 setting domain for cmand
2018/06/20 07:54:20.625 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/lman_lic_serv_socket
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
epoch file read /tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Detect newly epoch file generated: new epoch:
/tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Flag tdlh stale epoch for all tdl handles
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Chasfs Watch on rp/0/0/rtu_licensing for platform to create RTU properties
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
 chassis product id: 'ISR4461/K9'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
 chassis serial number: 'FDO2213A0GL'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
```

```
 proc path is /tmp/patch/CRDU/BPROC_LM_RP/
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
 procstr is BPROC_LM_RP
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): No
licensing objects present in chasfs to delete
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Deleting any existing licensing chasfs objects under [rp/0/0/licensing]
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
 build device: could not add register 7 dev:
/sys/bus/platform/devices/cpld/reg_rp_sku_register (No such file or directory) due to No
such file or directory
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
 build device: could not add register 5 dev: /sys/bus/platform/devices/cpld/phys_slot_number
 (No such file or directory) due to No such file or directory

Total messages : 49
```

show platform software trace message license-manager

To display the trace message for license-manager process of router processor, use the **show platform software trace message license-manager** command in privileged EXEC mode.

show platform software trace message license-manager [**chassis** { *chassis-number* | **active** | **standby** } **R0**]

Syntax Description

active R0	Active instance in Route-processor slot 0.
standby R0	Standby instance in Route-processor slot 0.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

This example shows how to display the trace messages for the Forwarding Engine Driver processes:

```
Device# show platform software trace message license-manager chassis active R0
.......
2018/06/25 06:53:20.421 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 34
 msecs
/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy: DECODE(48:48:0:7)
2018/06/25 06:53:20.389 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Processing all-modules
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Empty trace conf file
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Constructing domain iosd_lmrp for RP/0/0 to RP/0/0
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received registration msg from [IOS]
2018/06/20 07:54:46.449 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/license_mgr_socket
2018/06/20 07:54:45.557 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:44.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:43.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:42.555 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:41.554 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:40.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:39.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
```

```
2018/06/20 07:54:38.552 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:37.551 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:36.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:35.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:34.549 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:33.548 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:32.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:31.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.537 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Pending connection to server 10.0.1.0
2018/06/20 07:54:29.546 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:28.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:27.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:26.544 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:25.543 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:24.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:23.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:22.541 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:21.540 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Peer
 attach: from location R0:0 is successful
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Not
 setting domain for cmand
2018/06/20 07:54:20.625 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/lman_lic_serv_socket
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
epoch file read /tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Detect newly epoch file generated: new epoch:
/tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Flag tdlh stale epoch for all tdl handles
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Chasfs Watch on rp/0/0/rtu_licensing for platform to create RTU properties
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
 chassis product id: 'ISR4461/K9'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
 chassis serial number: 'FDO2213A0GL'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
 proc path is /tmp/patch/CRDU/BPROC_LM_RP/
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
```

```
 procstr is BPROC_LM_RP
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): No
licensing objects present in chasfs to delete
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Deleting any existing licensing chasfs objects under [rp/0/0/licensing]
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
 build device: could not add register 7 dev:
/sys/bus/platform/devices/cpld/reg_rp_sku_register (No such file or directory) due to No
such file or directory
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
 build device: could not add register 5 dev: /sys/bus/platform/devices/cpld/phys_slot_number
 (No such file or directory) due to No such file or directory
```

show policy-map

To display quality of service (QoS) policy maps, which define classification criteria for incoming traffic, use the **show policy-map** command in EXEC mode.

show policy-map [*policy-map-name* | **interface** *interface-id*]

show policy-map interface {**Auto-template** | **Capwap** | **GigabitEthernet** | **GroupVI** | **InternalInterface** | **Loopback** | **Lspvif** | **Null** | **Port-channel** | **TenGigabitEthernet** | **Tunnel** | **Vlan** | **brief** | **class** | **input** | **output**

show policy-map interface {**ap name** *ap_name* | **client mac** *mac_address* | **radio type** {**24ghz** | **5ghz**} **ap name** *ap_name* | **ssid name** *ssid_name* {**ap name** *ap_name* | **radio type** {**24ghz** | **5ghz**} **ap name** *ap_name*} }

Syntax Description

policy-map-name	(Optional) Name of the policy-map.
interface *interface-id*	(Optional) Displays the statistics and the configurations of the input and output policies that are attached to the interface.
ap name *ap_name*	Displays SSID policy configuration of an access point.
client mac *mac_address*	Displays information about the policies for all the client targets.
radio type {**24ghz**	**5ghz**	Displays policy configuration of the access point in the specified radio type.
ssid name *ssid_name*	Displays policy configuration of an SSID.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
	This comman

Usage Guidelines

Policy maps can include policers that specify the bandwidth limitations and the action to take if the limits are exceeded.

Note Though visible in the command-line help string, the **control-plane**, **session**, and **type** keywords are not supported, and the statistics shown in the display should be ignored.

To display classification counters for ternary content addressable memory (TCAM) (marking or policing) based policies, enter the interface ID. Classification counters have the following restrictions:

- Classification counters are supported only on wired ports (in the ingress and egress directions).
- Classification counters count packets instead of bytes.
- Only QoS configurations with marking or policing trigger the classification counter.
- As long as there is policing or marking action in the policy, the class-default will have classification counters.
- Classification counters are not port based. The counters are shared across targets sharing the same policy map. This means that the classification counter aggregates all packets belonging to the same class of the same policy which attach to different interfaces.

This is an example of output from the **show policy-map interface** command, where classification counters are displayed:

```
Device# show policy-map interface gigabitethernet1/0/1

  GigabitEthernet1/0/1

  Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

    Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
      0 packets
      Match: cos  5
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        dscp ef
      police:
          cir 128000 bps, bc 8000 bytes
        conformed 0 bytes; actions:
          transmit
        exceeded 0 bytes; actions:
          set-dscp-transmit dscp table policed-dscp
        conformed 0000 bps, exceed 0000 bps

    Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
      0 packets
      Match: cos  3
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        dscp cs3
      police:
          cir 32000 bps, bc 8000 bytes
        conformed 0 bytes; actions:
          transmit
        exceeded 0 bytes; actions:
          set-dscp-transmit dscp table policed-dscp
        conformed 0000 bps, exceed 0000 bps
```

```
  Class-map: AutoQos-4.0-Default-Class (match-any)
    0 packets
    Match: access-group name AutoQos-4.0-Acl-Default
      0 packets, 0 bytes
      5 minute rate 0 bps
    QoS Set
      dscp default

  Class-map: class-default (match-any)
    0 packets
    Match: any
      0 packets, 0 bytes
      5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

  queue stats for all priority classes:
    Queueing
    priority level 1

    (total drops) 0
    (bytes output) 0

  Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
    0 packets
    Match:  dscp cs4 (32) cs5 (40) ef (46)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  5
      0 packets, 0 bytes
      5 minute rate 0 bps
    Priority: 30% (300000 kbps), burst bytes 7500000,

    Priority Level: 1

  Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
    0 packets
    Match:  dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  3
      0 packets, 0 bytes
      5 minute rate 0 bps
    Queueing
    queue-limit dscp 16 percent 80
    queue-limit dscp 24 percent 90
    queue-limit dscp 48 percent 100
    queue-limit dscp 56 percent 100

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 10%

    queue-buffers ratio 10

  Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
    0 packets
    Match:  dscp af41 (34) af42 (36) af43 (38)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos  4
      0 packets, 0 bytes
      5 minute rate 0 bps
    Queueing
```

```
  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match:  dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos  2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match:  dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos  1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match:  dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match:  dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
```

```
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

show rate-limit client

To configure the rate-limit for a client on the AP, use the **show rate-limit client** command.

show rate-limit client

Syntax Description

This command has no arguments.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following example shows how to configure the rate-limit for a client on the AP:

```
Device# show rate-limit client
Config:
mac vap rt_rate_out rt_rate_in rt_burst_out rt_burst_in nrt_rate_out nrt_rate_in nrt_burst_out
 nrt_burst_in
00:1C:F1:09:85:E7 0 8001 8002 8003 8004 8005 8006 8007 8008
Statistics:
name up down
Unshaped 0 0
Client RT pass 0 0
Client NRT pass 0 0
Client RT drops 0 0
Client NRT drops 0 0
Per client rate limit:
mac vap rate_out rate_in policy
```

show ssh

To see the SSH connection status, use the **show ssh** command.

show ssh {*connection-number* | {**vty** *connection-number* }}

Syntax Description

connection-number	SSH connection number. Valid range is 0 to 530.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the SSH connection status:

```
Device# show ssh connection-number
```

show stealthwatch-cloud connection

To view the connection details of Stealthwatch Cloud, use the **show stealthwatch-cloud connection** command.

show stealthwatch-cloud connection

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the connection details of Stealthwatch Cloud:

```
Device# show stealthwatch-cloud connection
```

show stealthwatch-cloud wireless-shim

To view the wireless-shim details of Stealthwatch Cloud, use the **show stealthwatch-cloud wireless-shim** command.

show stealthwatch-cloud wireless-shim

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the wireless-shim details of Stealthwatch Cloud:

```
Device# show stealthwatch-cloud wireless-shim
```

show tech-support wireless

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless** command in privileged EXEC mode.

show tech-support wireless

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show tech-support wireless** command:

```
Device# show tech-support wireless
 *** show ap capwap timers ***

Cisco AP CAPWAP timers

AP Discovery timer       : 10
AP Heart Beat timeout    : 30
Primary Discovery timer  : 120
Primed Join timeout      : 0
Fast Heartbeat           : Disabled
Fast Heartbeat timeout   : 1
*** show ap capwap retransmit ***
Global control packet retransmit interval : 3
Global control packet retransmit count : 5

AP Name                           Retransmit Interval             Retransmit Count
-----------------------------------------------------------------------------------------
TSIM_AP-2                         3                               5
TSIM_AP-3                         3                               5
*** show ap dot11 24ghz cleanair air-quality summary ***

AQ = Air Quality
DFS = Dynamic Frequency Selection

*** show ap dot11 24ghz cleanair air-quality worst ***

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name             Channel   Avg AQ  Min AQ  Interferers  DFS
-----------------------------------------------------------------
                    0         0       0       0            No
*** show ap dot11 24ghz cleanair config ***

Clean Air Solution................................ : Disabled
Air Quality Settings:
    Air Quality Reporting......................... : Disabled
    Air Quality Reporting Period (min)............ : 15
```

```
    Air Quality Alarms..................... : Enabled
    Air Quality Alarm Threshold............ : 10
Interference Device Settings:
    Interference Device Reporting.......... : Enabled
        Bluetooth Link..................... : Enabled
        Microwave Oven..................... : Enabled
        802.11 FH.......................... : Enabled
        Bluetooth Discovery................ : Enabled
        TDD Transmitter.................... : Enabled
        Jammer............................. : Enabled
        Continuous Transmitter............. : Enabled
        DECT-like Phone.................... : Enabled
        Video Camera....................... : Enabled
        802.15.4........................... : Enabled
        WiFi Inverted...................... : Enabled
        WiFi Invalid Channel............... : Enabled
        SuperAG............................ : Enabled
        Canopy............................. : Enabled
        Microsoft Device................... : Enabled
        WiMax Mobile....................... : Enabled
        WiMax Fixed........................ : Enabled
    Interference Device Types Triggering Alarms:
        Bluetooth Link..................... : Disabled
        Microwave Oven..................... : Disabled
        802.11 FH.......................... : Disabled
        Bluetooth Discovery................ : Disabled
        TDD Transmitter.................... : Disabled
        Jammer............................. : Disabled
        Continuous Transmitter............. : Disabled
        DECT-like Phone.................... : Disabled
        Video Camera....................... : Disabled
  802.15.4............................... : Disabled
        WiFi Inverted...................... : Enabled
        WiFi Invalid Channel............... : Enabled
        SuperAG............................ : Disabled
        Canopy............................. : Disabled
        Microsoft Device................... : Disabled
        WiMax Mobile....................... : Disabled
        WiMax Fixed........................ : Disabled
    Interference Device Alarms............. : Enabled
Additional Clean Air Settings:
    CleanAir Event-driven RRM State........ : Disabled
    CleanAir Driven RRM Sensitivity........ : LOW
    CleanAir Persistent Devices state...... : Disabled
```

show tech-support wireless ap

To display specific information about the Cisco APs variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless ap** command in privileged EXEC mode.

show tech-support wireless ap

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless ap**command:

- show ap session termination statistics
- show ap status
- show ap tag summary
- show platform software bssid chassis active F0 statistics
- show platform software bssid chassis active R0 statistics
- show platform software capwap chassis active F0 statistics
- show platform software capwap chassis active R0 statistics
- show platform software dtls chassis active F0 statistics
- show platform software dtls chassis active R0 statistics
- show platform software radio chassis active F0 statistics
- show platform software radio chassis active R0 statistics

Example

The following is sample output from the **show tech-support wireless ap** command

```
Device# show tech-support wireless ap

------------------ show platform software dtls chassis active R0 statistics ------------------


DTLS Counters     (Success/Failure)
-----------------------------------
Create                  0/0
```

```
Delete                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
Ack Nack Notify         0/0


------------------ show platform software radio chassis active R0 statistics
------------------



Switch 1:
NACK Notify             0/0
  Create Failure        0
  Delete Failure        0


------------------ show platform software bssid chassis active R0 statistics
------------------



Switch 1:
NACK Notify             0/0
  Create Failure        0
  Delete Failure        0


------------------ show platform software capwap chassis active R0 statistics
------------------


Capwap Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
Modify                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
ACK-NACK Notify         0/0
  Tunnel State          0/0
  Tunnel Create         0/0
  Tunnel Modify         0/0
  Tunnel Delete         0/0


------------------ show platform software dtls chassis active F0 statistics ------------------


DTLS Counters     (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Ack Ack Notify          0/0
```

```
Ack Nack Notify         0/0
Nack Notify             0/0
HA Seq GET              665/0
HA Seq SET              0/0
HA Seq Crypto GET       0/0
HA Seq Crypto SET       0/0
HA Seq Crypto Callback  0/0

HA Seq last Responsed   0
HA Seq Pending          0
HA Seq Outstanding cb   0


------------------ show platform software radio chassis active F0 statistics
------------------


Radio Counters    (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Nack Notify             0/0


------------------ show platform software bssid chassis active F0 statistics
------------------


Bssid Counters    (Success/Failure)
-----------------------------------
Create                 0/0
Delete                 0/0
HW Create              0/0
HW Modify              0/0
HW Delete              0/0
Create Ack             0/0
Modify Ack             0/0
Delete Ack             0/0
Nack Notify            0/0


------------------ show platform software capwap chassis active F0 statistics
------------------


Capwap Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
Ack Ack Notify          0/0
Ack Nack Notify         0/0
Nack Notify             0/0
```

```
------------------ show ap auto-rf dot11 24ghz ------------------


------------------ show ap auto-rf dot11 5ghz ------------------


------------------ show ap capwap retransmit ------------------


------------------ show ap config dot11 dual-band summary ------------------


------------------ show ap config general ------------------



------------------ show ap dot11 24ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 25 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 10 dB
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown


------------------ show ap dot11 24ghz group ------------------


Radio RF Grouping

  802.11b Group Mode               : AUTO
  802.11b Group Update Interval    : 600 seconds
  802.11b Group Leader             : ewlc-doc (9.12.32.10)
  802.11b Last Run                 : 26 seconds ago


RF Group Members

Controller name                  Controller IP
```

```
------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 24ghz load-info ------------------


------------------ show ap dot11 24ghz monitor ------------------


Default 802.11b AP monitoring
  802.11b Monitor Mode                  : Enabled
  802.11b Monitor Channels              : Country channels
  802.11b RRM Neighbor Discover Type    : Transparent
  802.11b AP Coverage Interval          : 180 seconds
  802.11b AP Load Interval              : 60 seconds
  802.11b AP Noise Interval             : 180 seconds
  802.11b AP Signal Strength Interval   : 60 seconds
  802.11b NDP RSSI Normalization        : Enabled


------------------ show ap dot11 24ghz network ------------------


802.11b Network                           : Enabled
11gSupport                                : Enabled
11nSupport                                : Enabled
802.11b/g Operational Rates
  802.11b 1M                              : Mandatory
  802.11b 2M                              : Mandatory
  802.11b 5.5M                            : Mandatory
  802.11b 11M                             : Mandatory
  802.11g 6M                              : Supported
  802.11g 9M                              : Supported
  802.11g 12M                             : Supported
  802.11g 18M                             : Supported
  802.11g 24M                             : Supported
  802.11g 36M                             : Supported
  802.11g 48M                             : Supported
  802.11g 54M                             : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported


------------------ show ap dot11 24ghz profile ------------------


Default 802.11b AP performance profiles
  802.11b Global Interference threshold    : 10 %
  802.11b Global noise threshold           : -70 dBm
  802.11b Global RF utilization threshold  : 80 %
  802.11b Global throughput threshold      : 1000000 bps
  802.11b Global clients threshold         : 12 clients


------------------ show ap dot11 24ghz summary ------------------
```

```
------------------ show ap dot11 24ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 27 seconds ago


------------------ show ap dot11 5ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 27 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 15 dB
  DCA 802.11n/ac Channel Width              : 20 MHz
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown


------------------ show ap dot11 5ghz group ------------------


Radio RF Grouping

  802.11a Group Mode              : AUTO
  802.11a Group Update Interval   : 600 seconds
  802.11a Group Leader            : ewlc-doc (9.12.32.10)
  802.11a Last Run                : 28 seconds ago


RF Group Members

Controller name                  Controller IP
```

```
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 5ghz load-info ------------------


------------------ show ap dot11 5ghz monitor ------------------


Default 802.11a AP monitoring
  802.11a Monitor Mode                : Enabled
  802.11a Monitor Channels            : Country channels
  802.11a RRM Neighbor Discover Type  : Transparent
  802.11a AP Coverage Interval        : 180 seconds
  802.11a AP Load Interval            : 60 seconds
  802.11a AP Noise Interval           : 180 seconds
  802.11a AP Signal Strength Interval : 60 seconds
  802.11a NDP RSSI Normalization      : Enabled


------------------ show ap dot11 5ghz network ------------------


802.11a Network                         : Enabled
11nSupport                              : Enabled
  802.11a Low Band                      : Enabled
  802.11a Mid Band                      : Enabled
  802.11a High Band                     : Enabled
802.11a Operational Rates
  802.11a 6M                            : Mandatory
  802.11a 9M                            : Supported
  802.11a 12M                           : Mandatory
  802.11a 18M                           : Supported
  802.11a 24M                           : Mandatory
  802.11a 36M                           : Supported
  802.11a 48M                           : Supported
  802.11a 54M                           : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported


------------------ show ap dot11 5ghz profile ------------------


Default 802.11a AP performance profiles

  802.11a Global Interference threshold         : 10 %
  802.11a Global noise threshold                : -70 dBm
  802.11a Global RF utilization threshold       : 80 %
  802.11a Global throughput threshold           : 1000000 bps
  802.11a Global clients threshold              : 12 clients


------------------ show ap dot11 5ghz summary ------------------
```

```
------------------ show ap dot11 5ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 28 seconds ago


------------------ show ap image ------------------



------------------ show wireless stats ap join summary ------------------

Number of APs: 0

Base MAC        Ethernet MAC    AP Name                             IP Address       Status
     Last Failure Type     Last Disconnect Reason
-----------------------------------------------------------------------------------------------


------------------ show ap rf-profile summary ------------------


Number of RF-profiles: 6

RF Profile Name                  Band     Description                          State
------------------------------------------------------------------------------------
Low_Client_Density_rf_5gh        5 GHz    pre configured Low Client Density rf Up
High_Client_Density_rf_5gh       5 GHz    pre configured High Client Density r Up
Low_Client_Density_rf_24gh       2.4 GHz  pre configured Low Client Density rf Up
High_Client_Density_rf_24gh      2.4 GHz  pre configured High Client Density r Up
Typical_Client_Density_rf_5gh    5 GHz    pre configured Typical Density rfpro Up
Typical_Client_Density_rf_24gh   2.4 GHz  pre configured Typical Client Densit Up


------------------ show ap slots ------------------


------------------ show ap summary ------------------


Number of APs: 0
```

```
------------------ show ap uptime ------------------

Number of APs: 0


------------------ show ap tag summary ------------------

Number of APs: 0


------------------ show ap status ------------------


------------------ show ap cdp neighbors ------------------

Number of neighbors: 0


------------------ show ap ap-join-profile summary ------------------


Number of AP Profiles: 1
AP Profile Name                  Description
------------------------------------------------------------------------
default-ap-profile               default ap profile

------------------ show ap link-encryption ------------------


------------------ show wireless stats ap session termination ------------------


------------------ show wireless loadbalance ap affinity wncd 0 ------------------


------------------ show wireless loadbalance ap affinity wncd 1 ------------------


------------------ show wireless loadbalance ap affinity wncd 2 ------------------


------------------ show wireless loadbalance ap affinity wncd 3 ------------------


------------------ show wireless loadbalance ap affinity wncd 4 ------------------


------------------ show wireless loadbalance ap affinity wncd 5 ------------------
```

```
------------------- show wireless loadbalance ap affinity wncd 6 -------------------

------------------- show wireless loadbalance ap affinity wncd 7 -------------------
```

show tech-support wireless client

To print the data related to all clients or a particular client, use the **show tech-support wireless client** command in privileged EXEC mode.

show tech-support wireless client

Syntax Description

mac-address	Client MAC address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless client** command:

- show platform software wireless-client chassis active F0 statistics
- show platform software wireless-client chassis active R0 statistics
- show wireless client calls active
- show wireless client calls rejected
- show wireless client client-statistics summary
- show wireless client device summary
- show wireless client mac <mac-addr> details
- show wireless client probing
- show wireless client sleeping-client
- show wireless client statistic
- show wireless client steering
- show wireless client summary
- show wireless exclusionlist
- show wireless pmk-cache

Example

The following is sample output from the **show tech-support wireless client** command

```
Device# show tech-support wireless client

------------------ show wireless stats client summary ------------------

Number of Local Clients : 0


MAC Address    AP Name                          WLAN UpTime(secs) Rx Pkts Tx Pkts RSSI SNR
  Data Retries
------------------------------------------------------------------------------------------




------------------ show wireless client summary ------------------

Number of Local Clients: 0


Number of Excluded Clients: 0



------------------ show wireless client device summary ------------------



------------------ show wireless client steering ------------------


Client Steering Configuration Information
  Macro to micro transition threshold                 : -55 dBm
  Micro to Macro transition threshold                 : -65 dBm
  Micro-Macro transition minimum client count         : 3
  Micro-Macro transition client balancing window      : 3
  Probe suppression mode                              : Disabled
  Probe suppression validity window                   : 100 s
  Probe suppression aggregate window                  : 200 ms
  Probe suppression transition aggressiveness         : 3
  Probe suppression hysteresis                        : -6 dBm

WLAN Configuration Information



------------------ show wireless client calls active ------------------



------------------ show wireless client calls rejected ------------------



------------------ show wireless client sleeping-client ------------------

Total number of sleeping-client entries: 0


------------------ show wireless client probing ------------------



------------------ show wireless client ap dot11 24ghz ------------------
```

```
------------------ show wireless client ap dot11 5ghz ------------------



------------------ show wireless pmk-cache ------------------

Number of PMK caches in total : 0

Type      Station             Entry Lifetime  VLAN Override         IP Override
Audit-Session-Id
-----------------------------------------------------------------------------------------------------


------------------ show wireless exclusionlist ------------------


------------------ show wireless country  configured ------------------


Configured Country.........................   US - United States
Configured Country Codes
        US  - United States                 802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor


------------------ show wireless tag rf summary ------------------


Number of RF Tags: 1

RF tag name                       Description
------------------------------------------------------------------------
default-rf-tag                    default RF tag


------------------ show platform software wireless-client chassis active R0 statistics
------------------

Client Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
Modify                  0/0

Switch 1:
OM Create               0/0
OM Delete               0/0
NACK Notify             0/0
  Create Failure        0
  Modify Failure        0
  Delete Failure        0
```

```
------------------ show platform software wireless-client chassis active F0 statistics
------------------


Client Counters   (Success/Failure)
-----------------------------------
Create                  0/0
Delete                  0/0
HW Create               0/0
HW Modify               0/0
HW Delete               0/0
Create Ack              0/0
Modify Ack              0/0
Delete Ack              0/0
NACK Notify             0/0
```

show tech-support wireless radio

To print the data related to the radio, use the **show tech-support wireless radio** command in privileged EXEC mode.

show tech-support wireless radio

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless radio** command:

- show ap auto-rf dot11 24ghz
- show ap auto-rf dot11 5ghz
- show ap config dot11 dual-band summary
- show ap config general
- show ap dot11 24ghz channel
- show ap dot11 24ghz coverage
- show ap dot11 24ghz group
- show ap dot11 24ghz high-density
- show ap dot11 24ghz load-info
- show ap dot11 24ghz monitor
- show ap dot11 24ghz network
- show ap dot11 24ghz summary
- show ap dot11 24ghz txpower
- show ap dot11 5ghz channel
- show ap dot11 5ghz coverage
- show ap dot11 5ghz group
- show ap dot11 5ghz high-density
- show ap dot11 5ghz load-info

- show ap dot11 5ghz monitor
- show ap dot11 5ghz network
- show ap dot11 5ghz summary
- show ap dot11 5ghz txpower
- show ap fra
- show ap rf-profile name Rf1 detail
- show ap rf-profile summary
- show ap summary
- show wireless band-select

Example

The following is sample output from the **show tech-support wireless radio** command

```
Device# show tech-support wireless radio

------------------ show ap summary ------------------

Number of APs: 0


------------------ show ap dot11 24ghz summary ------------------


------------------ show ap dot11 5ghz summary ------------------


------------------ show ap config dot11 dual-band summary ------------------


------------------ show ap dot11 24ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 550 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 10 dB
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
```

```
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
  802.11b 2.4 GHz Auto-RF Channel List
    Allowed Channel List                    : 1,6,11
    Unused Channel List                     : 2,3,4,5,7,8,9,10


------------------ show ap dot11 5ghz channel ------------------


Leader Automatic Channel Assignment
  Channel Assignment Mode                   : AUTO
  Channel Update Interval                   : 600 seconds
  Anchor time (Hour of the day)             : 0
  Channel Update Contribution
    Noise                                   : Enable
    Interference                            : Enable
    Load                                    : Disable
    Device Aware                            : Disable
  CleanAir Event-driven RRM option          : Disabled
  Channel Assignment Leader                 : ewlc-doc (9.12.32.10)
  Last Run                                  : 552 seconds ago

  DCA Sensitivity Level                     : MEDIUM : 15 dB
  DCA 802.11n/ac Channel Width              : 20 MHz
  DCA Minimum Energy Limit                  : -95 dBm
  Channel Energy Levels
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : -128 dBm
  Channel Dwell Times
    Minimum                                 : unknown
    Average                                 : unknown
    Maximum                                 : unknown
  802.11a 5 GHz Auto-RF Channel List
    Allowed Channel List                    :
36,40,44,48,52,56,60,64,100,104,108,112,116,120,124,128,132,136,140,144,149,153,157,161
    Unused Channel List                     : 165


------------------ show ap dot11 24ghz coverage ------------------


Coverage Hole Detection
  802.11b Coverage Hole Detection Mode            : Enabled
  802.11b Coverage Voice Packet Count             : 100 packet(s)
  802.11b Coverage Voice Packet Percentage        : 50%
  802.11b Coverage Voice RSSI Threshold           : -80 dBm
  802.11b Coverage Data Packet Count              : 50 packet(s)
  802.11b Coverage Data Packet Percentage         : 50%
  802.11b Coverage Data RSSI Threshold            : -80 dBm
  802.11b Global coverage exception level         : 25 %
  802.11b Global client minimum exception level   : 3 clients


------------------ show ap dot11 5ghz coverage ------------------


Coverage Hole Detection
```

```
  802.11a Coverage Hole Detection Mode          : Enabled
  802.11a Coverage Voice Packet Count           : 100 packet(s)
  802.11a Coverage Voice Packet Percentage      : 50 %
  802.11a Coverage Voice RSSI Threshold         : -80dBm
  802.11a Coverage Data Packet Count            : 50 packet(s)
  802.11a Coverage Data Packet Percentage       : 50 %
  802.11a Coverage Data RSSI Threshold          : -80dBm
  802.11a Global coverage exception level       : 25 %
  802.11a Global client minimum exception level : 3 clients


------------------ show ap dot11 24ghz group ------------------


Radio RF Grouping

  802.11b Group Mode               : AUTO
  802.11b Group Update Interval    : 600 seconds
  802.11b Group Leader             : ewlc-doc (9.12.32.10)
  802.11b Last Run                 : 553 seconds ago


RF Group Members

Controller name                   Controller IP
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 5ghz group ------------------


Radio RF Grouping

  802.11a Group Mode               : AUTO
  802.11a Group Update Interval    : 600 seconds
  802.11a Group Leader             : ewlc-doc (9.12.32.10)
  802.11a Last Run                 : 553 seconds ago


RF Group Members

Controller name                   Controller IP
-------------------------------------------------
ewlc-doc                          9.12.32.10



------------------ show ap dot11 24ghz high-density ------------------


------------------ show ap dot11 5ghz high-density ------------------


------------------ show ap dot11 5ghz load-info ------------------


------------------ show ap dot11 24ghz load-info ------------------
```

```
------------------ show ap dot11 24ghz profile ------------------


Default 802.11b AP performance profiles
  802.11b Global Interference threshold    : 10 %
  802.11b Global noise threshold           : -70 dBm
  802.11b Global RF utilization threshold  : 80 %
  802.11b Global throughput threshold      : 1000000 bps
  802.11b Global clients threshold         : 12 clients


------------------ show ap dot11 5ghz profile ------------------


Default 802.11a AP performance profiles

  802.11a Global Interference threshold         : 10 %
  802.11a Global noise threshold                : -70 dBm
  802.11a Global RF utilization threshold       : 80 %
  802.11a Global throughput threshold           : 1000000 bps
  802.11a Global clients threshold              : 12 clients


------------------ show ap dot11 24ghz monitor ------------------


Default 802.11b AP monitoring
  802.11b Monitor Mode                 : Enabled
  802.11b Monitor Channels             : Country channels
  802.11b RRM Neighbor Discover Type   : Transparent
  802.11b AP Coverage Interval         : 180 seconds
  802.11b AP Load Interval             : 60 seconds
  802.11b AP Noise Interval            : 180 seconds
  802.11b AP Signal Strength Interval  : 60 seconds
  802.11b NDP RSSI Normalization       : Enabled


------------------ show ap dot11 5ghz monitor ------------------


Default 802.11a AP monitoring
  802.11a Monitor Mode                 : Enabled
  802.11a Monitor Channels             : Country channels
  802.11a RRM Neighbor Discover Type   : Transparent
  802.11a AP Coverage Interval         : 180 seconds
  802.11a AP Load Interval             : 60 seconds
  802.11a AP Noise Interval            : 180 seconds
  802.11a AP Signal Strength Interval  : 60 seconds
  802.11a NDP RSSI Normalization       : Enabled


------------------ show ap dot11 24ghz network ------------------



802.11b Network                          : Enabled
11gSupport                               : Enabled
11nSupport                               : Enabled
802.11b/g Operational Rates
  802.11b 1M                             : Mandatory
```

```
    802.11b 2M                                : Mandatory
    802.11b 5.5M                              : Mandatory
    802.11b 11M                               : Mandatory
    802.11g 6M                                : Supported
    802.11g 9M                                : Supported
    802.11g 12M                               : Supported
    802.11g 18M                               : Supported
    802.11g 24M                               : Supported
    802.11g 36M                               : Supported
    802.11g 48M                               : Supported
    802.11g 54M                               : Supported
  802.11n MCS Settings:
    MCS 0 : Supported
    MCS 1 : Supported
    MCS 2 : Supported
    MCS 3 : Supported
    MCS 4 : Supported
    MCS 5 : Supported
    MCS 6 : Supported
    MCS 7 : Supported
    MCS 8 : Supported
    MCS 9 : Supported
    MCS 10 : Supported
    MCS 11 : Supported
    MCS 12 : Supported
    MCS 13 : Supported
    MCS 14 : Supported
    MCS 15 : Supported
    MCS 16 : Supported
    MCS 17 : Supported
    MCS 18 : Supported
    MCS 19 : Supported
    MCS 20 : Supported
    MCS 21 : Supported
    MCS 22 : Supported
    MCS 23 : Supported
    MCS 24 : Supported
    MCS 25 : Supported
    MCS 26 : Supported
    MCS 27 : Supported
    MCS 28 : Supported
    MCS 29 : Supported
    MCS 30 : Supported
    MCS 31 : Supported
  802.11n Status:
    A-MPDU Tx:
      Priority 0                              : Enabled
      Priority 1                              : Disabled
      Priority 2                              : Disabled
      Priority 3                              : Disabled
      Priority 4                              : Enabled
      Priority 5                              : Enabled
      Priority 6                              : Disabled
      Priority 7                              : Disabled
      Aggregation scheduler                   : Enabled
      Realtime timeout                        : 10
    A-MSDU Tx:
      Priority 0                              : Enable
      Priority 1                              : Enable
      Priority 2                              : Enable
      Priority 3                              : Enable
      Priority 4                              : Enable
      Priority 5                              : Enable
      Priority 6                              : Disable
```

```
    Priority 7                              : Disable
  Guard Interval                            : Any
  Rifs Rx                                   : Enabled
Beacon Interval                             : 100
CF Pollable mandatory                       : Disabled
CF Poll Request Mandatory                   : Disabled
CFP Period                                  : 4
CFP Maximum Duration                        : 60
Default Channel                             : 1
Default Tx Power Level                      : 1
DTPC Status                                 : Enabled
Call Admission Limit                        :
G711 CU Quantum                             :
ED Threshold                                : -50
Fragmentation Threshold                     : 2346
RSSI Low Check                             : Disabled
RSSI Threshold                              : -127 dbm
PBCC Mandatory                              : unknown
Pico-Cell-V2 Status                         : unknown
RTS Threshold                               : 2347
Short Preamble Mandatory                    : Enabled
Short Retry Limit                           : 7
Legacy Tx Beamforming setting               : Disabled
Traffic Stream Metrics Status               : Disabled
Expedited BW Request Status                 : Disabled
EDCA profile type check                     : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM)        : Disabled
  Voice Stream-Size                         : 84000
  Voice Max-Streams                         : 2
  Voice Max RF Bandwidth                    : 75
  Voice Reserved Roaming Bandwidth          : 6
  Voice Load-Based CAC mode                 : Enabled
  Voice tspec inactivity timeout            : Enabled
CAC SIP-Voice configuration
  SIP based CAC                             : Disabled
  SIP call bandwidth                        : 64
  SIP call bandwith sample-size             : 20
Maximum Number of Clients per AP Radio      : 200


------------------ show ap dot11 5ghz network ------------------


802.11a Network                             : Enabled
11nSupport                                  : Enabled
  802.11a Low Band                          : Enabled
  802.11a Mid Band                          : Enabled
  802.11a High Band                         : Enabled
802.11a Operational Rates
  802.11a 6M                                : Mandatory
  802.11a 9M                                : Supported
  802.11a 12M                               : Mandatory
  802.11a 18M                               : Supported
  802.11a 24M                               : Mandatory
  802.11a 36M                               : Supported
  802.11a 48M                               : Supported
  802.11a 54M                               : Supported
802.11n MCS Settings:
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
```

```
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported
  MCS 6 : Supported
  MCS 7 : Supported
  MCS 8 : Supported
  MCS 9 : Supported
  MCS 10 : Supported
  MCS 11 : Supported
  MCS 12 : Supported
  MCS 13 : Supported
  MCS 14 : Supported
  MCS 15 : Supported
  MCS 16 : Supported
  MCS 17 : Supported
  MCS 18 : Supported
  MCS 19 : Supported
  MCS 20 : Supported
  MCS 21 : Supported
  MCS 22 : Supported
  MCS 23 : Supported
  MCS 24 : Supported
  MCS 25 : Supported
  MCS 26 : Supported
  MCS 27 : Supported
  MCS 28 : Supported
  MCS 29 : Supported
  MCS 30 : Supported
  MCS 31 : Supported
802.11n Status:
  A-MPDU Tx:
    Priority 0                          : Enabled
    Priority 1                          : Disabled
    Priority 2                          : Disabled
    Priority 3                          : Disabled
    Priority 4                          : Enabled
    Priority 5                          : Enabled
    Priority 6                          : Disabled
    Priority 7                          : Disabled
    Aggregation scheduler               : Enabled
    Realtime timeout                    : 10
  A-MSDU Tx:
    Priority 0                          : Enable
    Priority 1                          : Enable
    Priority 2                          : Enable
    Priority 3                          : Enable
    Priority 4                          : Enable
    Priority 5                          : Enable
    Priority 6                          : Disable
    Priority 7                          : Disable
  Guard Interval                        : Any
  Rifs Rx                               : Enabled
802.11ac                                : Enabled
  Frame burst                           : Automatic
802.11ac MCS Settings:
Beacon Interval                         : 100
CF Pollable mandatory                   : Disabled
CF Poll Request Mandatory               : Disabled
CFP Period                              : 4
CFP Maximum Duration                    : 60
Default Channel                         : 36
Default Tx Power Level                  : 1
DTPC Status                             : Enabled
Fragmentation Threshold                 : 2346
```

```
RSSI Low Check                           : Disabled
RSSI Threshold                           : -127 dbm
Pico-Cell-V2 Status                      : unknown
TI Threshold                             :
Legacy Tx Beamforming setting            : Disabled
Traffic Stream Metrics Status            : Disabled
Expedited BW Request Status              : Disabled
EDCA profile type check                  : default-wmm
Call Admision Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM)     : Disabled
  Voice Stream-Size                      : 84000
  Voice Max-Streams                      : 2
  Voice Max RF Bandwidth                 : 75
  Voice Reserved Roaming Bandwidth       : 6
  Voice Load-Based CAC mode              : Enabled
  Voice tspec inactivity timeout         : Enabled
CAC SIP-Voice configuration
  SIP based CAC                          : Disabled
  SIP call bandwidth                     : 64
  SIP call bandwith sample-size          : 20
Maximum Number of Clients per AP Radio   : 200


------------------ show ap dot11 24ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 558 seconds ago


------------------ show ap dot11 5ghz txpower ------------------


Automatic Transmit Power Assignment

Transmit Power Assignment Mode          : AUTO
Transmit Power Update Interval          : 600 seconds
Transmit Power Threshold                : -70 dBm
Transmit Power Neighbor Count           : 3 APs
Min Transmit Power                      : -10 dBm
Max Transmit Power                      : 30 dBm
Update Contribution
    Noise                               : Enable
    Interference                        : Enable
    Load                                : Disable
    Device Aware                        : Disable
Transmit Power Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                                : 558 seconds ago
```

```
------------------ show ap auto-rf dot11 5ghz ------------------


------------------ show ap auto-rf dot11 24ghz ------------------


------------------ show ap config general ------------------



------------------ show ap dot11 5ghz optimized-roaming ------------------

802.11a OptimizedRoaming

  Mode                                  : Disabled
  Reporting Interval                    : 90 seconds
  Rate Threshold                        : Disabled
  Hysteresis                            : 6 db


------------------ show ap rf-profile summary ------------------


Number of RF-profiles: 6

RF Profile Name                  Band     Description                              State
------------------------------------------------------------------------------------------
Low_Client_Density_rf_5gh        5 GHz    pre configured Low Client Density rf Up
High_Client_Density_rf_5gh       5 GHz    pre configured High Client Density r Up
Low_Client_Density_rf_24gh       2.4 GHz  pre configured Low Client Density rf Up
High_Client_Density_rf_24gh      2.4 GHz  pre configured High Client Density r Up
Typical_Client_Density_rf_5gh    5 GHz    pre configured Typical Density rfpro Up
Typical_Client_Density_rf_24gh   2.4 GHz  pre configured Typical Client Densit Up


------------------ show ap fra ------------------

FRA State                                          : Disabled
FRA Sensitivity                                    : medium (95%)
FRA Interval                                       : 1 Hour(s)
  Last Run                                         : 2299 seconds ago
  Last Run time                                    : 0 seconds

AP Name              MAC Address       Slot ID  Current-Band      COF %      Suggested Mode
------------------------------------------------------------------------------------------

COF : Coverage Overlap Factor


------------------ show wireless band-select ------------------


Band Select Probe Response   : per WLAN enabling
Cycle Count                  : 2
Cycle Threshold (millisec)   : 200
Age Out Suppression (sec)    : 20
Age Out Dual Band (sec)      : 60
Client RSSI (dBm)            : -80
Client Mid RSSI (dBm)        : -80
```

```
------------------ show wireless  country  configure ------------------


Configured Country.........................   US - United States
Configured Country Codes
        US  - United States                 802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor


------------------ show wireless tag rf summary ------------------


Number of RF Tags: 1

RF tag name                     Description
------------------------------------------------------------------------
default-rf-tag                  default RF tag


------------------ show ap tag summary ------------------


Number of APs: 0


------------------ show ap status ------------------


------------------ show ap uptime ------------------


Number of APs: 0
```

show tunnel eogre global-configuration

To display the Ethernet over GRE (EoGRE) global configuration, use the **show tunnel eogre global-configuration** command.

show tunnel eogre global-configuration

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the EoGRE global configuration:

```
Device# show tunnel eogre global-configuration

Heartbeat interval       : 60
Max Heartbeat skip count : 3
Source Interface         : (none)
```

show tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain detailed** command.

show tunnel eogre domain detailed *domain-name*

Syntax Description

domain-name	EoGRE domain name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain detailed eogre_domain

Domain Name    : eogre_domain
 Primary GW    : Tunnel1
 Secondary GW  : Tunnel2
 Active GW     : Tunnel1
 Redundancy    : Non-Revertive
```

show tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain summary** command.

show tunnel eogre domain summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain summary

Domain Name          Primary GW   Secondary GW      Active GW      Redundancy
-------------------------------------------------------------------------------
domain1              Tunnel1      Tunnel2           Tunnel1        Non-Revertive
eogre_domain         Tunnel1      Tunnel2           Tunnel1        Non-Revertive
```

show tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway, use the **show tunnel eogre gateway summary** command.

show tunnel eogre gateway summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the summary information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre gateway summary

Name               Type  Address                                    AdminState  State  Clients
-------------------------------------------------------------------------------------------------
Tunnel1             IPv4  9.51.1.11                                   Up          Up     0

Tunnel2             IPv4  9.51.1.12                                   Up          Down   0

Tunnel10            IPv6  fd09:9:8:21::90                             Down        Down   0

Tunnel11            IPv4  9.51.1.11                                   Up          Up     0

Tunnel12            IPv6  fd09:9:8:21::90                             Up          Down   0

Tunnel100           IPv4  9.51.1.100                                  Up          Down   0
```

show tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre gateway detailed** command.

show tunnel eogre gateway detailed *gateway-name*

Syntax Description

gateway-name	EoGRE gateway name.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the detailed information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre domain detailed Tunnel1

Gateway : Tunnel1
 Mode   : IPv4
 IP     : 9.51.1.11
 Source : Vlan51 / 9.51.1.1
 State  : Up
 SLA ID : 56
 MTU    : 1480
 Up Time: 4 minutes 45 seconds

 Clients
  Total Number of Wireless Clients      : 0
 Traffic
  Total Number of Received Packets      : 0
  Total Number of Received Bytes        : 0
  Total Number of Transmitted Packets   : 0
  Total Number of Transmitted Bytes     : 0
 Keepalives
  Total Number of Lost Keepalives       : 0
  Total Number of Received Keepalives   : 5
  Total Number of Transmitted Keepalives: 5
  Windows                               : 1
  Transmitted Keepalives in last window : 2
  Received Keepalives in last window    : 2
```

show tunnel eogre manager stats global

To display the global tunnel manager statistics, use the **show tunnel eogre manager stats global** command.

show tunnel eogre manager stats global

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the global tunnel manager statistics:

```
Device# show tunnel eogre manager stats global

Tunnel Global Statistics
Last Updated                    : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                      : 6
  Domains                       : 2

EoGRE Flex Objects
  AP Gateways                   : 2
  AP Domains                    : 1
  AP Gateways HA inconsistencies : 0
  AP Domains HA inconsistencies  : 0

Config events
  IOS Tunnel updates            : 806
  IOS Domain updates            : 88
  Global updates                : 48
  Tunnel Profile updates        : 120
  Tunnel Rule updates           : 16
  AAA proxy key updates         : 0

AP events
  Flex AP Join                  : 1
  Flex AP Leave                 : 0
  Local AP Join                 : 0
  Local AP leave                : 0
  Tunnel status (rx)            : 4
  Domain status (rx)            : 1
  IAPP stats msg (rx)           : 3
  Client count (rx)             : 6
  VAP Payload msg (tx)          : 4
  Domain config (tx)            : 1
  Global config (tx)            : 1
  Client delete (tx)            : 1
```

```
  Client delete per domain (tx)  : 3
  DHCP option 82 (tx)            : 4

Client events
  Add-mobile                     : 2
  Run-State                      : 3
  Delete                         : 1
  Cleanup                        : 0
  Join                           : 2
  Plumb                          : 0
  Join Errors                    : 0
  HandOff                        : 0
  MsPayload                      : 2
  FT Recover                     : 0
  Zombie GW counter increase     : 0
  Zombie GW counter decrease     : 0
  Tunnel Profile reset           : 88
  Client deauth                  : 0
  HA reconciliation              : 0

Client Join Events
  Generic Error                  : 0
  MSPayload Fail                 : 0
  Invalid VLAN                   : 0
  Invalid Domain                 : 0
  No GWs in Domain               : 0
  Domain Shut                    : 0
  Invalid GWs                    : 0
  GWs Down                       : 0
  Rule Match Error               : 0
  AAA-override                   : 0
  Flex No Active GW              : 0
  Open Auth join attempt         : 2
  Dot1x join attempt             : 2
  Mobility join attempt          : 0
  Tunnel Profile not valid       : 2
  Tunnel Profile valid           : 2
  No rule match                  : 0
  Rule match                     : 2
  AAA proxy                      : 0
  AAA proxy accounting           : 0
  AAA eogre attributes           : 0
  Has aaa override               : 0
  Error in handoff payload       : 0
  Handoff AAA override           : 0
  Handoff no AAA override        : 0
  Handoff payload received       : 0
  Handoff payload sent           : 0

SNMP Traps
  Client                         : 0
  Tunnel                         : 2
  Domain                         : 0

IPC
  IOSd TX messages               : 0

Zombie Client
  Entries                        : 0
```

show tunnel eogre manager stats instance

To display the tunnel manager statistics for a specific WNCd instance, use the **show tunnel eogre manager stats instance** command.

show tunnel eogre manager stats instance *instance-number*

Syntax Description

instance-number	WNCd instance number.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Example

This example shows how to display the tunnel manager statistics for a specific WNCd instance:

```
Device# show tunnel eogre manager stats instance 0

Tunnel Manager statistics for process instance : 0
Last Updated                      : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                        : 6
  Domains                         : 2

EoGRE Flex Objects
  AP Gateways                     : 2
  AP Domains                      : 1
  AP Gateways HA inconsistencies  : 0
  AP Domains HA inconsistencies   : 0

Config events
  IOS Tunnel updates              : 102
  IOS Domain updates              : 11
  Global updates                  : 6
  Tunnel Profile updates          : 15
  Tunnel Rule updates             : 2
  AAA proxy key updates           : 0

AP events
  Flex AP Join                    : 1
  Flex AP Leave                   : 0
  Local AP Join                   : 0
  Local AP leave                  : 0
  Tunnel status (rx)              : 4
  Domain status (rx)              : 1
  IAPP stats msg (rx)             : 3
  Client count (rx)               : 6
  VAP Payload msg (tx)            : 4
```

```
  Domain config (tx)             : 1
  Global config (tx)             : 1
  Client delete (tx)             : 1
  Client delete per domain (tx)  : 3
  DHCP option 82 (tx)            : 4

Client events
  Add-mobile                     : 2
  Run-State                      : 3
  Delete                         : 1
  Cleanup                        : 0
  Join                           : 2
  Plumb                          : 0
  Join Errors                    : 0
  HandOff                        : 0
  MsPayload                      : 2
  FT Recover                     : 0
  Zombie GW counter increase     : 0
  Zombie GW counter decrease     : 0
  Tunnel Profile reset           : 11
  Client deauth                  : 0
  HA reconciliation              : 0

Client Join Events
  Generic Error                  : 0
  MSPayload Fail                 : 0
  Invalid VLAN                   : 0
  Invalid Domain                 : 0
  No GWs in Domain               : 0
  Domain Shut                    : 0
  Invalid GWs                    : 0
  GWs Down                       : 0
  Rule Match Error               : 0
  AAA-override                   : 0
  Flex No Active GW              : 0
  Open Auth join attempt         : 2
  Dot1x join attempt             : 2
  Mobility join attempt          : 0
  Tunnel Profile not valid       : 2
  Tunnel Profile valid           : 2
  No rule match                  : 0
  Rule match                     : 2
  AAA proxy                      : 0
  AAA proxy accounting           : 0
  AAA eogre attributes           : 0
  Has aaa override               : 0
  Error in handoff payload       : 0
  Handoff AAA override           : 0
  Handoff no AAA override        : 0
  Handoff payload received       : 0
  Handoff payload sent           : 0

SNMP Traps
  Client                         : 0
  Tunnel                         : 2
  Domain                         : 0

IPC
  IOSd TX messages               : 0

Zombie Client
  Entries                        : 0
```

show wireless stats ap history

To verify historical statistics of an AP, use the **show wireless stats ap history** command.

show wireless stats ap history

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC#

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

This example shows how to verify the statistics of the access point hisory:

```
Device# show wireless stats ap history
AP Name             Radio MAC       Event      Time                Recent      Disconnect
Reason          Disconnect
                                                                   Disconnect  Reason
               Count
                                                                   Time
-------------------------------------------------------------------------------------------------
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/26/21 10:11:52  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/26/21 10:05:18  NA          Heart beat
timer expiry    1
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/22/21 17:00:39  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/22/21 16:54:54  NA          Heart beat
timer expiry    1
APA023.9FD8.EA22   40ce.24bf.8ca0  Joined     06/21/21 23:01:17  NA          NA
              NA
APA023.9FD8.EA22   40ce.24bf.8ca0  Disjoined  06/21/21 22:56:21  NA          Image Download
 Success     1
```

show wireless stat redundancy statistics client-recovery mobilityd

To view the statistics of Mobilityd configuration database, use the **show wireless stat redundancy statistics client-recovery mobilityd** command.

show wireless stat redundancy statistics client-recovery mobilityd

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the statistics of Mobilityd configuration database:

```
Device# show wireless stat redundancy statistics client-recovery mobilityd

Mobility Client Deletion Reason Statistics
------------------------------------------
Mobility Incomplete State         : 0
Inconsistency in WNCD & Mobility  : 0
Partial Delete                    : 0
General statistics
--------------------
```

show wireless stat redundancy statistics client-recovery sisf

To view the statistics for Switch Integrated Security Features (SISF) configuration database, use the **show wireless stat redundancy statistics client-recovery sisf** command.

show wireless stat redundancy statistics client-recovery sisf

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the statistics for SISF configuration database:

```
Device# show wireless stat redundancy statistics client-recovery sisf
Client SSO statistics for SISF
------------------------------
Number of recreate attempted post switchover    : 0
Number of recreate succeeded post switchover    : 0
Number of recreate failed because of no mac     : 0
Number of recreate failed because of no ip      : 0
Number of ipv4 entry recreate success           : 0
Number of ipv4 entry recreate failed            : 0
Number of ipv6 entry recreate success           : 0
Number of ipv6 entry recreate failed            : 0
Number of partial delete received               : 0
Number of client purge attempted                : 0
Number of heap and db entry purge success       : 0
Number of purge success for db entry only       : 0
Number of client purge failed                   : 0
Number of garp sent                             : 0
Number of garp failed                           : 0
Number of IP table create callbacks on standby  : 0
Number of IP table modify callbacks on standby  : 0
Number of IP table delete callbacks on standby  : 0
Number of MAC table create callbacks on standby : 0
Number of MAC table modify callbacks on standby : 0
Number of MAC table delete callbacks on standby : 0
```

show wireless stat redundancy client-recovery wncd

To view the redundancy configuration statistics for all the Wireless Network Control Daemon (WNCd) instances, use the **show wireless stat redundancy client-recovery wncd** command.

show wireless stat redundancy client-recovery wncd { *instance-id* | **all** }

Syntax Description

instance-id	Instance ID. Valid values range from 0 to 7.
all	Specifies the statistics for all WNCd instances.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the redundancy configuration statistics for all the WNCd instances:

```
Device# show wireless stat redundancy statistics client-recovery wncd all

Client SSO statistics
---------------------
No. of Clients                            : 0
No. of Clients recovered successfully     : 0
No. of Clients failed to recover          : 0
No. of Reconcile messages received from AP : 0
WNCD instance  : 0
Reconcile messages received from AP                    : 0
Reconcile clients received from AP                     : 0
Recreate attempted post switchover                     : 0
Recreate attempted by SANET                            : 0
Recreate attempted by DOT1x                            : 0
Recreate attempted by SISF                             : 0
Recreate attempted by SVC CO                           : 0
Recreate attempted by Unknown module                   : 0
Recreate succeeded post switchover                     : 0
Recreate Failed post switchover                        : 0
Recreate Failure in mmif                               : 0
Recreate Failure in co                                 : 0
Recreate Failure in sanet                              : 0
Recreate Failure in authmgr                            : 0
Recreate Failure in dot1x                              : 0
Recreate Failure in mab                                : 0
Recreate Failure in sanet_accounting                   : 0
Recreate Failure in sisf                               : 0
Recreate Failure in web auth                           : 0
Recreate Failure in lisp                               :
Recreate Failure in ipv6                               : 0
Recreate Failure in qos                                : 0
```

show wireless band-select

To display the status of the band-select configuration, use the **show wireless band-select** command in privileged EXEC mode.

show wireless band-select

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless band-select** command:

```
Device# show wireless band-select
Band Select Probe Response    : per WLAN enabling
Cycle Count                   : 2
Cycle Threshold (millisec)    : 200
Age Out Suppression (sec)     : 20
Age Out Dual Band (sec)       : 60
Client RSSI (dBm)             : 80
```

show wireless certification config

To display the wireless certification configuration summary, use the **show wireless certification config** command.

show wireless cerification config

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Dublin 17.12.1	This command was introduced.

Example

This example shows how to display the wireless certification configuration summary:

```
Device# show wireless certification config
Wireless Certification Configurations

WLANCC                                    : Not Configured
FIPS                                      : Not Configured

AP DTLS Version                           : DTLS v1.0 - v1.2
AP DTLS Cipher Suite List:

                          Ciphersuite (Implicit list)
--------------------------------------------------------------------------------
                          AES128-SHA
                          DHE-RSA-AES128-SHA
                          DHE-RSA-AES256-SHA
                          DHE-RSA-AES256-SHA256
                          ECDHE-RSA-AES128-GCM-SHA256
                          ECDHE-ECDSA-AES128-GCM-SHA256
                          ECDHE-ECDSA-AES256-GCM-SHA384
The output can vary depending on the various security modes and AP DTLS configurations.
```

show wireless client

To see the summary of the classified devices, use the **show wireless client** command.

show wireless client device {**cache** | **count** | **summary** } | **{steering**}[**chassis** {*chassis-number* | **active** | **standby** }]**R0**

Syntax Description

device	Shows classified devices.
steering	Wireless client steering information
cache	Shows the cached classified device summary.
count	Shows the wireless device count.
summary	Shows the active classified device summary.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the summary of the classified devices:

```
Device# show wireless client device summary
```

show wireless client mac-address

To view detailed information of a client using its mac-address, use the **show wireless client mac-addressdetail** command.

show wireless client mac-address *mac-address* **detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

mac-address	Client MAC address.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Usage Guidelines

The Client Scan Reports section in the output of the **show wireless client mac-address detail** is populated only for the following Apple devices:

- Any iPhone 7 and running iOS 11.0 or higher
- Any iPad after iPad Pro (1st gen, 12.9-inch, 2015) and running iOS 11.0 or higher

Other client devices, even if it supports 802.11k or is Wi-Fi Agile Multiband (MBO) certified, are not currently supported to populate the Client Scan Reports section.

Client ACLs shown under **show wireless client mac-address** <*mac address*> **detail** are ACLs applied on the client in Flexconnect local authentication case with MAB+Web authentication WLAN with AAA override enabled. This is applicable only for Express Wi-Fi by Facebook Policy on Controller. For more information about Facebook policy, see Express Wi-Fi by Facebook.

From Cisco IOS XE Amsterdam 17.3.1 onwards, the controller retains client session for 10 seconds. This feature is applicable for clients in the RUN state and is supported on central authentication with local and flex mode.

In idle state, 10 sec represents idle state timeout and 09 sec represent remaining time out of 10 sec. An example is given below:

```
Idle state timeout : 10 sec (Remaining time: 09 sec)
```

Examples

The following example shows how to see detailed client information using its MAC address:

```
Device# show wireless client mac-address 98-XX-7B-XX-EF-XX detail
```

show wireless client mac-address (Call Control)

To view call control information related to clients, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **call-control call-info**

Syntax Description

mac-address	The client MAC address.
call-control call-info	Displays the call control and IP-related information about a client.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
	This command was introduced.

This example shows how to display call control and IP-related information about a client:

```
Device# show wireless client mac-address  30e4.db41.6157 call-control call-info
Client MAC Address        : 30E4DB416157

Call 1 Statistics

Uplink IP Address         : 209.165.200.225
Downlink IP Address       : 209.165.200.226
Uplink Port               : 29052
Downlink Port             : 27538
Call ID                   : c40acb4d-3b3b0.3d27da1e-356bed03
Called Party              : sip:1011
Calling Party             : sip:1012
Priority                  : 6
Call On Hold              : false
Call Duration             : 30

Call 2 Statistics

No Active Call
```

show wireless client mac-address (TCLAS)

To view information about TCLAS and user priority, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **tclas**

Syntax Description

mac-address	The client MAC address.
tclas	Displays TCLAS and user priority-related information about a client.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to display the TCLAS and user priority-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 tclas
MAC Address      UP TID Mask Source IP Addr  Dest IP Addr    SrcPort DstPort Proto
-------------------------------------------------------------------------------
30e4.db41.6157    4   4   95 167838052       2164326668      5060     5060       6
30e4.db41.6157    6   1   31 0               2164326668      0        27538    17
```

show wireless client summary

To display a summary of active clients associated with the controller, use the **show wireless client summary** command in privileged EXEC mode.

show wireless client summary

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines

The following is sample output from the **show wireless client summary** command:

Use the **show wireless exclusionlist** command to display clients on the exclusion list.

```
Device# show wireless client summary

Number of Clients: 1

MAC Address       AP Name                 Type ID  State  Protocol  Method  Role
------------------------------------------------------------------------------------
6c40.0899.0466    9115i-r4-sw2-te1-0-37   WLAN 7   Run    11ac      None    Local
```

show wireless client timers

To display 802.11 system timers, use the **show wireless client timers** command in privileged EXEC mode.

show wireless client timers

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless client timers** command:

```
Device# show wireless client timers
 Authentication Response Timeout (seconds)      : 10
```

show wireless country

To display the configured country and the radio types supported, use the **show wireless country** command in privileged EXEC mode.

show wireless country {**channels** | **configured** | **supported** [**tx-power**]}

Syntax Description

channels	Displays the list of possible channels for each band, and the list of channels allowed in the configured countries.
configured	Display configured countries.
supported tx-power	Displays the list of allowed Tx powers in each supported country.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless country channels** command:

```
Device# show wireless country channels
  Configured Country...........................: US  - United States
      KEY: * = Channel is legal in this country and may be configured manually.
           A = Channel is the Auto-RF default in this country.
           . = Channel is not legal in this country.
           C = Channel has been configured for use by Auto-RF.
           x = Channel is available to be configured for use by Auto-RF.
         (-,-) = (indoor, outdoor) regulatory domain allowed by this country.
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
    802.11bg     :
    Channels     :                   1 1 1 1 1
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-A   ,-AB  )  US  :  A * * * * A * * * * A . . .
 Auto-RF         : . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 802.11a         :                         1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
 Channels        : 3 3 3 4 4 4 4 4 5 5 6 6 0 0 0 1 1 2 2 2 3 3 4 4 5 5 6 6
                 : 4 6 8 0 2 4 6 8 2 6 0 4 0 4 8 2 6 0 4 8 2 6 0 9 3 7 1 5
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-A   ,-AB  )  US  :  . A . A . A . A A A A A * * * * * . . . * * * A A A A *
 Auto-RF         : . . . . . . . . . . . . . . . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 4.9GHz 802.11a  :
   Channels      :                   1 1 1 1 1 1 1 1 1 1 2 2 2 2 2 2 2
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 US (-A   ,-AB  ): * * * * * * * * * * * * * * * * * * A * * * * * A
 Auto-RF         : . . . . . . . . . . . . . . . . . . . . . . . . . .
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-
```

The following is sample output from the **show wireless country configured** command:

```
Device# show wireless country configured
 Configured Country............................: US  - United States
 Configured Country Codes
        US  - United States : 802.11a Indoor,Outdoor/ 802.11b / 802.11g
```

The following is sample output from the **show wireless country supported tx-power** command:

```
Device# show wireless country supported tx-power
      KEY: ##    = Tx Power in dBm.
           ##*   = Channel supports radar detection .
           .     = Channel is not legal in this country.
           (-)   = Regulatory Domains allowed by this country.
           (-,-) = (indoor, outdoor) regulatory Domains allowed by this country.
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
    802.11bg     :
    Channels     :                   1 1 1 1 1
                 : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----------------:+-+-+-+-+-+-+-+-+-+-+-+-+-+-
 (-CE  ,-CE  )  AE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  AL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AR  )  AR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  AT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-NA  )  AU  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  BA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  BE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  BG  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-    )  BH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-A   )  BO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-AR  )  BR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  BY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-ABN )  CA  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-ABN )  CA2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  CH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-AER ,-AR  )  CL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  CM  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-CE  ,-CE  )  CN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AR  )  CO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-A   ,-AB  )  CR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  CY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  CZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  DE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  DK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-ABN )  DO  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  DZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-AB  )  EC  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-E   )  EE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  EG  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  ES  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  FI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  FR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GB  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  GR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-A   ,-NA  )  HK  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
 (-E   ,-    )  HR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  HU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-ER  )  ID  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-E   ,-E   )  IE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
 (-EI  ,-IE  )  IL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
```

```
(-I   ,-I   )  ILO :   .  .  .  . 20 20 20 20 20 20 20 20 20  .
(-A   ,-AN  )  IN  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  IQ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  IS  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  IT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-JPU ,-JPU )  J2  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPU ,-JPU )  J3  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPQU,-PQ  )  J4  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-E   ,-    )  JO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-JPU ,-JPU )  JP  :  23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-ACE ,-ACEK)  KE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-ACE ,-ACEK)  KR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KW  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  KZ  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LB  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,     )  LK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  LV  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MC  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  ME  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,     )  MO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  MT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-NA  )  MX  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-ACE ,-AEC )  MY  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  NL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  NO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-NA  )  NZ  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  OM  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-AR  )  PA  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AR  )  PE  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-ABN )  PH  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-ABN )  PH2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  PK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  PL  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-A   )  PR  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  PT  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-A   )  PY  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  QA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  RO  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  RS  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-AER ,-ER  )  RU  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-AE  ,-AE  )  SA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  SE  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-SE  )  SG  :  20 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E   ,-E   )  SI  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  SK  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-ER  )  TH  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  TN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-EI  ,-E   )  TR  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-ANT )  TW  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  UA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-A   ,-AB  )  US  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AB  )  US2 :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AB  )  USL :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-    )  USX :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-A   )  UY  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-A   ,-AR  )  VE  :  27 27 27 27 27 27 27 27 27 27 27  .  .  .
(-E   ,-E   )  VN  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
(-E   ,-E   )  ZA  :  20 20 20 20 20 20 20 20 20 20 20 20 20  .
```

show wireless detail

To display the details of the wireless parameters configured, use the **show wireless detail** command in privileged EXEC mode.

show wireless detail

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

The following parameters are displayed:

- The wireless user idle timeout
- The controller configured RF group name
- Fast SSID change

The following is sample output from the **show wireless detail** command:

```
Device# show wireless detail
User Timeout               : 300
RF network                 : default
Fast SSID                  : Disabled
```

show wireless dhcp relay statistics

To configure the wireless DHCP relay on the AP, use the **show wireless dhcp relay statistic** command.

show wireless dhcp relay statistic

Syntax Description

A.B.C.D	Indicates the target IPv4 address.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 17.3.1	This command was introduced.

Examples

The following example shows how to configure the wireless DHCP relay on the AP:

```
Device# show wireless dhcp relay statistics ip-address 10.1.1.1
```

show wireless dot11h

To see 802.11h configuration details, use the **show wireless dot11h** command.

show wireless dot11h [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the 802.11h configuration details:

```
Device# show wireless dot11h
```

show wireless dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show wireless dtls connections** command in privileged EXEC mode.

show wireless dtls connections

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless dtls connections** command:

```
Device# show wireless dtls connections
 AP Name         Local Port   Peer IP    Peer Port  Ciphersuite
------------------------------------------------------------------------
  AP-2       Capwap_Ctrl   10.0.0.16     52346      TLS_RSA_WITH_AES_128_CBC_SHA
  AP-3       Capwap_Ctrl   10.0.0.17     52347      TLS_RSA_WITH_AES_128_CBC_SHA
```

show wireless exclusionlist

To see the wireless exclusion list, use the **show wireless exclusionlist** command.

show wireless exclusionlist [**client mac-address** *client-mac-addr* **detail**] [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description

client-mac-addr	Client MAC address.
chassis-number	Enter the chassis number as either 1 or 2.
active R0	Active instance of the configuration in Route-processor slot 0.
standby R0	Standby instance of the configuration in Route-processor slot 0.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the wireless exclusion list:

```
Device# show wireless exclusionlist

Excluded Clients

MAC Address       Description          Exclusion Reason               Time Remaining
---------------------------------------------------------------------------------------
10da.4320.cce9                         Client Policy  failure          59
```

show wireless load-balancing

To display the status of the load-balancing feature, use the **show wireless load-balancing** command in privileged EXEC mode.

show wireless load-balancing

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless load-balancing** command:

```
 > show wireless load-balancing
Aggressive Load Balancing.........................: per WLAN enabling
Aggressive Load Balancing Window (clients)..................:: 5
Aggressive Load Balancing Denial Count.....................:: 3

Statistics
Total Denied Count (clients)................................:: 0
Total Denial Sent (messages)................................:: 0
Exceeded Denial Max Limit Count (times).....................:: 0
None 5G Candidate Count (times).............................:: 0
None 2.4G Candidate Count (times)...........................:: 0
```

show wireless mesh rrm dca changed

To display the Dynamic Channel Assignment (DCA) information for the last channel change on mesh backhaul, use the **show wireless mesh rrm dca changed** command.

show wireless mesh rrm dca changed

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Examples

This example shows how to display the Dynamic Channel Assignment (DCA) information for the last channel change on mesh backhaul:

```
Device# show wireless mesh rrm dca changed
Mesh Tree        : AP-E1-CXXX subtree
  Root AP Name     : AP-E1-CXXX
  Root AP slot MAC : 4xxx.0xxx.cxxx
  Radio slot id    : 1
  Radio Type       : 802.11a
  DCA reason       : Auto-DCA configured

  Mesh RRM DCA status
    Backhaul channel before DCA run : 60
    Backhaul channel width          : 40

    Mesh RRM DCA outcome
      DCA run start                  : 11/23/2023 11:28:41
      DCA run end                    : 11/23/2023 11:28:49
      DCA proposed best Channel      : 140
      Channel width                  : 40
      DCA proposed next best Channel : 52
      Channel width                  : 40
      Outcome of DCA run             : Channel change proposed
      Channel change status          : Channel change initiated

  DCA input data for latest run
    Noise Information
      Channel  36:  -82 dBm
      Channel  40:  -82 dBm
      Channel  44:  -79 dBm
      Channel  48:  -81 dBm
      Channel  52:  -82 dBm
      Channel  56:  -81 dBm
      Channel  60:  -81 dBm
      Channel  64:  -79 dBm
      Channel 100:  -81 dBm
      Channel 104:  -80 dBm
```

```
  Channel 108:  -80 dBm
  Channel 112:  -80 dBm
  Channel 116:  -79 dBm
  Channel 120:  -80 dBm
  Channel 124:  -79 dBm
  Channel 128:  -79 dBm
  Channel 132:  -80 dBm
  Channel 136:  -80 dBm
  Channel 140:  -80 dBm
  Channel 144:  -78 dBm
  Channel 149:  -80 dBm
  Channel 153:  -81 dBm
  Channel 157:  -80 dBm
  Channel 161:  -80 dBm
  Channel 165:  -81 dBm
Interference Information
  Channel  36:  -51 dBm @  3% busy
  Channel  40:  -52 dBm @  1% busy
  Channel  44:  -60 dBm @  3% busy
  Channel  48: -128 dBm @  0% busy
  Channel  52: -128 dBm @  0% busy
  Channel  56: -128 dBm @  0% busy
  Channel  60:  -53 dBm @  3% busy
  Channel  64: -128 dBm @  0% busy
  Channel 100:  -41 dBm @  2% busy
  Channel 104: -128 dBm @  0% busy
  Channel 108:  -55 dBm @  1% busy
  Channel 112: -128 dBm @  0% busy
  Channel 116: -128 dBm @  0% busy
  Channel 120: -128 dBm @  0% busy
  Channel 124: -128 dBm @  0% busy
  Channel 128:  -31 dBm @  1% busy
  Channel 132: -128 dBm @  0% busy
  Channel 136: -128 dBm @  0% busy
  Channel 140: -128 dBm @  0% busy
  Channel 144: -128 dBm @  0% busy
  Channel 149: -128 dBm @  0% busy
  Channel 153:  -52 dBm @  2% busy
  Channel 157: -128 dBm @  0% busy
  Channel 161: -128 dBm @  0% busy
  Channel 165: -128 dBm @  0% busy
Rogue Histogram (20)
  Channel  36                                :  0/ 2/ 7
  Channel  40                                :  1/ 0/ 2
  Channel  44                                :  0/ 2/ 4
  Channel  48                                :  0/ 0/ 2
  Channel  52                                :  1/ 0/ 0
  Channel  56                                :  0/ 0/ 0
  Channel  60                                :  0/ 0/ 2
  Channel  64                                :  0/ 0/ 0
  Channel 100                                :  2/ 4/ 0
  Channel 104                                :  2/ 0/ 0
  Channel 108                                :  2/ 3/ 2
  Channel 112                                :  0/ 0/ 0
  Channel 116                                :  1/ 0/ 0
  Channel 120                                :  0/ 0/ 0
  Channel 124                                :  1/ 0/ 0
  Channel 128                                :  0/ 0/ 0
  Channel 132                                :  1/ 2/ 0
  Channel 136                                :  4/ 0/ 0
  Channel 140                                :  5/ 1/ 0
  Channel 144                                :  0/ 0/ 0
  Channel 149                                :  0/ 0/ 0
  Channel 153                                :  0/ 0/ 6
```

```
  Channel 157                                 :  0/ 0/ 0
  Channel 161                                 :  0/ 0/ 0
  Channel 165                                 :  0/ 0/ 0
Load Information
  Receive Utilization  : 0%
  Transmit Utilization : 0%
  Channel Utilization  : 6%
  Attached Clients     : 0 clients
Radar Information
  Channel  36: Not detected
  Channel  40: Not detected
  Channel  44: Not detected
  Channel  48: Not detected
  Channel  52: Not detected
  Channel  56: Not detected
  Channel  60: Not detected
  Channel  64: Not detected
  Channel 100: Not detected
  Channel 104: Not detected
  Channel 108: Not detected
  Channel 112: Not detected
  Channel 116: Not detected
  Channel 120: Not detected
  Channel 124: Not detected
  Channel 128: Not detected
  Channel 132: Not detected
  Channel 136: Not detected
  Channel 140: Not detected
  Channel 144: Not detected
  Channel 149: Not detected
  Channel 153: Not detected
  Channel 157: Not detected
  Channel 161: Not detected
  Channel 165: Not detected
Client Data
  802.11ac clients     : 0
  802.11n clients      : 0
  802.11a clients      : 0
  Voice clients        : 0
  Video clients        : 0
  802.11ac 160 clients : 0
  Total Clients        : 0
```

show wireless mesh rrm dca status

To display the status of the last DCA run per radio, use the **show wireless mesh rrm dca status** command.

show wireless mesh rrm dca status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.9.1	This command was introduced.

Example

This example shows how to display the status of the last DCA run per radio:

```
Device# show wireless mesh rrm dca status
Mesh Tree        : AP-E1-CBA0 subtree
  Root AP Name     : AP-E1-CBA0
  Root AP slot MAC : 488b.0a78.cba0
  Radio slot id    : 1
  Radio Type       : 802.11a
  DCA status       : Not Running
  DCA reason       : N/A

  Mesh RRM DCA status
    Backhaul channel before DCA run : 112
    Backhaul channel width          : 40

    Mesh RRM DCA outcome
      DCA run start                  : 06/04/2025 11:25:03
      DCA run end                    : 06/04/2025 11:25:11
      DCA proposed best Channel      : 112
      Channel width                  : 40
      DCA proposed next best Channel : 149
      Channel width                  : 40
      Outcome of DCA run             : Channel change not proposed
      Channel change status          : Channel change not applicable

  DCA input data for latest run
    Noise Information
      Channel  36:  -78 dBm
      Channel  40:  -77 dBm
      Channel  44:  -81 dBm
      Channel  48:  -81 dBm
      Channel  52:  -80 dBm
      Channel  56:  -80 dBm
      Channel  60:  -80 dBm
      Channel  64:  -78 dBm
      Channel 100:  -79 dBm
      Channel 104:  -78 dBm
```

```
  Channel 108:  -79 dBm
  Channel 112:  -80 dBm
  Channel 116:  -80 dBm
  Channel 120:  -80 dBm
  Channel 124:  -79 dBm
  Channel 128:  -79 dBm
  Channel 132:  -80 dBm
  Channel 136:  -77 dBm
  Channel 140:  -79 dBm
  Channel 144:  -78 dBm
  Channel 149:  -80 dBm
  Channel 153:  -76 dBm
  Channel 157:  -80 dBm
  Channel 161:  -78 dBm
  Channel 165:  -79 dBm
Interference Information
  Channel  36:  -48 dBm @ 12% busy
  Channel  40:  -52 dBm @  1% busy
  Channel  44:  -50 dBm @  7% busy
  Channel  48:  -54 dBm @  2% busy
  Channel  52:  -41 dBm @  1% busy
  Channel  56:  -54 dBm @  2% busy
  Channel  60:  -44 dBm @  1% busy
  Channel  64:  -51 dBm @  9% busy
  Channel 100:  -46 dBm @  1% busy
  Channel 104: -128 dBm @  0% busy
  Channel 108: -128 dBm @  0% busy
  Channel 112:  -59 dBm @  2% busy
  Channel 116:  -46 dBm @  2% busy
  Channel 120: -128 dBm @  0% busy
  Channel 124: -128 dBm @  0% busy
  Channel 128: -128 dBm @  0% busy
  Channel 132:  -47 dBm @  2% busy
  Channel 136:  -55 dBm @  2% busy
  Channel 140:  -43 dBm @  1% busy
  Channel 144: -128 dBm @  0% busy
  Channel 149:  -49 dBm @  4% busy
  Channel 153:  -50 dBm @  4% busy
  Channel 157:  -46 dBm @  2% busy
  Channel 161:  -54 dBm @  2% busy
  Channel 165:  -41 dBm @  1% busy
Rogue Histogram (20)
  Channel  36                                : 18/ 5/ 4
  Channel  40                                :  3/ 0/ 3
  Channel  44                                :  2/ 1/ 2
  Channel  48                                :  1/ 0/ 3
  Channel  52                                :  0/ 0/ 0
  Channel  56                                :  0/ 0/ 1
  Channel  60                                :  0/ 0/ 0
  Channel  64                                :  0/ 0/10
  Channel 100                                :  0/ 1/ 0
  Channel 104                                :  0/ 0/ 0
  Channel 108                                :  0/ 0/ 0
  Channel 112                                :  0/ 0/ 0
  Channel 116                                :  1/ 2/ 0
  Channel 120                                :  0/ 0/ 0
  Channel 124                                :  0/ 1/ 0
  Channel 128                                :  0/ 0/ 0
  Channel 132                                :  1/ 2/ 0
  Channel 136                                :  1/ 0/ 0
  Channel 140                                :  2/ 1/ 0
  Channel 144                                :  0/ 0/ 0
  Channel 149                                :  0/ 1/10
  Channel 153                                :  0/ 0/ 0
```

```
  Channel 157                                 :  0/ 0/ 0
  Channel 161                                 :  0/ 0/ 2
  Channel 165                                 :  1/ 0/ 0
Load Information
  Receive Utilization  : 0%
  Transmit Utilization : 0%
  Channel Utilization  : 14%
  Attached Clients     : 0 clients
Radar Information
  Channel  36: Not detected
  Channel  40: Not detected
  Channel  44: Not detected
  Channel  48: Not detected
  Channel  52: Not detected
  Channel  56: Not detected
  Channel  60: Not detected
  Channel  64: Not detected
  Channel 100: Not detected
  Channel 104: Not detected
  Channel 108: Not detected
  Channel 112: Not detected
  Channel 116: Not detected
  Channel 120: Not detected
  Channel 124: Not detected
  Channel 128: Not detected
  Channel 132: Not detected
  Channel 136: Not detected
  Channel 140: Not detected
  Channel 144: Not detected
  Channel 149: Not detected
  Channel 153: Not detected
  Channel 157: Not detected
  Channel 161: Not detected
  Channel 165: Not detected
Client Data
  802.11ac clients     : 0
  802.11n clients      : 0
  802.11a clients      : 0
  Voice clients        : 0
  Video clients        : 0
  802.11ac 160 clients : 0
  Total Clients        : 0
```

show wireless ewc-ap ap summary

To view the embedded wireless controller AP summary , use the **show wireless ewc-ap ap summary** command.

show wireless ewc-ap ap summary [**chassis** {*chassis_number* |**active** | **standby**} {**R0**}]

Syntax Description

ewc-ap	Configures the embedded wireless controller parameters.
ap summary	Displays the embedded wireless controller AP, AP summary.
chassis	Indicates the details of the chassis.
chassis-number	Indicates the chassis number, which is either 1 or 2..
R0	Indicates Route Processor slot 0.
Active	Indicates the active operational mode of the AP chassis.
Standby	Indicates the standby operational mode of the AP chassis.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the embedded wireless controller, AP summary:

```
Device#show wireless ewc-ap ap summary
```

show wireless ewc-ap ap config-sync

To view the embedded wireless controller AP configuration synchronization information or summary, use the **show wireless ewc-ap ap config-sync** command.

show wireless ewc-ap ap config-sync summary [**chassis** {*chassis_number* | **active** | **standby**} {**R0**}]

Syntax Description

config-sync	Configures the embedded wireless controller parameters.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the embedded wireless controller AP configuration synchronization information or summary:

```
Device#show wireless ewc-ap ap config-sync summary
```

show wireless ewc-ap ap image predownload status

To view the AP image predownload statistics, use the **show wireless ewc-ap ap image predownload status** command.

show wireless ewc-ap ap image predownload status

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

Usage Guidelines

None

Example

The following example shows how to view the AP image predownload statistics:

```
Device#show wireless ewc-ap ap image predownload status
```

show wireless ewc-ap country-code

To view the default country codes and the supported country codes of the embedded wireless controller AP, use the **show wireless ewc-ap country-code** command.

show wireless ewc-ap country-code [**chassis** {*chassis_number* |**active** | **standby**} {**R0**}]

Syntax Description

country-code	Indicates the default country codes and the supported country codes.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the default and supported country codes of embedded wireless controller AP:

```
Device#show wireless ewc-ap country-codes
```

show wireless ewc-ap image-master

To view the image maser information, use the **show wireless ewc-ap image-master** command.

show wireless ewc-ap image-master [**chassis** {*chassis_number* |**active** | **standby**} {**R0**}]

Syntax Description

image-master	Indicates the image master information.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the image master information:

```
Device#show wireless ewc-ap image-master
```

show wireless ewc-ap invalid-image-master

To view the details of the invalid image master, use the **show wireless ewc-ap invalid-image-master** command.

show wireless ewc-ap invalid-image-master [**chassis** {*chassis_number* | **active** | **standby**} {**R0**}]

Syntax Description

invalid-image-master	Indicates the invalid image master information.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the invalid image master information:

```
Device#show wireless ewc-ap invalid-image-master
```

show wireless ewc-ap predownload

To view the image predownload information, use the **show wireless ewc-ap predownload** command.

show wireless ewc-ap predownload {**count** | **status**} [**chassis** {*chassis_number* | **active** | **standby**} {**R0**}]

Syntax Description

predownload	Indicates the image predownload information.
count	Indicates the image predownload count.
status	Indicates the image predownload status.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

Example

The following example shows how to view the image predownload count and status:

```
Device#show wireless ewc-ap predownload
```

show wireless ewc-ap redundancy summary

To view the HA redundancy summary, use the **show wireless ewc-ap redundancy summary** command.

show wireless ewc-ap redundancy summary [**chassis** {*chassis_number* | **active** | **standby**} {**R0**}]

Syntax Description

redundancy	Indicates the HA redundancy information.
summary	Indicates the summary of HA redundancy.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to view the default and supported country codes of embedded wireless controller AP:

```
Device#show wireless ewc-ap redundancy summary
```

show wireless ewc-ap redundancy peers

To view the HA redundancy peers, use the **show wireless ewc-ap redundancy peers** command.

show wireless ewc-ap redundancy peers [**chassis** {*chassis_number* | **active** | **standby**} {**R0**}]

Syntax Description

redundancy	Indicates the HA redundancy information.
peers	Indicates the peers of HA redundancy.

Command Default

None

Command Modes

Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Example

The following example shows how to view the default and supported country codes of embedded wireless controller AP:

```
Device#show wireless ewc-ap redundancy peers
```

show wireless mesh ethernet daisy-chain summary

To verify the ethernet daisy chain summary, use the **show wireless mesh ethernet daisy-chain summary** command.

show wireless mesh ethernet daisy-chain summary

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to verify the ethernet daisy chain summary:

```
Device# show wireless mesh ethernet daisy-chain summary

AP Name BVI MAC         BGN   Backhaul   Ethernet      STP Red
-----------------------------------------------------------------------------------------------------
RAP4    683b.78bf.15f0  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP3    683b.78bf.1634  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP1    6c8b.d383.b4d4  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP2    6c8b.d383.b4e8  IOT  Ethernet0   Up Up Up Dn   Enabled
```

show wireless mesh ethernet daisy-chain bgn

To verify the ethernet daisy chain Bridge Group Name (BGN) details, use the **show wireless mesh ethernet daisy-chain bgn** command.

show wireless mesh ethernet daisy-chain bgn *bridge-group-name*

Syntax Description

bridge-group-name	Enter the bridge group name.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Bengaluru 17.4.1	This command was introduced.

The following example shows how to verify the ethernet daisy chain Bridge Group Name (BGN) details:

```
Device# show wireless mesh ethernet daisy-chain bgn <IOT>

AP Name   BVI MAC       BGN  Backhaul    Ethernet      STP Red
-----------------------------------------------------------------------------------------------------
RAP4    683b.78bf.15f0  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP3    683b.78bf.1634  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP1    6c8b.d383.b4d4  IOT  Ethernet0   Up Up Dn Dn   Enabled
RAP2    6c8b.d383.b4e8  IOT  Ethernet0   Up Up Up Dn   Enabled
```

show wireless pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show wireless pmk-cache** command in privileged EXEC mode.

show wireless pmk-cache[**mac-address** *mac-addr*]

Syntax Description

mac-address *mac-addr*	(Optional) Information about a single entry in the PMK cache.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless pmk-cache mac-address** command:

```
Device# show wireless pmk-cache mac-address H.H.H
Number of PMK caches in total : 0
```

show wireless profile flex

To see the flex parameters of an wireless profile, use the **show wireless profile flex** command.

show wireless profile flex { **detailed** *flex-profile-name* **chassis** {*chassis-number* | **active** | **standby** }**R0** } | **summary chassis** {*chassis-number* | **active** | **standby**}**R0**}

Syntax Description

detailed	Shows the flex-profile detailed parameters
summary	Show the flex-profile summary.
chassis-number	Chassis number. Valid range is 1–2.
active	Active instance.
standby	Standby instance.
R0	Route-Processor slot 0.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the flex parameter's summary of the wireless profile:

```
Device# show wireless profile flex summary
```

show wireless profile policy detailed

To display the wireless policy profile details, use the **show wireless profile policy detailed** command.

show wireless profile policy detailed *policy-profile-name*

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privilege EXEC (#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

Example

This example displays the wireless policy profile details:

```
Device#show wireless profile policy detailed policy-profile-name
```

show wireless profile urwb detailed

To view the detailed parameters of the URWB profile, use the **show wireless profile urwb detailed** *urwb-profile-name*

show wireless profile radio detailed *urwb-profile-name*

Syntax Description

urwb-profile-name	Specifies the name of the URWB profile.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 17.18.1	This command was introduced.

Examples

The following example shows how to view the detailed parameters of the URWB profile:

```
Device# show wireless profile radio detailed urwb-profile-name
```

show wireless rfid

To display RFID tag information, use the **show wireless rfid** command in privileged EXEC mode.

show wireless rfid {**client** | **detail** *rfid-mac-address* | **stats** | **summary**}

Syntax Description

client	Displays the summary of RFID tags that are clients.
detail	Displays information about a particular RFID tag.
stats	Displays RFID statistics.
summary	Displays summary information for all known RFID tags.
rfid-mac-address	RFID MAC address.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Example

This example shows how to view RFID information:

```
Device# show wireless rfid summary

Total RFID entries: : 16
Total Unique RFID entries : 16
RFID ID VENDOR Closet AP RSSI Time Since Last Heard
0012.b80a.c791 Cisco 7069.5a63.0520 -31 1 minute 40 seconds ago
0012.b80a.c953 Cisco 7069.5a63.0460 -33 2 minutes 15 seconds ago
0012.b80b.806c Cisco 7069.5a63.0260 -45 22 seconds ago
0012.b80d.e9f9 Cisco 7069.5a63.0460 -38 2 minutes 37 seconds ago
0012.b80d.ea03 Cisco 7069.5a63.0520 -43 2 minutes 38 seconds ago
0012.b80d.ea6b Cisco 7069.5a63.0460 -39 2 minutes 35 seconds ago
0012.b80d.ebe8 Cisco 7069.5a63.0520 -43 1 minute 31 seconds ago
0012.b80d.ebeb Cisco 7069.5a63.0520 -43 2 minutes 37 seconds ago
0012.b80d.ec48 Cisco 7069.5a63.0460 -42 2 minutes 16 seconds ago
0012.b80d.ec55 Cisco 7069.5a63.0520 -41 1 second ago
```

show wireless stats client delete reasons

To verify total client delete reasons, use the **show wireless stats client delete reasons** command.

show wireless stats client delete reasons

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Privileged EXEC(#)

Command History

Release	Modification
Cisco IOS XE Amsterdam 17.1.1	This command was introduced.

This example shows how to verify the total client delete reasons:

```
Device# show wireless stats client delete reasons

Total client delete reasons
---------------------------
Controller deletes
---------------------------
---------------------------
No Operation                                                  : 0
Unknown                                                       : 0
Session Manager                                               : 0
Connection timeout                                            : 0
Datapath plumb                                                : 0
WPA key exchange timeout                                      : 0
802.11w MAX SA queries reached                                : 0
Client deleted during HA recovery                             : 0
Inter instance roam failure                                   : 0
Inter instance roam success                                   : 0
Inter controller roam success                                 : 0
Due to mobility failure                                       : 0
NAS error                                                     : 0
Policy Manager internal error                                 : 0
80211v smart roam failed                                      : 0
DOT11v association failed                                     : 0
DOT11r pre-authentication failure                             : 0
SAE authentication failure                                    : 0
DOT11 failure                                                 : 0
DOT11 SAE invalid message                                     : 0
DOT11 denied data rates                                       : 0
802.11v Client RSSI lower than the association RSSI threshold   : 0
invalid QoS parameter                                         : 0
DOT11 IE validation failed                                    : 0
DOT11 group cipher in IE validation failed                    : 0
DOT11 invalid pairwise cipher                                 : 0
DOT11 invalid AKM                                             : 0
DOT11 unsupported RSN version                                 : 0
DOT11 invalid RSNIE capabilities                              : 0
DOT11 received invalid PMKID in the received RSN IE           : 0
```

```
DOT11 received invalid PMK length                                : 0
DOT11 invalid MDIE                                               : 0
DOT11 invalid FT IE                                              : 0
DOT11 AID allocation conflicts                                   : 0
AVC client re-anchored at the foreign controller                 : 0
Client EAP ID timeout                                            : 0
Client DOT1x timeout                                             : 0
Malformed EAP key frame                                          : 0
EAP key install bit is not expected                              : 0
EAP key error bit is not expected                                : 0
EAP key ACK bit is not expected                                  : 0
Invalid key type                                                 : 0
EAP key secure bit is not expected                               : 0
key description version mismatch                                 : 0
wrong replay counter                                             : 0
EAP key MIC bit expected                                         : 0
MIC validation failed                                            : 0
MAC theft                                                        : 0
IP theft                                                         : 0
Policy bind failure                                              : 0
Web authentication failure                                       : 0
802.1X authentication credential failure                         : 0
802.1X authentication timeout                                    : 0
802.11 authentication failure                                    : 0
802.11 association failure                                       : 0
Manually excluded                                                : 0
DB error                                                         : 0
Anchor creation failure                                          : 0
Anchor invalid Mobility BSSID                                    : 0
Anchor no memory                                                 : 0
Call admission controller at anchor node                         : 0
Supplicant restart                                               : 0
Port admin disabled                                              : 0
Reauthentication failure                                         : 0
Client connection lost                                           : 0
Error while PTK computation                                      : 0
MAC and IP theft                                                 : 0
QoS policy failure                                               : 0
QoS policy send to AP failure                                    : 0
QoS policy bind on AP failure                                    : 0
QoS policy unbind on AP failure                                  : 0
Static IP anchor discovery failure                               : 0
VLAN failure                                                     : 0
ACL failure                                                      : 0
Redirect ACL failure                                             : 0
Accounting failure                                               : 0
Security group tag failure                                       : 0
FQDN filter definition does not exist                            : 0
Wrong filter type, expected postauth FQDN filter                 : 0
Wrong filter type, expected preauth FQDN filter                  : 0
Invalid group id for FQDN filter valid range  1..16              : 0
Policy parameter mismatch                                        : 0
Reauth failure                                                   : 0
Wrong PSK                                                        : 0
Policy failure                                                   : 0
AAA server unavailable                                           : 0
AAA server not ready                                             : 0
No dot1x method configuration                                    : 0
Association connection timeout                                   : 0
MAC-AUTH connection timeout                                      : 0
L2-AUTH connection timeout                                       : 0
L3-AUTH connection timeout                                       : 0
Mobility connection timeout                                      : 0
static IP connection timeout                                     : 0
```

```
SM session creation timeout                                 : 0
IP-LEARN connection timeout                                 : 0
NACK IFID exists                                            : 0
Guest-LAN invalid MBSSID                                    : 0
Guest-LAN no memory                                         : 0
Guest-LAN ceate request failed                              : 0
EoGRE Reset                                                 : 0
EoGRE Generic Join Failure                                  : 0
EoGRE HA-Reconciliation                                     : 0
Wired idle timeout                                          : 0
IP Update timeout                                           : 0
SAE Commit received in Associated State                     : 0
NACK IFID mismatch                                          : 0
EoGRE Invalid VLAN                                          : 0
EoGRE Empty Domain                                          : 0
EoGRE Invalid Domain                                        : 0
EoGRE Domain Shut                                           : 0
EoGRE Invalid Gateway                                       : 0
EoGRE All Gateways down                                     : 0
EoGRE Flex - no active gateway                              : 0
EoGRE Rule Matching error                                   : 0
EoGRE AAA Override error                                    : 0
EoGRE client onboarding error                               : 0
EoGRE Mobility Handoff error                                : 0
L3 VLAN Override connection timeout                         : 0
Delete received from AP                                     : 0
QoS failure                                                 : 0
WPA group key update timeout                                : 0
DOT11 unsupported client capabilities                       : 0
DOT11 association denied unspecified                        : 0
DOT11 AP have insufficient bandwidth                        : 0
DOT11 invalid QoS parameter                                 : 0
Client not allowed by assisted roaming                      : 0
Wired client deleted due to WGB delete                      : 0
Client Abort                                                : 0
Mobility peer delete                                        : 0
No IP                                                       : 0
BSSID down                                                  : 0
DOT11 QoS policy                                            : 0
Roam across policy profile deny                             : 0
4WAY handshake failure - M1 issue                           : 0
4WAY handshake failure - M3 issue                           : 0
Exclusion policy template fail                              : 0
DOT11 Cipher Suite Rejected                                 : 0
WLAN-ID mismatch in access accept failures                  : 0
EasyPSK AAA unknown error                                   : 0
EasyPSK unspecified error                                   : 0
EasyPSK PSK mismatch error                                  : 0
EasyPSK radius busy error                                   : 0
EasyPSK limit reached error                                 : 0
EasyPSK bad 802.1X frame error                              : 0
EasyPSK missing parameter error                             : 0
Supplicant name failure                                     : 0
User name failure                                           : 0
Service set ID failure                                      : 0
Anchor VLAN ID failure                                      : 0
PSK failure                                                 : 0
PSK mode failure                                            : 0
Interim interval failure                                    : 0
Link-local bridging VLAN failure                            : 0
Link-local bridging VLAN failure                            : 0
Maximum client limit reached on AP                          : 0
Maximum client limit reached on AP per wlan                 : 0
Maximum client limit reached on AP radio per wlan           : 0
```

```
Maximum client limit reached on AP radio                        : 0
L3 Access Roam across policy profile deny                       : 0
L3 Access Inter controller roam deny                            : 0
----------------------------
Informational Delete Reason
----------------------------
Mobility WLAN down                                              : 0
AP upgrade                                                      : 0
L3 authentication failure                                       : 0
AP down/disjoin                                                 : 0
MAC authentication failure                                      : 0
Due to SSID change                                              : 0
Due to VLAN change                                              : 0
Admin deauthentication                                          : 0
Session timeout                                                 : 0
Idle timeout                                                    : 0
Supplicant request                                              : 0
Mobility tunnel down                                            : 0
DOT11v timer timeout                                            : 0
DOT11 max STA                                                   : 0
IAPP disassociation for wired client                            : 0
Wired WGB change                                                : 0
Wired VLAN change                                               : 0
WGB Wired client joins as a direct wireless client              : 0
Incorrect credentials                                           : 0
Wired client cleanup due to WGB roaming                         : 0
Radio Down                                                      : 0
Mobility failure on fast roam                                   : 0
Due to IP Zone change                                           : 0
Access denied due to Locally Administered MAC Address           : 0
----------------------------
----------------------------
Client initiate delete
----------------------------
Deauthentication or disassociation request                      : 0
Client DHCP                                                     : 0
Client EAP timeout                                              : 0
Client 8021x failure                                            : 0
Client device idle                                              : 0
Client captive portal security failure                          : 0
Client decryption failure                                       : 0
Client interface disabled                                       : 0
Client user triggered disassociation                            : 0
Client miscellaneous reason                                     : 0
Unknown                                                         : 0
Client peer triggered                                           : 0
Client beacon loss                                              : 0
STA triggered PMK timeout                                  : 0
Excess ARP activity                                        : 0
Excess NDP activity                                        : 0
Unspecified QOS failure                                       : 0
Dpath encode failed                                           : 0
VRF-VLAN mismatch failures                                   : 0
----------------------------
AP Deletes
----------------------------
When client is sending disassociation                      : 0
Idle timeout                                               : 0
Client ACL mismatch                                        : 0
AP authentication stop                                     : 0
Association expired at AP                                  : 0
4-way handshake failed                                     : 0
DHCP timeout                                               : 0
Reassociation timeout                                      : 0
```

```
SA query timeout                                          : 0
Intra AP roam                                             : 0
Channel switch at AP                                      : 0
Bad AID                                                   : 0
AP requests for client deletion                           : 0
Interface reset                                           : 0
All on slot                                               : 0
Link to client has changed and uplink can be reaper       : 0
Slot disable                                              : 0
MIC failure                                               : 0
VLAN delete                                               : 0
Channel change                                            : 0
Stop reassociation                                        : 0
Packet maximum retry                                      : 0
Transmission deauthentication                             : 0
Sensor station timeout                                    : 0
Age timeout                                               : 0
Transmission threshold fail                               : 0
Uplink receive timeout                                    : 0
Sensor scan next radio                                    : 0
Sensor scan other BSSID                                   : 0
Authentication timeout and web-auth timeout               : 0
Sending deauthentication packet to client                 : 0
AP IP learn timeout                                       : 0
Flex group change                                         : 0
EAPOL log off                                             : 0
EAP request timeout                                       : 0
4way handshake failure                                    : 0
MIC validation                                            : 0
Wrong replay counter                                      : 0
AP tunnel down                                            : 0
Inter roam                                                : 0
Unknown client                                            : 0
Reauthentication timeout                                  : 0
Continuous idle timeout                                   : 0
RLDP cleanup                                              : 0
Intra-switch roam                                         : 0
PEM cleanup                                               : 0
RLAN Central switch                                       : 0
RLAN data path add failure                                : 0
RLAN Delete                                               : 0
RLAN Inactive timeout                                     : 0
RLAN MAB failure                                          : 0
CLSM No memory counter                                    : 0
CLSM BSSID mismatch                                       : 0
CLSM No ACL found                                         : 0
CLSM no parent WGB found                                  : 0
CLSM Key plumb faiure                                     : 0
CLSM Mesh key plumb failure                               : 0
CLSM data path add fail                                   : 0
CLSM Authentication response reject                       : 0
CLSM Authentication response send failure                 : 0
CLSM Association response send failure                    : 0
CLSM association response failure with status             : 0
CLSM Webauth timer expired                                : 0
CLSM Dot1x timer expired                                  : 0
CLSM deauthentication and disassociation send failure     : 0
Driver event Class3 received                              : 0
Driver event PsPoll when not authenticated                : 0
Driver event ioctl error                                  : 0
Flex FT failure                                           : 0
CLSM driver add failure                                   : 0
Driver client not found                                   : 0
Driver management packet allocation failure               : 0
```

```
Driver invalid cipher                                        : 0
Driver invalid association identifier                        : 0
Driver invalid key                                           : 0
Driver firmware set key failure                              : 0
Driver found invalid HT VHT rates                            : 0
Driver found invalid legacy rates                            : 0
Driver found no overlapping legacy rates                     : 0
Driver found maximum VHT streams                             : 0
Driver found association identifer in use                    : 0
Driver found too many association requests                   : 0
Driver found cipher attach failure                           : 0
Driver found algorithm mismatch                              : 0
Driver found invalid key length                              : 0
Driver found invalid key index                               : 0
Driver rejected association due to authentication failure    : 0
Driver found client addition to internal records failure     : 0
Driver found client association entry failure                : 0
Driver found client additions to firmware failure            : 0
Driver related internal failure                              : 0
AP limiting maximum client per AP                            : 0
AP limiting maximum client per AP radio per wlan             : 0
AP limiting maximum client per AP radio                      : 0
-------------------
PC Analytics stats:
---------------------------------------
Report Type            Processed Reports
---------------------------------------
 PC_STA_INFO          : 0
 PC_NEIGH_INFO        : 0
 PC_LOW_RSSI          : 0
 PC_TEMP_DISCONN      : 0
 PC_AP_FAILURE        : 0
 PC_UNKNOWN_AP        : 0
---------------------------------------
Report Type            Dropped Reports
---------------------------------------
 PC_STA_INFO          : 0
 PC_NEIGH_INFO        : 0
 PC_LOW_RSSI          : 0
 PC_TEMP_DISCONN      : 0
 PC_AP_FAILURE        : 0
 PC_UNKNOWN_AP        : 0
```

show wireless stats redundancy config database

To view the high availabilty redundancy configuration statistics, use the **show wireless stats redundancy config database** command.

show wireless stats redundancy config database { **mobility** | **nmspd** | **rrm** | **wncd** | **wncmgrd** } *instance-id* **chassis** { *chassis-num* | **active** | **standby** } **R0**

Syntax Description

mobility	Specifes the statistics of Mobilityd configuration database.
nmspd	Specifes the statistics of NMSPD configuration database.
rrm	Specifes the statistics of RRM configuration database.
wncd	Specifes the statistics of WNCD configuration database.
wncmgrd	Specifes the statistics of WNCD configuration database.
instance-id	Instance ID. Valid values range from 0 to 7.
chassis	Specifies the chassis.
chassis-num	Chassis number.
active	Specifies the active instance.
standby	Specifies the standby instance.
R0	Specifies the route processor slot.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Cupertino 17.7.1	This command was introduced.

Examples

The following example shows how to view the high availabilty redundancy configuration statistics:

```
Device# show wireless stats redundancy config database wncd 0 chassis 1 R0

Wncd Configuration Sync Statistics
 Index   Number of Locks    Duration(sec)   Threshold-count   Max-Duration(nsec)
--------------------------------------------------------------------------------
    1        535               127              1           1112156700
```

show wireless summary

To display the number of access points, radios and wireless clients known to the controller, use the **show wireless summary** command in privileged EXEC mode.

show wireless summary

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

The following is sample output from the **show wireless summary** command:

```
Device# show wireless summary

Access Point Summary

               Total    Up    Down
-----------------------------------
802.11a/n          2     2       0
802.11b/g/n        2     2       0
All APs            2     2       0

Client Summary

Current Clients : 1
Excluded Clients: 0
Disabled Clients: 0
```

show wireless urlfilter details

To view the details of a specified wireless URL filter, use the **show wireless urlfilter details** command.

show wireless urlfilter details *list-name*

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the details of a specified wireless URL filter:

```
Device# show wireless urlfilter details urllist_flex_preauth
List Name..................... : urllist_flex_preauth
Filter ID..................... : : 1
Filter Type................... : PRE-AUTH
Action........................ : PERMIT
Redirect server ipv4...... : 8.8.8.8
Redirect server ipv6...... : 2001:0300:0008:0000:0000:0000:0000:0081
Configured List of URLs
   URL........................ : url1.dns.com
```

show wireless urlfilter summary

To view the summary of all wireless URL filters, use the **show wireless urlfilter summary** command.

show wireless urlfilter summary

Syntax Description

This command has no arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of all wireless URL filters:

```
Device# show wireless urlfilter summary
Black-list    - DENY
White-list    - PERMIT
Filter-Type   - Specific to Local Mode

URL-List                          ID  Filter-Type  Action   Redirect-ipv4  Redirect-ipv6
-------------------------------------------------------------------------------------------------------
urllist_flex_preauth              1    PRE-AUTH     PERMIT    8.8.8.8
2001:0300:0008:0000:0000:0000:0000:0081
```

show wireless vlan details

To see the VLAN details, use the **show wireless vlan details** command.

show wireless vlan details [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the VLAN details:

```
Device# show wireless vlan details chassis active r0
```

show wireless wgb mac-address

To view all the clients of the wireless workgroup bridge (WGB) using its MAC address, use the **show wireless wgb mac-address** command.

show wireless wgb mac-address *mac-address* **detail**

Syntax Description

mac-address	MAC address of the WGB.
detail	View clients of the wireless WGB.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the clients of the wireless WGB:

```
Device# show wireless wgb mac-address 98-C7-7B-09-EF-ED detail
```

show wireless wgb summary

To see the active workgroup bridges (WGB), use the **show wireless wgb summary** command.

show wireless wgb summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

Examples

The following example shows how to see the active workgroup bridges (WGB):

```
Device# show wireless wgb summary
```

show wireless wps rogue ap summary

To display a list of all rogue access points detected by the device, use the **show wireless wps rogue ap summary** command.

show wireless wps rogue ap summary

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to display a list of all rogue access points detected by the device:

```
Device# show wireless wps rogue ap summary
Rogue Location Discovery Protocol            : Disabled
Rogue on wire Auto-Contain                   : Disabled
Rogue using our SSID Auto-Contain            : Disabled
Valid client on rogue AP Auto-Contain        : Disabled
Rogue AP timeout                             : 1200
Rogue Detection Report Interval              : 10
Rogue AP minimum RSSI                        : -128
Rogue AP minimum transient time              : 0

Number of rogue APs detected : 624

MAC Address         Classification     # APs    # Clients   Last Heard
-------------------------------------------------------------------------------------
0018.e78d.250a      Unclassified       1        0           Thu Jul 25 05:04:01 2013
0019.0705.d5bc      Unclassified       1        0           Thu Jul 25 05:16:26 2013
0019.0705.d5bd      Unclassified       1        0           Thu Jul 25 05:10:28 2013
0019.0705.d5bf      Unclassified       1        0           Thu Jul 25 05:16:26 2013
```

show wireless wps rogue client detailed

To view the detailed information of a specific rogue client, use the **show wireless wps rogue client detailed** *client-mac* command.

show wireless wps rogue client detailed *client-mac*

Syntax Description

client-mac	MAC address of the rogue client.

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

None.

This example shows how to display the detailed information for a specific rogue client:

```
Device# show wireless wps rogue client detail  0024.d7f1.2558
Rogue BSSID                       : 64d8.146f.379f
Rogue Radio Type                  : 802.11n - 5GHz
State                             : Alert
First Time Rogue was Reported     : Wed Aug  7 12:51:43 2013
Last Time Rogue was Reported      : Wed Aug  7 12:51:43 2013
Reported by
  AP 2
    MAC Address                   : 3cce.7309.0370
    Name                          : AP3502-talwar-ccie
    Radio Type                    : 802.11a
    RSSI                          : -42 dBm
    SNR                           : 47 dB
    Channel                       : 52
    Last reported by this AP      : Wed Aug  7 12:51:43 2013
```

show wireless wps rogue ap detailed

To view the detailed information of a rogue access point, use **show wireless wps rogue ap detailed** *mac-address* command.

show wireless wps rogue ap detailed *0008.30a7.7797*

Syntax Description

mac-address The MAC address of the rogue access point.

Note
If a rogue access point uses dot11n on 2.4GHz, the command output displays the **radio type** as **dot11g , dot11n - 2.4 GHz**.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Fuji 16.7.x	This command was introduced.

Example

This example shows how to display the detailed information about a rogue access point:

```
Device# wireless wps rogue ap detailed 0008.30a7.7797
Rogue Event history

Rogue BSSID                          : 0008.30a7.7797
Is Rogue on Wired Network            : No
Classification                       : Unclassified
Manually Contained                   : Yes
State                                : Contained Pending
Containment Level                    : 1
Number of Containing APs             : 0
First Time Rogue was Reported        : 03/08/2017 17:41:55
Last Time Rogue was Reported         : 03/08/2017 21:48:34

Number of clients                    : 0

Reported By
  AP Name : JEWLC-AA
    MAC Address                      : 00d7.8f4e.7240
    Detecting slot ID                : 0
    Radio Type                       : dot11g , dot11n - 2.4 GHz
    SSID                             : psk
    Channel                          : 5
    Channel Width                    : 20 MHz
    RSSI                             : -128 dBm
    SNR                              : 0 dB
    Encryption                       : Enabled
    ShortPreamble                    : Disabled
```

```
WPA Support                          : Not Friendly
Last reported by this AP             : 03/08/2017 21:48:34
```

show wireless wps rogue client summary

To display summary of WPS rogue clients, use the **show wireless wps rogue client summary** command.

show wireless wps rogue client summary

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

Usage Guidelines

Example

The following displays the output of the **show wireless wps rogue client summary** command:

```
Device# show wireless wps rogue client summary
Validate rogue clients against AAA  : Disabled
Validate rogue clients against MSE  : Enabled
Number of rogue clients detected : 0
```



INDEX

[no] ap remote-lan shutdown command 192

A

aaa accounting update periodic interval-in-minutes 15
aaa attribute list 16
aaa authentication login command 18
aaa authorization credential download default command 23
aaa group server ldap command 25
aaa group server radius command 26
aaa local authentication default authorization 27
aaa-policy 35
aaa-realm enable 36
access-list 38
access-list acl-ace-limit 40
accounting-list command 41
acl-policy 42
allow at-least 5 at-most 10 47
ap auth-list ap-policy 53
ap capwap retransmit 54
ap capwap timers 55
ap cdp 219
ap country 57
ap dot11 80
ap dot11 24ghz cleanair command 58–59
ap dot11 24ghz dot11g 61
ap dot11 24ghz rate 62
ap dot11 24ghz rrm 66
ap dot11 24ghz rrm coverage command 110
ap dot11 24ghz rrm tpc command 118
ap dot11 24ghz rx-sop threshold 67
ap dot11 24ghz shutdown 68
ap dot11 5ghz channelswitch quiet 69
ap dot11 5ghz cleanair 70
ap dot11 5ghz cleanair command 71
ap dot11 5ghz power-constraint 72
ap dot11 5ghz rate 73
ap dot11 5ghz rrm channel device command 75
ap dot11 5ghz rrm command 101
ap dot11 5ghz rrm txpower command 119–120
ap dot11 5ghz rx-sop threshold 77
ap dot11 5ghz shutdown 78
ap dot11 5ghz smart-dfs 79
ap dot11 beaconperiod 81
ap dot11 cac media-stream 82
ap dot11 cac voice 86
ap dot11 cleanair 89
ap dot11 cleanair device 90
ap dot11 dot11n 91
ap dot11 dtpc 94
ap dot11 dual-band cleanair 142
ap dot11 edcs-parameters 96
ap dot11 multimedia 85
ap dot11 rrm channel cleanair-event 105
ap dot11 rrm channel command 64–65, 74, 104
ap dot11 rrm channel dca 106
ap dot11 rrm group-member 112
ap dot11 rrm group-mode 113
ap dot11 rrm logging 114
ap dot11 rrm monitor 116
ap dot11 rrm ndp-type 117
ap filter 121
ap fra 122
ap name 167–170, 178
ap name clear-personal-ssid 127
ap name country 129
ap name crash-file 130
ap name dot11 rrm profile 144
ap name image 146
ap name led 154
ap name location 156
ap name mesh block-child 165
ap name mesh daisy-chaining 166
ap name mesh security psk provisioning delete 171
ap name monitor-mode dot11b 173
ap name name 174
ap name priority 175
ap name reset 176
ap name reset-button 177
ap name shutdown 183
ap name slot 179
ap name static-ip 182
ap name-regex 189
ap profile 190
ap remote-lan profile-name command 191
ap remote-lan-policy policy-name command 193
ap tag-source-priority 197
ap tag-sources revalidate 198
ap upgrade staggered 195
assisted-roaming command 200

attribute type 201
avg-packet-size packetsize 202

C

captive-portal-bypass command 210
capwap backup 213
chassis ha-interface 225
class command 229
class-map command 232
classify 231
clear platform condition all 238
client association limit command 243
client-l2-vnid 246
commands 600
    configuration 600
        username 600
convergence 249
custom-page login device 267

D

default command 268
description command 271
destination command 272
device-tracking binding vlan 274
dhcp-tlv-caching command 275
dnscrypt command 276
dot11 5ghz reporting-interval 280

E

eap profile 285

F

fallback-radio-shut 291
flex 292

I

idle-timeout 313
inactive-timeout command 315
interface vlan command 328
ip access-group command 329
ip access-list extended 330
ip domain-name 340
ip flow-export destination command 341
ip verify source command 363
ipv4 dhcp 365
ipv4 flow monitor 366
ipv4 flow monitor output 367
ipv6 flow monitor input 368
ipv6 flow monitor output 369
ipv6 nd managed-config-flag command 382
ipv6 nd ra throttler attach-policy 384
ipv6 traffic-filter command 387

L

local-auth ap eap-fast 415
local-site 416
location notify-threshold command 418

M

mac-filtering 422
match (access-map configuration) command 426, 440
match (class-map configuration) command 442
match any 430
match non-client-nrt command 432
match protocol command 433
match user-role 438
match wlan user-priority command 445
max-bandwidth 446
method fast 452
mgmtuser username 453

N

nas-id option2 481
network 482
nmsp cloud-services enable 484
nmsp cloud-services http-proxy 485
nmsp cloud-services server token 486
nmsp cloud-services server url 487
nmsp notification interval command 488

O

option command 493

P

parameter-map type subscriber attribute-to-service 495
peer-blocking command 499
police command 502
policy 501
policy-map command 505, 507
port 509
priority priority-value 510

Q

qos video 512

R

radius server command 513

range 519
record wireless avc basic 520
redirect 521
redirect portal 522
remote-lan command 523
rrc-evaluation 527

S

security 528
security dot1x authentication-list 529
security static-wep-key 534
security web-auth command 535
service-policy qos 542
service-template command 543
session-timeout command 546
set command 547
set platform software trace 921
show ap 783
show ap auth-list 711
show ap config general 715
show ap crash-file 718
show ap dot11 733
show ap dot11 24 ghz cleanair air-quality 731–732
show ap dot11 24ghz cleanair device type command 726
show ap dot11 24ghz command 725
show ap dot11 24ghz SI config 727
show ap dot11 24ghz SI device type 728
show ap dot11 5ghz 719, 729
show ap dot11 cleanair summary 735
show ap environment 737
show ap filter all 739
show ap filters active 738
show ap fra 740
show ap gps location 741
show ap link-encryption 744
show ap master list 748
show ap multicast mom 749
show ap name 754, 758, 761–767
show ap name auto-rf 750
show ap name config 755
show ap name dot11 759
show ap name wlan 774
show ap profile 777
show ap summary 779
show ap tag sources 780
show arp 786
show arp summary 787
show avc client command 789
show avc wlan command 790
show chassis 791
show flow exporter command 804
show flow record command 810
show interfaces command 811
show ip 820
show ldap attributes command 822
show ldap server command 823
show nmsp cloud-services statistics 907
show nmsp cloud-services summary 908
show nmsp command 906
show platform condition 915
show platform software system all 920
show platform software trace level 922
show platform software trace message 925
show policy-map command 933
show ssh 939
show tech-support wireless command 942
show wireless band-select command 982
show wireless client 984
show wireless client mac-address 985
show wireless client mac-address command 987–988
show wireless client timers command 990
show wireless country command 991
show wireless detail command 994
show wireless dot11h 996
show wireless dtls connections command 997
show wireless exclusionlist 998
show wireless load-balancing command 999
show wireless pmk-cache command 1017
show wireless profile flex 1018
show wireless summary command 1029
show wireless urlfilter details command 1030
show wireless urlfilter summary command 1031
show wireless vlan details 1032
show wireless wgb mac-address 1033
show wireless wgb summary 1034
show wireless wps rogue ap command 1035
show wireless wps rogue client detailed command 1036

T

tag rf 576
tag site site-tag 577

U

udp-timeout command 583
umbrella-param-map command 584

V

violation 602

W

wgb broadcast-tagging 603
wgb vlan 604
whitelist acl command 605
wireless aaa policy 608–609
wireless broadcast vlan command 611

wireless client command 612
wireless client mac-address command 614
wireless country 622
wireless load-balancing command 625
wireless macro-micro steering probe-suppression 627
wireless macro-micro steering transition-threshold 626
wireless mesh alarm association count 631
wireless mesh alarm high-snr 632
wireless mesh alarm low-snr 633
wireless mesh alarm max-children map 634
wireless mesh alarm max-children rap 635
wireless mesh alarm max-hop 636
wireless mesh alarm parent-change count 637
wireless mesh backhaul bdomain-channels 638
wireless mesh backhaul rrm 639
wireless mesh cac 640
wireless mesh ethernet-bridging allow-bdpu 641
wireless mesh security psk provisioning 642
wireless mesh subset-channel-sync 643
wireless profile policy 655
wireless security dot1x command 659
wireless security web-auth retries command 666
wireless tag policy 667
wireless wps client-exclusion command 670
wireless wps rogue rule command 693
wireless-default radius server command 696
wlan wlan1 policy policy1 697