

Check OpenRoaming Activation

• Check OpenRoaming Activation, on page 1

Check OpenRoaming Activation

After configuring the controller-based network or Meraki network, confirm activation before client testing.

Procedure

Step 1 In Cisco Spaces, check the OpenRoaming activation status on the **OpenRoaming** dashboard.

Step 2 For Catalyst 9800 and AireOS deployments, confirm that the hotspot-enabled connector remains **Running** and that the controller remains associated with the OpenRoaming profile.

Step 3 For Cisco Meraki deployments, confirm that pilot clients appear under **Network-wide** > **Clients** in Meraki Dashboard after testing.

Step 4 For Cisco Meraki deployments, verify that Cisco Spaces API changes were pushed to Meraki by reviewing **Organization** > **Monitor** > **Change Log**.

Check OpenRoaming Activation