

Compatibility

• Cross-Version Firmware Support, on page 1

Cross-Version Firmware Support

Note The three-part version number format, such as 4.3(6) or 6.0(1), represents a general version series. For example, 4.3(6) indicates all firmware versions that start with 4.3(6), encompassing detailed subversions such as 4.3(6.260058) and 4.3(6.260054). Similarly, 6.0(1) indicates all firmware versions that start with 6.0(1), encompassing detailed subversions such as 6.0(1.260003) and 6.0(1.250127). For detailed information about specific firmware versions and their equivalencies across Cisco Intersight, Cisco Integrated Management Controller (Cisco IMC), and Cisco UCS Manager, see the Cisco UCS Equivalency Matrix.

XE-Series Server Firmware Version	eCMC Infrastructure Firmware Version	
	6.0(1)	**6.0(2)**
6.0(2)	Yes	Yes
6.0(1)	Yes	Yes

X-Series Server Firmware Version	Infrastructure Firmware Version										
	4.1(3)	**4.2(1)**	**4.2(2)**	**4.2(3)**	**4.3(2)**	**4.3(3)**	**4.3(4)**	**4.3(5)**	**4.3(6)**	**6.0(1)**	**6.0(2)**
6.0(2)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
6.0(1)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.4(0)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.3(0)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.2(2)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.2(1)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

5.2(0)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.1(1)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.1(0)	N/A	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.0(4)	N/A	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.0(2)	N/A	Yes	Yes	Yes	No	No	No	No	No	No	No
5.0(1)	N/A	Yes	Yes	Yes	No	No	No	No	No	No	No

C-Series Server Firmware Version	**Infrastructure Firmware Version**										
	4.1(3)	**4.2(1)**	**4.2(2)**	**4.2(3)**	**4.3(2)**	**4.3(3)**	**4.3(4)**	**4.3(5)**	**4.3(6)**	**6.0(1)**	**6.0(2)**
6.0(2)	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
6.0(1)	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(6)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(5)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(4)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(3)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(2)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(1)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.2(3)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.2(2)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No
4.2(1)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No
4.1(3)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No

B-Series Server Firmware Version	**Infrastructure Firmware Version**										
	4.1(3)	**4.2(1)**	**4.2(2)**	**4.2(3)**	**4.3(2)**	**4.3(3)**	**4.3(4)**	**4.3(5)**	**4.3(6)**	**6.0(1)**	**6.0(2)**
6.0(2)	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
6.0(1)	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.4(0)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.3(0)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.2(2)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

5.2(1)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.2(0)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
5.1(0)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(3)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.3(2)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.2(3)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4.2(2)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No
4.2(1)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No
4.1(3)	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No