

# show gmb

This chapter includes the **show gmb** command output tables.


- show gmb statistics, on page 1


# show gmb statistics

***Table 1: show gmb statistics Command Output Descriptions***

| Field | Description |
|---|---|
| MBMS Context Stats | |
| Total Current | Total number of MBMS contexts currently in active status on Gmb interface. |
| Total Setup | Total number of MBMS contexts are in setup status on Gmb interface. |
| Total Released | Total number of MBMS contexts release on Gmb interface. |
| Total Denied | Total number of MBMS contexts requests denied on Gmb interface. |
| MBMS UE | Total number of UEs in active/setup status or released/denied on this Gmb interface for MBMS service. |
| MBMS Mcast Bearer | Total number of multicast bearers in active/setup status or released/denied on this Gmb interface for MBMS service. |
| MBMS Bcast Bearer | Total number of broadcast bearers in active/setup status or released/denied on this Gmb interface for MBMS service. |
| MBMS UE Context Management Stats | |
| MBMS UE Auth | Total number of UE Auth Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of UE Auth Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of UE Auth Request messages received and denied on this Gmb interface for MBMS service. |

| Field | Description |
|---|---|
| MBMS UE Update | Total number of UE Update Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of UE Update Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of UE Update Request messages received and denied on this Gmb interface for MBMS service. |
| MBMS UE Delete Tx | Total number of UE Delete Request messages transmitted on this Gmb interface for MBMS service. |
| Accepted | Total number of UE Delete Request messages transmitted and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of UE Delete Request messages transmitted and denied on this Gmb interface for MBMS service. |
| MBMS UE Delete Rx | Total number of UE Delete Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of UE Delete Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of UE Delete Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of UE Delete Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Bearer (Multicast) Context Management Stats | |
| MBMS Bearer Reg | Total number of Multicast Bearer Context Register request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Multicast Bearer Context Register request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Bearer Context Register request messages received and denied on this Gmb interface for MBMS service. |
| MBMS Bearer Dereg TX | Total number of Multicast Bearer Context Dereg Request messages transmitted on this Gmb interface for MBMS service. |
| Accepted | Total number of Multicast Bearer Context Dereg Request messages transmitted and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Bearer Context Dereg Request messages transmitted and denied on this Gmb interface for MBMS service. |
| MBMS Bearer Dereg RX | Total number of Multicast Bearer Context Dereg messages received on this Gmb interface for MBMS service. |

| Field | Description |
|---|---|
| Accepted | Total number of Multicast Bearer Context Dereg Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Bearer Context Dereg Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Multicast Bearer Context Dereg Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Mcast Sess Start | Total number of Multicast Session Start Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Multicast Session Start Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Session Start Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Multicast Session Start Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Mcast Sess Stop | Total number of Multicast Session Stop Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Multicast Session Stop Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Session Stop Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Multicast Session Stop Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Mcast Sess Update | Total number of Multicast Session Update Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Multicast Session Update Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Multicast Session Update Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Multicast Session Update Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Bearer (Broadcast) Context Management Stats | |
| MBMS Bcast Sess Start | Total number of Broadcast Session Start Request messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Broadcast Session Start Request messages received and accepted on this Gmb interface for MBMS service. |

| Field | Description |
|---|---|
| Denied | Total number of Broadcast Session Start Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Broadcast Session Start Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Bcast Sess Stop | Total number of Broadcast Session Stop messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Broadcast Session Stop Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Broadcast Session Stop Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Broadcast Session Stop Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Bcast Sess Update | Total number of Broadcast Session Update messages received on this Gmb interface for MBMS service. |
| Accepted | Total number of Broadcast Session Update Request messages received and accepted on this Gmb interface for MBMS service. |
| Denied | Total number of Broadcast Session Update Request messages received and denied on this Gmb interface for MBMS service. |
| Discarded | Total number of Broadcast Session Update Request messages received but discarded on this Gmb interface for MBMS service. |
| MBMS Bearer (Unknown Service Type) Stats | |
| MBMS Unknown Sess Start denied | Total number of unknown type of Session Start messages received and denied on this Gmb interface for MBMS service. |
| MBMS Unknown Sess Stop denied | Total number of unknown type of Session Stop messages received and denied on this Gmb interface for MBMS service. |
| MBMS Unknown Sess Update denied | Total number of unknown type of Session Update messages received and denied on this Gmb interface for MBMS service. |